# P14203

# [6188]-S-189 B.E. (E & TC) (Insem)

### RADIATION AND MICROWAVE THEORY

# $(2019\ Pattern)\ (Semester-VII)\ (404181)$

# **Solution/Scheme of Marking**

Que. No.			
Q1.	a)	Derive the fundamental equation for free space propagation.	[04]
		For fundamental equation for free space propagation or transmission, first of all assume average power ( $W_T$ ) radiated equally in all directions (Isotropically). Then assume that the isotropic radiator is kept in a free space (homogeneous, non-absorbing medium of unity dielectric constant). When this radiations spread spherically then at a distance (r) from the source the power density (power per unit area) is given by $P_r = \frac{W_T}{4\pi d^2} \ (W/m^2) \qquad \ (1)$	
		<ul> <li>where, 4πd<sup>4</sup> represents surface area of sphere of radius (d) centered at the source.</li> <li>As all antennas have directional properties i.e. they radiate more power in one direction and less in the other direction, the directivity gain is defined as "the ratio of actual power density along the main axis of the radiation of antenna to that which would be produced by isotropic antenna at same</li> </ul>	
		distance fed with the same input power".	
8	*	Thus, $G_T = \frac{P_{D(test antenna)}}{P_{r(Isotropic antenna)}}$ (2)	-Im
		Hence, $P_D = G_T \cdot P_r = \frac{G_T W_T}{4\pi d^2} \dots (3)$	
		<ul> <li>Now, assume that the receiving antenna is positioned so as to collect the maximum power. The effective aperture area (A<sub>e</sub>) of receiving antenna receives a power (W<sub>R</sub>) so that</li> </ul>	
		$W_R = P_D \cdot Ae = \frac{G_T W_T A_e}{4\pi d^2} \qquad (4)$	-am
		This is known as friis transmission equation.	:
	77	But for any antenna maximum directivity gain (G) and effective aperture area (Ae) is related by	
	445	$G = \frac{4\pi}{\lambda^2} \cdot A_e$	
		or $\frac{A_e}{G} = \frac{\lambda^2}{4\pi} \qquad (5)$	-1m
		If G <sub>R</sub> is the maximum directivity gain of receiving antenna then	
		$A_{e} = G_{R} \frac{\lambda^{2}}{4\pi} \qquad \dots (6)$	i .
	E.	From equation (1.12) and (1.14) we have	-lm
		$\frac{W_R}{W_T} = \frac{G_T G_R}{4\pi d^2} \left(\frac{\lambda^2}{4\pi}\right) $ (Watts) (7)	


		Above equation (1.15) is the fundamental equation for the free space	
		propagation (or transmission). This equation is also called FRITS FREE	
		SPACE equation in S.I. unit for antenna in a loss-free medium.	
		In alternative form it is also given by :	
		$\frac{W_R}{W_T} = G_T G_R \left(\frac{\lambda}{4\pi d}\right)^2$	
		$W_T = G_T G_R \left( \frac{4\pi d}{4\pi d} \right)$	
		or $W_R = W_T \frac{G_T G_R}{(4\pi d)^2} \dots (8)$	
		$\left(\frac{4\pi d}{2}\right)^2$	
	1	where, $W_T$ : Radiated power (Watts).	
	1	W <sub>R</sub> : Received power (Watts).	
		G <sub>T</sub> : Maximum directivity gain of transmitting antenna.	
		G <sub>R</sub> : Maximum directivity gain of receiving antenna.	
	1	f	
	-	$\lambda$ : Wavelength (in meters) = $\frac{1}{c}$ .	
		d : Distance (meters).	
		a . Distance (meters).	2 10
	b)	The radiation resistance of an antenna is $72\Omega$ and loss resistance is $8\Omega$ .	[05]
	, D	Calculate directivity in db if power gain is 16.	[05]
	-		
		D=G/1.	
		$N = \frac{R^{7}/R^{7}+RL}{D} = \frac{7^{2}/7^{2}+8}{0.9} = 0.9 = 90.7.$ $D = \frac{16}{0.9} = 17.77.$	Im
		1 = K. / KITEL = /72/8	
			-Im
		D= 6/1= 10 = 17.77.	•
		00	
	2.7	D(d8) = 10.log10 D.  D = 10.log10 (17-77)	
		2001 2 (2010	Lam.
		0-1010dia (1777)	- 5.
		27 (0-0/10	
		to a marda	1
		D=12.497dB	
2012			
			di .
	(2)	Explain in details the radiation machanism of antonio with a vial 1	[06]
	c)	Explain in details the radiation mechanism of antenna with suitable	[06]
W 7	-	diagram.	
	-	Antenna is a device which converts electromagnetic wave into RF current or	
		vice-versa. Thus, antenna is called as a transducer. Antenna is a structure	
		associated with the region of transition between a guided wave and a free space wave, or vice-versa.	
		The basic principle of the antenna that radiation is produced by the	1
		accelerated (or decelerated) charge. The basic equation of the radiation can	
		be expressed as,	
	1		
		I DI DV	
		$\frac{L  dl}{dt} = Q \frac{dv}{dt} \qquad \dots (1.23)$	
		$\frac{L  dI}{dt} = Q \frac{dV}{dt} \qquad (1.23)$ where, L = Length of the current element, m	

 $\frac{dI}{dt}$  = Time changing current, A/s

Q = Charge, C

 $\frac{dv}{dt}$  = Time change of velocity, m/s<sup>2</sup>

- The time change of velocity which equals the acceleration of the charge.
  Therefore, from the equation which states that time changing current
  radiates and accelerated charge radiates. In steady-state harmonic
  variation, we generally consider current and in transient or pulse we
  generally consider charge.
- Therefore, we can say that radiation is perpendicular to the acceleration and the radiated power is proportional to the square of  $L \frac{dl}{dt}$  or  $Q \frac{dv}{dt}$ .
- Let us consider a two-wire transmission line connected with a transmitter
  as shown in Fig. 1.12. The energy is guided as a plane transverse
  electromagnetic mode wave with little loss along the uniform part of the
  line. The spacing between the wires is assumed to be a small fraction of
  wavelength and the transmission line further opens out in a tappered
  transition.
- At the tappered end, the wave tends to be radiated therefore, the opened outline act as an antenna which launches a free space wave. The current on the transmission line flow out on the antenna and the field associated with them keep on going.
- The transmitting antenna which is a region of transition from a guided wave on a transmission line to a free space wave and the receiving antenna is a region of transition from a space wave to a guided wave on a transmission line as shown in below Fig.
- It is seen that a resistance coupled from space to the antenna terminals is called as radiation resistance (R<sub>r</sub>). In the transmitting case, the radiated power is absorbed by objects at a distance trees, buildings, the ground, the sky and the other antenna.
- However, in receiving case, passive radiation from distant objects or active radiation from other antennas raises the apparent temperature of R<sub>r</sub>. Both the radiation resistance R<sub>r</sub> and its temperature T<sub>A</sub> are simple scalar quantities.



	12	Fig. (a) Transmitting Antenna, (b) Receiving Antenna	
_		OR	
Q2.	a)	Explain the following characteristics of antenna in detail: i. Radiation Pattern, ii. Efficiency	[04]
		The radiation pattern of the antenna consists of three-dimensional quantities involving variation of power which is proportional to the square of field as a function of spherical co-ordinates $\theta$ and $\phi$ as shown in below Fig. The pattern parameters are half power beamwidth and beamwidth between first nulls.	
		Half power beamwidth  Beamwidth between first nulls	
		Fig.: Power pattern of antenna	
		<ul> <li>Power pattern can be expressed in terms of the power per unit area [or Poynting vector P(θ, φ)]. The normalized power pattern is obtained by normalizing this power with respect to its maximum value, which is a function of angle and dimensionless number with a maximum value of unity.</li> </ul>	
		Normalized power pattern = $P_n(\theta, \phi)$	
		$= \frac{P(\theta, \phi)}{P(\theta, \phi)_{max}} $ (dimensionless) (1)	
		where, $P(\theta, \phi) = \frac{E_{\theta}^{2}(\theta, \phi) + E_{\phi}^{2}(\theta, \phi)}{\eta} \cdot r^{2}$ $P(\theta, \phi) = \text{Radiation intensity, W/m}^{2}$	
		$E_{\theta} (\theta, \phi) = \theta$ component of E, $V_{rms}/m$ $E_{\phi} (\theta, \phi) = \phi$ component of E, $V_{rms}/m$ $\eta = Characteristic impedance of space,$ $377 \Omega$	
		r = Distance from antenna to point of measurement, m	
	-	From equation (1.7), decibel level is given by, $dB = 10 \log_{10} P_n (\theta, \phi)$	
	b)	A communication link is to be established between two stations using half wavelength antenna for maximum directivity gain 1.64. The	[05]
		distance between transmitter and receiver is 100km and transmitter power is 1KW. Frequency of operation is 100MHz. What is the maximum power received by receiver.	

	Pr = 1x10 watts, T= 100km, CT=GR = 164.	- IM
-	N=C/F = 3/ 300/f(MHz) = 300 = 3m.	2
	PRIMAR) = PT CIT.GR/ (4AY) 2 - PrGTGRX (1AY)	-1m
	PRIMAN) = 1×103x (-1664) 2× 5 3/4 MX100×103 } 2.	-1m
		-12
	PR(max) = 24.2064 ×107	-1m
	PRIMAX) = 0.01534 Watts	
- 1	TRIMAN EU DIS	
 (c)	Explain the different types of antennas.	[06]
	Antenna can be divided into four basic types from their operating	
-	frequency. From this performance parameter i.e. frequency, we can	
	determine type of antenna  1. Electrically small antenna	
	2. Resonant antenna	
	3. Broadband antennas	
	4. Aperture antennas	
	1. Electrically Small Antenna	
	It has small wavelength. Its size is smaller than the wavelength. Its structure	
	is simple as shown in below Fig. Its properties are not sensitive to	
1	construction details. These small antennas are operating well at a single or selected narrow frequency bands.	
	Radiation pattern of small antennas is nearly omni-directional in horizontal	3
	plane. Gain of small antenna is low to moderate. It operates at narrow	
	bandwidth. Disadvantages of this small antennas are low input resistance	
	and high input reactance. These antennas are inefficient because of ohmic	
	losses on the structure.	
	(a) (b)	,
	Fig.: Electrically Small Antenna	
		1

These types of antenna has simple structure with good input impedance. Resonant antennas are popular at narrowband of frequencies applications. Its radiation pattern has a broad main beam and low or moderate gain.

2. Resonant Antenna:

 Resonant antennas are operate at a single or selected narrow frequency bands. The half wavelength dipole, microstrip patch, yagi are examples of resonant antennas as shown in below Fig.




Fig.: Resonant antennas

#### 3. Broadband Antennas:

- These antennas are operated over a wide range of frequencies. A
  broadband antenna performance can be measured with parameters like
  pattern, gain and impedance. These antennas are characterized by an active
  region, where most of the power is radiated. The broadband antenna which
  has circular geometry as an active region produces circular polarization.
- A broadband antenna made-up of linear elements has an active regions
  where these elements are about a half wavelength produces linearly
  polarized radiation. A broadband antenna has low to moderate gain due to
  their radiation pattern particular at direction. It has wide bandwidth.
  Example of broadband antennas are spiral and log periodic dipole array as
  shown in below Fig.





Fig.: Broadband antenna

### 4. Aperture Antennas:

- Aperture antennas have opening called aperture due to this structure its propagate electromagnetic wave in space. The sizes of the aperture is several wavelength long in one or more direction.
- Example of aperture antenna is horn antenna, its structure is looks like funnel, directing the waves into the connecting transmission line such as waveguide.
- The radiation pattern of aperture antenna has narrow main beam which
  result in high gain. The pattern will be narrow with increasing frequency for
  a fixed aperture size. Examples of aperture antennas are Horn antenna and
  reflector as shown in below Fig. These antennas has moderate bandwidth.



	(b) Fig.: Aperture antenna	
Q3. a	Give the comparison between co-axial cable and waveguide	[04]
	Waveguide 1. Waveguide transmits frequency above cut off frequency so acts as a high pass filter  2. It is one conductor transmission line.  3. Electric and magnetic field lines are confined through waveguide hence there is no power loss.  4. Waveguide does not support TEM wave  5. EM energy propagate through waveguide in the form of TE and TM mode  6. Power handling capability  1. Coaxial Cable transmits all frequencies hence acts as a all pass filter  2. It is a two-conductor transmission line.  3. Electric and magnetic field lines are confined to outer cable through inner conductor hence there is power loss.  4. TEM wave exist in the Coaxial Cable  5. EM energy propagate through coaxial cable in the form of TE and TM mode  6. Coaxial Cable is suitable	
b	of waveguide is better for low power transmission.	[05]
	Advantages of Microwave:  The important characteristic of microwaves frequencies are shorter wavelength and higher frequencies which prompts the various advantages as follows.  • Wide Bandwidth: In electromagnetic spectrum the microwave operates at higher frequency. Due to high frequency operation, wider bandwidth is realize that provides more information carrying capacity. Therefore more channels with more data bits can be sent which result in low cost operation.  • Improved Gain / Directive Properties: The radiated power and the gain/directivity of an antenna are inversely proportional to wavelength. Hence at high frequency, the resultant wavelength is very small which gives antenna gain/directivity very large. The high gain antenna produces narrow beam radiation pattern which results in narrow beam width.  • Low Power Requirement: Small wavelength provides narrow beam width and high gain/directivity which allows microwave energy to be concentrated in small area that, make low power requirement for	

- Small Antenna Size: The size of an antenna is proportional to the operating wavelength. At microwave frequency the wavelength is small which reduces the size of antenna.
- c) Explain the constructional details, advantages and applications of reentrant type of cavity resonator.

[06]

When one end of the waveguide is terminated in a shorting plate there will be reflections and hence standing waves as shown in Fig. 2.9. When another shorting plate is kept at a distance of "Multiple of  $\lambda_g/2$ " then the hollow space so formed can support a signal which bounces back and forth between the two shorting plates. This results in a resonance and hence hollow space is called cavity and hence resonator as "Cavity Resonator".




Fig.: Standing waves




Fig. 2.10: Rectangular cavity resonator




Fig. 2.11: Circular cavity resonator

- In microwave applications, the commonly used cavity resonators are :
  - > Rectangular cavity resonator.
  - Circular cavity resonator.
  - Re-entrant cavity resonator.
- Rectangular and circular cavity waveguides are shown in Fig. 2.10 and Fig.
   2.11 respectively. Just like a parallel resonator circuit, cavity resonator can resonate at only one particular frequency.

ree space so have a resonator. oth TE and
so have a resonator.
so have a resonator.
resonator.
No confirmation (1)
1.
- 40
1.0
) mode in [04]
2m
- /
- 2m
-
nes. [05]
n as shown
rison to W. node if it is
ire can be
citance can
(8)
**
given by
1

	,	
		$vp = \frac{1}{\sqrt{\text{m0e0er}}} = \frac{c}{\sqrt{\text{er}}} = \frac{1}{\sqrt{\text{LC}}}$
	-	Therefore, characteristic impedance can be written as
		$ZO = \sqrt{\frac{L}{C}} = \frac{\sqrt{LC}}{C} = \frac{1}{npC}$
		To determine shielded stripline capacitance, consider that the dielectric within
		the stripline is lossless and the thickness of the center conductor is zero. The
1		characteristic impedance can be written as
10		$ZO = \frac{30p}{\sqrt{er}} \frac{K(k)}{K(k')}$
	-	Where, K is the elliptic integral
		$k = \operatorname{sech}\left(\frac{pW}{2b}\right)$ $k' = \tanh\left(\frac{pW}{2b}\right)$
	. 4	Apply curve fit, we get
-		$ZO = \frac{30p}{\sqrt{er}} \frac{1}{\left(\frac{We}{b}\right) + 0.441}$
1		whore We is the effective width of the center conductor

where, We is the effective width of the center conductor

$$\frac{We}{b} = \begin{cases} \frac{W}{b} & \frac{W}{b} > 0.35 \\ \frac{W}{b} - \left(0.35 - \frac{W}{b}\right)^2 & \frac{W}{b} < 0.35 \end{cases}$$

In stripline design, characteristic impedance is We/b. Therefore, We can be written as

[06]

tten as 
$$\frac{W}{b} = \begin{cases} \frac{30p}{\sqrt{erZo}} - 0.441 & \sqrt{erZO} < 120 \\ 0.85 - \sqrt{1.041 - \frac{30p}{\sqrt{erZo}}} & \sqrt{erZO} > 120 \end{cases}$$

The attenuation constant in a stripline (with a center conductor of thickness t) occur due to conductor losses. It can be written as

$$\alpha c = \begin{cases} \frac{90RserZoA}{p(b-t)} & \sqrt{erZo} < 120\\ \frac{0.16RsB}{Z0b} & \sqrt{erZ0} > 120 \end{cases}$$

$$A = 1 + \frac{2W}{b-t} + \frac{1}{p} \frac{b+t}{b-t} \ln \left( \frac{2b-t}{t} \right)$$

$$B = 1 + \frac{b}{0.5W + 0.7t} \left( 0.5 + \frac{0.414t}{W} + \frac{1}{2p} \ln \frac{4pW}{t} \right)$$

Determine the cut off wavelength, guide wavelength, the group c) velocity and phase velocity in rectangular waveguide of breadth 10cms and having a 2.5GHz signal propagation in waveguide with dominant mode.

> X X