Serial Communication

CMPE364: Qatar University. Dr. Ryan Riley

Some information based on a lecture by Prabal Dutta at the University of Michigan and Bard, Erez, Janapa Reddi, Gerstlauer, Telang, Tiwari, Valvano, Yerraballi from the University of Texas

Discussion

Imagine I need to interface my microprocessor to a device that outputs an 8-bit number. How many pins do I need?

Intro to Serial Communication

- Serial communication allows us to transmit information using a smaller number of pins/wires.
 - Could be as few as one! (OneWire interface)
 - Frequently 2 or 3
- ▶ Imagine a 2 pin system...
 - ▶ Pin 1 for Clock
 - Pin 2 for Data
 - One device generates the clock and 1 bit is transmitted every clock cycle.

Pros and Cons

Pros

- Fewer pins
- Can handle MANY devices on those pins

Cons

- Clock generation/synchronization
- Slower than transmitting bits in parallel

Examples

- **USB**
 - Universal Serial Bus
- COM ports on your machine
 - These are beginning to die out
- ▶ SDCards
 - Use a serial interface
- Many more!

Serial Communication Between Chips

- ▶ The previous examples are for communicating with devices separate from your system.
- ▶ There are three main standards for serial communication between chips on the same board:
 - ▶ I²C Inter-Integrated Circuit
 - ▶ SPI Serial Peripheral Interface
 - UART Universal Asynchronous Receiver

I²C – Inter-Integrated Circuit

- Serial interface for chips on the same printed circuit board
- Requires two wires
- ▶ Invented by Phillips/NXP in the 1980s


I²C – Inter-Integrated Circuit

- Supports many devices on the same two wires
- Devices can be masters or slaves
- ▶ Every connected device needs a unique, 7-bit address

I²C – Inter-Integrated Circuit

- Maximum speed: 3.4 Mbps
- Minimum speed: None

I²C: Circuit Diagram



Source: http://en.wikipedia.org/wiki/I2C

Lines

SDA: Serial Data

SCL: Serial Clock

Two pullup resistors

Should be between 2K and 10K, depending on the speed you want to transmit

I²C: Common Usages


- Supports multiple masters and multiple slaves
- Most commonly used with one master (the uC) and one or more slaves (the other devices)

I²C: The Clock


- Doesn't operate like a normal clock
- By default, held high by the pull-up resistors
- During data transmission (by master OR slave) the master pulses the clock to produce the clock signal

I²C: Starting and Stopping an Operation

- Starting a transmission
 - Master pulls SDA low while SCL is high




- Stopping a transmission
 - Master pulls SDA high while SCL is high



I²C: Standard Write Operation

- Master sends start signal
- Master sends 7-bit device address
- Master sends 1-bit operation (write)
- 4. Slave sends ACK
- 5. Master sends memory address or command
- 6. Slave sends ACK
- Master sends 8-bits of data
- Slave sends ACK
- Master sends stop signal

I²C: Timing Diagram



From: http://www.nxp.com/documents/user_manual/UM10204.pdf

I²C: Standard Read Operation

- 1. Master sends start signal
- 2. Master sends 7-bit device address
- 3. Master sends 1-bit operation (read)
- 4. Slave sends ACK
- 5. Master pulses clock and slave sends 8-bits of data
- Master sends ACK
- 7. Master sends stop signal

I²C: Note on Read


- Notice that the memory address/command is not sent
 - ▶ The master can't send data after requesting a read operation!
- So, how can we communicate which memory address we want to read?
- Do a write and send the memory address, then do a read

I²C: Read Expanded

- Master sends start signal
- 2. Master sends 7-bit device address + W
- 3. Slave sends ACK
- 4. Master sends 8-bit memory address
- Slave sends ACK
- 6. Master sends start signal (again!)
- 7. Master sends 7-bit device address + R
- 8. Slaves sends ACK
- 9. Master pulses clock and slaves sends 8-bits of data
- 10. Master sends ACK
- 11. Master sends stop signal

I²C: Usage Details

Other than START and STOP, SDA should only be changed while SCL is low



From: http://www.nxp.com/documents/user manual/UM10204.pdf

I²C: Usage Details


- Data is always sent 8-bits at a time
- You can send multiple 8-bit values one after another

I²C: Usage Details

- Where do I get the device address?
 - From the device's data sheet
 - Some devices make it configurable via pins
- How do I know the proper memory addresses/command to send?
 - From the device's data sheet
- How do I know what clock rate to use?
 - From the device's data sheet. (Or, when in doubt, use a slow one like 100 KHz)
- Lesson: Read your device's data sheet!

I²C: Sample Psuedo Code

Device address is... 1001 000




I²C: mbed

https://developer.mbed.org/handbook/I2C

SPI: Serial Peripheral Interface

- From Motorola
- Operates in full-duplex mode
 - Data can be sent both directions at the same time
- Uses a master/slave model
- Supports multiple slaves

SPI: Simplified Diagram




SPI: Basic Operation

- Master controls clock
- ► Each clock cycle...
 - Master sends 1-bit to slave
 - Slave sends 1-bit to master
- ▶ This is full-duplex communication

SPI: Full-Duplex

- Data can be sent and received at the same time
- Typically done with a shift register



Source: https://en.wikipedia.org/wiki/Serial_Peripheral_Interface_Bus

SPI: mbed


https://developer.mbed.org/handbook/SPI

UART - Universal Asynchronous Receiver

One of the initial serial communication standards in computers

- ▶ In the previous two interfaces there was a common clock
 - UART has no common clock

UART Frame



- By default, the signal is high
 - Design choice taken from the telegraph
- Pulled low to "start"
- Send 8 bits
- Set high to "stop"

UART – Setting the speed

- With no common clock, how do you decide how fast to send the bits?
- Speeds are standardized
- Both sides need to be programmed to assume the same speed
- Common rates:
 - ▶ 1200 bps
 - > 2400 bps
 - ▶ 4800 bps
 - ...
 - ▶ 115,200 bps
 - ...
 - ▶ 460,800 bps

UART - mbed

https://developer.mbed.org/handbook/Serial