0.1 **Modelling aircraft take-off**

The set of ordinary differential equations that model the take-off run are written in the following form:

$$\begin{cases}
\dot{s} \\
\dot{V} \\
\dot{\gamma} \\
\dot{h}
\end{cases} = \begin{cases}
f_1(s, V, \gamma, h; \alpha) \\
f_2(s, V, \gamma, h; \alpha) \\
f_3(s, V, \gamma, h; \alpha) \\
f_4(s, V, \gamma, h; \alpha)
\end{cases} \text{ with } \begin{cases}
x_1 = s \\
x_2 = V \\
x_3 = \gamma \\
x_4 = h
\end{cases}$$
 and $u = \alpha$ (1)

or, more concisely:

$$\dot{\mathbf{x}} = f(\mathbf{x}, \mathbf{u}(t)) \tag{2}$$

The unknown $\mathbf{x} = [x_1, x_2, x_3, x_4]^T$ is the vector of state variables. The input u(t) is a given function of time, for $0 \le t \le t_{\text{final}}$, that corresponds to an assumed time history of the angle of attack during take-off.

The right-hand sides of system (1) are defined by the following functions:

$$f_1(\mathbf{x}, u) = x_2 \tag{3a}$$

$$f_2(\mathbf{x}, u) = \frac{g}{W} \begin{cases} T(x_2) - D(x_2, u) - \mu[W - L(x_2, u)] & \text{if } \mathcal{S}(x_2, u) < 1 \\ T(x_2) \cos u - D(x_2, u) - W \sin x_3 & \text{if } \mathcal{S}(x_2, u) \ge 1 \end{cases}$$
(3b)

$$f_{2}(\mathbf{x}, u) = \frac{g}{W} \begin{cases} T(x_{2}) - D(x_{2}, u) - \mu [W - L(x_{2}, u)] & \text{if } \mathcal{S}(x_{2}, u) < 1 \\ T(x_{2}) \cos u - D(x_{2}, u) - W \sin x_{3} & \text{if } \mathcal{S}(x_{2}, u) \ge 1 \end{cases}$$
(3b)
$$f_{3}(\mathbf{x}, u) = \frac{g}{W x_{2}} \begin{cases} 0 & \text{if } \mathcal{S}(x_{2}, u) < 1 \\ L(x_{2}, u) + T(x_{2}) \sin u - W \cos x_{3} & \text{if } \mathcal{S}(x_{2}, u) \ge 1 \end{cases}$$
(3c)

$$f_4(x, u) = x_2 \sin x_3 \tag{3d}$$

The thrust $T(x_2)$ is calculated by means of the interpolating function $T_{\text{tab}}(V_a)$ based on a table lookup algorithm — where $V_a = V + V_w$ is the airspeed and V_w is the wind speed (horizontal component, positive if opposite to the aircraft motion). The drag D and lift L, as functions of airspeed V_a and angle of attack, are given by the conventional formnulas

$$D(x_2, u) = \frac{1}{2} \rho \left(x_2 + V_w \cos x_3 \right)^2 S C_D(u) , \quad L(x_2, u) = \frac{1}{2} \rho \left(x_2 + V_w \cos x_3 \right)^2 S C_L(u)$$
(3e)

The switching function \mathcal{S} of aircraft velocity and angle of attack is defined as follows:

$$\mathcal{S}(x_2, u) = \frac{L(x_2, u)}{W \cos x_3}$$
 (3f)

The formulas (3) make the system (2) a closed set of ODEs. When the function u(t) is assigned and the system is associated to a set of initial conditions a well-posed initial value problem (IVP) is formed, which can be solved numerically.

The function u can be constructed by picking the time t_{Rot} when the rotation speed V_{rot} is

reached along the ground roll. Setting

$$u(t) = \begin{cases} \alpha_{\text{ground}} & \text{if } t < t_{\text{rot}} \\ \alpha(t) & \text{if } t \ge t_{\text{rot}} \end{cases}$$
 (4)

In Table 1 are reported the take-off characteristic speeds and their corresponding requirements as defined by FAR 25.

Table 1 Take-off speeds and FAR 25 requirements..

Speed	Description	Requirement
$V_{ m S}$	fuselage total length	_
$V_{ m MC}$	minimum control speed with one engine inoperative (OEI)	_
V_1	OEI decision speed	$\geq V_{ m mc}$
$V_{ m Rot}$	rotation speed	$> 1.05 V_{\rm MC}$
$V_{ m MU}$	minimum unstick speed for safe flight	$\geq V_{ m S}$
$V_{ m LO}$	lift-off speed	$> 1.10 V_{\rm MU}$
		$> 1.05 V_{MU} (OEI)$
V_2	take-off climb speed at 35 ft	$> 1.20 V_{\rm S}$
		$> 1.10 V_{\rm MC}$