



# **Engineering the Storm: Principles of Hydrology & Urban Water Management**


**From Watersheds to Hydrographs: Quantifying  
and Managing Runoff in the Built Environment.**



# The Fundamental Unit: The Watershed



A watershed is an area of land where all of the water that falls under it and drains off of it goes to a common outlet.




Water is in constant motion—evaporation, transpiration, precipitation, and runoff.



In a natural state, the cycle is balanced. In an engineered environment, we must calculate how much of that precipitation becomes 'Direct Runoff' versus how much is lost to infiltration and evaporation.

# The Conflict: Urbanization vs. Infiltration




"As we replace soil with concrete, we lose the earth's natural sponge. In New York City, for example, the land is more than 66% impervious. This shift requires precise engineering to handle the excess volume."

# Gray vs. Green: A Philosophy of Management

**Gray Infrastructure**

Single-purpose. Uses pipes to dispose of rainwater quickly.



**Green Infrastructure**

Multi-functional. Uses vegetation and soil to manage rainwater where it falls.

**Core Benefit:** By weaving natural processes into the built environment, we achieve stormwater management alongside flood mitigation and air quality improvement.

# Input Data: Quantifying Rainfall

Engineers characterize storms by three metrics: **Depth, Duration, and Frequency.**


PDS-based point precipitation frequency estimates (in inches)

Duration	1 Yr	2 Yr	5 Yr	10 Yr	25 Yr	50 Yr	100 Yr	200 Yr	500 Yr	1000 Yr
5-min	0.334	0.397	0.471	0.524	0.589	0.634	0.680	0.720	0.771	0.808
10-min	0.533	0.635	0.754	0.838	0.938	1.01	1.08	1.14	1.22	1.27
15-min	0.666	0.799	0.954	1.06	1.19	1.28	1.37	1.44	1.53	1.60
30-min	0.913	1.10	1.36	1.54	1.76	1.93	2.09	2.24	2.44	2.59
60-min	1.14	1.38	1.74	2.00	2.35	2.61	2.88	3.15	3.50	3.78
2-hr	1.39	1.70	2.15	2.51	3.00	3.40	3.81	4.24	4.84	5.32
3-hr	1.55	1.89	2.40	2.80	3.35	3.80	4.26	4.75	5.43	5.97
6-hr	1.99	2.41	3.06	3.59	4.34	4.97	5.65	6.38	7.43	8.30
12-hr	2.42	2.94	3.75	4.44	5.45	6.33	7.28	8.34	9.90	11.2
24-hr	2.76	3.34	4.28	5.08	6.29	7.34	8.51	9.81	11.8	13.4
2-day	3.21	3.89	4.96	5.86	7.18	8.31	9.53	10.9	12.8	14.5
3-day	3.40	4.11	5.23	6.16	7.50	8.64	9.86	11.2	13.1	14.7
4-day	3.59	4.34	5.50	6.45	7.83	8.97	10.2	11.5	13.4	15.0
7-day	4.22	5.07	6.30	7.31	8.76	9.97	11.3	12.6	14.6	16.2
10-day	4.81	5.74	7.03	8.09	9.57	10.8	12.1	13.4	15.3	16.9
20-day	6.49	7.71	9.19	10.4	12.0	13.2	14.4	15.7	17.4	18.7
30-day	8.09	9.56	11.2	12.4	14.0	15.2	16.4	17.6	19.1	20.2
45-day	10.3	12.1	14.0	15.4	17.2	18.5	19.8	21.0	22.6	23.7
60-day	12.3	14.5	16.5	18.1	20.0	21.4	22.7	23.9	25.4	26.4

**The Gold Standard:** NOAA Atlas 14 is the authoritative source for precipitation frequency estimates.

**Key Concept:** A "100-year storm" doesn't happen every 100 years; it has a 1% chance of occurring in any given year.

# The IDF Curve: Intensity-Duration-Frequency



**Key Insight:** Rainfall intensity is inversely proportional to duration. A 5-minute burst is far more intense than a 24-hour drizzle. This relationship dictates how we design pipes and basins.

# Effective Precipitation: What Actually Runs Off?

$$P_e = P - \text{Losses}$$

$P_e$  = Effective Precipitation  
(Runoff Depth)

$P$  = Total Rainfall

Interception, Depression Storage,  
Infiltration, Evaporation

## Method 1: The Rational Method

Used for peak discharge ( $Q_p$ ) in small areas.

## Method 2: The NRCS (SCS) Curve Number Method

Used for volume and flow in larger, complex watersheds.

# Method 1: The Rational Method

$$Q_p = C_i A$$

Diagram illustrating the Rational Method formula:


- Peak Discharge ( $cfs$ ):** Points to the variable  $Q_p$ .
- Runoff Coefficient (dimensionless):** Points to the variable  $C_i$ . Subtext: "surface impermeability".
- Rainfall Intensity (in/hr):** Points to the variable  $A$ .
- Drainage Area (acres):** Points to the variable  $A$ .

**Typical Runoff Coefficients**

Description of Area	Runoff Coefficient
Business: Downtown areas	0.70–0.95
Business: Neighborhood areas	0.50–0.70
Residential: Single-family areas	0.30–0.50
Residential: Multiunits, attached	0.60–0.75
Residential: Residential, suburban	0.25–0.40
Industrial: Light areas	0.50–0.80
Parks, cemeteries	0.10–0.25
Pavement: Asphalt or concrete	0.70–0.95
Roofs	0.75–0.95
Lawns, sandy soil: Flat, 2%	0.05–0.10
Lawns, sandy soil: Average, 2%–7%	0.10–0.15
Lawns, heavy soil: Flat, 2%	0.13–0.17
Source: ASCE (1992).	

# Critical Parameter: Time of Concentration ( $T_c$ )


**Definition:** The longest time required for a drop of water to travel from the most remote point of the watershed divide to the watershed outlet.



**Design Rule:** When determining rainfall intensity ( $i$ ), we set the storm duration equal to  $T_c$ .  $T_c$  represents the moment the entire basin contributes to the flow.

# Case Study: Rational Method in Action

## The Scenario



## The Calculation

### Step 1. Weighted C Calculation

$$\text{Composite } C = \frac{(0.9 \times 0.5) + (0.35 \times 11.5) + (0.25 \times 12)}{24} = 0.31$$

### Step 2: Determine Intensity ( $i$ )

From IDF Curve @ 30 min duration:

$$i = 3.7 \text{ in/hr}$$

### Step 3: Calculate Peak Discharge ( $Q_p$ )

$$Q_p = 0.31 \times 3.7 \times 24 = 27.5 \text{ cfs}$$

# Method 2: The NRCS (SCS) Curve Number Method

## Calculating Volume based on Soil and Land Use

Instead of a simple "C", we use a Curve Number (CN) derived from Land Use + Hydrologic Soil Group.

- Soil Group A: High infiltration (Sand)
- Soil Group D: Low infiltration (Clay)

Potential Maximum Retention:

$$S = 1000/CN - 10$$

Effective Runoff:

$$Pe = (P - 0.2S)^2 / (P + 0.8S)$$

	Runoff Curve Numbers				
	Soil Group				
	A	B	C	D	
Open space (lawns, parks, etc.)					
Poor condition	68	79	86	89	
Fair condition	49	69	79	84	
Good condition	39	61	74	80	
Residential districts by average lot size					
1/8 acre or less	77	85	90	92	
1/4 acre	61	75	83	87	
1/3 acre	57	72	81	86	
1/2 acre	54	70	80	85	
1 acre	51	68	79	84	
2 acres	46	65	77	82	

# Case Study: NRCS Method in Action

400-acre basin, Middlesex, NJ. Soil Group B. Rainfall (P) = 6.36 inches.

## Step 1: Calculate Weighted Curve Number

Based on mixed land use (Impervious, Wooded, Meadow, Residential),  
the weighted average CN is determined to be **61.7**.



## Step 2: Calculate Potential Retention (S)

$$S = \frac{1000}{61.7} - 10 = \mathbf{6.21 \text{ inches}}$$




## Step 3: Calculate Effective Runoff (Pe)

$$P_e = \frac{(6.36 - 0.2(6.21))^2}{6.36 + 0.8(6.21)} = \mathbf{2.31 \text{ inches}}$$

Result: Out of 6.36 inches of rain, the soil absorbs ~4 inches. The infrastructure must handle the remaining 2.31 inches of runoff.


# Visualizing the Storm: The Hydrograph



(Note: The runoff volume under post-urbanization conditions—area under the red curve should be larger than pre-urbanization conditions—area under the blue curve.)


# Hydrologic Routing: Managing the Flow

We use detention basins to flatten the hydrograph. This process is modeled using the “Level Pool Routing” method.



(Note: If no water is lost from the storage basin—e.g., through exfiltration—the outflow volume [area under the blue curve] should equal the inflow volume [area under the red curve].)

# Summary: The Hydrologic Design Cycle



Effective stormwater design is not just about moving water away—it's about restoring the natural balance to protect our communities and environment.