Qumulo Alerts Administrator Guide

Version 6.0.1



Copyright © 2023 Qumulo, Inc.

Table of Contents

Getting Started with Qumulo Alerts

How Qumulo Alerts Works	2
Supported Alarms and Alerts	4
Suported Language Locales	6
Installing and Configuring Qumulo Alerts	
Installing and Connecting Qumulo Alerts	8
Configuring Alarms and Alerts	
Configuring Qumulo Alerts Notifications	
Alarm and Alert Notifications to Administrators	
Default Quota Notifications	20
Quota Notifications to Administrators	22
Quota Notifications to Users	25
Configuring Qumulo Alerts Integrations	
Integration with an Email Server	28
Integration with IFTTT	30
Integration with SMS (ClickSend)	

i

Getting Started with Qumulo Alerts


How Qumulo Alerts Works with Qumulo Core

This section explains how Qumulo Alerts monitors alarms and alerts for a Qumulo Cluster.

How Qumulo Alerts Works

Qumulo Alerts is a Docker-based system that comprises multiple containers. The main container uses a series of *plugins* to collect *hardware alarms* and *software alerts* from Qumulo clusters.

In Qumulo Alerts, *producers* are Docker containers that take data from various sources, pass it through *the Exchange*, a processing queue, and finally give the data to *consumers*, defined users or user groups. In addition to processing data, the Exchange facilitates the transfers between the producers and consumers.



Both producers and consumers use plugins that help process alarms and alerts from a Qumulo cluster. A *plugin* is a mechanism that processes a single function, such as fan failure, disk failure, or node failure. Plugins help with granular control over the information that Qumulo Alerts collects and processes.

Working with the alerts CLI

The alerts CLI lets you configure Qumulo Alerts. For more information, use the --help flag.

Qumulo Alerts includes a CLI for the following operating systems:

- · Ubuntu 20 and 22
- · Red Hat Enterprise (RHEL) 8
- · macOS
- · Windows Server 2019 and Windows 10 and 11

Known Limitations of Qumulo Alerts

This section lists the currenly known limitations for Qumulo Alerts.

• Floating IP Addresses or Network Load Balancing (NLB): To prevent overloading any node in a Qumulo cluster, Qumulo Alerts plugins connect to all nodes in the cluster by using floating IP addresses or an NLB.



Qumulo Alerts can't function if neither IP addresses nor NLBs are configured.

• Error Logging: Qumulo Alerts generates a large number of error messages that can help you debug issues. However, currently, all logging remains within the Docker container and is therefore not accessible easily. For help with troubleshooting issues, contact the Qumulo Care team.

What Alarms and Alerts Qumulo Alerts Supports

This section lists the alarms and alerts that Qumulo Alerts collects and processes.

Alarms

The following alarms report hardware changes in a Qumulo cluster.

Plugin Name	Description
CPU	Temperature deviation
Disks	Failure, state change
Fans	Speed deviation, failure
Network	Link failure
Nodes	Addition, failure

Alerts

The following alerts report software changes and changes in environmental conditions for a Qumulo cluster.

Plugin Name	Description
AD	Joining or leaving an Active Directory domain
Audit	Auditing enabled or disabled
Capacity	Change in cluster capacity (configured percentage of the entire cluster)
Exports	NFS exports created, modified, or deleted
FTP	FTP enabled or disabled
Groups	Local groups added, modified, or deleted
Monitoring	Cloud-based monitoring enabled, disabled, or unreachable
Quotas	Quota notification (configured percentage for specified directories)
Restriper	Restriper started, stopped, or percentage complete

Plugin Name	Description
Shares	SMB shares added, modified, or deleted
Softquotas	Soft quota notification (configured percentage for specified directories)
Users	Local users added, modified, or deleted

Informational

The following informational notifications show performance and status information for a Qumulo cluster.

Plugin Name	Description
Metrics	Performance metrics (throughput, IOPS, and latency)
OSUpgrade	Qumulo Core upgrade

What Language Locales Qumulo Alerts Supports

This section lists the language locales that Qumulo Alerts supports for notifying users through email, IFTTT, and SMS (ClickSend).

Language Locales

The consumer processes for email (page 28), IFTTT (page 30), and SMS (ClickSend) (page 31) integrations translate messages into the recipient's native language.

Code	Description
de_AT	German (Austria)
de_CH	German (Switzerland)
de_DE	German (Germany)
en_GB	English (Great Britain)
en_US	English (USA)
es_ES	Spanish (Spain)
fr_BE	French (Belgium)
fr_CA	French (Canada)
fr_CH	French (Switzerland)
fr_FR	French (France)
hu_HU	Hungarian (Hungary)
it_CH	Italian (Switzerland)
it_IT	Italian (Italy)
ja_JP	Japanese (Japan)
ko_KR	Korean (Korea)
pl_PL	Polish (Poland)
sk_SK	Slovak (Slovakia)

Code	Description
tr_TR	Turkish (Turkey)
zh_TW	Traditional Chinese (Taiwan)

Converting Time Zones

Each message that the Exchange processes contains a timestamp encoded in UTC time by default. This timestamp must match the recipient's time zone. If you don't use the --timezone flag when you create a user by using the alerts CLI, Qumulo Alerts uses UTC time.

Each translated message that a user receives includes a time zone in the Continent/City format (for example, America/Los_Angeles). For more information, see List of TZ Database Time Zones.



UTC doesn't follow the Continent/City format.

Installing and Configuring Qumulo Alerts

Installing Qumulo Alerts and Connecting it to a Qumulo Cluster

This section explains how to install Qumulo Alerts and connect it to a Qumulo cluster.

Prerequisites

We recommend the following system requirements for Qumulo Alerts.

- 4-core processor
- · 16 GB memory
- · 2 TB disk space

Before you install Qumulo Alerts, make sure you have the following tools:

- Git (You can also browse the QumuloAlerts GitHub repository.)
- Docker
- · Docker Compose Plugin

A Important

Qumulo Alerts requires the Docker Compose Plugin to operate correctly.

Before you connect Qumulo Alerts to a Qumulo cluster, collect the information that can help you configure Qumulo Alerts to monitor your cluster.

- · Cluster Address: Use a fully qualified domain name (FQDN) rather than an IP address.
- Traffic Distribution: Will your Qumulo Alerts installation use a network load balancer or a floating IP address?
- Default Plugin Frequency: What should be the default frequency for plugin execution? (You can specify the frequency in minutes or seconds.)
- Alarm and Alert Types: Which alarms and alerts will Qumulo Alerts will collect from your Qumulo cluster?

Step 1: Clone the QumuloAlerts Repository

Navigate to the directory where you want Git to download files and run the following command.

git clone https://github.com/Qumulo/QumuloAlerts.git

Git creates a directory called **QumuloAlerts** and places the necessary files in it.

Step 2: Create a Local User for Qumulo Alerts

To be able to generate access tokens, you must create a local user for Qumulo Alerts.

- 1. Use SSH to log in to any node in your cluster.
- 2. To create a local user, use the auth_add_user command and specify a name and password.

```
qq auth_add_user --name QumuloAlerts --password <password>
```

3. You need the user ID that appears in the command output to create a role for Qumulo Alerts.

In the following example, the user ID is 1234.

```
{
   "can_change_password": true,
   "home_directory": null,
   "id": "1234",
   "name": "QumuloAlerts",
   "primary_group": "999",
   "sid": "S-1-5-21-1234567890-098765432-1234567890-1234",
   "uid": ""
}
```

Step 3: Create a Role for Qumulo Alerts

- 1. Log in to the Qumulo Core Web UI and then click Cluster > Role Management.
- 2. On the Role Management page, click Create Role.
- 3. On the Create Role page:
 - a. Enter QumuloAlerts.

A Important

Because Qumulo Alerts verifies that it has sufficient role permissions before starting, this name is required.

b. Enter a description, for example This account lets an administrator restrict the privileges of the QumuloAlerts user.

- 4. For Privileges, click all of the following:
 - · ACCESS_TOKENS_READ: View any access tokens present in the system
 - · AD_READ: Read Qumulo Active Directory Settings
 - · ANALYTICS_READ: Read cluster analytics
 - · AUDIT_READ: Read audit settings
 - · CHECKSUMMING_READ: View the status of checksumming
 - · CLUSTER_READ: View nodes, disks, protection status, and SSL certificate
 - · DNS_READ: Read DNS setting
 - · ENCRYPTION_READ: View the status of at rest encryption
 - · FS_ATTRIBUTES_READ: Read file system statistics
 - · FS_DELETE_TREE_READ: View the status of directory tree delete operations
 - FS_KEY_MANAGEMENT_READ: Read and list public keys for various FS security features
 - · FS_LOCK_READ: View NLM and SMB locks and waiters
 - FS_SETTINGS_READ: View file system permissions settings
 - FTP_READ: View FTP status and settings
 - IDENTITY_MAPPING_READ: Get AD/LDAP User Defined Mappings
 - · IDENTITY_READ: Use Qumulo's identity lookup and translation APIs
 - KERBEROS_KEYTAB_READ: View Kerberos keytab
 - KERBEROS_SETTINGS_READ: Read Kerberos settings
 - · LDAP_READ: View LDAP settings
 - · LOCAL_GROUP_READ: View local groups and members
 - · LOCAL_USER_READ: Get information about local users
 - · METRICS_READ: Get all metrics
 - NETWORK_IP_ALLOCATION_READ: View network IP address allocations
 - · NETWORK_READ: Read network status and settings
 - NFS_EXPORT_READ: Read network status and settings
 - NFS_SETTINGS_READ: Internal-Only: View NFS server settings
 - · QUOTA_READ: View all file system quotas

- · REBOOT_READ: View Reboot Status
- · RECONCILER_READ: View reconciler status and metrics
- REPLICATION_OBJECT_READ: View object store relationship settings and status
- · REPLICATION_SOURCE_READ: View source relationship settings and status
- · REPLICATION_TARGET_READ: View target relationship settings and status
- · ROLE_READ: View roles and assignments
- · S3_BUCKETS_READ: View all S3 buckets present in the system
- · S3_CREDENTIALS_READ: View any S3 access key present in the system
- · S3_SETTINGS_READ: View S3 server settings
- · S3_UPLOADS_READ: View all S3 uploads present in the system.
- · SAML_SETTINGS_READ: View SAML integration settings
- · SMB_FILE_HANDLE_READ: List open SMB file handles
- · SMB_SESSION_READ: List logged on SMB sessions
- · SMB_SHARE_READ: View configuration of SMB shares and SMB server settings
- SNAPSHOT_CALCULATE_USED_CAPACITY_READ: Recalculate capacity usage of snapshots
- · SNAPSHOT_DIFFERENCE_READ: View the changes between snapshots
- · SNAPSHOT_POLICY_READ: View snapshot policies and status
- SNAPSHOT_READ: List snapshots and view their status and cached capacity.
- · SUPPORT_READ: View support configuration and status
- · TENANT_READ: View any tenant information
- · TIME_READ: View time and time settings
- UNCONFIGURED_NODE_READ: List unconfigured Qumulo nodes
- · UPGRADE_READ: View upgrade configuration and status
- 5. Click Save.

Step 4: Assign the Qumulo Alerts Role to Your Local User

- 1. In the Web UI, click Cluster > Role Management.
- 2. On the Role Management page, in the QumuloAlerts section, click Add Member.

3. In the Add Member to Administrators dialog box, for Trustee, enter the local username you have created earlier (for example, QumuloAlerts) and then click Yes, Add Member.

Step 5: Create a Long-Lived Access Token

Use the auth_create_access_token command and specify the ID of the local user. For example:

```
qq auth_create_access_token auth_id:1234
```

The auth_create_access_token command returns a JSON response that contains the bearer token body and the access token ID, which you can use to manage the access token.

```
{
  "bearer_token": "access-v1:abAcde...==",
  "id": "12345678901234567890123"
}
```

A Important

As soon as you receive your bearer token, record it in a safe place. If you misplace the bearer token, you can't retrieve it at a later time. You must create a new access token.

For more information, see Using Qumulo Core Access Tokens in the Qumulo Administrator Guide.

Step 6: Start Qumulo Alerts

To start Qumulo Alerts, run the following command from the directory to which you cloned the QumuloAlerts repository.

```
./start-docker-qumulo-alerts.sh
```

Step 7: Configure Qumulo Alerts

- 1. Configure alarms and alerts (page 14).
- 2. Configure alarm and alert notifications (page 17).
- 3. Configure integration with an email server (page 28) or with SMS (ClickSend) (page 31).

Step 8: Stop Qumulo Alerts

To stop Qumulo Alerts, run the following command from the directory to which you cloned the 'QumuloAlerts' repository.

./stop-docker-qumulo-alerts.sh

Configuring Alarms and Alerts

This section explains how to configure Qumulo Alerts to generate alarms and alerts.

To Configure Qumulo Alerts to Collect Specific Data from a Qumulo Cluster

Use the ./alerts cluster_add command and specify the fully qualified domain name (FQDN) of your Qumulo cluster, your long-lived access token for the Qumulo REST API, and the plugins to include or exclude from monitoring. In the following example, we include Disks and Nodes.

```
./alerts cluster_add \
--name cluster.example.com \
--token 12345678901234567890 \
-pi Disks \
-pi Nodes
```

```
[{
  "frequency": 1,
  "id": 1,
  "name": "cluster.example.com",
  "nlb": false,
  "plugins": [{
    "category": "Alarms",
    "description": "Get Disk State Information",
    "frequency": null,
    "name": "Disks"
  },{
    "category": "Alarms",
    "description": "Get Cluster Node Failures",
    "frequency": null,
    "name": "Nodes"
  }],
  "port": 8000
}]
```

O Note

- For the --nlb flag, the false setting requires floating IP address configuration.
- To prevent spreading the load of a plugin's API requests across all nodes in a Qumulo cluster, each alarm or alert plugin that you configure communicates with your cluster by using either a network load balancer or floating IPs. You can configure *one*—but not both—of these communication methods.

To Configure Qumulo Alerts to Collect All Alerts for Specific Data from a Qumulo Cluster

Use the ./alerts cluster_add command and specify the fully qualified domain name (FQDN) of your Qumulo cluster, your long-lived access token for the Qumulo REST API, the plugins to include or exclude from monitoring, and the plugin category to include. In the following example, we include <code>Disks</code> and <code>Nodes</code>, and include the <code>Alerts</code> category.

```
./alerts cluster_add \
  --name cluster.example.com \
  --token 12345678901234567890 \
  -pi Disks \
  -pi Nodes \
  -pc Alerts
```

The following is example JSON output from the command. This example output is truncated.

```
[{
 "frequency": 1,
  "id": 1,
  "name": "cluster.example.com",
  "nlb": false,
  "plugins": [{
    "category": "Alarms",
    "description": "Get Disk State Information",
    "frequency": null,
    "name": "Disks"
 },{
    "category": "Alarms",
    "description": "Get Cluster Node Failures",
    "frequency": null,
    "name": "Nodes"
 },{
    "category": "Alerts",
    "description": "Get Active Directory State",
    "frequency": null,
    "name": "AD"
 },{
    "category": "Alerts",
    "description": "Get Audit Status",
    "frequency": null,
    "name": "Audit"
 },{
    "category": "Alerts",
    "description": "Get Cluster Volume Capacity",
    "frequency": null,
    "name": "Capacity"
 },
  . . .
  "port": 8000
}]
```

Configuring Qumulo Alerts Notifications

Configuring Alarm and Alert Notifications to an Administrative Account in Qumulo Alerts

This section explains how to configure Qumulo Alerts to send alarm and alert notifications from a Qumulo cluster to an administrative account.

You must first add the account as a Qumulo Alerts user, create a notification group and configure its notifications, and then add the user to the notification group.

Step 1: Add an Administrative Account as a Qumulo Alerts User

Use the ./alerts user_add command and specify the administrator's full name, username, password, email address, language, and time zone. For example:

```
./alerts user_add \
   --full_name "Jane Johnson" \
   --username jjohnson \
   --password MyPassword123 \
   --email jjohnson@example.com \
   --language en_US \
   --timezone "America/Los_Angeles"
```

Note

- For the --language flag, see What Language Locales Qumulo Alerts Supports (page 6). The consumer processes for email (page 28), IFTTT (page 30), and SMS (ClickSend) (page 31) integrations translate messages into the recipient's native language.
- For the --timezone flag, see Converting Time Zones (page 7).

```
[{
    "disabled": false,
    "email": "jjohnson@example.com",
    "full_name": "Jane Johnson",
    "id": 3,
    "ifttt_event": null,
    "language": "en_US",
    "phone": null,
    "timezone": "America/Los_Angeles",
    "username": "jjohnson"
}]
```

Step 2: Create and Configure a Notification Group

Use the ./alerts notification_group_add command and specify the notification group's name, description, and the events for which the notification group receives notifications. In the following example, the NotifyOnHardwareChange group receives notifications for all hardware state change events.

```
./alerts notification_group_add \
--name NotifyOnHardwareChange \
--description "Send a notification when any hardware changes state" \
--event NOTIFY_FANS \
--event NOTIFY_CPU \
--event NOTIFY_DISKS \
--event NOTIFY_NETWORK \
--event NOTIFY_NODES
```

The following is example JSON output from the command.

```
[{
   "description": "Send a notification when any hardware changes state",
   "id": 2,
   "name": "NotifyOnHardwareChange"
}]
```

Step 3: Add a Qumulo Alerts User to a Notification Group

Use the ./alerts notification_group_add_user command and specify the notification group name and the Qumulo Alerts user name to add to the notification group. For example:

```
./alerts notification_group_add_user \
   --name NotifyOnHardwareChange \
   --username jjohnson
```

```
[ {
  "description": "Notify when certain hardware changes state",
  "id": 2,
  "name": "NotifyOnHardwareChange",
  "users": [{
    "can_change_password": true,
    "disabled": false,
    "email": "jjohnson@example.com",
    "full name": "Jane Johnson",
    "id": 3,
    "ifttt_event": null,
    "language": "en_US",
    "phone": null,
    "timezone": "America/Los_Angeles",
    "username": "jjohnson"
  }]
}]
```

Configuring Default Quota Notifications in Qumulo Alerts

This section explains how to configure default quota notifications in Qumulo Alerts.

Qumulo Alerts lets an administrator configure notifications that inherit a template from one of the following default quotas.

- No-Path Quota: This quota type has no defined file system path. It is the most common quota type and it applies thresholds to every quota defined for a Qumulo cluster.
- Inherited-Path Quotas: This quota type lets an administrator specify a default path for every quota defined for a Qumulo cluster. Every quota created under the default path inherits its thresholds from this quota.

You can configure quota monitoring by using thresholds.

- For the --warning flag, the threshold must be lower than the thresholds of both the -error and --critical flags.
- For the --error flag, the threshold must be lower than the threshold of the --critical flag.
- For the --critical flag, the threshold must be greater than the thresholds of both the --warning and --error flags.

For more information about how quotas work, see Configuring Quota Notifications to an Administrative Account (page 22) and Configuring Quota Notifications to a User Account (page 25).

To List the Predefined No-Path Quota

Qumulo Alerts comes with a predefined no-path quota. To get information about this quota, use the ./alerts default_quota_list command.

```
[{
  "items": [{
    "admin_notification": true,
    "critical": 95,
    "error": 85,
    "id": 1,
    "quota_prefix": "",
    "user_mode": "owner",
    "user_notification": false,
    "warning": 75
  }],
  "page": 1,
  "pages": 1,
  "size": 50,
  "total": 1
}]
```

To Configure an Inherited-Path Quota

Use the ./alerts default_quota_add command and specify the default path and thresholds. For example:

```
./alerts default_quota_add \
--quota-prefix /Home \
--warning 80 \
--error 90 \
--critical 98
```

```
[{
    "admin_notification": true,
    "critical": 98,
    "error": 90,
    "id": 2,
    "quota_prefix": "/Home/",
    "user_mode": "owner",
    "user_notification": false,
    "warning": 80
}]
```

Configuring Quota Notifications to an Administrative Account in Qumulo Alerts

This section explains how to configure Qumulo Alerts to send quota notifications from a Qumulo cluster to an administrative account.

You can configure quota monitoring by using thresholds.

- For the --warning flag, the threshold must be lower than the thresholds of both the -error and --critical flags.
- For the --error flag, the threshold must be lower than the threshold of the --critical flag.
- For the --critical flag, the threshold must be greater than the thresholds of both the --warning and --error flags.

You can configure unattached quotas or attach them to a Qumulo cluster.

To Configure Quota Notifications with Two Thresholds

Use the ./alerts quota_add command and specify the quota path to monitor. The following example specifies the warning threshold and the error threshold and doesn't attach the quota to a Qumulo cluster.

```
./alerts quota_add \
  --quotapath /Reports/Sales \
  --warning 80 \
  --error 85
```

```
[{
    "admin_notification": true,
    "critical": 95,
    "error": 85,
    "id": 2,
    "quota_path": "/Reports/Sales/",
    "user_email": "",
    "user_mode": "direct",
    "user_notification": false,
    "warning": 80
}]
```

To Configure Quota Notifications with a Single Threshold

Use the ./alerts quota_add command and specify the quota path. The following example specifies the error threshold and attaches the quota to the fully qualified domain name (FQDN) of a Qumulo cluster.

```
./alerts quota_add \
   --quotapath /Reports/Marketing \
   --error 90 \
   --cluster-include cluster.example.com
```

Note

When you add a quota and attach it to a Qumulo cluster, the alerts CLI doesn't list the cluster.

The following is example JSON output from the command.

```
[{
    "admin_notification": true,
    "critical": 95,
    "error": 90,
    "id": 3,
    "quota_path": "/Movies/Dutch/",
    "user_email": "",
    "user_mode": "direct",
    "user_notification": false,
    "warning": 75
}]
```

To List All Defined Quotas and Attached Clusters

Use the ./alerts quota_list command.

The following is example JSON output from the command. In this example, the second quota is attached to the fully qualified domain name (FQDN) of a Qumulo cluster.

```
[{
  "items": [{
    "admin_notification": true,
    "clusters": [],
    "critical": 95,
    "error": 85,
    "id": 2,
    "quota_path": "/Reports/Sales/",
    "user email": "",
    "user_mode": "direct",
    "user notification": false,
    "warning": 80
  },{
    "admin_notification": true,
    "clusters": [{
      "frequency": 1,
      "name": "cluster.example.com",
      "nlb": false,
      "port": 8000
    }],
    "critical": 95,
    "error": 90,
    "id": 3,
    "quota_path": "/Reports/Marketing/",
    "user_email": "",
    "user mode": "direct",
    "user_notification": false,
    "warning": 75
  }],
  "page": 1,
  "pages": 1,
  "size": 50,
  "total": 2
}]
```

Configuring Quota Notifications to a User Account in Qumulo Alerts

This section explains how to configure Qumulo Alerts to send quota notifications from a Qumulo cluster to a user account.

Qumulo Alerts can notify an individual user's email address manually or use default quotas (page 20) to notify email addresses associated in Active Directory (AD) with the security identifier (SID) of the quota directory's owner automatically.

To Notify an Individual Email Address

Use the ./alerts quota_add command and specify the quota path, the email address to notify, the email address to notify, and the fully qualified domain name (FQDN) of your Qumulo cluster. For example:

```
./alerts quota_add \
    --quotapath /Reports/Marketing \
    --user-notification True \
    --user-mode direct \
    --user-email jjohnson@example.com \
    --cluster-include cluster.example.com
```

O Note

For the --user-email flag, you can specify a comma-delimited list of email addresses to notify, if you also specify --user-notification True --user-mode direct.

```
[{
    "admin_notification": true,
    "critical": 95,
    "error": 85,
    "id": 1,
    "quota_path": "/Reports/Marketing/",
    "user_email": "jjohnson@example.com",
    "user_mode": "direct",
    "user_notification": true,
    "warning": 75
}]
```

Notifying Directory Owners Automatically

To ue this method, you must first add an AD server to Qumulo Alerts and then configure the default quota to use AD lookup to retrieve users' email addresses.

Step 1: Connect Qumulo Alerts to an Active Directory Server

Use the ./alerts ad_server_add command and specify the AD server, AD login name, AD password, the search base for looking up users, and the fully qualified domain name (FQDN) of your Qumulo cluster. For example:

```
./alerts ad_server_add \
    --server-name "ad.example.com" \
    --login-name "example.com\LookupUser" \
    --password MyPassword123 \
    --search-base "CN=Users,DC=example,DC=com" \
    --cluster-include cluster.example.com
```

A Important

For maximum security, configure a specific AD user to issue lookup requests.

The following is example JSON output from the command.

```
[{
    "clusters": [{
        "frequency": 1,
        "name": "cluster.example.com",
        "nlb": false,
        "port": 8000
}],
    "id": 2,
    "login_name": "example.com\\LookupUser",
    "search_base": "CN=Users,DC=example,DC=com",
    "server_name": "ad.example.com"
}]
```

Step 2: Configure a Default Quota to use Active Directory Lookup

Use the ./alerts default_quota_update command, specify the default quota ID, and configure the quota to notify users. For example:

```
./alerts default_quota_update \
   --id 1 \
   --user-notification True \
   --admin-notification False
```

```
[{
    "admin_notification": false,
    "critical": 95,
    "error": 85,
    "quota_prefix": "",
    "user_mode": "owner",
    "user_notification": true,
    "warning": 75
}]
```

Configuring Qumulo Alerts Integrations

Configuring Qumulo Alerts Integration with an Email Server

This section explains how to configure Qumulo Alerts to work with an email server.

O Note

After May 2022, only organizations with access to the Google Admin Console can use SMTP relay. If your organization has this access, see Route outgoing SMTP relay messages through Google.

To Add a New Email Server to Qumulo Alerts

Use the ./alerts email_server_add and specify the sender's email address, recipient's email address, email server hostname and port, language, and time zone. For example:

```
./alerts email_server_add \
    --from-addr alerts@example.com \
    --to-addr name@example.com \
    --server mail.example.com \
    --port 25
    --language en_US
    --timezone "America/Los_Angeles"
```

O Note

- The --login, --password, and --security flags might be optional, depending on the type of SMTP email server that you use.
- For the --language flag, see What Language Locales Qumulo Alerts Supports (page 6). The consumer processes for email (page 28), IFTTT (page 30), and SMS (ClickSend) (page 31) integrations translate messages into the recipient's native language.
- For the --timezone flag, see Converting Time Zones (page 7).

```
[{
    "from_address": "alerts@example.com",
    "language": "en_US",
    "login": null,
    "password": null,
    "port": 25,
    "security": null,
    "server": "mail.example.com",
    "timezone": "America/Los_Angeles",
    "to_address": "name@example.com"
}]
```

To Test Integration with Your Email Server

```
Use the ./alerts email_server_test command.
```

A successful response returns the [{ "ok": true }] JSON output.

Configuring Qumulo Alerts Integration with IFTTT

This section explains how to configure Qumulo Alerts to work with IFTTT.

IFTTT (If This Then That) is a paid, third-party service that provides delivery of messages by using Webhooks integrations and events. For more information, see the IFTTT documentation.

To Integrate IFTTT with Qumulo Alerts

Use the ./alerts ifttt_server_add command and specify the IFTTT server token, language, and time zone. For example:

```
./alerts ifttt_server_add \
   --token abcABde12f3g4567CDE89 \
   --language en_US \
   --timezone "America/Phoenix"
```

O Note

- For the --language flag, see What Language Locales Qumulo Alerts Supports (page 6). The consumer processes for email (page 28), IFTTT (page 30), and SMS (ClickSend) (page 31) integrations translate messages into the recipient's native language.
- For the --timezone flag, see Converting Time Zones (page 7).

The following is example JSON output from the command.

```
[{
    "language": "en_US",
    "timezone": "America/Los_Angeles",
    "token": "abcABde12f3g4567CDE89"
}]
```

To Test Integration with IFTTT

```
Use the ./alerts ifttt_server_test command.
```

A successful response returns the [{ "ok": true }] JSON output.

Configuring Qumulo Alerts Integration with SMS (ClickSend)

This section explains how to configure Qumulo Alerts to work with SMS by using ClickSend.

ClickSend is a paid, third-party service that provides delivery of messages as SMS (and other formats). For more information, see How to get started with ClickSend in the ClickSend documentation.

▲ Important

To be able to send SMS in the U.S. and Canada, you must sign up for a dedicated toll-free number (TFN).

To Integrate ClickSend with Qumulo Alerts

Use the ./alerts clicksend_server_add command and specify the username, token, sender ID, and recipient's phone number.

```
./alerts clicksend_server_add \
--username name@example.com \
--token 12345678-ABCDEFGH-12345678-ABCDEFGH \
--senderid "+15551234567" \
--to-address "+15550987654"
```

O Note

- For the --username and --token flags, see API Credentials in the ClickSend documentation.
- The --senderid flag is mandatory for the U.S. and Canada. For more information, see Toll-Free Number (TFN) Verification in the ClickSend documentation.
- For the --language flag, see What Language Locales Qumulo Alerts Supports (page 6). The consumer processes for email (page 28), IFTTT (page 30), and SMS (ClickSend) (page 31) integrations translate messages into the recipient's native language.
- For the --timezone flag, see Converting Time Zones (page 7).

```
[{
    "language": "en_GB",
    "senderid": "+15551234567",
    "timezone": "UTC",
    "to_address": "+15550987654",
    "username": "name@example.com"
}]
```

To Test Integration with ClickSend

Use the ./alerts clicksend_server_test command.

O Note

For integration testing to complete successfully, the --to-address flag must be configured already.

A successful response returns the [{ "ok": true }] JSON output. In addition, the recipient's phone number receives a test message.