Computer Organization &

Architecture

Chapter 2 – Stacks & Subroutines

Zhang Yang 张杨 cszyang@scut.edu.cn Autumn 2021

Content of this lecture

- 2.6 Stacks
- 2.7 Subroutines

Stacks (1)

- A stack is a list of data elements, usually words, with the accessing restriction that elements can be added or removed at one end of the list only.
- The structure is sometimes referred to as a pushdown stack or last-in-first-out (LIFO) stack.
- Push
 - □ Place a new item on the stack.
- Pop
 - □ Remove the top item from the stack.
- In modern computers, a stack is implemented by using a portion of the main memory.
- Programmer can create a stack in the memory.
- There is often a special processor stack as well.

Stacks (2)

- Processor Stack
 - □ Processor has stack pointer (SP) register that points to top of the processor stack.
 - □ Assume a byte-addressable memory with a 32bit word length.
 - □ Push operation involves two instructions:

Subtract SP, SP, #4

Store R_{j} , (SP)

□ Pop operation also involves two instructions:

Load R_{j} , (SP)

Add SP, SP, #4

Stacks (3)

ProcessorStack (ctd.)




Figure 2.14 A stack of words in the memory.

Stacks (4)

Processor Stack (ctd.)




Figure 2.15 Effect of stack operations on the stack in Figure 2.14.

Subroutines (1)

- In a given program, a particular task may be executed many times using different data.
 - □ Examples: mathematical function, list sorting
- Implement task in one block of instructions.
 - ☐ This is called a subroutine.
- Rather than reproduce entire subroutine block in each part of program, use a subroutine call.
 - Special type of branch with Call instruction.

Subroutines (2)


- Branching to same block of instructions saves space in memory, but must branch back.
 - The subroutine must return to calling program after executing last instruction in subroutine.
 - □ This branch is done with a Return instruction.
- Subroutine Linkage
 - □ Subroutine can be called from different places.
 - □ How can return be done to correct place?
 - This is the issue of subroutine linkage.

Subroutines (3)

- Subroutine Linkage (ctd.)
 - During execution of Call instruction, PC updated to point to instruction after Call.
 - □ Save this address for Return instruction to use.
 - □ Simplest method: place address in link register.
 - □ Call instruction performs two operations:
 - Store updated PC contents in link register,
 - Then branch to target (subroutine) address.
 - □ Return just branches to address in link register.

Subroutines (4)

Subroutine Linkage (ctd.)






Figure 2.16 Subroutine linkage using a link register.

Subroutines (5)

- Subroutine Nesting & The Processor Stack
 - □ We can permit one subroutine to call another, which results in subroutine nesting.
 - □ Link register contents after first subroutine call are overwritten after second subroutine call.
 - ☐ First subroutine should save link register on the processor stack before second call.
 - □ After return from second subroutine, first subroutine restores link register.
 - □ Subroutine nesting can be carried out to any depth.
 - □ Return addresses are generated and used in a last-in– first-out order. This suggests that the return addresses associated with subroutine calls should be pushed onto the processor stack.