Firmware input sample format

Input data order:

The following serial data will be sent to firmware from software via serial communication as well in order to control the motor setup,

- 1. ESC inputs to control motor speeds
- 2. ESC calibration limits for safety purpose
- 3. No. of propeller blades used in current test in case required for RPM calculation

The input data to Arduino from software will be the following data in the corresponding order,

Parameter	Values to be sent	Datatype	Size	Sample data
No. of. Propeller blades	No. of propeller blades value set by user during powertrain setup in software	String	1	2
Minimum PWM value	Minimum ESC calibration value set by user during powertrain setup in software		1	1000
Maximum PWM value	Maximum ESC calibration value set by user during powertrain setup in software		1	2000
User input PWM to ESC	The latest PWM value (throttle value) set by user in the software for testing		1	1300

Table 3. Data order in which data will be sent to firmware

Note:

- Each data has to be delimited by ','
- Data has to be sent in the same order as in the table

An example of the data input:

2,1000,2000,1100