
EECS 370 Virtual Memory Basics



Announcements

- Lab
 - Assignment Due Wednesday
 - Pre-lab quiz Thursday
- P4 out
 - Check out simulator on website (not same as project... doesn't cache instrs)





<u>Poll:</u> What is the CPI increase over base (1) due to hazards?

Practice Problem: CPI with caches

The *blaster* application run on the LC2k with full data forwarding and all branches predicted not-taken has the following instruction frequencies:

45% R-type 20% Branches 15% Loads 20% Stores

In blaster, 40% of branches are taken and 50% of LWs are followed by an immediate use.

The I-cache has a miss rate of 3% and the D-cache has a miss rate of 6% (no overlapping of misses). On a miss, the main memory is accessed and has a latency of 100 ns. The clock frequency is 500 MHz.

Problem Solution

The *blaster* application run on the LC2k with full data forwarding and all branches predicted not-taken has the following instruction frequencies:

45% R-type 20% Branches

15% Loads 20% Stores

In blaster, 40% of branches are taken and 50% of LWs are followed by an immediate use.

The I-cache has a miss rate of 3% and the D-cache has a miss rate of 6% (no overlapping of misses). On a miss, the main memory is accessed and has a latency of 100 ns. The clock frequency is 500 MHz.

What is the CPI of *blaster* on the LC2k?

```
Stalls per cache miss = 100 ns / 2ns = 50 cycles (500 Mhz \rightarrow 2ns cycle time)

CPI = 1 + data hazard stalls + control hazard stalls + icache stalls + dcache stalls

CPI = 1 + 0.15*0.50*1 + 0.20*0.40*3 + 1*0.03*50 + 0.35*0.06*50
```




Agenda

- Motivation
- Virtual Memory Principles
- Page Tables
- Class Problem




Storage Hierarchy





Memory: Two Issues


- 1.We've been working with the abstraction that all programs have full, private access to memory
 - But in practice, multiple programs run at the same time!



What happens if two programs try to write to the same memory address??



Revisit real system view—multitasking





Memory: Two Issues

- 2.Even if only one program is running, modern computers have 48-64 bit address spaces!
 - No computer actually has 18 exabytes (18 billion GBs)
 - What if a computer tries to write to address 0xFFFF...FFFF
 - Should it just crash??



Memory: Two Issues

- Modern systems use the same solution for both problems: virtual memory
 - In a nutshell, each program thinks it has full, private access to memory (it can safely index any address from 0x0-0xFFF...FFFF)
 - Hardware and software transparently maps these addresses to distinct addresses in DRAM and in hard disk / SSD
 - Focus for the next 3 lectures



Agenda

- Motivation
- Virtual Memory Principles
- Page Tables
- Class Problem




Basics of Virtual Memory

- Any time you see the word <u>virtual</u> in computer science and architecture it means "using a level of indirection".
 - Examples?




• Virtual memory hardware changes the virtual address the programmer sees into the physical one the memory chips see.





Virtual Memory





How to Translate Addresses?

- Address Translation is not done entirely in hardware
- We'll get help in software via the operating system
- The operating system is a special set of programs
 - Always running (after the system boots)
 - Is in charge of **managing the hardware resources** for all other running programs
 - E.g. initializing memory for a starting program, managing the file system, choosing when a particular program gets to run...
 - ... and translating virtual addresses into physical addresses!
- OS handles address translation by maintaining a data structure in main memory: the page table



Virtual memory terminology

- Memory is divided into fixed-size chunks called Pages (e.g., 4KB for x86)
 - Size of physical page = size of virtual page
 - A virtual address consists of
 - A virtual page number
 - A page offset field (low order bits of the address)
 - Translating a virtual address into a physical address only requires translating the page numbers
 - The page offset will stay the same

Virtual address	Virtual page number	Page offset	
	31	11	0

Physical address

Physical page number Page offset

??



Page Table

- 0x0000
 0x1000

 0x6000
 0x1000

 0x1000
- Translate page numbers using page tables
- Contains address translation information, i.e. virtual page # → physical page #
- Each process has its own page table
 - Maintained by operating system (OS)
- Page tables themselves are kept in memory by OS, and OS knows the physical address of the page tables
 - No address translation is required by the OS for accessing the page tables


<u>Poll:</u> What is the cost of this scheme? (select all that apply)

- a) Uses up more memory
- o) Takes longer to do loads and stores
- c) Fewer addresses accessible by program
- d) None of the above



Why Pages?

- Why have the idea of "pages"? Why not just have a mapping for each individual address?
 - Equivalent to asking: "why not have pages of size 1 byte?"
 - Otherwise need a mapping entry for every single element of memory
 - The mapping data would take up as much space as the actual program data!
 - Also would screw up spatial locality of cache blocks (things contiguous in virtual memory wouldn't be contiguous in physical memory)






Agenda

- Motivation
- Virtual Memory Principles
- Page Tables
- Class Problem




Page table components





Page table components - Example

Virtual address = 0x000040F3



Physical address = 0x020C00F3




Virtual Memory Goals

- VM should provide the following 3 capabilities to the programs:
 - 1. Transparency
 - Don't need to know how other programs are using memory
 - 2. Protection
 - No program can access the data of any other program
 - 3. Programs not limited by DRAM capacity
 - Each program can have more data than DRAM size



1-2: How to achieve transparency & protection?





3. How to be not limited by DRAM capacity?

- Use disk as temporary space in case memory capacity is exhausted
 - This temporary space in disk is called swap-partition in Linux-based systems
 - For fun check swap space in a linux system by:

\$: top

```
1. ssh
                    1 running, 661 sleeping,
Tasks: 662 total,
                                               0 stopped,
                                                             Ø zombie
%Cpu(s): 0.1 us, 0.0 sy, 0.0 ni, 99.8 id, 0.0 wa, 0.0 hi, 0.0 si, 0.0 st
KiB Mem: 32704372 total, 10813444 used, 21890928 free,
                                                          1018840 buffers
KiB Swap: 35162108 total, 89248 used, 35072860 free.
                                                          7053764 cached Mem
                           VIRT
                                   RES
                                                 %CPU %MEM
                                                                TIME+ COMMAND
   PID USER
                 \mathsf{PR}
                     NΙ
                                          SHR S
                          25356
                                  3356
                                         2444 R
 60256 nehaaa
                 20
                                                  6.0
                                                              0:00.02 top
                          38424
                                         2780 S
                                                              1:56.96 init
     1 root
                 20
                                  9040
                                                  0.0
                                                       0.0
                                                              0:02.21 kthreadd
     2 root
                 20
                                            0 S
                                                  0.0
                                                       0.0
                 20
                                                              6:20.75 ksoftirad/0
     3 root
```




2. How to be not limited by DRAM capacity?

- We can mark a page table entry as "Invalid", indicating that the data for that page doesn't exist in main memory, but instead is located on the disk
- Looking up a page table entry that corresponds to disk is called a page fault




2. How to be not limited by DRAM capacity?





Page faults





How do we find it on disk?

- That is not a hardware problem! Go take EECS 482! ©
- This is the operating system's job. Most operating systems partition the disk into logical devices
 (C: , D: , /home, etc.)
- They also have a hidden partition to support the disk portion of virtual memory
 - Swap partition on UNIX machines
 - You then index into the correct page in the swap partition.



Agenda

- Motivation
- Virtual Memory Principles
- Page Tables
- Class Problem



Class Problem

- Given the following:
 - 4KB page size, physical memory of 16KB, page table stored in physical page 0 and can never be evicted, 20 bit, byte-addressable virtual address space.
 - The page table initially has virtual page 0 in physical page 1, virtual page 1 in physical page 2 and no valid data in other physical pages.
- Fill in the table on the next slide for each reference
 - Note: like caches we'll use LRU when we need to replace a page.



Class Problem (continued)

Virt addr	Virt page	Page fault?	Phys addr
0x00F0C			
0x01F0C			
0x20F0C			
0x00100			
0x00200			
0x30000			
0x01FFF			
0x00200			

4KB page size, physical memory of 16KB, page table stored in physical page 0 and can never be evicted, 20 bit, byte-addressable virtual address space.

The page table initially has virtual page 0 in physical page 1, virtual page 1 in physical page 2 and no valid data in other physical pages.

<u>Poll:</u> How many hex digits should the page number be?



Class Problem (continued)

Virt addr	Virt page	Page fault?	Phys addr
0x00F0C	0x0	N	0x1F0C
0x01F0C	0x1	N	0x2F0C
0x20F0C	0x20	Y (into 3)	0x3F0C
0x00100	0x0	N	0x1100
0x00200	0x0	N	0x1200
0x30000	0x30	Y (into 2)	0x2000
0x01FFF	0x1	Y (into 3)	0x3FFF
0x00200	0x0	N	0x1200

4KB page size, physical memory of 16KB, page table stored in physical page 0 and can never be evicted, 20 bit, byteaddressable virtual address space.

The page table initially has virtual page 0 in physical page 1, virtual page 1 in physical page 2 and no valid data in other physical pages.



Size of the page table

- How big is a page table entry?
 - For 32-bit virtual address:
 - If the machine can support $1GB = 2^{30}$ bytes of <u>physical</u> memory and we use pages of size $4KB = 2^{12}$,
 - then the physical page number is 30-12 = 18 bits.
 Plus another valid bit + other useful stuff (read only, dirty, etc.)
 - Let say about 3 bytes.
- How many entries in the page table?
 - 1 entry per virtual page
 - ARM virtual address is 32 bits 12 bit page offset = 20
 - Total number of virtual pages = 2^{20}
- Total size of page table = Number of virtual pages
 - * Size of each page table entry
 - $= 2^{20} \times 3$ bytes ~ 3 MB



Next time

- Improving Virtual Memory Design
 - Multi-level page-tables



Extra Slides




How can you organize the page table?

Single-level page table occupies continuous region in physical memory

Previous example always takes 3MB regardless of how much virtual

memory is used





How can you organize the page table?

2. Option 2: Use a multi-level page table

- 1st level page table (much smaller!) holds addresses 2nd level page tables
 - 2nd level page tables hold translation info, or 3rd level page tables if we wanna go deeper
 - Only allocate space for 2nd level page tables that are used

valid	PPN	
1	0x1	
1	0x2	
1	0x3	
Single	lovel: Tops of	
Single-level: Tons of wasted space!		

valid	2 nd level page table
1	0x1000

valid	PPN
1	0x1
1	0x2
1	0x3

Multi-Level Page Table

- Only allocate second (and later) page tables when needed
- Program starts: everything is invalid, only first level is allocated

valid	2 nd level page table
0	
0	
0	
0	

Multi-level: Size is proportional to amount of memory used

As we access more, second level page tables are allocated

valid	2 nd level page table	
1	0x1000	L
1	0x3500	


valid	PPN
1	0x1
1	0x6
1	0x2
1	0x1f

	valid	PPN
•	1	0x9a
	1	0x3
	0	
	1	0xff

Common case: most programs use small portion of virtual memory space



Hierarchical page table





Agenda


- Motivation for Multi-level Page Tables
- Example architecture
- Class Problem: 32bit Intel x86
- Class Problem: Multi-Level VM Design
- VM Miscellanea



Hierarchical page table – 32bit Intel x86

1 st level	offset 2 nd leve	l offset Page offs	virtual address
31	21	11	

- How many bits in the virtual 1st level offset field? 10
- 10 How many bits in the virtual 2nd level offset field?
- 12 How many bits in the page offset?
- $2^{10} = 1024$ How many entries in the 1st level page table?






Hierarchical page table – 32bit Intel x86


1 st level	offset 2 nd leve	l offset Page offs	virtual address
31	21	11	

- Let's say physical address size + overhead bits is 4 bytes per entry
- Total size of 1st level page table
 - 4 bytes * 1024 entries = 4 KB



Hierarchical page table

- How many entries in the 2nd level of the page table?
 - $2^{10} = 1024$
- How many bytes for each VPN in a 2nd level table?
 - Let's round up to 4 bytes





Hierarchical page table – 32bit Intel x86

	1 st level offset	2 nd level offset	Page offset	Virtual address
31		21	11	
 How many bits in the virtual 1st level offset field? 				10
 How many bits in the virtual 2nd level offset field? 				10
 How many bits in the page offset? 				12
 How many entries in the 1st level page table? 				2 ¹⁰ =1024
 How many bytes for each entry in the 1st level page table? 				4
 How many entries in the 2nd level of the page table? 				2 ¹⁰ =1024
 How many bytes for each entry in a 2nd level table? 				~4
 What is the total size of the page table? 				4K+n*4K
(here n is number of valid entries in the 1 st level page table)				

