




Data Communications and Networking

Fourth Edition

Forouzan

Chapter 10

Error Detection and Correction



Note

**Data can be corrupted
during transmission.**

**Some applications require that
errors be detected and corrected.**

10-1 INTRODUCTION

Let us first discuss some issues related, directly or indirectly, to error detection and correction.

Topics discussed in this section:

Types of Errors


Redundancy

Detection Versus Correction

Forward Error Correction Versus Retransmission

Coding


Modular Arithmetic




Note

In a single-bit error, only 1 bit in the data unit has changed.

Figure 10.1 Single-bit error







Note

A burst error means that 2 or more bits in the data unit have changed.

Figure 10.2 *Burst error of length 8*







Note

To detect or correct errors, we need to send extra (redundant) bits with data.


Figure 10.3 *The structure of encoder and decoder*





Note

In this book, we concentrate on block codes; we leave convolution codes to advanced texts.



Note

In modulo-N arithmetic, we use only the integers in the range 0 to $N - 1$, inclusive.

Figure 10.4 XORing of two single bits or two words

$$0 \oplus 0 = 0$$

$$1 \oplus 1 = 0$$

a. Two bits are the same, the result is 0.

$$0 \oplus 1 = 1$$

$$1 \oplus 0 = 1$$

b. Two bits are different, the result is 1.

$$\begin{array}{r} 1 & 0 & 1 & 1 & 0 \\ + & 1 & 1 & 1 & 0 \\ \hline 0 & 1 & 0 & 1 & 0 \end{array}$$

c. Result of XORing two patterns

10-2 BLOCK CODING

*In block coding, we divide our message into blocks, each of k bits, called **datawords**. We add r redundant bits to each block to make the length $n = k + r$. The resulting n -bit blocks are called **codewords**.*

Topics discussed in this section:


Error Detection


Error Correction

Hamming Distance

Minimum Hamming Distance

Figure 10.5 *Datawords and codewords in block coding*







Example 10.1

The 4B/5B block coding discussed in Chapter 4 is a good example of this type of coding. In this coding scheme, $k = 4$ and $n = 5$. As we saw, we have $2^k = 16$ datawords and $2^n = 32$ codewords. We saw that 16 out of 32 codewords are used for message transfer and the rest are either used for other purposes or unused.

Figure 10.6 *Process of error detection in block coding*






Example 10.2

Let us assume that $k = 2$ and $n = 3$. Table 10.1 shows the list of datawords and codewords. Later, we will see how to derive a codeword from a dataword.

Assume the sender encodes the dataword 01 as 011 and sends it to the receiver. Consider the following cases:

- 1. The receiver receives 011. It is a valid codeword. The receiver extracts the dataword 01 from it.*




Example 10.2 (continued)

- 2.** *The codeword is corrupted during transmission, and 111 is received. This is not a valid codeword and is discarded.*

- 3.** *The codeword is corrupted during transmission, and 000 is received. This is a valid codeword. The receiver incorrectly extracts the dataword 00. Two corrupted bits have made the error undetectable.*

Table 10.1 A code for error detection (Example 10.2)


<i>Datawords</i>	<i>Codewords</i>
00	000
01	011
10	101
11	110




Note

An error-detecting code can detect only the types of errors for which it is designed; other types of errors may remain undetected.


Figure 10.7 Structure of encoder and decoder in error correction





Example 10.3

Let us add more redundant bits to Example 10.2 to see if the receiver can correct an error without knowing what was actually sent. We add 3 redundant bits to the 2-bit dataword to make 5-bit codewords. Table 10.2 shows the datawords and codewords. Assume the dataword is 01. The sender creates the codeword 01011. The codeword is corrupted during transmission, and 01001 is received. First, the receiver finds that the received codeword is not in the table. This means an error has occurred. The receiver, assuming that there is only 1 bit corrupted, uses the following strategy to guess the correct dataword.




Example 10.3 (continued)

- 1.** *Comparing the received codeword with the first codeword in the table (01001 versus 00000), the receiver decides that the first codeword is not the one that was sent because there are two different bits.*
- 2.** *By the same reasoning, the original codeword cannot be the third or fourth one in the table.*
- 3.** *The original codeword must be the second one in the table because this is the only one that differs from the received codeword by 1 bit. The receiver replaces 01001 with 01011 and consults the table to find the dataword 01.*


Table 10.2 *A code for error correction (Example 10.3)*

<i>Dataword</i>	<i>Codeword</i>
00	00000
01	01011
10	10101
11	11110



Note

The Hamming distance between two words is the number of differences between corresponding bits.



Example 10.4


Let us find the Hamming distance between two pairs of words.

1. *The Hamming distance $d(000, 011)$ is 2 because*

$$000 \oplus 011 \text{ is } 011 \text{ (two 1s)}$$


2. *The Hamming distance $d(10101, 11110)$ is 3 because*

$$10101 \oplus 11110 \text{ is } 01011 \text{ (three 1s)}$$



Note

The minimum Hamming distance is the smallest Hamming distance between all possible pairs in a set of words.



Example 10.5


Find the minimum Hamming distance of the coding scheme in Table 10.1.

Solution

We first find all Hamming distances.

$$\begin{array}{llll} d(000, 011) = 2 & d(000, 101) = 2 & d(000, 110) = 2 & d(011, 101) = 2 \\ d(011, 110) = 2 & d(101, 110) = 2 & & \end{array}$$

The d_{min} in this case is 2.



Example 10.6


Find the minimum Hamming distance of the coding scheme in Table 10.2.

Solution

We first find all the Hamming distances.


$$\begin{array}{lll} d(00000, 01011) = 3 & d(00000, 10101) = 3 & d(00000, 11110) = 4 \\ d(01011, 10101) = 4 & d(01011, 11110) = 3 & d(10101, 11110) = 3 \end{array}$$

The d_{min} in this case is 3.




Note

To guarantee the detection of up to s errors in all cases, the minimum Hamming distance in a block code must be $d_{\min} = s + 1$.



Example 10.7

The minimum Hamming distance for our first code scheme (Table 10.1) is 2. This code guarantees detection of only a single error. For example, if the third codeword (101) is sent and one error occurs, the received codeword does not match any valid codeword. If two errors occur, however, the received codeword may match a valid codeword and the errors are not detected.



Example 10.8

Our second block code scheme (Table 10.2) has $d_{min} = 3$. This code can detect up to two errors. Again, we see that when any of the valid codewords is sent, two errors create a codeword which is not in the table of valid codewords. The receiver cannot be fooled.

However, some combinations of three errors change a valid codeword to another valid codeword. The receiver accepts the received codeword and the errors are undetected.

Figure 10.8 Geometric concept for finding d_{min} in error detection







Figure 10.9 Geometric concept for finding d_{min} in error correction





Note

**To guarantee correction of up to t errors
in all cases, the minimum Hamming
distance in a block code
must be $d_{\min} = 2t + 1$.**



Example 10.9

A code scheme has a Hamming distance $d_{min} = 4$. What is the error detection and correction capability of this scheme?

Solution

*This code guarantees the detection of up to **three** errors ($s = 3$), but it can correct up to **one** error. In other words, if this code is used for error correction, part of its capability is wasted. Error correction codes need to have an odd minimum distance (3, 5, 7, . . .).*


10-3 LINEAR BLOCK CODES

*Almost all block codes used today belong to a subset called **linear block codes**. A linear block code is a code in which the exclusive OR (addition modulo-2) of two valid codewords creates another valid codeword.*

Topics discussed in this section:


Minimum Distance for Linear Block Codes

Some Linear Block Codes



Note


In a linear block code, the exclusive OR (XOR) of any two valid codewords creates another valid codeword.



Example 10.10


Let us see if the two codes we defined in Table 10.1 and Table 10.2 belong to the class of linear block codes.

- 1. The scheme in Table 10.1 is a linear block code because the result of XORing any codeword with any other codeword is a valid codeword. For example, the XORing of the second and third codewords creates the fourth one.*
- 2. The scheme in Table 10.2 is also a linear block code. We can create all four codewords by XORing two other codewords.*



Example 10.11

In our first code (Table 10.1), the numbers of 1s in the nonzero codewords are 2, 2, and 2. So the minimum Hamming distance is $d_{min} = 2$. In our second code (Table 10.2), the numbers of 1s in the nonzero codewords are 3, 3, and 4. So in this code we have $d_{min} = 3$.




Note


A simple parity-check code is a single-bit error-detecting code in which $n = k + 1$ with $d_{\min} = 2$.

Table 10.3 *Simple parity-check code C(5, 4)*

<i>Datawords</i>	<i>Codewords</i>	<i>Datawords</i>	<i>Codewords</i>
0000	00000	1000	10001
0001	00011	1001	10010
0010	00101	1010	10100
0011	00110	1011	10111
0100	01001	1100	11000
0101	01010	1101	11011
0110	01100	1110	11101
0111	01111	1111	11110

Figure 10.10 Encoder and decoder for simple parity-check code






Example 10.12


Let us look at some transmission scenarios. Assume the sender sends the dataword 1011. The codeword created from this dataword is 10111, which is sent to the receiver. We examine five cases:

- 1. No error occurs; the received codeword is 10111. The syndrome is 0. The dataword 1011 is created.**
- 2. One single-bit error changes a_1 . The received codeword is 10011. The syndrome is 1. No dataword is created.**
- 3. One single-bit error changes r_0 . The received codeword is 10110. The syndrome is 1. No dataword is created.**




Example 10.12 (continued)

- 4. An error changes r_0 and a second error changes a_3 .**
The received codeword is 00110. The syndrome is 0.
The dataword 0011 is created at the receiver. Note that here the dataword is wrongly created due to the syndrome value.
- 5. Three bits— a_3 , a_2 , and a_1 —are changed by errors.**
The received codeword is 01011. The syndrome is 1.
The dataword is not created. This shows that the simple parity check, guaranteed to detect one single error, can also find any odd number of errors.



Note

**A simple parity-check code can detect
an odd number of errors.**



Note

All Hamming codes discussed in this book have $d_{\min} = 3$.


The relationship between m and n in these codes is $n = 2m - 1$.

Figure 10.11 Two-dimensional parity-check code


1	1	0	0	1	1	1	1	1
1	0	1	1	1	1	0	1	1
0	1	1	1	0	0	1	0	0
0	1	0	1	0	0	1	1	1
0	1	0	1	0	1	0	1	1

a. Design of row and column parities

Figure 10.11 Two-dimensional parity-check code




b. One error affects two parities




c. Two errors affect two parities

Figure 10.11 Two-dimensional parity-check code



d. Three errors affect four parities



e. Four errors cannot be detected

Table 10.4 *Hamming code C(7, 4)*

<i>Datawords</i>	<i>Codewords</i>	<i>Datawords</i>	<i>Codewords</i>
0000	0000000	1000	1000110
0001	0001101	1001	1001011
0010	0010111	1010	1010001
0011	0011010	1011	1011100
0100	0100011	1100	1100101
0101	0101110	1101	1101000
0110	0110100	1110	1110010
0111	0111001	1111	1111111

Figure 10.12 The structure of the encoder and decoder for a Hamming code





Table 10.5 *Logical decision made by the correction logic analyzer*


<i>Syndrome</i>	000	001	010	011	100	101	110	111
<i>Error</i>	None	q_0	q_1	b_2	q_2	b_0	b_3	b_1



Example 10.13

Let us trace the path of three datawords from the sender to the destination:

- 1. The dataword 0100 becomes the codeword 0100011.**
The codeword 0100011 is received. The syndrome is 000, the final dataword is 0100.
- 2. The dataword 0111 becomes the codeword 0111001.**
The syndrome is 011. After flipping b_2 (changing the 1 to 0), the final dataword is 0111.
- 3. The dataword 1101 becomes the codeword 1101000.**
The syndrome is 101. After flipping b_0 , we get 0000, the wrong dataword. This shows that our code cannot correct two errors.



Example 10.14

We need a dataword of at least 7 bits. Calculate values of k and n that satisfy this requirement.


Solution

We need to make $k = n - m$ greater than or equal to 7, or $2m - 1 - m \geq 7$.

1. If we set $m = 3$, the result is $n = 23 - 1$ and $k = 7 - 3$, or 4, which is not acceptable.
2. If we set $m = 4$, then $n = 24 - 1 = 15$ and $k = 15 - 4 = 11$, which satisfies the condition. So the code is

$$C(15, 11)$$

Figure 10.13 Burst error correction using Hamming code



10-4 CYCLIC CODES

Cyclic codes are special linear block codes with one extra property. In a cyclic code, if a codeword is cyclically shifted (rotated), the result is another codeword.

Topics discussed in this section:

Cyclic Redundancy Check

Hardware Implementation

Polynomials

Cyclic Code Analysis

Advantages of Cyclic Codes

Other Cyclic Codes

Table 10.6 A CRC code with $C(7, 4)$

<i>Dataword</i>	<i>Codeword</i>	<i>Dataword</i>	<i>Codeword</i>
0000	0000000	1000	1000101
0001	0001011	1001	1001110
0010	0010110	1010	1010011
0011	0011101	1011	1011000
0100	0100111	1100	1100010
0101	0101100	1101	1101001
0110	0110001	1110	1110100
0111	0111010	1111	1111111

Figure 10.14 CRC encoder and decoder




Figure 10.15 Division in CRC encoder




Figure 10.16 Division in the CRC decoder for two cases




Figure 10.17 Hardwired design of the divisor in CRC




Figure 10.18 Simulation of division in CRC encoder




Figure 10.19 *The CRC encoder design using shift registers*






Figure 10.20 General design of encoder and decoder of a CRC code

Note:

The divisor line and XOR are missing if the corresponding bit in the divisor is 0.




a. Encoder




b. Decoder

Figure 10.21 A polynomial to represent a binary word





a. Binary pattern and polynomial



b. Short form


Figure 10.22 CRC division using polynomials





Note

The divisor in a cyclic code is normally called the generator polynomial or simply the generator.




Note

In a cyclic code,

If $s(x) \neq 0$, one or more bits is corrupted.


If $s(x) = 0$, either

- a. No bit is corrupted. or**
- b. Some bits are corrupted, but the decoder failed to detect them.**




Note

In a cyclic code, those $e(x)$ errors that are divisible by $g(x)$ are not caught.



Note

**If the generator has more than one term
and the coefficient of x^0 is 1,
all single errors can be caught.**



Example 10.15


Which of the following $g(x)$ values guarantees that a single-bit error is caught? For each case, what is the error that cannot be caught?


- a. $x + 1$
- b. x^3
- c. 1

Solution

- a. No x^i can be divisible by $x + 1$. Any single-bit error can be caught.
- b. If i is equal to or greater than 3, x^i is divisible by $g(x)$. All single-bit errors in positions 1 to 3 are caught.
- c. All values of i make x^i divisible by $g(x)$. No single-bit error can be caught. This $g(x)$ is useless.


Figure 10.23 *Representation of two isolated single-bit errors using polynomials*





Note

**If a generator cannot divide $x^t + 1$
(t between 0 and $n - 1$),
then all isolated double errors
can be detected.**




Example 10.16

Find the status of the following generators related to two isolated, single-bit errors.

- a. $x + 1$
- b. $x^4 + 1$
- c. $x^7 + x^6 + 1$
- d. $x^{15} + x^{14} + 1$


Solution

- a. *This is a very poor choice for a generator. Any two errors next to each other cannot be detected.*
- b. *This generator cannot detect two errors that are four positions apart.*
- c. *This is a good choice for this purpose.*
- d. *This polynomial cannot divide $x^t + 1$ if t is less than 32,768. A codeword with two isolated errors up to 32,768 bits apart can be detected by this generator.*




Note

A generator that contains a factor of $x + 1$ can detect all odd-numbered errors.



Note

- All burst errors with $L \leq r$ will be detected.
 - All burst errors with $L = r + 1$ will be detected with probability $1 - (1/2)^{r-1}$.
 - All burst errors with $L > r + 1$ will be detected with probability $1 - (1/2)^r$.
-




Example 10.17

Find the suitability of the following generators in relation to burst errors of different lengths.

a. $x^6 + 1$ **b.** $x^{18} + x^7 + x + 1$ **c.** $x^{32} + x^{23} + x^7 + 1$

Solution


a. This generator can detect all burst errors with a length less than or equal to 6 bits; 3 out of 100 burst errors with length 7 will slip by; 16 out of 1000 burst errors of length 8 or more will slip by.



Example 10.17 (continued)

- b.** *This generator can detect all burst errors with a length less than or equal to 18 bits; 8 out of 1 million burst errors with length 19 will slip by; 4 out of 1 million burst errors of length 20 or more will slip by.*

- c.** *This generator can detect all burst errors with a length less than or equal to 32 bits; 5 out of 10 billion burst errors with length 33 will slip by; 3 out of 10 billion burst errors of length 34 or more will slip by.*



Note

A good polynomial generator needs to have the following characteristics:

- 1.** It should have at least two terms.
- 2.** The coefficient of the term x^0 should be 1.
- 3.** It should not divide $x^t + 1$, for t between 2 and $n - 1$.
- 4.** It should have the factor $x + 1$.

Table 10.7 *Standard polynomials*

Name	Polynomial	Application
CRC-8	$x^8 + x^2 + x + 1$	ATM header
CRC-10	$x^{10} + x^9 + x^5 + x^4 + x^2 + 1$	ATM AAL
CRC-16	$x^{16} + x^{12} + x^5 + 1$	HDLC
CRC-32	$x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} + x^{10} + x^8 + x^7 + x^5 + x^4 + x^2 + x + 1$	LANs


10-5 CHECKSUM

The last error detection method we discuss here is called the checksum. The checksum is used in the Internet by several protocols although not at the data link layer. However, we briefly discuss it here to complete our discussion on error checking

Topics discussed in this section:


Idea

One's Complement
Internet Checksum




Example 10.18

Suppose our data is a list of five 4-bit numbers that we want to send to a destination. In addition to sending these numbers, we send the sum of the numbers. For example, if the set of numbers is (7, 11, 12, 0, 6), we send (7, 11, 12, 0, 6, 36), where 36 is the sum of the original numbers. The receiver adds the five numbers and compares the result with the sum. If the two are the same, the receiver assumes no error, accepts the five numbers, and discards the sum. Otherwise, there is an error somewhere and the data are not accepted.



Example 10.19

*We can make the job of the receiver easier if we send the negative (complement) of the sum, called the **checksum**. In this case, we send (7, 11, 12, 0, 6, **-36**). The receiver can add all the numbers received (including the checksum). If the result is 0, it assumes no error; otherwise, there is an error.*




Example 10.20

How can we represent the number 21 in one's complement arithmetic using only four bits?

Solution

The number 21 in binary is 10101 (it needs five bits). We can wrap the leftmost bit and add it to the four rightmost bits. We have $(0101 + 1) = 0110$ or 6.




Example 10.21

How can we represent the number -6 in one's complement arithmetic using only four bits?


Solution

In one's complement arithmetic, the negative or complement of a number is found by inverting all bits. Positive 6 is 0110; negative 6 is 1001. If we consider only unsigned numbers, this is 9. In other words, the complement of 6 is 9. Another way to find the complement of a number in one's complement arithmetic is to subtract the number from $2^n - 1$ ($16 - 1$ in this case).



Example 10.22


Let us redo Exercise 10.19 using one's complement arithmetic. Figure 10.24 shows the process at the sender and at the receiver. The sender initializes the checksum to 0 and adds all data items and the checksum (the checksum is considered as one data item and is shown in color). The result is 36. However, 36 cannot be expressed in 4 bits. The extra two bits are wrapped and added with the sum to create the wrapped sum value 6. In the figure, we have shown the details in binary. The sum is then complemented, resulting in the checksum value 9 ($15 - 6 = 9$). The sender now sends six data items to the receiver including the checksum 9.




Example 10.22 (continued)

The receiver follows the same procedure as the sender. It adds all data items (including the checksum); the result is 45. The sum is wrapped and becomes 15. The wrapped sum is complemented and becomes 0. Since the value of the checksum is 0, this means that the data is not corrupted. The receiver drops the checksum and keeps the other data items. If the checksum is not zero, the entire packet is dropped.

Figure 10.24 Example 10.22






Note

Sender site:

- 1. The message is divided into 16-bit words.**
- 2. The value of the checksum word is set to 0.**
- 3. All words including the checksum are added using one's complement addition.**
- 4. The sum is complemented and becomes the checksum.**
- 5. The checksum is sent with the data.**



Note

Receiver site:

- 1. The message (including checksum) is divided into 16-bit words.**
- 2. All words are added using one's complement addition.**
- 3. The sum is complemented and becomes the new checksum.**
- 4. If the value of checksum is 0, the message is accepted; otherwise, it is rejected.**

Example 10.23

Let us calculate the checksum for a text of 8 characters (“Forouzan”). The text needs to be divided into 2-byte (16-bit) words. We use ASCII (see Appendix A) to change each byte to a 2-digit hexadecimal number. For example, F is represented as 0x46 and o is represented as 0x6F. Figure 10.25 shows how the checksum is calculated at the sender and receiver sites. In part a of the figure, the value of partial sum for the first column is 0x36. We keep the rightmost digit (6) and insert the leftmost digit (3) as the carry in the second column. The process is repeated for each column. Note that if there is any corruption, the checksum recalculated by the receiver is not all 0s. We leave this an exercise.

Figure 10.25 Example 10.23

1	0	1	3	Carries
4	6	6	F	(Fo)
7	2	6	7	(ro)
7	5	7	A	(uz)
6	1	6	E	(an)
0	0	0	0	Checksum (initial)
<hr/>				
8	F	C	6	Sum (partial)
<hr/>				
8	F	C	7	Sum
7	0	3	8	Checksum (to send)

a. Checksum at the sender site

1	0	1	3	Carries
4	6	6	F	(Fo)
7	2	6	7	(ro)
7	5	7	A	(uz)
6	1	6	E	(an)
7	0	3	8	Checksum (received)
<hr/>				
F	F	F	E	Sum (partial)
<hr/>				
8	F	C	7	Sum
0	0	0	0	Checksum (new)

a. Checksum at the receiver site



Data Communications and Networking

Fourth Edition

Forouzan

Chapter 11

Data Link Control

11-1 FRAMING

*The data link layer needs to pack bits into **frames**, so that each frame is distinguishable from another. Our postal system practices a type of framing. The simple act of inserting a letter into an envelope separates one piece of information from another; the envelope serves as the delimiter.*

Topics discussed in this section:

Fixed-Size Framing

Variable-Size Framing

Figure 11.1 A frame in a character-oriented protocol






Figure 11.2 Byte stuffing and unstuffing







Note

Byte stuffing is the process of adding 1 extra byte whenever there is a flag or escape character in the text.

Figure 11.3 A frame in a bit-oriented protocol






Note

Bit stuffing is the process of adding one extra 0 whenever five consecutive 1s follow a 0 in the data, so that the receiver does not mistake the pattern 0111110 for a flag.

Figure 11.4 Bit stuffing and unstuffing




11-2 FLOW AND ERROR CONTROL

*The most important responsibilities of the data link layer are **flow control** and **error control**. Collectively, these functions are known as **data link control**.*

Topics discussed in this section:


Flow Control

Error Control



Note

Flow control refers to a set of procedures used to restrict the amount of data that the sender can send before waiting for acknowledgment.




Note

Error control in the data link layer is based on automatic repeat request, which is the retransmission of data.

11-3 PROTOCOLS

Now let us see how the data link layer can combine framing, flow control, and error control to achieve the delivery of data from one node to another. The protocols are normally implemented in software by using one of the common programming languages. To make our discussions language-free, we have written in pseudocode a version of each protocol that concentrates mostly on the procedure instead of delving into the details of language rules.

Figure 11.5 *Taxonomy of protocols discussed in this chapter*



11-4 NOISELESS CHANNELS


Let us first assume we have an ideal channel in which no frames are lost, duplicated, or corrupted. We introduce two protocols for this type of channel.

Topics discussed in this section:

Simplest Protocol

Stop-and-Wait Protocol

Figure 11.6 *The design of the simplest protocol with no flow or error control*




Algorithm 11.1 *Sender-site algorithm for the simplest protocol*

```
1 while(true)          // Repeat forever
2 {
3     WaitForEvent();    // Sleep until an event occurs
4     if(Event(RequestToSend)) //There is a packet to send
5     {
6         GetData();
7         MakeFrame();
8         SendFrame();      //Send the frame
9     }
10 }
```

Algorithm 11.2 *Receiver-site algorithm for the simplest protocol*

```
1 while(true)                                // Repeat forever
2 {
3     WaitForEvent();                         // Sleep until an event occurs
4     if(Event(ArrivalNotification)) //Data frame arrived
5     {
6         ReceiveFrame();
7         ExtractData();
8         DeliverData();                  //Deliver data to network layer
9     }
10 }
```



Example 11.1

Figure 11.7 shows an example of communication using this protocol. It is very simple. The sender sends a sequence of frames without even thinking about the receiver. To send three frames, three events occur at the sender site and three events at the receiver site. Note that the data frames are shown by tilted boxes; the height of the box defines the transmission time difference between the first bit and the last bit in the frame.

Figure 11.7 Flow diagram for Example 11.1





Figure 11.8 Design of Stop-and-Wait Protocol




Algorithm 11.3 *Sender-site algorithm for Stop-and-Wait Protocol*

```
1 while(true)                                //Repeat forever
2 canSend = true                            //Allow the first frame to go
3 {
4     WaitForEvent();                      // Sleep until an event occurs
5     if(Event(RequestToSend) AND canSend)
6     {
7         GetData();
8         MakeFrame();
9         SendFrame();                     //Send the data frame
10        canSend = false;                //Cannot send until ACK arrives
11    }
12    WaitForEvent();                      // Sleep until an event occurs
13    if(Event(ArrivalNotification) // An ACK has arrived
14    {
15        ReceiveFrame();                //Receive the ACK frame
16        canSend = true;
17    }
18 }
```

Algorithm 11.4 *Receiver-site algorithm for Stop-and-Wait Protocol*


```
1 while(true)                                //Repeat forever
2 {
3     WaitForEvent();                         // Sleep until an event occurs
4     if(Event(ArrivalNotification)) //Data frame arrives
5     {
6         ReceiveFrame();
7         ExtractData();
8         Deliver(data);                  //Deliver data to network layer
9         SendFrame();                  //Send an ACK frame
10    }
11 }
```



Example 11.2

Figure 11.9 shows an example of communication using this protocol. It is still very simple. The sender sends one frame and waits for feedback from the receiver. When the ACK arrives, the sender sends the next frame. Note that sending two frames in the protocol involves the sender in four events and the receiver in two events.

Figure 11.9 Flow diagram for Example 11.2



11-5 NOISY CHANNELS


Although the Stop-and-Wait Protocol gives us an idea of how to add flow control to its predecessor, noiseless channels are nonexistent. We discuss three protocols in this section that use error control.

Topics discussed in this section:

Stop-and-Wait Automatic Repeat Request


Go-Back-N Automatic Repeat Request

Selective Repeat Automatic Repeat Request




Note

Error correction in Stop-and-Wait ARQ is done by keeping a copy of the sent frame and retransmitting of the frame when the timer expires.



Note


**In Stop-and-Wait ARQ, we use sequence numbers to number the frames.
The sequence numbers are based on modulo-2 arithmetic.**



Note

In Stop-and-Wait ARQ, the acknowledgment number always announces in modulo-2 arithmetic the sequence number of the next frame expected.

Figure 11.10 Design of the Stop-and-Wait ARQ Protocol



Algorithm 11.5 *Sender-site algorithm for Stop-and-Wait ARQ*

```
1 Sn = 0;                                // Frame 0 should be sent first
2 canSend = true;                           // Allow the first request to go
3 while(true)                               // Repeat forever
4 {
5   WaitForEvent();                         // Sleep until an event occurs
6   if(Event(RequestToSend) AND canSend)
7   {
8     GetData();
9     MakeFrame(Sn);                   //The seqNo is Sn
10    StoreFrame(Sn);                  //Keep copy
11    SendFrame(Sn);
12    StartTimer();
13    Sn = Sn + 1;
14    canSend = false;
15  }
16  WaitForEvent();                         // Sleep
```


(continued)

Algorithm 11.5 Sender-site algorithm for Stop-and-Wait ARQ (continued)

```
17    if(Event(ArrivalNotification))          // An ACK has arrived
18    {
19        ReceiveFrame(ackNo);           //Receive the ACK frame
20        if(not corrupted AND ackNo == Sn) //Valid ACK
21        {
22            StopTimer();
23            PurgeFrame(Sn-1);         //Copy is not needed
24            canSend = true;
25        }
26    }
27
28    if(Event(TimeOut))                  // The timer expired
29    {
30        StartTimer();
31        ResendFrame(Sn-1);         //Resend a copy check
32    }
33 }
```

Algorithm 11.6 Receiver-site algorithm for Stop-and-Wait ARQ Protocol


```
1 Rn = 0;                                // Frame 0 expected to arrive first
2 while(true)
3 {
4     WaitForEvent();                      // Sleep until an event occurs
5     if(Event(ArrivalNotification))      //Data frame arrives
6     {
7         ReceiveFrame();
8         if(corrupted(frame));
9             sleep();
10        if(seqNo == Rn)              //Valid data frame
11        {
12            ExtractData();
13            DeliverData();           //Deliver data
14            Rn = Rn + 1;
15        }
16        SendFrame(Rn);           //Send an ACK
17    }
18 }
```




Example 11.3

Figure 11.11 shows an example of Stop-and-Wait ARQ. Frame 0 is sent and acknowledged. Frame 1 is lost and resent after the time-out. The resent frame 1 is acknowledged and the timer stops. Frame 0 is sent and acknowledged, but the acknowledgment is lost. The sender has no idea if the frame or the acknowledgment is lost, so after the time-out, it resends frame 0, which is acknowledged.

Figure 11.11 Flow diagram for Example 11.3






Example 11.4

Assume that, in a Stop-and-Wait ARQ system, the bandwidth of the line is 1 Mbps, and 1 bit takes 20 ms to make a round trip. What is the bandwidth-delay product? If the system data frames are 1000 bits in length, what is the utilization percentage of the link?

Solution


The bandwidth-delay product is

$$(1 \times 10^6) \times (20 \times 10^{-3}) = 20,000 \text{ bits}$$



Example 11.4 (continued)

The system can send 20,000 bits during the time it takes for the data to go from the sender to the receiver and then back again. However, the system sends only 1000 bits. We can say that the link utilization is only $1000/20,000$, or 5 percent. For this reason, for a link with a high bandwidth or long delay, the use of Stop-and-Wait ARQ wastes the capacity of the link.




Example 11.5

What is the utilization percentage of the link in Example 11.4 if we have a protocol that can send up to 15 frames before stopping and worrying about the acknowledgments?

Solution


The bandwidth-delay product is still 20,000 bits. The system can send up to 15 frames or 15,000 bits during a round trip. This means the utilization is 15,000/20,000, or 75 percent. Of course, if there are damaged frames, the utilization percentage is much less because frames have to be resent.




Note

In the Go-Back-N Protocol, the sequence numbers are modulo 2^m , where m is the size of the sequence number field in bits.


Figure 11.12 Send window for Go-Back-N ARQ



a. Send window before sliding




b. Send window after sliding



Note



The send window is an abstract concept defining an imaginary box of size $2^m - 1$ with three variables: S_f , S_n , and S_{size} .




Note

The send window can slide one or more slots when a valid acknowledgment arrives.

Figure 11.13 Receive window for Go-Back-N ARQ





Note

The receive window is an abstract concept defining an imaginary box of size 1 with one single variable R_n .

The window slides when a correct frame has arrived; sliding occurs one slot at a time.

Figure 11.14 Design of Go-Back-N ARQ






Figure 11.15 Window size for Go-Back-N ARQ





Note

In Go-Back-N ARQ, the size of the send window must be less than 2^m ; the size of the receiver window is always 1.

Algorithm 11.7 Go-Back-N sender algorithm

```
1 Sw = 2m - 1;  
2 Sf = 0;  
3 Sn = 0;  
4  
5 while (true) //Repeat forever  
6 {  
7   WaitForEvent();  
8   if(Event(RequestToSend)) //A packet to send  
9   {  
10     if(Sn-Sf >= Sw) //If window is full  
11       Sleep();  
12     GetData();  
13     MakeFrame(Sn);  
14     StoreFrame(Sn);  
15     SendFrame(Sn);  
16     Sn = Sn + 1;  
17     if(timer not running)  
18       StartTimer();  
19   }  
20 }
```

(continued)

Algorithm 11.7 Go-Back-N sender algorithm

(continued)

```
21  if(Event(ArrivalNotification)) //ACK arrives
22  {
23      Receive(ACK);
24      if(corrupted(ACK))
25          Sleep();
26      if((ackNo>Sf)&&(ackNo<=Sn)) //If a valid ACK
27      While(Sf <= ackNo)
28      {
29          PurgeFrame(Sf);
30          Sf = Sf + 1;
31      }
32      StopTimer();
33  }
34
35  if(Event(TimeOut)) //The timer expires
36  {
37      StartTimer();
38      Temp = Sf;
39      while(Temp < Sn);
40      {
41          SendFrame(Sf);
42          Sf = Sf + 1;
43      }
44  }
45 }
```


Algorithm 11.8 Go-Back-N receiver algorithm


```
1 Rn = 0;  
2  
3 while (true) //Repeat forever  
4 {  
5     WaitForEvent();  
6  
7     if(Event(ArrivalNotification)) /Data frame arrives  
8     {  
9         Receive(Frame);  
10        if(corrupted(Frame))  
11            Sleep();  
12        if(seqNo == Rn) //If expected frame  
13        {  
14            DeliverData(); //Deliver data  
15            Rn = Rn + 1; //Slide window  
16            SendACK(Rn);  
17        }  
18    }  
19}
```

Example 11.6

Figure 11.16 shows an example of Go-Back-N. This is an example of a case where the forward channel is reliable, but the reverse is not. No data frames are lost, but some ACKs are delayed and one is lost. The example also shows how cumulative acknowledgments can help if acknowledgments are delayed or lost. After initialization, there are seven sender events. Request events are triggered by data from the network layer; arrival events are triggered by acknowledgments from the physical layer. There is no time-out event here because all outstanding frames are acknowledged before the timer expires. Note that although ACK 2 is lost, ACK 3 serves as both ACK 2 and ACK 3.


Figure 11.16 Flow diagram for Example 11.6





Example 11.7


Figure 11.17 shows what happens when a frame is lost. Frames 0, 1, 2, and 3 are sent. However, frame 1 is lost. The receiver receives frames 2 and 3, but they are discarded because they are received out of order. The sender receives no acknowledgment about frames 1, 2, or 3. Its timer finally expires. The sender sends all outstanding frames (1, 2, and 3) because it does not know what is wrong. Note that the resending of frames 1, 2, and 3 is the response to one single event. When the sender is responding to this event, it cannot accept the triggering of other events. This means that when ACK 2 arrives, the sender is still busy with sending frame 3.




Example 11.7 (continued)

The physical layer must wait until this event is completed and the data link layer goes back to its sleeping state. We have shown a vertical line to indicate the delay. It is the same story with ACK 3; but when ACK 3 arrives, the sender is busy responding to ACK 2. It happens again when ACK 4 arrives. Note that before the second timer expires, all outstanding frames have been sent and the timer is stopped.

Figure 11.17 Flow diagram for Example 11.7





Note

Stop-and-Wait ARQ is a special case of Go-Back-N ARQ in which the size of the send window is 1.

Figure 11.18 Send window for Selective Repeat ARQ




Figure 11.19 Receive window for Selective Repeat ARQ




Figure 11.20 Design of Selective Repeat ARQ







Figure 11.21 Selective Repeat ARQ, window size



a. Window size = 2^{m-1}



b. Window size > 2^{m-1}



Note

In Selective Repeat ARQ, the size of the sender and receiver window must be at most one-half of 2^m .

Algorithm 11.9 Sender-site Selective Repeat algorithm

```
1 Sw = 2m-1 ;
2 Sf = 0 ;
3 Sn = 0 ;
4
5 while (true) //Repeat forever
6 {
7     WaitForEvent() ;
8     if(Event(RequestToSend)) //There is a packet to send
9     {
10         if(Sn-Sf >= Sw) //If window is full
11             Sleep();
12         GetData();
13         MakeFrame(Sn);
14         StoreFrame(Sn);
15         SendFrame(Sn);
16         Sn = Sn + 1;
17         StartTimer(Sn);
18     }
19 }
```

(continued)

Algorithm 11.9 Sender-site Selective Repeat algorithm

(continued)

```
20  if(Event(ArrivalNotification)) //ACK arrives
21  {
22      Receive(frame);           //Receive ACK or NAK
23      if(corrupted(frame))
24          Sleep();
25      if (FrameType == NAK)
26          if (nakNo between Sf and Sn)
27          {
28              resend(nakNo);
29              StartTimer(nakNo);
30          }
31      if (FrameType == ACK)
32          if (ackNo between Sf and Sn)
33          {
34              while(sf < ackNo)
35              {
36                  Purge(sf);
37                  StopTimer(sf);
38                  Sf = Sf + 1;
39              }
40          }
41 }
```

Algorithm 11.9 *Sender-site Selective Repeat algorithm*

(continued)

```
42  
43     if(Event(TimeOut(t)))          //The timer expires  
44     {  
45         StartTimer(t);  
46         SendFrame(t);  
47     }  
48 }
```


Algorithm 11.10 Receiver-site Selective Repeat algorithm

```
1 Rn = 0;
2 NakSent = false;
3 AckNeeded = false;
4 Repeat(for all slots)
5     Marked(slot) = false;
6
7 while (true)                                //Repeat forever
8 {
9     WaitForEvent();
10
11    if(Event(ArrivalNotification))           /Data frame arrives
12    {
13        Receive(Frame);
14        if(corrupted(Frame))&& (NOT NakSent)
15        {
16            SendNAK(Rn);
17            NakSent = true;
18            Sleep();
19        }
20        if(seqNo <> Rn)&& (NOT NakSent)
21        {
22            SendNAK(Rn);
```


Algorithm 11.10 *Receiver-site Selective Repeat algorithm*

```
23     NakSent = true;
24     if ((seqNo in window) && (!Marked(seqNo)))
25     {
26         StoreFrame(seqNo)
27         Marked(seqNo)= true;
28         while(Marked(Rn))
29         {
30             DeliverData(Rn);
31             Purge(Rn);
32             Rn = Rn + 1;
33             AckNeeded = true;
34         }
35         if(AckNeeded);
36         {
37             SendAck(Rn);
38             AckNeeded = false;
39             NakSent = false;
40         }
41     }
42 }
43 }
44 }
```


Figure 11.22 *Delivery of data in Selective Repeat ARQ*



a. Before delivery




b. After delivery




Example 11.8

This example is similar to Example 11.3 in which frame 1 is lost. We show how Selective Repeat behaves in this case. Figure 11.23 shows the situation. One main difference is the number of timers. Here, each frame sent or resent needs a timer, which means that the timers need to be numbered (0, 1, 2, and 3). The timer for frame 0 starts at the first request, but stops when the ACK for this frame arrives. The timer for frame 1 starts at the second request, restarts when a NAK arrives, and finally stops when the last ACK arrives. The other two timers start when the corresponding frames are sent and stop at the last arrival event.




Example 11.8 (continued)

At the receiver site we need to distinguish between the acceptance of a frame and its delivery to the network layer. At the second arrival, frame 2 arrives and is stored and marked, but it cannot be delivered because frame 1 is missing. At the next arrival, frame 3 arrives and is marked and stored, but still none of the frames can be delivered. Only at the last arrival, when finally a copy of frame 1 arrives, can frames 1, 2, and 3 be delivered to the network layer. There are two conditions for the delivery of frames to the network layer: First, a set of consecutive frames must have arrived. Second, the set starts from the beginning of the window.



Example 11.8 (continued)

Another important point is that a NAK is sent after the second arrival, but not after the third, although both situations look the same. The reason is that the protocol does not want to crowd the network with unnecessary NAKs and unnecessary resent frames. The second NAK would still be NAK1 to inform the sender to resend frame 1 again; this has already been done. The first NAK sent is remembered (using the nakSent variable) and is not sent again until the frame slides. A NAK is sent once for each window position and defines the first slot in the window.



Example 11.8 (continued)

The next point is about the ACKs. Notice that only two ACKs are sent here. The first one acknowledges only the first frame; the second one acknowledges three frames. In Selective Repeat, ACKs are sent when data are delivered to the network layer. If the data belonging to n frames are delivered in one shot, only one ACK is sent for all of them.

Figure 11.23 Flow diagram for Example 11.8





Figure 11.24 Design of piggybacking in Go-Back-N ARQ



11-6 HDLC

High-level Data Link Control (HDLC) is a bit-oriented protocol for communication over point-to-point and multipoint links. It implements the ARQ mechanisms we discussed in this chapter.

Topics discussed in this section:

Configurations and Transfer Modes


Frames

Control Field

Figure 11.25 Normal response mode



a. Point-to-point



b. Multipoint

Figure 11.26 Asynchronous balanced mode




Figure 11.27 HDLC frames




Figure 11.28 Control field format for the different frame types





Table 11.1 U-frame control command and response


<i>Code</i>	<i>Command</i>	<i>Response</i>	<i>Meaning</i>
00 001	SNRM		Set normal response mode
11 011	SNRME		Set normal response mode, extended
11 100	SABM	DM	Set asynchronous balanced mode or disconnect mode
11 110	SABME		Set asynchronous balanced mode, extended
00 000	UI	UI	Unnumbered information
00 110		UA	Unnumbered acknowledgment
00 010	DISC	RD	Disconnect or request disconnect
10 000	SIM	RIM	Set initialization mode or request information mode
00 100	UP		Unnumbered poll
11 001	RSET		Reset
11 101	XID	XID	Exchange ID
10 001	FRMR	FRMR	Frame reject



Example 11.9


*Figure 11.29 shows how **U-frames** can be used for connection establishment and connection release. Node A asks for a connection with a set asynchronous balanced mode (SABM) frame; node B gives a positive response with an unnumbered acknowledgment (UA) frame. After these two exchanges, data can be transferred between the two nodes (not shown in the figure). After data transfer, node A sends a DISC (disconnect) frame to release the connection; it is confirmed by node B responding with a UA (unnumbered acknowledgment).*

Figure 11.29 Example of connection and disconnection



Example 11.10


Figure 11.30 shows an exchange using piggybacking. Node A begins the exchange of information with an I-frame numbered 0 followed by another I-frame numbered 1. Node B piggybacks its acknowledgment of both frames onto an I-frame of its own. Node B's first I-frame is also numbered 0 [N(S) field] and contains a 2 in its N(R) field, acknowledging the receipt of A's frames 1 and 0 and indicating that it expects frame 2 to arrive next. Node B transmits its second and third I-frames (numbered 1 and 2) before accepting further frames from node A.




Example 11.10 (continued)

Its $N(R)$ information, therefore, has not changed: B frames 1 and 2 indicate that node B is still expecting A's frame 2 to arrive next. Node A has sent all its data. Therefore, it cannot piggyback an acknowledgment onto an I-frame and sends an S-frame instead. The RR code indicates that A is still ready to receive. The number 3 in the $N(R)$ field tells B that frames 0, 1, and 2 have all been accepted and that A is now expecting frame number 3.

Figure 11.30 Example of piggybacking without error






Example 11.11

Figure 11.31 shows an exchange in which a frame is lost. Node B sends three data frames (0, 1, and 2), but frame 1 is lost. When node A receives frame 2, it discards it and sends a REJ frame for frame 1. Note that the protocol being used is Go-Back-N with the special use of an REJ frame as a NAK frame. The NAK frame does two things here: It confirms the receipt of frame 0 and declares that frame 1 and any following frames must be resent. Node B, after receiving the REJ frame, resends frames 1 and 2. Node A acknowledges the receipt by sending an RR frame (ACK) with acknowledgment number 3.

Figure 11.31 Example of piggybacking with error



11-7 POINT-TO-POINT PROTOCOL

*Although HDLC is a general protocol that can be used for both point-to-point and multipoint configurations, one of the most common protocols for point-to-point access is the **Point-to-Point Protocol (PPP)**. PPP is a byte-oriented protocol.*

Topics discussed in this section:


Framing


Transition Phases

Multiplexing

Multilink PPP

Figure 11.32 PPP frame format





Note

**PPP is a byte-oriented protocol using
byte stuffing with the escape byte
01111101.**

Figure 11.33 Transition phases





Figure 11.34 Multiplexing in PPP



LCP: 0xC021
AP: 0xC023 and 0xC223
NCP: 0x8021 and
Data: 0x0021 and

LCP: Link Control Protocol
AP: Authentication Protocol
NCP: Network Control Protocol

Figure 11.35 LCP packet encapsulated in a frame




Table 11.2 LCP packets

<i>Code</i>	<i>Packet Type</i>	<i>Description</i>
0x01	Configure-request	Contains the list of proposed options and their values
0x02	Configure-ack	Accepts all options proposed
0x03	Configure-nak	Announces that some options are not acceptable
0x04	Configure-reject	Announces that some options are not recognized
0x05	Terminate-request	Request to shut down the line
0x06	Terminate-ack	Accept the shutdown request
0x07	Code-reject	Announces an unknown code
0x08	Protocol-reject	Announces an unknown protocol
0x09	Echo-request	A type of hello message to check if the other end is alive
0x0A	Echo-reply	The response to the echo-request message
0x0B	Discard-request	A request to discard the packet

Table 11.3 *Common options*

<i>Option</i>	<i>Default</i>
Maximum receive unit (payload field size)	1500
Authentication protocol	None
Protocol field compression	Off
Address and control field compression	Off

Figure 11.36 PAP packets encapsulated in a PPP frame




Figure 11.37 CHAP packets encapsulated in a PPP frame




Figure 11.38 IPCP packet encapsulated in PPP frame





Table 11.4 *Code value for IPCP packets*


<i>Code</i>	<i>IPCP Packet</i>
0x01	Configure-request
0x02	Configure-ack
0x03	Configure-nak
0x04	Configure-reject
0x05	Terminate-request
0x06	Terminate-ack
0x07	Code-reject

Figure 11.39 *IP datagram encapsulated in a PPP frame*



Figure 11.40 Multilink PPP






Example 11.12

Let us go through the phases followed by a network layer packet as it is transmitted through a PPP connection. Figure 11.41 shows the steps. For simplicity, we assume unidirectional movement of data from the user site to the system site (such as sending an e-mail through an ISP).

The first two frames show link establishment. We have chosen two options (not shown in the figure): using PAP for authentication and suppressing the address control fields. Frames 3 and 4 are for authentication. Frames 5 and 6 establish the network layer connection using IPCP.



Example 11.12 (continued)

The next several frames show that some IP packets are encapsulated in the PPP frame. The system (receiver) may have been running several network layer protocols, but it knows that the incoming data must be delivered to the IP protocol because the NCP protocol used before the data transfer was IPCP.

After data transfer, the user then terminates the data link connection, which is acknowledged by the system. Of course the user or the system could have chosen to terminate the network layer IPCP and keep the data link layer running if it wanted to run another NCP protocol.

Figure 11.41 An example





Figure 11.41 An example (continued)





Data Communications and Networking

Fourth Edition

Forouzan

Chapter 12

Multiple Access

Figure 12.1 *Data link layer divided into two functionality-oriented sublayers*





Figure 12.2 *Taxonomy of multiple-access protocols discussed in this chapter*



12-1 RANDOM ACCESS

*In **random access** or **contention** methods, no station is superior to another station and none is assigned the control over another. No station permits, or does not permit, another station to send. At each instance, a station that has data to send uses a procedure defined by the protocol to make a decision on whether or not to send.*

Topics discussed in this section:

ALOHA

Carrier Sense Multiple Access

Carrier Sense Multiple Access with Collision Detection

Carrier Sense Multiple Access with Collision Avoidance

Figure 12.3 *Frames in a pure ALOHA network*






Figure 12.4 Procedure for pure ALOHA protocol






Example 12.1

The stations on a wireless ALOHA network are a maximum of 600 km apart. If we assume that signals propagate at 3×10^8 m/s, we find

$$T_p = (600 \times 10^5) / (3 \times 10^8) = 2 \text{ ms.}$$

Now we can find the value of T_B for different values of K .


- a. For $K = 1$, the range is $\{0, 1\}$. The station needs to generate a random number with a value of 0 or 1. This means that T_B is either 0 ms (0×2) or 2 ms (1×2), based on the outcome of the random variable.




Example 12.1 (continued)

- b.** *For $K = 2$, the range is $\{0, 1, 2, 3\}$. This means that T_B can be 0, 2, 4, or 6 ms, based on the outcome of the random variable.*
- c.** *For $K = 3$, the range is $\{0, 1, 2, 3, 4, 5, 6, 7\}$. This means that T_B can be 0, 2, 4, . . . , 14 ms, based on the outcome of the random variable.*
- d.** *We need to mention that if $K > 10$, it is normally set to 10.*

Figure 12.5 Vulnerable time for pure ALOHA protocol






Example 12.2

A pure ALOHA network transmits 200-bit frames on a shared channel of 200 kbps. What is the requirement to make this frame collision-free?

Solution

Average frame transmission time T_{fr} is 200 bits/200 kbps or 1 ms. The vulnerable time is $2 \times 1 \text{ ms} = 2 \text{ ms}$. This means no station should send later than 1 ms before this station starts transmission and no station should start sending during the one 1-ms period that this station is sending.




Note

The throughput for pure ALOHA is

$$S = G \times e^{-2G} .$$

The maximum throughput

$$S_{\max} = 0.184 \text{ when } G = (1/2).$$



Example 12.3


A pure ALOHA network transmits 200-bit frames on a shared channel of 200 kbps. What is the throughput if the system (all stations together) produces

- a. 1000 frames per second
- b. 500 frames per second
- c. 250 frames per second.

Solution

The frame transmission time is $200/200$ kbps or 1 ms.

- a. If the system creates 1000 frames per second, this is 1 frame per millisecond. The load is 1. In this case $S = G \times e^{-2G}$ or $S = 0.135$ (13.5 percent). This means that the throughput is $1000 \times 0.135 = 135$ frames. Only 135 frames out of 1000 will probably survive.





Example 12.3 (continued)

b. If the system creates 500 frames per second, this is (1/2) frame per millisecond. The load is (1/2). In this case $S = G \times e^{-2G}$ or $S = 0.184$ (18.4 percent). This means that the throughput is $500 \times 0.184 = 92$ and that only 92 frames out of 500 will probably survive. Note that this is the maximum throughput case, percentagewise.

c. If the system creates 250 frames per second, this is (1/4) frame per millisecond. The load is (1/4). In this case $S = G \times e^{-2G}$ or $S = 0.152$ (15.2 percent). This means that the throughput is $250 \times 0.152 = 38$. Only 38 frames out of 250 will probably survive.

Figure 12.6 *Frames in a slotted ALOHA network*





Note


The throughput for slotted ALOHA is


$$S = G \times e^{-G} .$$

The maximum throughput

$$S_{\max} = 0.368 \text{ when } G = 1.$$

Figure 12.7 Vulnerable time for slotted ALOHA protocol





Example 12.4

A slotted ALOHA network transmits 200-bit frames on a shared channel of 200 kbps. What is the throughput if the system (all stations together) produces


- a. 1000 frames per second
- b. 500 frames per second
- c. 250 frames per second.

Solution

The frame transmission time is $200/200$ kbps or 1 ms.

- a. If the system creates 1000 frames per second, this is 1 frame per millisecond. The load is 1. In this case $S = G \times e^{-G}$ or $S = 0.368$ (36.8 percent). This means that the throughput is $1000 \times 0.0368 = 368$ frames.

Only 386 frames out of 1000 will probably survive.



Example 12.4 (continued)

- b.** *If the system creates 500 frames per second, this is (1/2) frame per millisecond. The load is (1/2). In this case $S = G \times e^{-G}$ or $S = 0.303$ (30.3 percent). This means that the throughput is $500 \times 0.0303 = 151$. Only 151 frames out of 500 will probably survive.*
- c.** *If the system creates 250 frames per second, this is (1/4) frame per millisecond. The load is (1/4). In this case $S = G \times e^{-G}$ or $S = 0.195$ (19.5 percent). This means that the throughput is $250 \times 0.195 = 49$. Only 49 frames out of 250 will probably survive.*

Figure 12.8 Space/time model of the collision in CSMA




Figure 12.9 Vulnerable time in CSMA







Figure 12.10 Behavior of three persistence methods



a. 1-persistent




b. Nonpersistent




c. p-persistent


Figure 12.11 Flow diagram for three persistence methods



a. 1-persistent



b. Nonpersistent



c. p -persistent

Figure 12.12 Collision of the first bit in CSMA/CD






Figure 12.13 Collision and abortion in CSMA/CD





Example 12.5

A network using CSMA/CD has a bandwidth of 10 Mbps. If the maximum propagation time (including the delays in the devices and ignoring the time needed to send a jamming signal, as we see later) is 25.6 µs, what is the minimum size of the frame?

Solution

The frame transmission time is $T_{fr} = 2 \times T_p = 51.2 \mu s$. This means, in the worst case, a station needs to transmit for a period of 51.2 µs to detect the collision. The minimum size of the frame is $10 \text{ Mbps} \times 51.2 \mu s = 512 \text{ bits or } 64 \text{ bytes}$. This is actually the minimum size of the frame for Standard Ethernet.

Figure 12.14 Flow diagram for the CSMA/CD




Figure 12.15 Energy level during transmission, idleness, or collision







Figure 12.16 Timing in CSMA/CA





Note


In CSMA/CA, the IFS can also be used to define the priority of a station or a frame.



Note

In CSMA/CA, if the station finds the channel busy, it does not restart the timer of the contention window; it stops the timer and restarts it when the channel becomes idle.

Figure 12.17 Flow diagram for CSMA/CA



12-2 CONTROLLED ACCESS

*In **controlled access**, the stations consult one another to find which station has the right to send. A station cannot send unless it has been authorized by other stations. We discuss three popular controlled-access methods.*

Topics discussed in this section:

Reservation

Polling

Token Passing

Figure 12.18 Reservation access method




Figure 12.19 Select and poll functions in polling access method








Figure 12.20 *Logical ring and physical topology in token-passing access method*




a. Physical ring



b. Dual ring



c. Bus ring



d. Star ring

12-3 CHANNELIZATION


Channelization is a multiple-access method in which the available bandwidth of a link is shared in time, frequency, or through code, between different stations. In this section, we discuss three channelization protocols.

Topics discussed in this section:

Frequency-Division Multiple Access (FDMA)

Time-Division Multiple Access (TDMA)


Code-Division Multiple Access (CDMA)




Note

We see the application of all these methods in Chapter 16 when we discuss cellular phone systems.

Figure 12.21 Frequency-division multiple access (FDMA)







Note

In FDMA, the available bandwidth of the common channel is divided into bands that are separated by guard bands.


Figure 12.22 Time-division multiple access (TDMA)





Note

In TDMA, the bandwidth is just one channel that is timeshared between different stations.



Note

In CDMA, one channel carries all transmissions simultaneously.

Figure 12.23 Simple idea of communication with code




Figure 12.24 *Chip sequences*

C_1

[+1 +1 +1 +1]

C_2

[+1 -1 +1 -1]

C_3

[+1 +1 -1 -1]

C_4

[+1 -1 -1 +1]

Figure 12.25 *Data representation in CDMA*



Figure 12.26 Sharing channel in CDMA




Figure 12.27 Digital signal created by four stations in CDMA




Figure 12.28 Decoding of the composite signal for one in CDMA




Figure 12.29 General rule and examples of creating Walsh tables

$$W_1 = \begin{bmatrix} +1 \end{bmatrix}$$

$$W_{2N} = \begin{bmatrix} W_N & W_N \\ W_N & \overline{W_N} \end{bmatrix}$$


a. Two basic rules

$$W_1 = \begin{bmatrix} +1 \end{bmatrix}$$

$$W_2 = \begin{bmatrix} +1 & +1 \\ +1 & -1 \end{bmatrix}$$


$$W_4 = \begin{bmatrix} +1 & +1 & +1 & +1 \\ +1 & -1 & +1 & -1 \\ +1 & +1 & -1 & -1 \\ +1 & -1 & -1 & +1 \end{bmatrix}$$

b. Generation of W_1 , W_2 , and W_4



Note

The number of sequences in a Walsh table needs to be $N = 2^m$.



Example 12.6

Find the chips for a network with

- a. Two stations b. Four stations**

Solution


We can use the rows of W_2 and W_4 in Figure 12.29:

- a. For a two-station network, we have**

$$[+1 \ +1] \text{ and } [+1 \ -1].$$

- b. For a four-station network we have**

$$[+1 \ +1 \ +1 \ +1], \quad [+1 \ -1 \ +1 \ -1], \\ [+1 \ +1 \ -1 \ -1], \text{ and } [+1 \ -1 \ -1 \ +1].$$




Example 12.7

What is the number of sequences if we have 90 stations in our network?

Solution

The number of sequences needs to be 2^m . We need to choose $m = 7$ and $N = 2^7$ or 128. We can then use 90 of the sequences as the chips.



Example 12.8


Prove that a receiving station can get the data sent by a specific sender if it multiplies the entire data on the channel by the sender's chip code and then divides it by the number of stations.

Solution

Let us prove this for the first station, using our previous four-station example. We can say that the data on the channel

$$D = (d_1 \cdot c_1 + d_2 \cdot c_2 + d_3 \cdot c_3 + d_4 \cdot c_4).$$

The receiver which wants to get the data sent by station 1 multiplies these data by c_1 .



Example 12.8 (continued)

$$\begin{aligned}D \cdot c_1 &= (d_1 \cdot c_1 + d_2 \cdot c_2 + d_3 \cdot c_3 + d_4 \cdot c_4) \cdot c_1 \\&= d_1 \cdot c_1 \cdot c_1 + d_2 \cdot c_2 \cdot c_1 + d_3 \cdot c_3 \cdot c_1 + d_4 \cdot c_4 \cdot c_1 \\&= d_1 \times N + d_2 \times 0 + d_3 \times 0 + d_4 \times 0 \\&= d_1 \times N\end{aligned}$$

When we divide the result by N , we get d_1 .



Data Communications and Networking

Fourth Edition

Forouzan

Chapter 13

Wired LANs: Ethernet

13-1 IEEE STANDARDS

In 1985, the Computer Society of the IEEE started a project, called Project 802, to set standards to enable intercommunication among equipment from a variety of manufacturers. Project 802 is a way of specifying functions of the physical layer and the data link layer of major LAN protocols.

Topics discussed in this section:

Data Link Layer
Physical Layer

Figure 13.1 IEEE standard for LANs

LLC: Logical link control

MAC: Media access control





Figure 13.2 HDLC frame compared with LLC and MAC frames

DSAP: Destination service access point

SSAP: Source service access point



13-2 STANDARD ETHERNET

The original Ethernet was created in 1976 at Xerox's Palo Alto Research Center (PARC). Since then, it has gone through four generations. We briefly discuss the Standard (or traditional) Ethernet in this section.

Topics discussed in this section:

MAC Sublayer

Physical Layer

Figure 13.3 *Ethernet evolution through four generations*




Figure 13.4 802.3 MAC frame

Preamble: 56 bits of alternating 1s and 0s.

SFD: Start frame delimiter, flag (10101011)






Figure 13.5 *Minimum and maximum lengths*





Note

Frame length:

Minimum: 64 bytes (512 bits)


Maximum: 1518 bytes (12,144 bits)


Figure 13.6 *Example of an Ethernet address in hexadecimal notation*

06 : 01 : 02 : 01 : 2C : 4B

6 bytes = 12 hex digits = 48 bits

Figure 13.7 *Unicast and multicast addresses*






Note


The least significant bit of the first byte defines the type of address.

**If the bit is 0, the address is unicast;
otherwise, it is multicast.**



Note

The broadcast destination address is a special case of the multicast address in which all bits are 1s.



Example 13.1


Define the type of the following destination addresses:

- a.** 4A:30:10:21:10:1A
- b.** 47:20:1B:2E:08:EE
- c.** FF:FF:FF:FF:FF:FF

Solution

To find the type of the address, we need to look at the second hexadecimal digit from the left. If it is even, the address is unicast. If it is odd, the address is multicast. If all digits are F's, the address is broadcast. Therefore, we have the following:

- a.** *This is a unicast address because A in binary is 1010.*
- b.** *This is a multicast address because 7 in binary is 0111.*
- c.** *This is a broadcast address because all digits are F's.*



Example 13.2

Show how the address **47:20:1B:2E:08:EE** is sent out on line.

Solution

The address is sent left-to-right, byte by byte; for each byte, it is sent right-to-left, bit by bit, as shown below:



11100010 00000100 11011000 01110100 00010000 01110111

Figure 13.8 *Categories of Standard Ethernet*




Figure 13.9 *Encoding in a Standard Ethernet implementation*




Figure 13.10 *10Base5 implementation*




Figure 13.11 *10Base2 implementation*




Figure 13.12 10Base-T implementation




Figure 13.13 10Base-F implementation




Table 13.1 Summary of Standard Ethernet implementations

<i>Characteristics</i>	<i>10Base5</i>	<i>10Base2</i>	<i>10Base-T</i>	<i>10Base-F</i>
Media	Thick coaxial cable	Thin coaxial cable	2 UTP	2 Fiber
Maximum length	500 m	185 m	100 m	2000 m
Line encoding	Manchester	Manchester	Manchester	Manchester

13-3 CHANGES IN THE STANDARD

The 10-Mbps Standard Ethernet has gone through several changes before moving to the higher data rates. These changes actually opened the road to the evolution of the Ethernet to become compatible with other high-data-rate LANs.


Topics discussed in this section:

Bridged Ethernet


Switched Ethernet

Full-Duplex Ethernet

Figure 13.14 Sharing bandwidth




a. First station




b. Second station

Figure 13.15 *A network with and without a bridge*



a. Without bridging



b. With bridging

Figure 13.16 Collision domains in an unbridged network and a bridged network




Figure 13.17 *Switched Ethernet*





Figure 13.18 Full-duplex switched Ethernet




13-4 FAST ETHERNET

Fast Ethernet was designed to compete with LAN protocols such as FDDI or Fiber Channel. IEEE created Fast Ethernet under the name 802.3u. Fast Ethernet is backward-compatible with Standard Ethernet, but it can transmit data 10 times faster at a rate of 100 Mbps.


Topics discussed in this section:

MAC Sublayer
Physical Layer

Figure 13.19 *Fast Ethernet topology*



a. Point-to-point



b. Star

Figure 13.20 *Fast Ethernet implementations*




Figure 13.21 Encoding for Fast Ethernet implementation




Table 13.2 *Summary of Fast Ethernet implementations*

<i>Characteristics</i>	<i>100Base-TX</i>	<i>100Base-FX</i>	<i>100Base-T4</i>
Media	Cat 5 UTP or STP	Fiber	Cat 4 UTP
Number of wires	2	2	4
Maximum length	100 m	100 m	100 m
Block encoding	4B/5B	4B/5B	
Line encoding	MLT-3	NRZ-I	8B/6T

13-5 GIGABIT ETHERNET


The need for an even higher data rate resulted in the design of the Gigabit Ethernet protocol (1000 Mbps). The IEEE committee calls the standard 802.3z.

Topics discussed in this section:

MAC Sublayer

Physical Layer


Ten-Gigabit Ethernet




Note

In the full-duplex mode of Gigabit Ethernet, there is no collision; the maximum length of the cable is determined by the signal attenuation in the cable.


Figure 13.22 *Topologies of Gigabit Ethernet*




a. Point-to-point



b. Star



c. Two stars



d. Hierarchy of stars

Figure 13.23 *Gigabit Ethernet implementations*




Figure 13.24 Encoding in Gigabit Ethernet implementations




Table 13.3 Summary of Gigabit Ethernet implementations

<i>Characteristics</i>	<i>1000Base-SX</i>	<i>1000Base-LX</i>	<i>1000Base-CX</i>	<i>1000Base-T</i>
Media	Fiber short-wave	Fiber long-wave	STP	Cat 5 UTP
Number of wires	2	2	2	4
Maximum length	550 m	5000 m	25 m	100 m
Block encoding	8B/10B	8B/10B	8B/10B	
Line encoding	NRZ	NRZ	NRZ	4D-PAM5

Table 13.4 Summary of Ten-Gigabit Ethernet implementations

<i>Characteristics</i>	<i>10GBase-S</i>	<i>10GBase-L</i>	<i>10GBase-E</i>
Media	Short-wave 850-nm multimode	Long-wave 1310-nm single mode	Extended 1550-mm single mode
Maximum length	300 m	10 km	40 km



Data Communications and Networking

Fourth Edition

Forouzan

Chapter 14

Wireless LANs

14-1 IEEE 802.11


IEEE has defined the specifications for a wireless LAN, called IEEE 802.11, which covers the physical and data link layers.

Topics discussed in this section:

Architecture

MAC Sublayer

Physical Layer



Note

A BSS without an AP is called an ad hoc network;

a BSS with an AP is called an infrastructure network.

Figure 14.1 Basic service sets (BSSs)

BSS: Basic service set

AP: Access point




Figure 14.2 *Extended service sets (ESSs)*

ESS: Extended service set

BSS: Basic service set

AP: Access point




Figure 14.3 MAC layers in IEEE 802.11 standard




Figure 14.4 CSMA/CA flowchart




Figure 14.5 CSMA/CA and NAV




Figure 14.6 Example of repetition interval




Figure 14.7 *Frame format*




Table 14.1 *Subfields in FC field*

Field	Explanation
Version	Current version is 0
Type	Type of information: management (00), control (01), or data (10)
Subtype	Subtype of each type (see Table 14.2)
To DS	Defined later
From DS	Defined later
More flag	When set to 1, means more fragments
Retry	When set to 1, means retransmitted frame
Pwr mgt	When set to 1, means station is in power management mode
More data	When set to 1, means station has more data to send
WEP	Wired equivalent privacy (encryption implemented)
Rsvd	Reserved

Figure 14.8 *Control frames*






Table 14.2 *Values of subfields in control frames*

<i>Subtype</i>	<i>Meaning</i>
1011	Request to send (RTS)
1100	Clear to send (CTS)
1101	Acknowledgment (ACK)


Table 14.3 Addresses

To DS	From DS	Address 1	Address 2	Address 3	Address 4
0	0	Destination	Source	BSS ID	N/A
0	1	Destination	Sending AP	Source	N/A
1	0	Receiving AP	Source	Destination	N/A
1	1	Receiving AP	Sending AP	Destination	Source


Figure 14.9 Addressing mechanisms




a. Case 1



b. Case 2




c. Case 3




d. Case 4

Figure 14.10 *Hidden station problem*



B and C are hidden from each other with respect to A.



Note

**The CTS frame in CSMA/CA handshake
can prevent collision from
a hidden station.**

Figure 14.11 *Use of handshaking to prevent hidden station problem*




Figure 14.12 Exposed station problem




Figure 14.13 Use of handshaking in exposed station problem




Table 14.4 Physical layers

<i>IEEE</i>	<i>Technique</i>	<i>Band</i>	<i>Modulation</i>	<i>Rate (Mbps)</i>
802.11	FHSS	2.4 GHz	FSK	1 and 2
	DSSS	2.4 GHz	PSK	1 and 2
		Infrared	PPM	1 and 2
802.11a	OFDM	5.725 GHz	PSK or QAM	6 to 54
802.11b	DSSS	2.4 GHz	PSK	5.5 and 11
802.11g	OFDM	2.4 GHz	Different	22 and 54

Figure 14.14 Industrial, scientific, and medical (ISM) band




Figure 14.15 Physical layer of IEEE 802.11 FHSS




Figure 14.16 Physical layer of IEEE 802.11 DSSS




Figure 14.17 Physical layer of IEEE 802.11 infrared





Figure 14.18 Physical layer of IEEE 802.11b



14-2 BLUETOOTH

Bluetooth is a wireless LAN technology designed to connect devices of different functions such as telephones, notebooks, computers, cameras, printers, coffee makers, and so on. A Bluetooth LAN is an ad hoc network, which means that the network is formed spontaneously.

Topics discussed in this section:

Architecture

Bluetooth Layers

Baseband Layer

L2CAP

Figure 14.19 Piconet




Figure 14.20 Scatternet




Figure 14.21 *Bluetooth layers*




Figure 14.22 Single-secondary communication




Figure 14.23 *Multiple-secondary communication*




Figure 14.24 *Frame format types*




Figure 14.25 *L2CAP data packet format*

