Performance of Matched Filters and Correlators

&

Line Code

ID	الاسم
19016377	محمد سامي محمد عبدالعزيز
19015660	رشاد السيد ابراهيم احمد
19015336	تسنيم عبدالصمد رزق محمد

Part 1

```
clc; clear all; close all;
  %% (1) Simulation Parameters
  numBits = le5;
                    %bits number
  snrRange = 0:2:30; %SNR(0,2,4,6,...,30) dB
  m user=input('Enter the Number of samples that represents waveform : ');
  if isempty(m user)
     numSamples=20; %defualt number of samples
  else
     numSamples=m user;
  end
  samplingInstant = 20;
  % Generate rectangular pulse sl(t)
  Amp sl = input('Enter an amplitude number for sl(t) : ');
  if isempty(Amp sl)
     s1 = ones(1,numSamples);
  else
         s1 = Amp s1 * ones(1,numSamples);
  end
  % Generate rectangular pulse s2(t)
  Amp s2 = input('Enter an amplitude number for s2(t) : ');
  if isempty(Amp s2)
     s2 = zeros(1,numSamples); %defualt
  else
          s2 = Amp s2 * ones(1,numSamples);
  end
  receiverType = {'Matched Filter', 'Correlator'};
  %% (2) Generate random binary data vector
  bits = randi([0 1], 1, numBits); % Generate Random Binary Data Vector
 %% (3) Represent Bits with Proper Waveform (20 sample for each) & calculate power
 waveform=repelem(bits,numSamples);
 Powerr = 1/(numBits*numSamples) * (sum(waveform.^2)) % calculate power ------>
 <del>88</del> .....
 BER MF=zeros(1, length(snrRange)); %array for BER valuee at every SNR
p for SNR i = 1:length(snrRange)
 %% (4) Apply noise to samples & calculate noise power based on SNR
 SNR=snrRange(SNR i);
 ReSequence = awgn(bits, SNR, 'measured'); % recived waveform with noise
                                     SNRdB=10*log_10(snr)
 SNR not dB = 10^(SNR/10); % SNR ratio
 sl power = Amp s1^2;
 noise power(SNR i) = sl power/SNR not dB
 %% (5) Apply convolution process in the receiver
 % matched
 filter=fliplr(sl - s2);
                              FL=length(filter); %filter length
 output_MF = zeros(1, (2*20-1)*numBits);
```


```
%% (5) Apply convolution process in the receiver
% matched
filter=fliplr(sl - s2);
                               FL=length(filter); %filter length
output MF = zeros(1, (2*20-1)*numBits);
| for i = 0:numBits-1
    Bit 20 = ReSequence((i*20)+1:(i+1)*20);
                                                    %take 20 samples
    conv_20 = conv(Bit_20, filter); %length = (20+20-1) = 39
    output MF( (FL+numSamples-1)*i+1: (FL+numSamples-1)*i+length(conv_20) ) = conv_20;
                (20+20-1) = 39
                                        (1:39 40:78 79:. ....)
end
% Correlator Receiver
    y_t = zeros(1, numBits);
 q=s1 - s2;
     for k=1:numBits
    y t = sum(ReSequence(((k-1)*numSamples+1:k*numSamples).*g));
    end
% simple detector
| for i = 1:1:length(bits)
 S t(i) = ReSequence(i*numSamples);
end
%% (6) Sample the output of the Matched filter
sampledOutput MF = output MF(numSamples:(samplingInstant+numSamples)-1:end);
% take sample num 20 every 39 samples
 %% (7) Decide whether the recived seq is 1 or 0
                                                        ક ()
                                                                  ---->
  %sample detector
  Vth = (s1(10)+s2(10))/2;
  rx_bits_s = S_t >= Vth; % 1 or 0
% '''matched'''
  Vth_m_c =mean(sampledOutput_MF);
  detectedBits MF = sampledOutput MF >= Vth; % 1 or 0
  % '''CorrelatorMake''' decision based on threshold
  rx_bits_c = y_t >= Vth; % 1 or 0
  %% (8,9) calculate number of errors, Save the BER of each SNR in matrix
  numErrorsMF = biterr(bits, detectedBits MF);
  BER=numErrorsMF/numBits;
  BER_MF(SNR_i) =BER;
  if BER==0
      fprintf('MF BER=0 at SNR= %d', SNR);
  errors(SNR i) = sum(xor(bits,rx bits c));
      BER c(SNR_i) = errors(SNR_i)/numBits;
  error(SNR i) = sum(xor(bits,rx bits s));
      BER S(SNR i) = error(SNR i)/numBits;
  end
  %BER MF
          Plot the BER curve against SNR
  %% (10)
  semilogy(snrRange, BER_S, 'r-x');
  xlabel('SNR (dB)');
  ylabel('BER');
  title('Simple Detector SNR & BER relation');
```


```
semilogy(snrRange, BER_MF, 'b-x');
xlabel('SNR (dB)');
ylabel('BER');
title('Matched Filter SNR & BER relation');
figure;
semilogy(snrRange, BER_c, 'g-o');
xlabel('SNR (dB)');
ylabel('BER');
title('Matched Filter SNR & BER relation');
figure;
semilogy(snrRange, BER_c, 'g-o');
hold on;
semilogy(snrRange, BER_MF, 'b-x');
hold on;
semilogy(snrRange, BER S, 'r-x');
xlabel('SNR (dB)');
ylabel('BER');
title('Matched Filter & Correlated SNR & BER relation');
```

Plot

a matched filter will provide a lower bit error rate than a simple detector for the same level of noise.

transmitted power =0.5027





Simple Detector.

A Simple detector is a device or circuit that is used to detect the presence of a digital signal and to recover the original information bits from the received signal. The main function of a detector is to distinguish between the two possible signal levels, which are typically represented as binary 1 and binary 0

Matched Detector

A matched detector is a type of detector used in digital communication systems to recover the transmitted data from the received signal. The matched detector is designed to maximize the signal-to-noise ratio and minimize the probability of errors in the received data.

The advantage of the matched detector is that it maximizes the signal-to-noise ratio, which results in better performance and lower error rates. This is because the reference signal is optimized to match the channel characteristics, and therefore provides the best possible match between the transmitted and received signals

correlator Detector

A correlator detector is a type of detector used in digital communications systems to detect and recover the transmitted data from the received signal. The correlator detector works by correlating the received signal with a known signal to extract the transmitted information.

The output of the correlator is a correlation function that indicates the presence and timing of the signal

Part 2

Line code

```
n = 10;
  % Set pulse duration and sampling rate
            % Pulse duration in seconds
  T = 1;
  fs = 100;
                    % Sampling rate in Hz
  t = 0:1/fs:T-1/fs; % Time vector for one pulse
  % Generate random bits
  bits = randi([0 1], 1, n)
  %% -----Non return zero inverted -----
  NRZ I = zeros(l, length(bits)*length(t));
  x=-1;
p for i = 1:length(bits)
      if bits(i) ==1
          NRZ I((i-1)*length(t)+l:(i)*length(t)) = -x;
          x=-x;
      else
          NRZ I((i-1)*length(t)+l:(i)*length(t)) = x;
      end
  end
  plot(NRZ_I, 'LineWidth', 2);
  axis([0 length(NRZ_I) -1.5 1.5]);
  grid on;
  xlabel('Time');
  ylabel('Amplitude');
  title('NRZ_Inverted ');
 %% ----- Polar
            ---- NRZ
 Polar_NRZ = zeros(1, length(bits)*length(t));
p for i = 1:length(bits)
     if bits(i) == 1
         Polar NRZ ((i-1)*length(t)+l:i*length(t)) = 1;
         Polar NRZ ((i-1)*length(t)+1:i*length(t)) = -1;
     end
end
 subplot (4,1,3);
 plot(Polar NRZ , 'LineWidth', 2);
 axis([0 length(Polar NRZ) -1.5 1.5]);
 grid on;
 xlabel('Time');
 ylabel('Amplitude');
 title('Polar NRZ ');
 %----- RZ
 Polar RZ = zeros(1, length(bits)*length(t));
 s=length(Polar_RZ);
p for i = 1:length(bits)
     if bits(i) == 1
            Polar RZ((i-1)*length(t)+1:i*length(t)-50) =1;
          Polar RZ((i-1)*length(t)+1:i*length(t)-50)=-1;
     end
l end
```


```
subplot(4,1,4);
plot(Polar_RZ, 'LineWidth', 2);
 axis([0 s -1.5 1.5]);
 grid on;
 xlabel('Time');
 ylabel('Amplitude');
 title('Polar RZ ');
 88
       Bipolar
    ----- NR2
 Biolar_NRZ = zeros(1, length(bits)*length(t));
 x=1;
for i = 1:length(bits)
     if bits(i) == 1
          Biolar_NRZ((i-1)*length(t)+l:(i)*length(t)) = x;
            x = -x;
     else
         Biolar_NRZ((i-1)*length(t)+l:i*length(t)) = 0;
 end
 figure
 subplot (3,1,1);
 plot(Biolar_NRZ, 'LineWidth', 2);
 axis([0 length(Biolar_NRZ) -1.5 1.5]);
 grid on;
 xlabel('Time');
 ylabel('Amplitude');
 title('Bipolar NRZ ');
                    ---- RZ --
  Biolar RZ = zeros(1, length(bits)*length(t));
  s=length(Biolar RZ);
p for i = 1:length(bits)
      if bits(i) == 1
             Biolar RZ((i-1)*length(t)+1:i*length(t)-50) =c;
             c=-c:
      else
           Biolar RZ((i-1)*length(t)+1:i*length(t)-50)=0;
      end
 end
  subplot (3,1,2);
  plot(Biolar RZ, 'LineWidth', 2);
  axis([0 s - \overline{1.5} 1.5]);
  grid on;
  xlabel('Time');
  vlabel('Amplitude');
  title('Bipolar RZ ');
                       ----- Mancheseter -----
   Mancheseter = zeros(1, length(bits)*length(t));
   s=length (Mancheseter);
  for i = 1:length(bits)
       if bits(i) == 1
              Mancheseter((i-1)*length(t)+1:i*length(t)-50) =1;
              Mancheseter(i*length(t)-50+1:i*length(t)) =-1;
        else
            Mancheseter((i-1)*length(t)+1:i*length(t)-50) =-1;
              Mancheseter(i*length(t)-50+1:i*length(t)) =1;
        end
  end
   subplot (3, 1, 3);
   plot (Mancheseter, 'LineWidth', 2);
   axis([0 s -1.5 1.5]);
   grid on;
   xlabel('Time');
   ylabel('Amplitude');
   title('Manchester NRZ ');
```


```
-----MLT 3-----
 MLT3 = zeros(1, length(bits)*length(t));
 prev value=[ 0 1 0 -1 ];
 pulse=ones(1,length(t));
 Count=1;
p for i = 1:length(bits)
     if bits(i) == 0
         MLT3((i-1)*length(t)+1:i*length(t)) =prev_value(Count)*pulse;
     else
         Count=Count+1;
             if Count>4 %because the size of prev value is 4 and repeated continuous
             Count=1;
             end
         MLT3((i-1)*length(t)+1:i*length(t)) =prev_value(Count)*pulse;
     end
     end
 % Plot the modulated signals
 figure
 plot( MLT3, 'LineWidth', 2);
 axis([0 length(MLT3) -1.5 1.5]);
 grid on;
 xlabel('Time');
 ylabel('Amplitude');
 title('MLT 3');
```

Plots:

bits =


1 0 1 0 0 1 1 1 0 0






PSD

```
% Set pulse duration and sampling rate
T = 1;
                   % Pulse duration in seconds
fs = 100;
                    % Sampling rate in Hz
t = 0:1/fs:T-1/fs;
f=0:0.001:2;
Tb = 1;
A=1;
x=f*Tb;
%% Polar NRZ
PSD Pol NRZ=A.^2*Tb*(sinc(x).*sinc(x));
figure
subplot (4,1,1);
plot(f,PSD_Pol NRZ,'r')
xlabel('f ---->')
ylabel('P(f) ---->')
title('Non-return to zero ');
%% Polar NRZi
PSD Pol NRZ=A.^2*Tb*(sinc(x).*sinc(x));
subplot (4,1,2);
plot(f, PSD Pol NRZ, 'r')
xlabel('f ---->')
ylabel('P(f) ---
title('Non-return to zero inverted ');
   Polar RZ
PSD Pol RZ=A.^2*0.25*Tb*(sinc(x).*sinc(x));
subplot (4,1,3);
plot(f, PSD Pol RZ, 'r')
xlabel('f --->')
ylabel('P(f) ---->')
title('Return to zero ');
%% Biolar NRZ
PSD Bipol NRZ=A.^2*Tb*(sinc(x)).^2.*(sin(pi*x)).^2;
subplot (4,1,4);
plot(f, PSD Bipol NRZ, 'b');
xlabel('f ---->')
ylabel('P(f) ---->')
title('AMI ');
%% Manchester NRZ
PSD Manchester = A.^2*Tb*(sinc(x/2)).^2.*(sin(pi*x/2)).^2;
figure
subplot (2,1,1);
plot(f,PSD Manchester,'bl')
xlabel('f ---->')
ylabel('P(f) ---->')
title('PSD for Manchester NRZ ');
<del>8</del>% MLT3
PSD MLT3=A.^2*Tb*(sinc(x/2)).^2.*(cos(pi*x)).^2;
subplot(2,1,2);
plot(f,PSD_MLT3,'bl');
xlabel('f ---->')
ylabel('P(f) ---->')
title('MLT 3');
```



```
Another soln PSD:
   %% --- NRZ-Inverted
  figure
  subplot(3,1,1)
  x=plot(periodogram(NRZ_I,[],'centered',512,100));
  title('NRZ-Inverted')
  %% --- NRZ
  subplot(3,1,2)
  x=plot( periodogram(Polar_NRZ,[],'centered',512,100));
  title('NRZ')
  %% --- Rz
  subplot (3, 1, 3)
  x=plot( periodogram(Polar_RZ,[],'centered',512,100));
  title('RZ')
   %% --- AMI
  figure
  subplot(3,1,1)
  x=plot( periodogram(Biolar NRZ,[],'centered',512,100));
  title('AMI')
  %% --- Mancheseter
  subplot(3,1,2)
  x=plot( periodogram(Mancheseter,[],'centered',512,100));
  title('Mancheseter')
  %% --- MLT3
  subplot(3,1,3)
  x=plot( periodogram(MLT3,[],'centered',512,100));
  title('MLT3')
                                             NRZ-Inverted
                   100
                                 200
                                                300
                                                              400
                                                                             500
                                                                                           600
                                               NRZ
   20
   15
   10
                   100
                                                300
                                                                                           600
                                                RZ
                   100
                                 200
                                                300
                                                              400
                                                                             500
                                                                                           600
```



Comments:

notes:

- In NRZ line coding, a binary 0 is represented by a constant "0" voltage level, while a binary "1" is represented by a constant non-zero voltage level.

In RZ line coding, a binary "0" is represented by a zero voltage level, while a binary "1" is represented by a non-zero voltage level that returns to zero midway through the bit duration.

2- Polar:

Polar line codes are a type of line code that uses a positive signal represents a logical 1 and a negative signal represents a logical 0.

$$+V >> 1$$
 $-V >> 0$

Advantages:

- 1- Better Bandwidth Efficiency: Polar line codes are more efficient than unipolar line codes, as they use less bandwidth to transmit the same amount of data.
- 2- No DC component: Polar NRZ has no DC component, which makes it suitable for long-distance transmission.
- 3-Simple: Polar NRZ is a simple line code to implement.
- 4-Easy to Implement: Polar RZ line codes are easy to implement and can be used in both hardware and software-based communication systems.
- 5- NRZ-I (NRZ-Inverted) helps in synchronization at the receiver due to use of transition to map binary '1'
- 6- Polar RZ solves synchronization problem observed in polar NRZ type.

Disadvantages:

- 1-Limited DC Balance: Polar RZ line codes do not have perfect DC balance, meaning that the number of positive and negative voltage transitions may not be equal.
- 2-Not self-clocking: Polar NRZ is not a self-clocking line code. This means that the receiver needs to have a separate clock signal to synchronize with the incoming data
- -3 Polar RZ requires two signal changes to encode bit and hence it occupies more bandwidth.

3- Bipolar

Bipolar line codes are a type of line code that uses two voltage levels to represent logical 1 and logical 0 bits. The voltage level is positive or negative for logical 1 bits and zero voltage for logical 0 bits.

$$0 \ V >> 0$$

AMI (alternate mark inversion): AMI is a type of bipolar line code that uses a mark-space ratio of 1:1. This means that the number of mark (positive) symbols is equal to the number of space (negative) symbols.

Advantages:

- 1-No DC component: Bipolar line codes have no DC component, which makes them suitable for long-distance transmission.
- 2-Efficient: Bipolar line codes are efficient in terms of bandwidth usage.
- 3-DC Balanced: Bipolar line codes maintain a balance of positive and negative voltage levels.
- 4-Good Bandwidth Efficiency: Bipolar line codes are more bandwidth efficient than unipolar line codes because they use two voltage levels to represent two binary states.
- 5- Single error detection is possible using bipolar coding technique.

Disadvantages:

- 1- More complex: Bipolar line codes are more complex to implement than unipolar line codes
- 2- No clock signal is present for use.
- 3- Bipolar line codes require more power to transmit the signal since they use both positive and negative voltage levels.

4- Manchester

Manchester encoding is a type of line coding used in digital communication systems to represent binary data using transitions in the signal. In Manchester encoding, a binary 1 is represented by a transition from a positive voltage level to a negative voltage level, while a binary 0 is represented by a transition from a negative voltage level to a positive voltage level

advantage:

- 1- Bandwidth efficiency: Manchester encoding is bandwidth-efficient, which means that it uses less bandwidth than other line codes, such as unipolar NRZ. This is because the signal level changes at the middle of each bit time, which reduces the amount of time that the signal is at a constant level
- 2-Noise immunity: Manchester encoding is more noise-immune than other line codes,
- 3- Self-clocking: Manchester encoding is self-clocking, which means that the receiver can recover the clock signal from the signal itself.

Disadvantages:

- 1- Complexity: Manchester encoding is more complex to implement than other line codes, because the receiver needs to be able to detect the transitions in the signal.
- 2- Higher Bandwidth: Manchester encoding requires a higher bandwidth than other encoding techniques because it uses more transitions per bit.
- 3- Lower Spectral Efficiency: Manchester encoding has a lower spectral efficiency than other encoding techniques because it requires more bandwidth to transmit the same amount of data.

MLT-3 encoding:

MLT-3 encoding uses three levels (+V, 0, -V) and three transition rules to move between levels. It is similar to NRZ-I. Following rules are applied to encode bit pattern in the example below.

- If the next bit is zero ('0'), there is no transition.
- If the next bit is one ('1) and current level is not zero '0', the next level is 0.
- If the next bit is one ('1) and current level is zero ('0'), the next level is the opposite of the last nonzero level

Advantages:

- 1- It has signal rate which is (1/4)th of the bit rate
- 2- Due to its signal shape, it reduces required bandwidth.

Disadvantages:

- 1- It does not support self-synchronization for long string of zeros ('0').
- 2- It is more complex than NRZ-I due to use of three levels and complex transition rules.

Which type of line code has the highest bandwidth?

The type of line code with the highest bandwidth is Manchester encoding.

-Manchester encoding is a line code in which the signal level changes at the middle of each bit time. This ensures that there is always a transition in the signal, which makes it easy for the receiver to synchronize with the signal. Manchester encoding is also self-clocking, which means that the receiver can recover the clock signal from the signal itself. Manchester encoding has a bandwidth of twice the data rate.

This is because the signal level changes twice per bit time.

Mention 2 other used line codes and explain them mentioning the main advantages and disadvantages:

Unipolar:

In this type of line coding, the signal is represented by a single voltage level, usually positive.

Advantages:

- 1- It is simple encoding technique.
- 2- Unipolar NRZ: It requires less bandwidth for transmission.
- 3- Unipolar RZ: The spectral line present at the symbol rate can be used as clock signal.

Disadvantages:

- 1- Average amplitude of unipolar encoded signal is nonzero. This creates DC component which shifts zero level of the signal which can't travel through some medium such as microwave.
- 2-Unipolar encoding leads to synchronization issue at the receiver when long string of ones and zeros are present in the binary data. This is because such data do not produce any transitions which may create problems in error detection and recovery.
- 3- It does not have any error handling technique (i.e. Error correction)
- 4- It suffers from "Signal Droop" issue due to presence of low frequency components.
- 5- Unipolar RZ consumes twice bandwidth than unipolar NRZ.

B8ZS (Bipolar with 8 Zero Substitution:

- This code replaces any sequence of eight zeros with a special pattern consisting of alternating positive and negative pulses.

Advantages:

- 1- The coded signal does not contain D.C. component
- 2- It maintain synchronization

Disadvantages:

1- its complexity as well as its requirement for special hardware for implementation