




# EMT Bootcamp for BES IBR Studies Part 1: Plant-Level Emphasis 8/3/23

An initiative spearheaded by the Solar Energy Technologies Office and the Wind Energy Technologies Office

Thomas.McDermott@pnnl.gov

# How an EMT solver works with trapezoidal integration and a system admittance (Y) matrix.



"Stamping these in" to the system Y matrix:


$$\begin{bmatrix} y_Z + y_R + y_L + y_C & -y_R & -y_L & -y_C & \mathbf{0} \\ -y_R & y_R & 0 & 0 & 0 \\ -y_L & 0 & y_L & 0 & 0 \\ -y_C & 0 & 0 & y_C & 0 \\ \mathbf{0} & 0 & 0 & 0 & y_Z \end{bmatrix} \begin{bmatrix} v_1 \\ v_2 \\ v_3 \\ v_4 \\ v_5 \end{bmatrix} = \begin{bmatrix} i_1 - h_k - h_L - h_C \\ 0 \\ h_L \\ h_C \\ -h_m \end{bmatrix}$$

# Constant-parameter distributed line models rely on modal decomposition matrices with real-number elements.

For three-phase balanced lines, instead of symmetrical components:

$$\mathbf{I_{p}} = \mathbf{T_{i}} \mathbf{I_{m}}$$


$$\mathbf{T_{i}} = \begin{pmatrix} 1/\sqrt{3} & 1/\sqrt{2} & 1/\sqrt{6} \\ 1/\sqrt{3} & -1/\sqrt{2} & 1/\sqrt{6} \\ 1/\sqrt{3} & 0 & -2/\sqrt{6} \end{pmatrix}$$







- Four balanced three-phase lines
  - Optionally with zero-sequence coupling
- A "twelve-phase" unbalanced line
  - Optionally add the ground wires
- Two double-circuits, and other combinations in between






### Representing faults and fault clearing operations.






- Voltage across  $C_{line}/2$  can't change instantaneously;  $\tau = 0.5*R_{gnd}*C_{line}$  governs the discharge.
- Current through  $L_{src}$  can't change instantaneously, so, interruption occurs at a natural current zero.
- C<sub>bus</sub> determines the transient recovery voltage (TRV).


# EMT transformer models include multiple windings, neutral connections, saturation, and high-frequency characteristics.



### What is the meaning of frequency dependence in lines?



Source: https://doi.org/10.1109/TDC.2008.4517264




# EMT machine models include stator flux transients, saturation, shaft torsionals and unbalanced operation.

For control block diagrams: see IEEE 421.5, **EHV Grid** Power System Dynamic Performance (PSDP) Governor Exciter Committee reports, your dynamics program Power System Stabilizer user manual, etc. GSU **Faults** HP LP1 LP2 **IP** Exc Gen  $\mathsf{T}_{\mathsf{exc}}$  $0.25 T_{m}$  $0.25\,T_{m}$  $0.25 T_{m}$  $0.25 T_{\rm m}$ 

Suggested references: <a href="https://doi.org/10.1109/TPWRD.2005.848725">https://doi.org/10.1109/61.473358</a> and <a href="https://doi.org/10.1109/61.517533">https://doi.org/10.1109/61.473358</a> and <a href="https://doi.org/10.1109/61.517533">https://doi.org/10.1109/61.517533</a>

# "Compact" model of a power electronic switching device; a diode with reverse recovery voltage and switching losses.



$$i(t) = \frac{(q_E - q_M)}{T_M}$$

$$0 = \frac{dq_M}{dt} + \frac{q_M}{\tau} - \frac{(q_E - q_M)}{T_M}$$


$$q_E = I_S \tau \left[ \exp(\frac{v}{nV_T}) - 1 \right]$$

$$\tau = \frac{Q_{rr}}{I_{fm}}$$

$$T_M = \frac{\tau T_{rr}}{T_{rr} - \tau}$$

Results are from Simplorer, which is a SPICE-like simulator with variable time step.


# An EMT IBR model adds fast control loops, protection functions, and vendor-proprietary code to the phasor-domain model.



Source: Andrew L. Isaacs, "EMT Model Intake and Quality Assurance", ESIG Webinar, 5/18/2023. Adapted with permission.

# There are many phase-locked loop implementations; their performance matters to simulation and in the real world.

A simple Synchronous Reference Frame (SRF) PLL works by driving  $V_q$  to zero.



$$K_p = \frac{\omega_{bw}}{V_{pk}}$$

$$K_i = K_p T_s \omega_{bw}^2$$

- Choose  $\theta_{bw}$ =188.5 and  $T_s$ =20ms
- Choose V<sub>pk</sub>=1 in per-unit system
- $K_p = 188.5$  and  $K_i = 134e3$

Second-Order Generalized Integrator (SOGI) Frequency-Locked Loop (FLL) is more robust.

- 1. Transform  $V_{abc}$  to  $V_{\alpha}$  and  $V_{\beta}$
- 2. Pass  $V_{\alpha}$  and  $V_{\beta}$  through separate quadrature signal generator (QSG)s, each using two integrators
  - These require an estimate of  $\omega$  from the FLL
- 3. Algebraically separate the positive and negative sequence components of  $V_{\alpha}$  and  $V_{\beta}$ 
  - Those 4 sequence components feed a gainnormalized FLL, which uses 1 integrator in estimating  $\omega$  for step 2
  - Integrating  $\omega$  to estimate  $\theta$
  - They also establish  $V_1$  and  $V_2$  if needed
- 4. Comparable to the possibly more popular DDSRF:
  - No trig function evaluations
  - Smoother response has been observed

# Simulation time and time step selection guidelines.

Factor	Shortest Tmax	Typical Dt
Natural frequency	2 – 10 cycles	20 per cycle
Line travel time	1 – 4 travel times	1-20 per travel time
Lightning surges	100 – 200 μs	$0.1 - 1 \mu s$
Cable switching surges	0.2 – 1 ms	1 – 20 μs
Capacitor switching	1 – 100 ms	10 – 100 μs
Short circuits	0.1 - 1 s	10 – 200 μs
Machine dynamics	0.5 - 5 s	100 – 1000 μs
Ferroresonance	0.1 - 1 s	10 – 50 μs
Steady state / Harmonics	50 – 500 ms	50 μs
Inverter-based resources	0.5 - 45  s	1 – 200 μs

#### **EMT References**

#### **Theory**

- 1. Juan A. Martinez-Velasco (ed.), *Transient Analysis of Power Systems: Solution Techniques, Tools and Applications*, IEEE Press, 2014.
- 2. Watson & Arrillaga, *Power Systems Electromagnetic Transients Simulation (2<sup>nd</sup> ed.)*, IET, 2018.

#### **IBR Behaviors**


- 1. Yazdani & Iravani, Voltage-Sourced Converters in Power Systems: Modeling, Control, and Applications, IEEE Press, 2010.
- 2. Blaabjerg, Control of Power Electronic Converters and Systems, v1-3, Academic Press, 2018-2021.

#### **Industry Reports**

- 1. PES-TR77, "Stability definitions and characterization of dynamic behavior in systems with high penetration of power electronic interfaced technologies", PSDPC, April 2020.
- 2. PES-TR106, "Trends in microgrid modeling for stability analysis", PSDPC, November 2022.
- 3. CIGRE TB 727, "Modeling of Inverter-Based Generation for Power System Dynamic Studies", 2018.
- 4. CIGRE TB 736, "Power system test cases for EMT-type simulation studies", 2018.
- 5. CIGRE TB 766, "Network Modelling for Harmonic Studies", 2019.
- 6. CIGRE TB 832, "Guide for electromagnetic transient studies involving VSC converters", 2021.


International Conference on Power System Transients: https://www.ipstconf.org/

# Platform and tool-independent post-processing with COMTRADE and Python.




### Producing and using COMTRADE files from two EMT tools.

 In PSCAD, the recorder is under "Data recorders Readers"




In EMTP, the recorder is under "Protection"



- COMTRADE processing options:
  - Bootcamp examples using <a href="https://github.com/dparrini/python-comtrade">https://github.com/dparrini/python-comtrade</a>
  - Plotting tool in your EMT simulator probably reads COMTRADE
  - Relay vendors and other "COMTRADE viewers" you might Google
  - <a href="https://www.mathworks.com/matlabcentral/fileexchange/15619-comtrade-reader">https://www.mathworks.com/matlabcentral/fileexchange/15619-comtrade-reader</a>

### Framework of the bootcamp's plant-level model and basic tests.



#### From P2800.2/D0.3 SG3

- 1. 10-s initialize; then 10-s flat run;  $P=P_{min}$  and  $ICR^*$ ; Q=0,  $\pm$  0.3287 ICR
- 2. UV ride-through:  $3\phi g$  fault; 0.16-s;  $Z_f = 0$  and  $Z_s$ ; P=ICR; Q=0,  $\pm$  0.3287 ICR A. Repeat for  $2\phi g$ ,  $2\phi$  and  $1\phi g$ ;  $Z_f = 0$  only
- 3. OV ride-through: 1.2 V for 1-s; P=ICR; Q=0, ± 0.3287 ICR


Suggested reference: https://sagroups.ieee.org/2800-2/

<sup>\*</sup> IBR continuous rating


## More plant-level control and response tests (P2800.2/D0.3\_SG3).

- 1.  $V_{ref}$ ,  $Q_{ref}$ , or pf<sub>ref</sub> change at ICR; +0.05 pu 5-15s; -0.05 pu 25-35s; run 45s
- 2. P<sub>ref</sub> change at ICR; 1 pu 0-5s; 0.5 pu 5-15s; 0.04 pu 15-25s; 1 pu 35-35s
- 3. Frequency RT at  $P_{min}$  and ICR, Q=0; +1.8 or -3.0 Hz from 5-25s; run 35s
- 4. Grid angle ride-through: ± 25°; P=P<sub>min</sub> and ICR; Q=0
- 5. Short-circuit ratio (SCR) ramp-down (informational); P=ICR;  $3\phi g$  fault with  $Z_f = 0$  every 5s; stable operation expected until SCR approaches 2.5

Range [s]	SCR
0-5	20
5-10	10
10-15	5
15-20	4
20-25	3
25-30	2.5
30-35	2
35-40	1.5
40-45	1




### Some important figures of merit expected from post-processing.



- Reaction time: duration from step input to changed output at same location
- Rise time: duration from 10% to 90% of the final settled output level
- <u>Settling time</u>: duration from step change to output stays within a settling band around final output level
- Overshoot: normalized amount by which the peak output exceeds final settled output level
- <u>RMS Error</u>: point-by-point root mean square difference from expected output (measurement, spec, another model)

Suggested reference: <a href="https://doi.org/10.1109/IEEESTD.2022.9762253">https://doi.org/10.1109/IEEESTD.2022.9762253</a>, especially the definitions.

## Damping ratio estimates: by overshoot or by log decrement.



By per-unit overshoot (O):

$$\zeta = \frac{-\ln(O)}{\sqrt{\pi^2 + \ln^2(O)}}$$

By log decrement:

$$\sigma = \frac{1}{n} \ln \left( \frac{Q_{peak-1}}{Q_{peak-n}} \right)$$

$$\zeta = \frac{1}{\sqrt{1 + \left(\frac{2\pi}{\sigma}\right)^2}}$$

ζ	Behavior
0	Purely oscillatory
< 1	Damped oscillations
1	Critically damped, i.e., no overshoot
> 1	Sluggish

Suggested reference: <a href="https://doi.org/10.1109/IEEESTD.2022.9762253">https://doi.org/10.1109/IEEESTD.2022.9762253</a>, Annex L.

### **Important Links and Instructions**

- Instructions, models, slides, videos, and other material: <a href="https://github.com/pnnl/i2x/tree/develop/emt-bootcamp">https://github.com/pnnl/i2x/tree/develop/emt-bootcamp</a>
- Direct questions about software operation to your tool vendor
- Post questions about the bootcamp materials here:
  - https://github.com/pnnl/i2x/issues/16
  - You may benefit from the experience of others this way
- Upcoming video and exercise releases (separate for each tool):
  - August 10: Comparing rotating machine and IBR behaviors in EMT
  - August 17: Comparing switching and average models
  - August 24: Automation of faults
  - August 31: Automation of IEEE P2800.2 type tests
  - September 7: Automation of waveform evaluations
- September 14, 2-4 p.m. Eastern time: System-level Emphasis