Red Bird Racing EVRT Vehicle Control Unit (VCU) (2025)

Project Documentation

Red Bird Racing EVRT

May 11, 2025

Contents

1	Introduction 1.1 Project Structure	2 2
2	Setup and Tuning	2
3	Debugging	3
4	Reverse Mode 4.1 Reverse Mode Logic	3 3 4 4
5	Source Code Overview 5.1 main.cpp	4 8 17 19 20 21
6	PlatformIO Configuration	21
7	Future Development	22
8	References	22

1 Introduction

This document provides an overview of the Red Bird Racing EVRT Vehicle Control Unit (VCU) (2025). The VCU firmware is designed to manage pedal input, CAN communication, and vehicle state transitions for our Formula Student electric race car.

1.1 Project Structure

The project is organized as follows:

```
+-- include
3
 +-- Debug.h
      +-- pinMap.h
      +-- README
6
      lib
      +-- Pedal
7
          +-- Pedal.cpp
          +-- Pedal.h
          +-- library.json
10
      +-- Queue
11
          +-- Queue.cpp
12
          +-- Queue.h
      +-- Signal_Processing
          +-- Signal_Processing.cpp
15
          +-- Signal_Processing.h
16
      +-- README
17
      src
      +-- main.cpp
 +-- test
      +-- README
 +-- platformio.ini
      .vscode
      +-- launch.json
24
      +-- extensions.json
      +-- c_cpp_properties.json
```

2 Setup and Tuning

- 1. Adjust pedal input constants in Pedal.h.
- 2. Flash the VCU firmware. Ensure the car is jacked up and powered off during this process.
- 3. Clear the area around the car, especially the rear.
- 4. Test the minimum and maximum pedal input voltages and adjust the constants accordingly.

3 Debugging

Debugging is performed using the serial monitor. Enable specific debug messages by setting flags in Debug.h. Note that enabling debugging may introduce delays due to the slow serial communication.

4 Reverse Mode

Reverse mode is implemented for testing purposes only and is prohibited in competition. The driver must hold the reverse button to engage reverse mode. Releasing the button places the car in neutral. The car would re-enter reverse mode if criteria are met; else forward mode is engaged if its criteria are met.

Important Notes:

- Do NOT use in actual competition!
- Rules 5.2.2.3: 禁止通过驱动装置反转车轮。
- Rough translation: It is prohibited to use the motor to turn the wheels backwards.

4.1 Reverse Mode Logic

The reverse mode logic in Pedal.cpp allows the driver to toggle between reverse and forward modes using a single button. Below is the updated workflow and key components:

4.1.1 Key Functions

- void pedal_can_frame_update(can_frame *tx_throttle_msg, unsigned long millis): Updates the CAN frame with the current throttle value and handles reverse mode logic. The reverse button toggles between reverse and forward modes:
 - If the reverse button is pressed, the mode toggles between reverse and forward.
 - If reverseMode is true, the buzzer is activated, and reverse torque is calculated.
- int calculateReverseTorque(float throttleVolt, float vehicleSpeed, int torqueRequested): Calculates the torque value for reverse mode with the following constraints:
 - The throttle voltage must be less than one-third of the maximum throttle voltage (MAX_THROTTLE_IN_VOLT / 3).
 - The vehicle speed must not exceed the reverse speed limit (REVERSE_SPEED_MAX).
 - The torque is scaled down to 30% of the requested torque to ensure reverse mode is slow and controllable.

If any of the constraints are violated, the torque is set to zero.

4.1.2 Reverse Mode Workflow

- 1. The reverse button state is read using digitalRead(reverse_pin).
- 2. If the reverse button is pressed, and conditions are met:
 - If the vehicle is in forward mode (reverseMode = false), it switches to reverse mode (reverseMode = true).
 - If the vehicle is in reverse mode (reverseMode = true), it switches to forward mode (reverseMode = false).

3. In reverse mode:

- A buzzer is activated with a periodic beep to alert nearby individuals. The cycle time is BUZZER_CYCLE_TIME milliseconds.
- The reverse torque is calculated using calculateReverseTorque.
- 4. The throttle torque value is updated and sent via CAN messages.
- 5. If the motor direction needs to be flipped (e.g., for forward mode), the torque value is negated.

4.1.3 Safety Notes

- Reverse mode is implemented for testing purposes only and should not be used in competition.
- Rules 5.2.2.3
- Rough translation: It is prohibited to use the motor to turn the wheels backwards.
- The reverse mode logic ensures that the vehicle operates safely by limiting throttle and speed in reverse mode.
- However, care should be taken any time the vehicle is maneuvering, or if the buzzer is heard.

5 Source Code Overview

5.1 main.cpp

The main file initializes the pedal, CAN communication, and state machine for the car. It handles transitions between states such as INIT, IN_STARTING_SEQUENCE, BUZZING, and DRIVE_MODE.

```
#include <Arduino.h>
#include "pinMap.h"

#include "Pedal.h"

#include <mcp2515.h>

#include "Debug.h"

// === Pin setup ===

// Pin setup for pedal pins are done by the constructor of Pedal object
```

```
9 uint8_t pin_out[4] = {LED1, LED2, LED3, BRAKE_OUT};
10 uint8_t pin_in[4] = {BTN1, BTN2, BTN3, BTN4};
12 // === CAN + Pedal ===
13 MCP2515 mcp2515 (CS CAN);
14 Pedal pedal;
15
16 struct can_frame tx_throttle_msg;
17 struct can_frame rx_msg;
18
 // For limiting the throttle update cycle
 // const int THROTTLE_UPDATE_PERIOD_MILLIS = 50; // Period of sending
     canbus signal
 // unsigned long final_throttle_time_millis = 0; // The last time sent a
     canbus message
23 /* === Car Status State Machine ===
24 Meaning of different car statuses
25 INIT (0): Just started the car
 IN_STARTING_SEQUENCE (1): 1st Transition state -- Driver holds the "Start"
      button and is on full brakes, lasts for STATUS_1_TIME_MILLIS
     milliseconds
27 BUZZING (2): 2nd Transition state -- Buzzer bussin, driver can release "
     Start" button and brakes
28 DRIVE MODE (3): Ready to drive -- Motor starts responding according to the
      driver pedal input. "Drive mode" LED lights up, indicating driver can
     press the throttle
 Separately, the following will be done outside the status checking part:
30
31 1. Before the "Drive mode" LED lights up, if the throttle pedal is pressed
      (Throttle input is not euqal to 0), the car_status will return to 0
32 2. Before the "Drive mode" LED lights up, the canbus will keep sending "O
     torque" messages to the motor
33
 Also, during status 0, 1, and 2, the VCU will keep sending "O torque"
     messages to the motor via CAN
35
 enum CarStatus
36
      INIT = 0,
38
      IN_STARTING_SEQUENCE = 1,
39
      BUZZING = 2,
40
      DRIVE_MODE = 3
41
42 };
43 CarStatus car_status = INIT;
44 unsigned long car_status_millis_counter = 0; // Millis counter for 1st and
     2nd transitionin states
                                               // The amount of time that the
45 const int STATUS_1_TIME_MILLIS = 2000;
      driver needs to hold the "Start" button and full brakes in order to
     activate driving mode
 const int BUSSIN_TIME_MILLIS = 2000;
                                         // The amount of time that the
      buzzer will buzz for
47
48 void setup()
49 {
      // Init pedals
50
      pedal = Pedal(APPS_5V, APPS_3V3, REVERSE_BUTTON, LED1, millis());
51
52
```

```
// Init input pins
53
       for (int i = 0; i < 4; i++)</pre>
54
           pinMode(pin_in[i], INPUT);
55
       // Init output pins
56
       for (int i = 0; i < 4; i++)</pre>
57
           pinMode(pin_out[i], OUTPUT);
58
59
       // Init mcp2515
       mcp2515.reset();
61
       mcp2515.setBitrate(CAN_500KBPS, MCP_8MHZ); // 8MHZ for testing on uno
62
       mcp2515.setNormalMode();
63
64
       // Init serial for testing if DEBUG flag is set to true
65
       if (DEBUG == true)
66
67
           while (!Serial)
69
           Serial.begin(9600);
70
       }
71
72
       DBGLN_STATUS("Entered State 0 (Idle)");
73
  }
74
75
  void loop()
76
77
       // Update pedal value
78
       pedal.pedal_update(millis());
79
80
81
       For the time being:
82
       BTN1 = "Start" button
       BTN2 = Brake pedal
84
       LED1 = Buzzer output
85
       LED2 = "Drive" mode indicator
86
       */
       DBG PEDAL ("Pedal Value: ");
88
       DBGLN_PEDAL(pedal.final_pedal_value);
89
90
       if (car_status == INIT)
92
           // car_status = 3; // For testing drive mode
93
           pedal.pedal_can_frame_stop_motor(&tx_throttle_msg);
95
           mcp2515.sendMessage(&tx_throttle_msg);
96
           DBGLN_CAN("Holding 0 torque during state 0");
97
98
           if (digitalRead(BTN1) == HIGH && digitalRead(BTN2) == HIGH) //
99
               Check if "Start" button and brake is fully pressed
           {
100
                car_status = IN_STARTING_SEQUENCE;
101
                car_status_millis_counter = millis();
102
                DBGLN_STATUS("Entered State 1");
103
           }
104
105
       else if (car_status == IN_STARTING_SEQUENCE)
106
107
           pedal.pedal_can_frame_stop_motor(&tx_throttle_msg);
108
           mcp2515.sendMessage(&tx_throttle_msg);
109
```

```
DBGLN_CAN("Holding 0 torque during state 1");
110
111
           if (digitalRead(BTN1) == LOW || digitalRead(BTN2) == LOW) // Check
112
               if "Start" button or brake is not fully pressed
113
               car_status = INIT;
114
                car_status_millis_counter = millis();
115
               DBGLN_STATUS("Entered State 0 (Idle)");
116
117
           else if (millis() - car_status_millis_counter >=
118
               STATUS_1_TIME_MILLIS) // Check if button held long enough
           {
119
               car_status = BUZZING;
120
               digitalWrite(LED1, HIGH); // Turn on buzzer
121
                car_status_millis_counter = millis();
122
               DBGLN_STATUS("Transition to State 2: Buzzer ON");
124
       }
125
       else if (car_status == BUZZING)
126
127
           pedal.pedal_can_frame_stop_motor(&tx_throttle_msg);
128
           mcp2515.sendMessage(&tx_throttle_msg);
129
           DBGLN_CAN("Holding 0 torque during state 2");
130
131
           if (millis() - car_status_millis_counter >= BUSSIN_TIME_MILLIS)
132
           {
133
               digitalWrite(LED2, HIGH); // Turn on "Drive" mode indicator
134
                                           // Turn off buzzer
               digitalWrite(LED1, LOW);
135
                car_status = DRIVE_MODE;
136
               DBGLN_STATUS("Transition to State 3: Drive mode");
137
           }
138
139
       else if (car_status == DRIVE_MODE)
140
141
           // In "Drive mode", car_status won't change, the driver either
142
               continue to drive, or shut off the car
           DBGLN STATUS("In Drive Mode");
143
       }
144
       else
145
       {
146
           // Error, idk wtf to do here
147
           DBGLN_STATUS("ERROR: Invalid car_status encountered!");
148
       }
149
150
       // Pedal update
151
       if (car_status == DRIVE_MODE)
152
       {
153
           // Send pedal value through canbus
154
           pedal.pedal_can_frame_update(&tx_throttle_msg, millis());
155
           // The following if block is needed only if we limit the lower
156
               bound for canbus cycle period
           // if (millis() - final_throttle_time_millis >=
157
               THROTTLE_UPDATE_PERIOD_MILLIS)
           // {
158
           //
                   mcp2515.sendMessage(&tx_throttle_msg);
159
           //
                   final_throttle_time_millis = millis();
160
           // }
161
           mcp2515.sendMessage(&tx_throttle_msg);
162
```

```
DBGLN_CAN("Throttle CAN frame sent");
163
       }
164
       else
165
166
           if (pedal.final_pedal_value > MIN_THROTTLE_OUT_VAL)
167
           {
168
                car_status = INIT;
169
                car_status_millis_counter = millis(); // Set to current time,
                   in case any counter relies on this
                pedal.pedal_can_frame_stop_motor(&tx_throttle_msg);
171
                mcp2515.sendMessage(&tx_throttle_msg);
172
                DBGLN_STATUS("Throttle pressed too early - Resetting to State 0
173
                   ");
           }
174
       }
175
       // mcp2515.sendMessage(&tx throttle msg);
177
       // uint32_t lastLEDtick = 0;
178
       // Optional RX handling (disabled for now)
179
       // if (mcp2515.readMessage(&rx_msg) == MCP2515::ERROR_OK)
180
       // {
181
       //
               // Commented out as currenlty no need to include receive
182
           functionality
              // if (rx_msg.can_id == 0x522)
183
                      for (int i = 0; i < 8; i++)
       //
              //
184
              //
                          digitalWrite(pin_out[i], (rx_msg.data[0] >> i) & 0x01
       //
185
          );
       // }
186
187
```

Listing 1: main.cpp

5.2 Pedal.cpp and Pedal.h

These files define the Pedal class, which encapsulates functionality for reading pedal input, filtering signals, and constructing CAN frames.

```
#include "Pedal.h"
 #include "Arduino.h"
 #include "Signal_Processing.cpp"
  #include "Debug.h"
  // Sinc function of size 128
  float SINC_128[128] = {0.017232, 0.002666, -0.013033, -0.026004, -0.032934,
      -0.031899, -0.022884, -0.007851, 0.009675, 0.025427,
                          0.035421, 0.036957, 0.029329, 0.014081, -0.005294,
                             -0.024137, -0.037732, -0.042472, -0.036792,
                             -0.021652,
                          -0.000402, 0.021937, 0.039841, 0.048626, 0.045647,
                             0.031053, 0.007888, -0.018512, -0.041722,
                             -0.055750,
                          -0.056553, -0.043139, -0.017994, 0.013320, 0.043353,
10
                              0.064476, 0.070758, 0.059540, 0.032321,
                             -0.005306,
                          -0.044714, -0.076126, -0.090908, -0.083781,
11
                             -0.054402, -0.007911, 0.045791, 0.093940,
                             0.123670, 0.125067,
```

```
0.093855, 0.033095, -0.046569, -0.128280, -0.191785,
12
                               -0.217229, -0.189201, -0.100224, 0.047040,
                              0.239389,
                          0.454649, 0.664997, 0.841471, 0.958851, 1, 0.958851,
                               0.841471, 0.664997, 0.454649, 0.239389,
                              0.047040,
                          -0.100224, -0.189201, -0.217229, -0.191785,
14
                              -0.128280, -0.046569, 0.033095, 0.093855,
                              0.125067, 0.123670,
                          0.093940, 0.045791, -0.007911, -0.054402, -0.083781,
15
                               -0.090908, -0.076126, -0.044714, -0.005306,
                              0.032321,
                          0.059540, 0.070758, 0.064476, 0.043353, 0.013320,
16
                              -0.017994, -0.043139, -0.056553, -0.055750,
                              -0.041722,
                          -0.018512, 0.007888, 0.031053, 0.045647, 0.048626,
                              0.039841, 0.021937, -0.000402, -0.021652,
                              -0.036792,
                          -0.042472, -0.037732, -0.024137, -0.005294,
                              0.014081, 0.029329, 0.036957, 0.035421, 0.025427,
                               0.009675,
                          -0.007851, -0.022884, -0.031899, -0.032934,
19
                              -0.026004, -0.013033};
20
 Pedal::Pedal()
21
      : input_pin_1(-1), input_pin_2(-1), reverse_pin(-1), buzzer_pin(-1),
22
         previous_millis(0), conversion_rate(0), fault(true),
         fault_force_stop(false) {}
23
 Pedal::Pedal(int input_pin_1, int input_pin_2, int reverse_pin, int
     buzzer_pin, unsigned long millis, unsigned short conversion_rate)
      : input_pin_1(input_pin_1), input_pin_2(input_pin_2), reverse_pin(
25
         reverse_pin), buzzer_pin(buzzer_pin), previous_millis(millis),
         conversion_rate(conversion_rate), fault(false), fault_force_stop(
         false)
  {
26
      // Init pins
27
      pinMode(input_pin_1, INPUT);
28
      pinMode(input_pin_2, INPUT);
      pinMode(buzzer_pin, OUTPUT);
30
      conversion_period = 1000 / conversion_rate;
31
32
      // Init ADC buffers
33
      for (int i = 0; i < ADC_BUFFER_SIZE; ++i)</pre>
34
35
          pedalValue_1.buffer[i] = 0;
36
          pedalValue_2.buffer[i] = 0;
      }
38
 }
39
  void Pedal::pedal_update(unsigned long millis)
41
42
      // If is time to update
43
      if (millis - previous_millis > conversion_period)
44
45
          // Updating the previous millis
46
          previous_millis = millis;
47
          // Record readings in buffer
```

```
pedalValue_1.push(analogRead(input_pin_1));
49
          pedalValue_2.push(analogRead(input_pin_2));
50
51
          // By default range of pedal 1 is APPS PEDAL 1 RANGE, pedal 2 is
52
              APPS PEDAL 2 RANGE;
53
          // this is current taking the direct array the circular queue
54
              writes into. Bad idea to do anything other than a simple average
          // if not using a linear filter, pass the pedalValue_1.
55
              getLinearBuffer() to the filter function to ensure the ordering
              is correct.
          // can also consider injecting the filter into the queue if need
56
          // depends on the hardware filter, reduce software filtering as
57
             much as possible
          int pedal_filtered_1 = round(AVG_filter<float>(pedalValue_1.buffer,
58
              ADC BUFFER SIZE));
          int pedal filtered 2 = round(AVG filter<float>(pedalValue 2.buffer,
59
               ADC_BUFFER_SIZE));
60
          // int pedal_filtered_1 = round(FIR_filter<float>(pedalValue_1.
61
              buffer, SINC_128, ADC_BUFFER_SIZE, 6.176445));
          // int pedal_filtered_2 = round(FIR_filter<float>(pedalValue_2.
62
              buffer, SINC_128, ADC_BUFFER_SIZE, 6.176445));
          final_pedal_value = pedal_filtered_1; // Only take in pedal 1 value
63
64
          DBG_PEDAL("Pedal 1: ");
65
          DBG_PEDAL(pedal_filtered_1);
66
67
          DBG_PEDAL(" | Pedal 2: ");
          DBG_PEDAL(pedal_filtered_2);
68
          DBG_PEDAL(" | Final: ");
69
          DBGLN_PEDAL(final_pedal_value);
70
71
          if (check_pedal_fault(pedal_filtered_1, pedal_filtered_2))
72
          {
73
              if (fault)
74
              { // Previous scan is already faulty
75
                   if (millis - fault_start_millis > 100)
76
                   { // Faulty for more than 100 ms
77
                       // TODO: Add code for alerting the faulty pedal, and
78
                          whatever else mandated in rules Ch.2 Section 12.8,
                          12.9
79
                       // Turning off the motor is achieved using another
80
                          digital pin, not via canbus, but will still send 0
                          torque can signals
                       fault_force_stop = true;
                       DBGLN_PEDAL("FAULT: Pedal mismatch persisted > 100ms!")
83
84
                       return;
85
                  }
86
              }
87
88
              else
89
              {
                   fault_start_millis = millis;
90
                   DBGLN_PEDAL("FAULT: Pedal mismatch started");
91
              }
```

```
93
                fault = true;
94
                return;
95
           }
96
       }
97
98
99
  void Pedal::pedal_can_frame_stop_motor(can_frame *tx_throttle_msg)
101
       tx_throttle_msg->can_id = 0x201;
102
       tx_throttle_msg->can_dlc = 3;
103
       tx_throttle_msg->data[0] = 0x90; // 0x90 for torque, 0x31 for speed
104
       tx_throttle_msg->data[1] = 0;
105
       tx_throttle_msg->data[2] = 0;
106
107
       DBGLN PEDAL ("CAN STOP");
108
109
110
  void Pedal::pedal_can_frame_update(can_frame *tx_throttle_msg, unsigned
111
      long millis)
  {
112
       if (fault_force_stop)
113
114
           pedal_can_frame_stop_motor(tx_throttle_msg);
115
           return;
116
117
       float throttle_volt = (float)final_pedal_value * APPS_PEDAL_1_RANGE /
           1024; // Converts most update pedal value to a float between OV and
119
       int16_t throttle_torque_val = 0;
120
121
       Between OV and THROTTLE_LOWER_DEADZONE_MAX_IN_VOLT: Error for open
122
           circuit
       Between THROTTLE_LOWER_DEADZONE_MAX_IN_VOLT and MIN_THROTTLE_IN_VOLT:
123
          0% Torque
       Between MIN THROTTLE IN VOLT and MAX THROTTLE IN VOLT: Linear
124
           relationship
       Between MAX_THROTTLE_IN_VOLT and THORTTLE_UPPER_DEADZONE_MIN_IN_VOLT:
125
          100% Torque
       Between THORTTLE_UPPER_DEADZONE_MIN_IN_VOLT and 5V: Error for short
126
           circuit
127
       if (throttle_volt < THROTTLE_LOWER_DEADZONE_MIN_IN_VOLT)</pre>
128
129
           DBG_PEDAL("Throttle voltage too low");
130
           DBGLN_PEDAL(throttle_volt);
131
           throttle_torque_val = 0;
132
       }
133
       else if (throttle_volt < MIN_THROTTLE_IN_VOLT)</pre>
134
       {
135
           throttle_torque_val = MIN_THROTTLE_OUT_VAL;
136
137
       else if (throttle_volt < MAX_THROTTLE_IN_VOLT)</pre>
138
139
           // Scale up the value for canbus
140
           throttle_torque_val = (throttle_volt - MIN_THROTTLE_IN_VOLT) *
141
               MAX_THROTTLE_OUT_VAL / (MAX_THROTTLE_IN_VOLT -
```

```
MIN_THROTTLE_IN_VOLT);
       }
142
       else if (throttle_volt < THROTTLE_UPPER_DEADZONE_MAX_IN_VOLT)</pre>
143
144
            throttle_torque_val = MAX_THROTTLE_OUT_VAL;
145
       }
146
       else
147
       {
148
            DBG_PEDAL("Throttle voltage too high");
149
            DBGLN_PEDAL(throttle_volt);
150
            // For safety, this should not be set to other values
151
            throttle_torque_val = 0;
152
       }
153
154
       //
155
       // Reverse mode logic
       // Do NOT use in actual competition! Read Documentation
157
       //
158
159
       reverseButtonPressed = digitalRead(reverse_pin);
160
       // temp override for testing
161
       float brakePercentage = 0.0;
162
163
       float vehicleSpeed = 0.0;
164
       // check enter reverse mode
165
       if (reverseButtonPressed)
166
167
            if (!reverseMode)
168
            {
169
                reverseMode = check_enter_reverse_mode(brakePercentage,
170
                    throttle_volt, vehicleSpeed);
            }
171
            else
172
            {
173
                reverseMode = check_enter_forward_mode(brakePercentage,
174
                    throttle volt, vehicleSpeed);
            }
175
176
       }
          (reverseMode)
177
178
            // Reverse mode
179
            // buzzer
180
            if (millis % (2 * REVERSE_BEEP_CYCLE_TIME) <</pre>
181
               REVERSE_BEEP_CYCLE_TIME)
            {
182
                digitalWrite(buzzer_pin, HIGH);
183
            }
184
            else
185
            {
186
                digitalWrite(buzzer_pin, LOW);
187
188
            // Reverse mode torque calculation
189
            throttle_torque_val = calculateReverseTorque(throttle_volt,
190
               vehicleSpeed, throttle_torque_val);
191
       }
192
       DBG_PEDAL("CAN UPDATE: Throttle = ");
193
       DBGLN_PEDAL(throttle_torque_val);
```

```
195
       // motor reverse is car forward
196
       if (Flip_Motor_Dir)
197
       {
198
           throttle_torque_val = -throttle_torque_val;
199
200
201
       tx_throttle_msg->can_id = 0x201;
       tx_throttle_msg->can_dlc = 3;
203
       tx_throttle_msg->data[0] = 0x90; // 0x90 for torque, 0x31 for speed
204
       tx_throttle_msg->data[1] = throttle_torque_val & 0xFF;
205
       tx_throttle_msg->data[2] = (throttle_torque_val >> 8) & 0xFF;
206
207
208
  bool Pedal::check_pedal_fault(int pedal_1, int pedal_2)
209
210
       float pedal 1 percentage = (float)pedal 1 / 1024;
211
       float pedal_2_percentage = (float)pedal_2 * (APPS_PEDAL_1_RANGE /
212
          APPS_PEDAL_2_RANGE) / 1024;
214
       float pedal_percentage_diff = abs(pedal_1_percentage -
          pedal_2_percentage);
       // Currently the only indication for faulty pedal is just 2 pedal
215
          values are more than 10% different
216
       if (pedal_percentage_diff > 0.1)
217
218
           DBGLN_PEDAL("WARNING: Pedal mismatch > 10%");
219
           return true;
220
221
       return false;
223
224
  bool Pedal::check_enter_reverse_mode(float brakePercentage, float
      throttlePercentage, float vehicleSpeed)
  // Enable reverse mode.
226
227
228 // Do NOT use in actual competition!
229 // Read documentation
230
  //
  // returns reverseMode status
231
  {
232
       if (brakePercentage > REVERSE_ENTER_BRAKE_THRESHOLD &&
233
           throttlePercentage < REVERSE_ENTER_THROTTLE_THRESHOLD &&
          vehicleSpeed < CAR_STATIONARY_SPEED_THRESHOLD)</pre>
234
           DBGLN_PEDAL("Entering reverse mode!");
235
           return true;
236
       }
237
       return false;
238
239
240
241 bool Pedal::check_enter_forward_mode(float brakePercentage, float
      throttlePercentage, float vehicleSpeed)
  // will see what additional criteria can be added
  // returns reverseMode status
243
244 {
       if (brakePercentage > REVERSE_ENTER_BRAKE_THRESHOLD &&
245
```

```
throttlePercentage < MIN_THROTTLE_IN_VOLT && vehicleSpeed <
          CAR_STATIONARY_SPEED_THRESHOLD)
       {
246
           DBGLN_PEDAL("Entering forward mode!");
           return false;
248
249
       return true;
250
251
252
  int Pedal::calculateReverseTorque(float throttleVolt, float vehicleSpeed,
253
      int torqueRequested)
  // Calculate the torque value for reverse mode
254
  // require throttle to be less than 1/3
  // limit speed to threshold
256
  {
257
       if (throttleVolt > MAX_THROTTLE_IN_VOLT / 3)
258
259
           return 0;
       if (vehicleSpeed > REVERSE_SPEED_MAX)
260
           return 0;
261
       DBG_PEDAL("Reverse mode: ");
262
       return torqueRequested * 0.3; // make reverse slow and controllable
263
       // consider that throttle must be less than 1/3
264
       // then max torque is 1/10 of the normal torque
266 }
```

Listing 2: Pedal.cpp

```
#ifndef PEDAL_H
 #define PEDAL_H
 #include "Queue.h"
5 #include "mcp2515.h"
 // Constants
  const float APPS_PEDAL_1_MIN_VOLTAGE = 0.0;
 const float APPS_PEDAL_1_MAX_VOLTAGE = 5.0;
10 const float APPS_PEDAL_2_MIN_VOLTAGE = 0.0;
11 const float APPS_PEDAL_2_MAX_VOLTAGE = 3.3;
12
 const float APPS_PEDAL_1_RANGE = APPS_PEDAL_1_MAX_VOLTAGE -
     APPS_PEDAL_1_MIN_VOLTAGE;
 const float APPS_PEDAL_2_RANGE = APPS_PEDAL_2_MAX_VOLTAGE -
     APPS_PEDAL_2_MIN_VOLTAGE;
15
16 const float APPS_PEDAL_1_LOWER_DEADZONE_WIDTH = 0.0;
17 const float APPS PEDAL 1 UPPER DEADZONE WIDTH = 0.4;
18 // const float APPS_PEDAL_2_LOWER_DEADZONE_WIDTH = 0.0;
19 // const float APPS_PEDAL_2_UPPER_DEADZONE_WIDTH = 0.0;
  const float MIN_THROTTLE_IN_VOLT = APPS_PEDAL_1_MIN_VOLTAGE +
21
     APPS_PEDAL_1_LOWER_DEADZONE_WIDTH;
 const float MAX_THROTTLE_IN_VOLT = APPS_PEDAL_1_MAX_VOLTAGE -
     APPS_PEDAL_1_UPPER_DEADZONE_WIDTH;
23 const float THROTTLE_LOWER_DEADZONE_MIN_IN_VOLT = APPS_PEDAL_1_MIN_VOLTAGE
     - APPS_PEDAL_1_LOWER_DEADZONE_WIDTH;
24 const float THROTTLE_UPPER_DEADZONE_MAX_IN_VOLT = APPS_PEDAL_1_MAX_VOLTAGE
     + APPS_PEDAL_1_UPPER_DEADZONE_WIDTH;
25
```

```
26 const int MAX_THROTTLE_OUT_VAL = 32430; // Maximum torque value is 32760
     for mcp2515
27 // currently set to a slightly lower value to not use speed control (100%)
28 // see E,EnS group discussion, 20250425HKT020800 discussion
29 const int MIN THROTTLE OUT VAL = 300; // Minium torque value tested is 300
      (TBC)
30
  // To go forward, this should be true; false sets the motor to go in
32 bool Flip_Motor_Dir = true; // Flips the direction of motor output
33 // set to true for gen 3
35 // Reverse mode "stationary" speed threshold
36 const float CAR_STATIONARY_SPEED_THRESHOLD = 0.2;
37 // Reverse mode entering brake threshold
38 const float REVERSE_ENTER_BRAKE_THRESHOLD = 0.5;
39 // Reverse mode entering throttle threshold
40 const float REVERSE_ENTER_THROTTLE_THRESHOLD = 0.1;
41 // Reverse mode maximum speed
42 const float REVERSE_SPEED_MAX = 0.2;
43 // Reverse mode buzzer cycle time
44 const unsigned short REVERSE_BEEP_CYCLE_TIME = 400; // in ms
46 #define ADC_BUFFER_SIZE 16
47
48 // Class for generic pedal object
49 // For Gen 5 car, only throttle pedal is wired through the VCU, so we use
     Pedal class for Throttle pedal only.
50 class Pedal
  {
51
52 public:
      // Two input pins for reading both pedal potentiometer
53
      // Conversion rate in Hz
54
      Pedal(int input_pin_1, int input_pin_2, int reverse_pin, int buzzer_pin
55
          , unsigned long millis, unsigned short conversion_rate = 1000);
56
      // Defualt constructor, expected another constructor should be called
57
         before start using
      Pedal();
58
59
      // Update function. To be called on every loop and pass the current
60
         time in millis
      void pedal_update(unsigned long millis);
61
62
      // Updates the can_frame with the most update pedal value. To be called
63
           on every loop and pass the can_frame by reference.
      void pedal_can_frame_update(can_frame *tx_throttle_msg, unsigned long
64
         millis);
65
      // Updates the can_frame to send a "O Torque" value through canbus.
      void pedal_can_frame_stop_motor(can_frame *tx_throttle_msg);
67
68
      // Pedal value after filtering and processing
69
      // Under normal circumstance, should store a value between 0 and 1023
         inclusive (translates to 0v - 5v)
      int final_pedal_value;
71
73 private:
```

```
int input_pin_1, input_pin_2, reverse_pin, buzzer_pin;
75
       // Will rollover every 49 days
76
       unsigned long previous_millis;
77
78
       unsigned short conversion_rate;
79
80
       // If the two potentiometer inputs are too different (> 10%), the
          inputs are faulty
       // Definition for faulty is under FSEC 2024 Chapter 2, section 12.8,
82
          12.9
       bool fault = false;
83
       unsigned long fault_start_millis;
84
85
       // Forced stop the car due too long fault sensors, restart car to reset
86
           this to false
       bool fault_force_stop = true;
87
88
       // Period in millisecond
89
       unsigned short conversion_period;
91
       // Returns true if pedal is faulty
92
       bool check_pedal_fault(int pedal_1, int pedal_2);
93
94
       RingBuffer<float, ADC_BUFFER_SIZE> pedalValue_1;
95
       RingBuffer<float, ADC_BUFFER_SIZE> pedalValue_2;
96
97
       // reverse mode
98
99
       // Do NOT use in actual competition!
100
       // Read documentation
102
       //
103
       // calculate reverse torque value
104
       int calculateReverseTorque(float throttleVolt, float vehicleSpeed, int
105
          torqueRequested);
106
       // reverse button pin to bool
107
       bool reverseButtonPressed = false;
109
       // Reverse mode status
110
       bool reverseMode = false;
111
       // function check and set reverse, return reverse mode status
113
       bool check_enter_reverse_mode(float brakePercentage, float
114
          throttlePercentage, float vehicleSpeed);
115
       // function check and set forward, return reverse mode status
116
       bool check_enter_forward_mode(float brakePercentage, float
117
          throttlePercentage, float vehicleSpeed);
118 };
119
120 #endif // PEDAL_H
```

Listing 3: Pedal.h

5.3 Queue.cpp and Queue.h

These files implement a static FIFO queue and a ring buffer for managing pedal input data.

```
#include "Queue.h"
  template <typename T, int size>
  Queue < T, size >:: Queue() : queue Full(false), queue Empty(true), queue Count(0)
       {}
  template <typename T, int size>
  void Queue<T, size>::push(T val)
  {
      for (int i = size - 1; i > 0; i--)
10
           buffer[i] = buffer[i - 1];
11
12
      buffer[0] = val;
13
14
      if (!queueFull)
15
           ++queueCount;
16
17
      queueFull = (queueCount == size);
18
  }
19
20
  template <typename T, int size>
  T Queue<T, size>::pop()
22
23
      if (queueCount == 0) // If the queue is empty and attempts to pop an
          object, the program will end
           this->exit(0);  // this->exit() somehow circumnavigates some
25
              errors
26
      --queueCount;
27
      queueEmpty = (queueCount == 0);
28
      return buffer[queueCount];
30
31 }
  template <typename T, int size>
  T Queue < T, size > :: getHead()
35
      return buffer[queueCount - 1];
36
37 }
38
39 template <typename T, int size>
40 bool Queue < T, size > :: is Empty()
      return queueEmpty;
42
43
  }
45 template <typename T, int size>
46 bool Queue < T, size > :: is Full()
47
  {
      return queueFull;
48
  }
49
```

Listing 4: Queue.cpp

```
1 #ifndef QUEUE_H
2 #define QUEUE_H
  // A simple FIFO object
  // This object is completely static
6 template <typename T, int size>
  class Queue
  {
  public:
      Queue();
10
      void push(T val);
12
      T pop();
13
      T getHead();
14
15
16
      bool isEmpty();
      bool isFull();
17
18
      T buffer[size];
20
  private:
21
      bool queueFull, queueEmpty;
      int queueCount;
24 };
25
  template <typename T, int size>
  class RingBuffer
28
  public:
29
      RingBuffer() : head(0), count(0) {}
31
      void push(T val)
32
33
           buffer[head] = val;
           head = (head + 1) % size;
36
           if (count < size)</pre>
               ++count;
37
      }
38
39
      void getLinearBuffer(T *out)
40
41
           for (int i = 0; i < count; ++i)</pre>
42
43
               out[i] = buffer[(head + i) % size];
44
^{45}
      }
46
47
      T buffer[size];
48
      int head;
49
       int count;
50
  };
51
#endif // QUEUE_H
```

Listing 5: Queue.h

5.4 Signal_Processing.cpp and Signal_Processing.h

These files provide simple DSP functions for filtering and processing pedal input signals.

```
#include "Signal_Processing.h"
  // Apply a FIR filter on the signal buffer
  // The buffer size must be the same as the kernel
  // Filtered output will be stored in the output_buf
6 template <typename T>
  T FIR_filter(T *buffer, float *kernel, int buf_size, float kernel_sum)
      float sum = 0;
10
      for (int i = 0; i < buf_size; ++i)</pre>
11
12
          sum += buffer[i] * kernel[i];
13
14
15
      // Kernel sum is the sum of all values in the kernel. This normalize
          the output value
      return sum / kernel_sum;
17
18
19
20
  template <typename T>
  T average(T val1, T val2)
      return (val1 + val2) / 2;
  }
24
26 template <typename T>
  T AVG_filter(T *buffer, int buf_size)
27
28
      float sum = 0;
29
30
      for (int i = 0; i < buf_size; ++i)</pre>
31
          sum += buffer[i];
32
      return sum / (float)buf_size;
33
```

Listing 6: Signal_Processing.cpp

```
// A library containing simple DSP functions, for ADC filtering, buffer
    comparisons and more

#ifndef SIGNAL_PROCESSING_H

#define SIGNAL_PROCESSING_H

template <typename T>
T FIR_filter(T *buffer, float *kernel, int buf_size, float kernel_sum);

template <typename T>
T average(T val1, T val2);

template <typename T>
T AVG_filter(T *buffer, int buf_size);

#endif
```

Listing 7: Signal Processing.h

5.5 Debug.h

This file defines macros for enabling or disabling debug messages.

```
#ifndef DEBUG H
  #define DEBUG_H
  // === Debug Flags ===
6 // ALWAYS LEAVE FALSE FOR GITHUB
  #define DEBUG false // Oveall debug functionality
9 #define DEBUG_PEDAL true && DEBUG
10 #define DEBUG_SIGNAL_PROC false && DEBUG
  #define DEBUG_GENERAL true && DEBUG
12 #define DEBUG_PEDAL true && DEBUG
| #define DEBUG_CAN true && DEBUG
_{14}| #define DEBUG_STATUS true && DEBUG
16 #if DEBUG_PEDAL
#define DBG_PEDAL(x) Serial.print(x)
18 #define DBGLN_PEDAL(x) Serial.println(x)
19 #else
20 #define DBG_PEDAL(x)
21 #define DBGLN_PEDAL(x)
22 #endif
24 #if DEBUG_SIGNAL_PROC
25 #define DBG_SIG(x) Serial.print(x)
26 #define DBGLN_SIG(x) Serial.println(x)
27 #else
28 #define DBG_SIG(x)
29 #define DBGLN_SIG(x)
30 #endif
32 #if DEBUG_GENERAL
#define DBG_GENERAL(x) Serial.print(x)
34 #define DBGLN_GENERAL(x) Serial.println(x)
35 #else
36 #define DBG_GENERAL(x)
37 #define DBGLN_GENERAL(x)
38 #endif
40 #if DEBUG_PEDAL
41 #define DBG_PEDAL(x) Serial.print(x)
42 #define DBGLN_PEDAL(x) Serial.println(x)
43 #else
44 #define DBG_PEDAL(x)
45 #define DBGLN_PEDAL(x)
46 #endif
47
48 #if DEBUG_CAN
49 #define DBG_CAN(x) Serial.print(x)
50 #define DBGLN_CAN(x) Serial.println(x)
51 #else
52 #define DBG_CAN(x)
53 #define DBGLN_CAN(x)
54 #endif
55
```

```
#if DEBUG_STATUS
#define DBG_STATUS(x) Serial.print(x)
#define DBGLN_STATUS(x) Serial.println(x)
#else
#define DBG_STATUS(x)
#define DBG_STATUS(x)
#define DBGLN_STATUS(x)
#endif
#endif // DEBUG_H
```

Listing 8: Debug.h

5.6 pinMap.h

This file maps the pins used in the project to meaningful names.

```
#ifndef PINMAP H
  #define PINMAP_H
  #define BTN1 5
  #define BTN2 6
  #define BTN3 7
  #define BTN4 8
  // #define CS_CAN 14
10 #define CS_CAN 10 // For arduino testing
12 // #define APPS_5V 23
13 // #define APPS 3V3 24
14 // #define BRAKE_5V 25
  // #define BRAKE_OUT 26
  #define APPS_5V A0
                       // For arduino testing
  #define APPS_3V3 A1
                      // For arduino testing
18 #define BRAKE_5V A2 // For arduino testing
19 #define BRAKE_OUT A3 // For arduino testing
21 #define REVERSE_BUTTON A4 // For arduino testing
23 #define LED1 2
  #define LED2 3
  #define LED3 4
27 #endif // PINMAP_H
```

Listing 9: pinMap.h

6 PlatformIO Configuration

The platformio.ini file configures the PlatformIO environment for the project. It specifies the board, framework, and library dependencies.

```
; PlatformIO Project Configuration File
;;
3 ; Build options: build flags, source filter
4 ; Upload options: custom upload port, speed and extra flags
5 ; Library options: dependencies, extra library storages
```

```
6  ; Advanced options: extra scripting
7  ;
8  ; Please visit documentation for the other options and examples
9  ; https://docs.platformio.org/page/projectconf.html

10  [env:uno]
11  [env:uno]
12  platform = atmelavr
13  board = uno
14  framework = arduino
15  lib_deps = autowp/autowp-mcp2515@^1.2.1
16  build_flags =
17   -Wall
18   -pedantic
19  -Wextra
```

Listing 10: platformio.ini

7 Future Development

- Add more CAN channels for BMS, data logger, and other components.
- Improve the torque curve for better performance.
- Fully implement reverse mode.

8 References

- PlatformIO Documentation
- GCC Header File Documentation