# Red Bird Racing EVRT Vehicle Control Unit (VCU) (2025)

## Project Documentation

## Red Bird Racing EVRT

June 3, 2025

## Contents

1	Introduction 1.1 Project Structure	<b>2</b> 2
_	·	
2	Setup and Tuning	2
3	Debugging	3
4	Reverse Mode	3
	4.1 Reverse Mode Logic	3
	4.1.1 Key Functions	3
	4.1.2 Reverse Mode Workflow	4
	4.1.3 Safety Notes	4
5	Source Code Overview	4
	5.1 main.cpp	4
	5.2 Pedal.cpp and Pedal.h	8
	5.3 Queue.cpp and Queue.h	17
	5.4 Signal_Processing.cpp and Signal_Processing.h	19
	5.5 Debug.h	20
	5.6 pinMap.h	21
6	PlatformIO Configuration	22
7	Future Development	23
8	References	23

## 1 Introduction

This document provides an overview of the Red Bird Racing EVRT Vehicle Control Unit (VCU) (2025). The VCU firmware is designed to manage pedal input, CAN communication, and vehicle state transitions for our Formula Student electric race car.

#### 1.1 Project Structure

The project is organized as follows:

```
+-- include
3
 +-- Debug.h
      +-- pinMap.h
      +-- README
6
      lib
      +-- Pedal
7
          +-- Pedal.cpp
          +-- Pedal.h
          +-- library.json
10
      +-- Queue
11
          +-- Queue.cpp
12
          +-- Queue.h
      +-- Signal_Processing
          +-- Signal_Processing.cpp
15
          +-- Signal_Processing.h
16
      +-- README
17
      src
      +-- main.cpp
 +-- test
      +-- README
 +-- platformio.ini
      .vscode
      +-- launch.json
24
      +-- extensions.json
      +-- c_cpp_properties.json
```

## 2 Setup and Tuning

- 1. Adjust pedal input constants in Pedal.h.
- 2. Flash the VCU firmware. Ensure the car is jacked up and powered off during this process.
- 3. Clear the area around the car, especially the rear.
- 4. Test the minimum and maximum pedal input voltages and adjust the constants accordingly.

## 3 Debugging

Debugging is performed using the serial monitor. Enable specific debug messages by setting flags in Debug.h. Note that enabling debugging may introduce delays due to the slow serial communication.

#### 4 Reverse Mode

Reverse mode is implemented for testing purposes only and is prohibited in competition. The driver must hold the reverse button to engage reverse mode. Releasing the button places the car in neutral. The car would re-enter reverse mode if criteria are met; else forward mode is engaged if its criteria are met.

#### **Important Notes:**

- Do NOT use in actual competition!
- Rules 5.2.2.3: 禁止通过驱动装置反转车轮。
- Rough translation: It is prohibited to use the motor to turn the wheels backwards.

#### 4.1 Reverse Mode Logic

The reverse mode logic in Pedal.cpp allows the driver to toggle between reverse and forward modes using a single button. Below is the updated workflow and key components:

#### 4.1.1 Key Functions

- void pedal\_can\_frame\_update(can\_frame \*tx\_throttle\_msg, unsigned long millis): Updates the CAN frame with the current throttle value and handles reverse mode logic. The reverse button toggles between reverse and forward modes:
  - If the reverse button is pressed, the mode toggles between reverse and forward.
  - If reverseMode is true, the buzzer is activated, and reverse torque is calculated.
- int calculateReverseTorque(float throttleVolt, float vehicleSpeed, int torqueRequested): Calculates the torque value for reverse mode with the following constraints:
  - The throttle voltage must be less than one-third of the maximum throttle voltage (MAX\_THROTTLE\_IN\_VOLT / 3).
  - The vehicle speed must not exceed the reverse speed limit (REVERSE\_SPEED\_MAX).
  - The torque is scaled down to 30% of the requested torque to ensure reverse mode is slow and controllable.

If any of the constraints are violated, the torque is set to zero.

#### 4.1.2 Reverse Mode Workflow

- 1. The reverse button state is read using digitalRead(reverse\_pin).
- 2. If the reverse button is pressed, and conditions are met:
  - If the vehicle is in forward mode (reverseMode = false), it switches to reverse mode (reverseMode = true).
  - If the vehicle is in reverse mode (reverseMode = true), it switches to forward mode (reverseMode = false).

#### 3. In reverse mode:

- A buzzer is activated with a periodic beep to alert nearby individuals. The cycle time is BUZZER\_CYCLE\_TIME milliseconds.
- The reverse torque is calculated using calculateReverseTorque.
- 4. The throttle torque value is updated and sent via CAN messages.
- 5. If the motor direction needs to be flipped (e.g., for forward mode), the torque value is negated.

#### 4.1.3 Safety Notes

- Reverse mode is implemented for testing purposes only and should not be used in competition.
- Rules 5.2.2.3
- Rough translation: It is prohibited to use the motor to turn the wheels backwards.
- The reverse mode logic ensures that the vehicle operates safely by limiting throttle and speed in reverse mode.
- However, care should be taken any time the vehicle is maneuvering, or if the buzzer is heard.

#### 5 Source Code Overview

#### 5.1 main.cpp

The main file initializes the pedal, CAN communication, and state machine for the car. It handles transitions between states such as INIT, IN\_STARTING\_SEQUENCE, BUZZING, and DRIVE\_MODE.

```
#include <Arduino.h>
#include "pinMap.h"

#include "Pedal.h"

#include <mcp2515.h>

#include "Debug.h"

// === Pin setup ===

// Pin setup for pedal pins are done by the constructor of Pedal object
```

```
9 uint8_t pin_out[4] = {LED1, LED2, LED3, BRAKE_OUT};
10 uint8_t pin_in[4] = {BTN1, BTN2, BTN3, BTN4};
12 // === CAN + Pedal ===
13 MCP2515 mcp2515 (CS CAN);
14 Pedal pedal;
15
16 struct can_frame tx_throttle_msg;
17 struct can_frame rx_msg;
18 struct can_frame *tx_debug_msg = nullptr; // If DBC is not enabled, we don'
     t need to send debug messages
 // For limiting the throttle update cycle
20
21 // const int THROTTLE_UPDATE_PERIOD_MILLIS = 50; // Period of sending
     canbus signal
22 // unsigned long final_throttle_time_millis = 0; // The last time sent a
     canbus message
23
 /* === Car Status State Machine ===
25 Meaning of different car statuses
26 INIT (0): Just started the car
27 IN_STARTING_SEQUENCE (1): 1st Transition state -- Driver holds the "Start"
      button and is on full brakes, lasts for STATUS_1_TIME_MILLIS
     milliseconds
28 BUZZING (2): 2nd Transition state -- Buzzer bussin, driver can release "
     Start" button and brakes
29 DRIVE_MODE (3): Ready to drive -- Motor starts responding according to the
      driver pedal input. "Drive mode" LED lights up, indicating driver can
     press the throttle
30
31 Separately, the following will be done outside the status checking part:
32 1. Before the "Drive mode" LED lights up, if the throttle pedal is pressed
      (Throttle input is not euqal to 0), the car_status will return to 0
2. Before the "Drive mode" LED lights up, the canbus will keep sending "0
     torque" messages to the motor
34
 Also, during status 0, 1, and 2, the VCU will keep sending "O torque"
35
     messages to the motor via CAN
 enum CarStatus
37
 {
38
      INIT = 0,
39
      IN_STARTING_SEQUENCE = 1,
40
      BUZZING = 2,
41
      DRIVE_MODE = 3
42
43 };
44 CarStatus car_status = INIT;
45 unsigned long car_status_millis_counter = 0; // Millis counter for 1st and
     2nd transitionin states
46 const int STATUS_1_TIME_MILLIS = 2000;
                                                // The amount of time that the
      driver needs to hold the "Start" button and full brakes in order to
     activate driving mode
47 const int BUSSIN_TIME_MILLIS = 2000;
                                              // The amount of time that the
      buzzer will buzz for
49 void setup()
50 {
     // Init pedals
```

```
pedal = Pedal(APPS_5V, APPS_3V3, REVERSE_BUTTON, LED1, millis());
52
53
       // Init input pins
54
       for (int i = 0; i < 4; i++)</pre>
55
           pinMode(pin in[i], INPUT);
56
       // Init output pins
57
       for (int i = 0; i < 4; i++)</pre>
58
           pinMode(pin_out[i], OUTPUT);
59
60
       // Init mcp2515
61
       mcp2515.reset();
62
       mcp2515.setBitrate(CAN_500KBPS, MCP_8MHZ); // 8MHZ for testing on uno
63
       mcp2515.setNormalMode();
64
65
       // Init serial for testing if DEBUG flag is set to true
66
       if (DEBUG == true)
68
           while (!Serial)
69
70
           Serial.begin(9600);
71
72
73
74
       DBGLN_STATUS("Entered State 0 (Idle)");
       if (DBC)
75
       {
76
           struct can_frame local_debug_msg; // Only created if needed
77
           tx_debug_msg = &local_debug_msg; // Point to the local variable
78
79
       }
  }
80
81
  void loop()
  {
83
       // Update pedal value
84
       pedal.pedal_update(millis());
85
       /*
87
       For the time being:
88
       BTN1 = "Start" button
89
       BTN2 = Brake pedal
       LED1 = Buzzer output
91
       LED2 = "Drive" mode indicator
92
       */
93
       DBG_PEDAL("Pedal Value: ");
94
       DBGLN_PEDAL(pedal.final_pedal_value);
95
96
       if (car_status == INIT)
97
       {
98
           // car_status = 3; // For testing drive mode
99
100
           pedal.pedal_can_frame_stop_motor(&tx_throttle_msg);
101
           mcp2515.sendMessage(&tx_throttle_msg);
102
           DBGLN_CAN("Holding 0 torque during state 0");
103
104
           if (digitalRead(BTN1) == HIGH && digitalRead(BTN2) == HIGH) //
105
               Check if "Start" button and brake is fully pressed
           {
106
                car_status = IN_STARTING_SEQUENCE;
107
                car_status_millis_counter = millis();
108
```

```
DBGLN_STATUS("Entered State 1");
109
           }
110
       }
111
       else if (car_status == IN_STARTING_SEQUENCE)
112
113
           pedal.pedal_can_frame_stop_motor(&tx_throttle_msg);
114
           mcp2515.sendMessage(&tx_throttle_msg);
115
           DBGLN_CAN("Holding 0 torque during state 1");
116
117
           if (digitalRead(BTN1) == LOW || digitalRead(BTN2) == LOW) // Check
118
               if "Start" button or brake is not fully pressed
           {
119
               car_status = INIT;
120
                car_status_millis_counter = millis();
121
               DBGLN_STATUS("Entered State 0 (Idle)");
122
           else if (millis() - car_status_millis_counter >=
124
               STATUS_1_TIME_MILLIS) // Check if button held long enough
125
               car_status = BUZZING;
126
               digitalWrite(LED1, HIGH); // Turn on buzzer
127
               car_status_millis_counter = millis();
128
               DBGLN_STATUS("Transition to State 2: Buzzer ON");
129
           }
130
       }
131
       else if (car_status == BUZZING)
132
133
           pedal.pedal_can_frame_stop_motor(&tx_throttle_msg);
134
           mcp2515.sendMessage(&tx_throttle_msg);
135
           DBGLN_CAN("Holding 0 torque during state 2");
136
137
           if (millis() - car_status_millis_counter >= BUSSIN_TIME_MILLIS)
138
139
               digitalWrite(LED2, HIGH); // Turn on "Drive" mode indicator
140
                                           // Turn off buzzer
               digitalWrite(LED1, LOW);
141
               car status = DRIVE MODE;
142
               DBGLN_STATUS("Transition to State 3: Drive mode");
143
144
           }
145
       else if (car_status == DRIVE_MODE)
146
147
           // In "Drive mode", car_status won't change, the drvier either
               continue to drive, or shut off the car
           DBGLN_STATUS("In Drive Mode");
149
       }
150
       else
151
       {
152
           // Error, idk wtf to do here
153
           DBGLN_STATUS("ERROR: Invalid car_status encountered!");
154
       }
155
156
       // Pedal update
157
       if (car_status == DRIVE_MODE)
158
159
       {
           // Send pedal value through canbus
160
           pedal.pedal_can_frame_update(&tx_throttle_msg, millis(),
161
               tx_debug_msg);
           // The following if block is needed only if we limit the lower
162
```

```
bound for canbus cycle period
           // if (millis() - final_throttle_time_millis >=
163
               THROTTLE UPDATE PERIOD MILLIS)
           // {
164
           //
                   mcp2515.sendMessage(&tx throttle msg);
165
                   final_throttle_time_millis = millis();
           //
166
167
           mcp2515.sendMessage(&tx_throttle_msg);
168
169
  \# if \ DBC \ // \ If \ DBC \ is enabled, send debug message; else don't compile this
170
      part
           tx_debug_msg->data[0] = static_cast < uint8_t > (car_status);
171
           tx_debug_msg->data[5] = BRAKE_5V;
172
           mcp2515.sendMessage(tx_debug_msg); // Send debug message to CAN bus
173
  #endif
174
175
           DBGLN CAN("Throttle CAN frame sent");
176
       }
177
       else
178
179
           if (pedal.final_pedal_value > MIN_THROTTLE_OUT_VAL)
180
           {
181
                car_status = INIT;
                car_status_millis_counter = millis(); // Set to current time,
183
                   in case any counter relies on this
               pedal.pedal_can_frame_stop_motor(&tx_throttle_msg);
184
                mcp2515.sendMessage(&tx_throttle_msg);
                DBGLN_STATUS("Throttle pressed too early - Resetting to State 0
186
                   ");
           }
187
       }
188
189
       // mcp2515.sendMessage(&tx_throttle_msg);
190
       // uint32_t lastLEDtick = 0;
191
       // Optional RX handling (disabled for now)
       // if (mcp2515.readMessage(&rx msg) == MCP2515::ERROR OK)
193
       // {
194
               // Commented out as currenlty no need to include receive
195
       //
           functionality
              // if (rx_msg.can_id == 0x522)
196
              //
                      for (int i = 0; i < 8; i++)
       //
197
                           digitalWrite(pin_out[i], (rx_msg.data[0] >> i) & 0x01
       //
              //
           );
       // }
199
  }
200
```

Listing 1: main.cpp

#### 5.2 Pedal.cpp and Pedal.h

These files define the Pedal class, which encapsulates functionality for reading pedal input, filtering signals, and constructing CAN frames.

```
#include "Pedal.h"
#include "Arduino.h"
#include "Signal_Processing.cpp"
#include "Debug.h"
```

```
// Sinc function of size 128
  float SINC 128[128] = {0.017232, 0.002666, -0.013033, -0.026004, -0.032934,
       -0.031899, -0.022884, -0.007851, 0.009675, 0.025427,
                          0.035421, 0.036957, 0.029329, 0.014081, -0.005294,
                             -0.024137, -0.037732, -0.042472, -0.036792,
                             -0.021652,
                          -0.000402, 0.021937, 0.039841, 0.048626, 0.045647,
                             0.031053, 0.007888, -0.018512, -0.041722,
                             -0.055750,
                          -0.056553, -0.043139, -0.017994, 0.013320, 0.043353,
10
                              0.064476, 0.070758, 0.059540, 0.032321,
                             -0.005306,
                          -0.044714, -0.076126, -0.090908, -0.083781,
11
                             -0.054402, -0.007911, 0.045791, 0.093940,
                             0.123670, 0.125067,
                          0.093855, 0.033095, -0.046569, -0.128280, -0.191785,
12
                              -0.217229, -0.189201, -0.100224, 0.047040,
                             0.239389,
                          0.454649, 0.664997, 0.841471, 0.958851, 1, 0.958851,
13
                              0.841471, 0.664997, 0.454649, 0.239389,
                             0.047040,
                          -0.100224, -0.189201, -0.217229, -0.191785,
                             -0.128280, -0.046569, 0.033095, 0.093855,
                             0.125067, 0.123670,
                          0.093940, 0.045791, -0.007911, -0.054402, -0.083781,
15
                              -0.090908, -0.076126, -0.044714, -0.005306,
                             0.032321,
                          0.059540, 0.070758, 0.064476, 0.043353, 0.013320,
16
                             -0.017994, -0.043139, -0.056553, -0.055750,
                             -0.041722,
                          -0.018512, 0.007888, 0.031053, 0.045647, 0.048626,
17
                             0.039841, 0.021937, -0.000402, -0.021652,
                             -0.036792,
                          -0.042472, -0.037732, -0.024137, -0.005294,
                             0.014081, 0.029329, 0.036957, 0.035421, 0.025427,
                              0.009675.
                          -0.007851, -0.022884, -0.031899, -0.032934,
19
                             -0.026004, -0.013033};
20
21 Pedal::Pedal()
      : input_pin_1(-1), input_pin_2(-1), reverse_pin(-1), buzzer_pin(-1),
         previous_millis(0), conversion_rate(0), fault(true),
         fault_force_stop(false) {}
24 Pedal::Pedal(int input_pin_1, int input_pin_2, int reverse_pin, int
     buzzer_pin, unsigned long millis, unsigned short conversion_rate)
      : input_pin_1(input_pin_1), input_pin_2(input_pin_2), reverse_pin(
25
         reverse_pin), buzzer_pin(buzzer_pin), previous_millis(millis),
         conversion_rate(conversion_rate), fault(false), fault_force_stop(
         false)
  {
26
      // Init pins
27
      pinMode(input_pin_1, INPUT);
      pinMode(input_pin_2, INPUT);
      pinMode(buzzer_pin, OUTPUT);
30
      conversion_period = 1000 / conversion_rate;
31
```

```
// Init ADC buffers
      for (int i = 0; i < ADC_BUFFER_SIZE; ++i)</pre>
34
35
          pedalValue_1.buffer[i] = 0;
36
          pedalValue 2.buffer[i] = 0;
37
38
  }
39
  void Pedal::pedal_update(unsigned long millis)
41
42
      // If is time to update
43
44
      if (millis - previous_millis > conversion_period)
45
          // Updating the previous millis
46
          previous_millis = millis;
47
          // Record readings in buffer
          pedalValue_1.push(analogRead(input_pin_1));
49
          pedalValue_2.push(analogRead(input_pin_2));
50
          // By default range of pedal 1 is APPS_PEDAL_1_RANGE, pedal 2 is
52
              APPS_PEDAL_2_RANGE;
53
          // this is current taking the direct array the circular queue
              writes into. Bad idea to do anything other than a simple average
          // if not using a linear filter, pass the pedalValue_1.
55
              getLinearBuffer() to the filter function to ensure the ordering
              is correct.
          // can also consider injecting the filter into the queue if need
56
          // depends on the hardware filter, reduce software filtering as
              much as possible
          int pedal_filtered_1 = round(AVG_filter<float>(pedalValue_1.buffer,
58
              ADC_BUFFER_SIZE));
          int pedal_filtered_2 = round(AVG_filter<float>(pedalValue_2.buffer,
59
               ADC_BUFFER_SIZE));
          // int pedal filtered 1 = round(FIR filter<float>(pedalValue 1.
61
              buffer, SINC_128, ADC_BUFFER_SIZE, 6.176445));
          // int pedal_filtered_2 = round(FIR_filter<float>(pedalValue_2.
62
              buffer, SINC_128, ADC_BUFFER_SIZE, 6.176445));
          final_pedal_value = pedal_filtered_1; // Only take in pedal 1 value
63
64
          DBG_PEDAL("Pedal 1: ");
65
          DBG_PEDAL(pedal_filtered_1);
66
          DBG_PEDAL(" | Pedal 2: ");
67
          DBG_PEDAL(pedal_filtered_2);
68
          DBG_PEDAL(" | Final: ");
69
          DBGLN_PEDAL(final_pedal_value);
70
71
          if (check_pedal_fault(pedal_filtered_1, pedal_filtered_2))
72
73
              if (fault)
74
              { // Previous scan is already faulty
75
                   if (millis - fault_start_millis > 100)
76
                   { // Faulty for more than 100 ms
77
78
                       // TODO: Add code for alerting the faulty pedal, and
                          whatever else mandated in rules Ch.2 Section 12.8,
                          12.9
79
```

```
// Turning off the motor is achieved using another
80
                            digital pin, not via canbus, but will still send 0
                            torque can signals
                        fault_force_stop = true;
81
82
                        DBGLN_PEDAL("FAULT: Pedal mismatch persisted > 100ms!")
83
                        return;
85
                    }
86
               }
87
88
               else
89
                    fault_start_millis = millis;
90
                    DBGLN_PEDAL("FAULT: Pedal mismatch started");
91
               }
93
               fault = true;
94
               return;
95
           }
96
       }
97
98
  }
  void Pedal::pedal_can_frame_stop_motor(can_frame *tx_throttle_msg)
100
101
       tx_throttle_msg->can_id = 0x201;
102
       tx_throttle_msg->can_dlc = 3;
103
       tx_throttle_msg->data[0] = 0x90; // 0x90 for torque, 0x31 for speed
104
       tx_throttle_msg->data[1] = 0;
105
       tx_throttle_msg->data[2] = 0;
106
107
       DBGLN_PEDAL("CAN STOP");
108
  }
109
110
  void Pedal::pedal_can_frame_update(can_frame *tx_throttle_msg, unsigned
      long millis, can frame *tx debug msg)
  ₹
112
       if (fault_force_stop)
113
114
           pedal_can_frame_stop_motor(tx_throttle_msg);
115
           return;
116
       }
117
       float throttle_volt = (float)final_pedal_value * APPS_PEDAL_1_RANGE /
118
           1024; // Converts most update pedal value to a float between OV and
          5V
119
       int16_t throttle_torque_val = 0;
120
121
       Between OV and THROTTLE_LOWER_DEADZONE_MAX_IN_VOLT: Error for open
122
       Between THROTTLE_LOWER_DEADZONE_MAX_IN_VOLT and MIN_THROTTLE_IN_VOLT:
123
          0% Torque
       Between MIN_THROTTLE_IN_VOLT and MAX_THROTTLE_IN_VOLT: Linear
124
          relationship
       Between MAX_THROTTLE_IN_VOLT and THORTTLE_UPPER_DEADZONE_MIN_IN_VOLT:
125
          100% Torque
       Between THORTTLE_UPPER_DEADZONE_MIN_IN_VOLT and 5V: Error for short
126
          circuit
```

```
127
       */
       if (throttle_volt < THROTTLE_LOWER_DEADZONE_MIN_IN_VOLT)</pre>
128
129
            DBG_PEDAL("Throttle voltage too low");
130
            DBGLN PEDAL(throttle volt);
131
            throttle_torque_val = 0;
132
       }
133
       else if (throttle_volt < MIN_THROTTLE_IN_VOLT)</pre>
134
135
            throttle_torque_val = MIN_THROTTLE_OUT_VAL;
136
       }
137
       else if (throttle_volt < MAX_THROTTLE_IN_VOLT)</pre>
138
139
            // Scale up the value for canbus
140
            throttle_torque_val = (throttle_volt - MIN_THROTTLE_IN_VOLT) *
141
               MAX_THROTTLE_OUT_VAL / (MAX_THROTTLE_IN_VOLT -
               MIN THROTTLE IN VOLT);
       }
142
       else if (throttle_volt < THROTTLE_UPPER_DEADZONE_MAX_IN_VOLT)</pre>
143
144
            throttle_torque_val = MAX_THROTTLE_OUT_VAL;
145
       }
146
147
       else
       {
148
            DBG_PEDAL("Throttle voltage too high");
149
            DBGLN_PEDAL(throttle_volt);
150
            // For safety, this should not be set to other values
151
            throttle_torque_val = 0;
152
       }
153
154
       //
155
       // Reverse mode logic
156
       // Do NOT use in actual competition! Read Documentation
157
       //
158
       reverseButtonPressed = digitalRead(reverse pin);
160
       // temp override for testing
161
       float brakePercentage = 0.0;
162
       float vehicleSpeed = 0.0;
163
164
       // check enter reverse mode
165
       if (reverseButtonPressed)
166
167
            if (!reverseMode)
168
            {
169
                reverseMode = check_enter_reverse_mode(brakePercentage,
170
                    throttle_volt, vehicleSpeed);
            }
171
            else
172
173
                reverseMode = check_enter_forward_mode(brakePercentage,
174
                    throttle_volt, vehicleSpeed);
            }
175
176
       }
177
       if (reverseMode)
178
            // Reverse mode
179
            // buzzer
```

```
if (millis % (2 * REVERSE_BEEP_CYCLE_TIME) <</pre>
181
               REVERSE_BEEP_CYCLE_TIME)
           {
182
               digitalWrite(buzzer_pin, HIGH);
183
184
           else
185
           {
186
               digitalWrite(buzzer_pin, LOW);
187
188
           // Reverse mode torque calculation
189
           throttle_torque_val = calculateReverseTorque(throttle_volt,
190
               vehicleSpeed, throttle_torque_val);
191
192
       DBG PEDAL("CAN UPDATE: Throttle = ");
193
       DBGLN_PEDAL(throttle_torque_val);
194
195
       // motor reverse is car forward
196
       if (Flip_Motor_Dir)
197
198
           throttle_torque_val = -throttle_torque_val;
199
       }
200
201
       tx_throttle_msg->can_id = 0x201;
202
       tx_throttle_msg->can_dlc = 3;
203
       tx_throttle_msg->data[0] = 0x90; // 0x90 for torque, 0x31 for speed
204
       tx_throttle_msg->data[1] = throttle_torque_val & 0xFF;
205
       tx_throttle_msg->data[2] = (throttle_torque_val >> 8) & 0xFF;
206
207
  #if DBC
208
       // CAN DBC debug
209
       tx_debug_msg->can_id = 0x102; // ID for debug message
210
       tx_debug_msg->can_dlc = 6;
                                      // Length of the message
211
       // created in main tx_debug_msg->data[0] = static_cast<uint8_t>(
212
          car_status); // State of the car
       tx_debug_msg->data[1] = input_pin_1; // Pedal 1 voltage
213
       tx_debug_msg->data[2] = input_pin_2; // Pedal 2 voltage
214
       tx_debug_msg->data[3] = throttle_torque_val & 0xFF;
215
       tx_debug_msg->data[4] = (throttle_torque_val >> 8) & 0xFF; // Torque
          value
       // VCU currently not handling brake voltage
217
                                                                             //
       // tx_debug_msg->data[5] = input_pin_3;
          Brake voltage
219
  #endif
  }
220
221
  bool Pedal::check_pedal_fault(int pedal_1, int pedal_2)
223
       float pedal_1_percentage = (float)pedal_1 / 1024;
224
       float pedal_2_percentage = (float)pedal_2 * (APPS_PEDAL_1_RANGE /
          APPS_PEDAL_2_RANGE) / 1024;
226
       float pedal_percentage_diff = abs(pedal_1_percentage -
227
          pedal_2_percentage);
       // Currently the only indication for faulty pedal is just 2 pedal
228
          values are more than 10% different
229
       if (pedal_percentage_diff > 0.1)
```

```
231
           DBGLN_PEDAL("WARNING: Pedal mismatch > 10%");
232
           return true;
233
       }
       return false;
235
236
237
  //// Reverse mode functions
239
  bool Pedal::check_enter_reverse_mode(float brakePercentage, float
240
      throttlePercentage, float vehicleSpeed)
   // Enable reverse mode.
242
  // Do NOT use in actual competition!
243
244 // Read documentation
245 //
246 // returns reverseMode status
247
  {
       if (brakePercentage > REVERSE_ENTER_BRAKE_THRESHOLD &&
248
           throttlePercentage < REVERSE_ENTER_THROTTLE_THRESHOLD &&
          vehicleSpeed < CAR_STATIONARY_SPEED_THRESHOLD)</pre>
       {
249
           DBGLN_PEDAL("Entering reverse mode!");
250
           return true;
251
252
       return false;
253
254
255
  bool Pedal::check_enter_forward_mode(float brakePercentage, float
      throttlePercentage, float vehicleSpeed)
  // will see what additional criteria can be added
  // returns reverseMode status
258
259
       if (brakePercentage > REVERSE_ENTER_BRAKE_THRESHOLD &&
260
           throttlePercentage < MIN_THROTTLE_IN_VOLT && vehicleSpeed <
           CAR STATIONARY SPEED THRESHOLD)
       {
261
           DBGLN_PEDAL("Entering forward mode!");
262
           return false;
264
       return true;
265
266
  int Pedal::calculateReverseTorque(float throttleVolt, float vehicleSpeed,
268
      int torqueRequested)
  // Calculate the torque value for reverse mode
  // require throttle to be less than 1/3
  // limit speed to threshold
271
  {
272
       if (throttleVolt > MAX_THROTTLE_IN_VOLT / 3)
273
           return 0;
274
       if (vehicleSpeed > REVERSE_SPEED_MAX)
275
           return 0;
276
       DBG_PEDAL("Reverse mode: ");
277
278
       return torqueRequested * 0.3; // make reverse slow and controllable
       // consider that throttle must be less than 1/3
279
       // then max torque is 1/10 of the normal torque
280
281
```

#### Listing 2: Pedal.cpp

```
#ifndef PEDAL_H
  #define PEDAL_H
  #include "Queue.h"
  #include "mcp2515.h"
7 // Constants
8 const float APPS_PEDAL_1_MIN_VOLTAGE = 0.0;
9 const float APPS_PEDAL_1_MAX_VOLTAGE = 5.0;
10 const float APPS_PEDAL_2_MIN_VOLTAGE = 0.0;
  const float APPS_PEDAL_2_MAX_VOLTAGE = 3.3;
11
12
13 const float APPS_PEDAL_1_RANGE = APPS_PEDAL_1_MAX_VOLTAGE -
     APPS_PEDAL_1_MIN_VOLTAGE;
  const float APPS_PEDAL_2_RANGE = APPS_PEDAL_2_MAX_VOLTAGE -
     APPS_PEDAL_2_MIN_VOLTAGE;
16 const float APPS_PEDAL_1_LOWER_DEADZONE_WIDTH = 0.0;
  const float APPS_PEDAL_1_UPPER_DEADZONE_WIDTH = 0.4;
18 // const float APPS_PEDAL_2_LOWER_DEADZONE_WIDTH = 0.0;
19 // const float APPS_PEDAL_2_UPPER_DEADZONE_WIDTH = 0.0;
  const float MIN_THROTTLE_IN_VOLT = APPS_PEDAL_1_MIN_VOLTAGE +
     APPS_PEDAL_1_LOWER_DEADZONE_WIDTH;
  const float MAX_THROTTLE_IN_VOLT = APPS_PEDAL_1_MAX_VOLTAGE -
     APPS_PEDAL_1_UPPER_DEADZONE_WIDTH;
  const float THROTTLE_LOWER_DEADZONE_MIN_IN_VOLT = APPS_PEDAL_1_MIN_VOLTAGE
     - APPS_PEDAL_1_LOWER_DEADZONE_WIDTH;
24 const float THROTTLE_UPPER_DEADZONE_MAX_IN_VOLT = APPS_PEDAL_1_MAX_VOLTAGE
     + APPS_PEDAL_1_UPPER_DEADZONE_WIDTH;
25
26 const int MAX_THROTTLE_OUT_VAL = 32430; // Maximum torque value is 32760
     for mcp2515
27 // currently set to a slightly lower value to not use speed control (100%)
  // see E,EnS group discussion, 20250425\,\mathrm{HKT}020800 discussion
29 const int MIN_THROTTLE_OUT_VAL = 300; // Minium torque value tested is 300
     (TBC)
30
  // To go forward, this should be true; false sets the motor to go in
     reverse
32 const bool Flip_Motor_Dir = true; // Flips the direction of motor output
  // set to true for gen 3
35 // Reverse mode "stationary" speed threshold
36 const float CAR_STATIONARY_SPEED_THRESHOLD = 0.2;
37 // Reverse mode entering brake threshold
38 const float REVERSE_ENTER_BRAKE_THRESHOLD = 0.5;
39 // Reverse mode entering throttle threshold
40 const float REVERSE_ENTER_THROTTLE_THRESHOLD = 0.1;
  // Reverse mode maximum speed
42 const float REVERSE_SPEED_MAX = 0.2;
43 // Reverse mode buzzer cycle time
44 const unsigned short REVERSE_BEEP_CYCLE_TIME = 400; // in ms
46 #define ADC_BUFFER_SIZE 16
```

```
48 // Class for generic pedal object
49 // For Gen 5 car, only throttle pedal is wired through the VCU, so we use
     Pedal class for Throttle pedal only.
  class Pedal
50
51
52 public:
      // Two input pins for reading both pedal potentiometer
      // Conversion rate in Hz
54
      Pedal(int input_pin_1, int input_pin_2, int reverse_pin, int buzzer_pin
55
          , unsigned long millis, unsigned short conversion_rate = 1000);
56
      // Defualt constructor, expected another constructor should be called
57
         before start using
      Pedal();
58
      // Update function. To be called on every loop and pass the current
60
         time in millis
      void pedal_update(unsigned long millis);
61
      // Updates the can_frame with the most update pedal value. To be called
63
           on every loop and pass the can_frame by reference.
      void pedal_can_frame_update(can_frame *tx_throttle_msg, unsigned long
         millis, can_frame *tx_debug_msg);
65
      // Updates the can_frame to send a "O Torque" value through canbus.
66
      void pedal_can_frame_stop_motor(can_frame *tx_throttle_msg);
67
68
      // Pedal value after filtering and processing
69
      // Under normal circumstance, should store a value between 0 and 1023
70
         inclusive (translates to 0v - 5v)
      int final_pedal_value;
71
72
  private:
73
      int input_pin_1, input_pin_2, reverse_pin, buzzer_pin;
74
75
      // Will rollover every 49 days
76
      unsigned long previous_millis;
77
78
      unsigned short conversion_rate;
79
80
      // If the two potentiometer inputs are too different (> 10%), the
          inputs are faulty
      // Definition for faulty is under FSEC 2024 Chapter 2, section 12.8,
82
         12.9
      bool fault = false;
83
      unsigned long fault_start_millis;
84
85
      // Forced stop the car due too long fault sensors, restart car to reset
86
           this to false
      bool fault_force_stop = true;
87
88
      // Period in millisecond
89
      unsigned short conversion_period;
90
91
      // Returns true if pedal is faulty
92
      bool check_pedal_fault(int pedal_1, int pedal_2);
93
94
```

```
RingBuffer<float, ADC_BUFFER_SIZE> pedalValue_1;
       RingBuffer<float, ADC_BUFFER_SIZE> pedalValue_2;
96
97
       // reverse mode
98
99
       // Do NOT use in actual competition!
100
       // Read documentation
101
102
103
       // calculate reverse torque value
104
       int calculateReverseTorque(float throttleVolt, float vehicleSpeed, int
105
          torqueRequested);
106
       // reverse button pin to bool
107
       bool reverseButtonPressed = false;
108
       // Reverse mode status
110
       bool reverseMode = false:
111
112
       // function check and set reverse, return reverse mode status
       bool check_enter_reverse_mode(float brakePercentage, float
114
          throttlePercentage, float vehicleSpeed);
115
       // function check and set forward, return reverse mode status
116
       bool check_enter_forward_mode(float brakePercentage, float
117
          throttlePercentage, float vehicleSpeed);
  };
118
  #endif // PEDAL_H
```

Listing 3: Pedal.h

#### 5.3 Queue.cpp and Queue.h

These files implement a static FIFO queue and a ring buffer for managing pedal input data.

```
#include "Queue.h"
  template <typename T, int size>
  Queue < T, size >:: Queue() : queueFull(false), queueEmpty(true), queueCount(0)
       {}
  template <typename T, int size>
  void Queue < T, size > :: push(T val)
  {
8
      for (int i = size - 1; i > 0; i--)
10
           buffer[i] = buffer[i - 1];
12
      buffer[0] = val;
13
14
15
      if (!queueFull)
16
           ++queueCount;
17
      queueFull = (queueCount == size);
18
19
```

```
21 template <typename T, int size>
22 T Queue < T, size > :: pop()
23
      if (queueCount == 0) // If the queue is empty and attempts to pop an
          object, the program will end
           this->exit(0); // this->exit() somehow circumnavigates some
25
               errors
26
      --queueCount;
27
      queueEmpty = (queueCount == 0);
28
30
      return buffer[queueCount];
31
33 template <typename T, int size>
34 T Queue < T, size > :: getHead()
35 {
      return buffer[queueCount - 1];
36
37
38
39 template <typename T, int size>
40 bool Queue < T, size > :: is Empty()
      return queueEmpty;
42
43 }
  template <typename T, int size>
46 bool Queue < T, size > :: is Full()
47
      return queueFull;
48
49 }
```

Listing 4: Queue.cpp

```
#ifndef QUEUE_H
  #define QUEUE_H
4 // A simple FIFO object
5 // This object is completely static
6 template <typename T, int size>
  class Queue
  public:
      Queue();
10
      void push(T val);
12
      T pop();
13
      T getHead();
14
15
      bool isEmpty();
16
      bool isFull();
17
18
19
      T buffer[size];
20
  private:
21
      bool queueFull, queueEmpty;
22
      int queueCount;
23
```

```
24 };
  template <typename T, int size>
  class RingBuffer
28
  public:
29
       RingBuffer() : head(0), count(0) {}
30
       void push(T val)
32
33
           buffer[head] = val;
34
           head = (head + 1) % size;
           if (count < size)</pre>
36
                ++count;
37
       }
38
       void getLinearBuffer(T *out)
40
41
           for (int i = 0; i < count; ++i)</pre>
42
43
                out[i] = buffer[(head + i) % size];
44
45
       }
46
47
       T buffer[size];
48
       int head;
49
       int count;
51
53 #endif // QUEUE_H
```

Listing 5: Queue.h

## 5.4 Signal\_Processing.cpp and Signal\_Processing.h

These files provide simple DSP functions for filtering and processing pedal input signals.

```
#include "Signal_Processing.h"
3 // Apply a FIR filter on the signal buffer
4 // The buffer size must be the same as the kernel
5 // Filtered output will be stored in the output_buf
6 template <typename T>
  T FIR_filter(T *buffer, float *kernel, int buf_size, float kernel_sum)
      float sum = 0;
10
      for (int i = 0; i < buf_size; ++i)</pre>
12
          sum += buffer[i] * kernel[i];
13
14
      // Kernel sum is the sum of all values in the kernel. This normalize
16
          the output value
      return sum / kernel_sum;
^{17}
18
  }
19
```

```
20 template <typename T>
T average (T val1, T val2)
22
      return (val1 + val2) / 2;
23
24
25
  template <typename T>
26
27 T AVG_filter(T *buffer, int buf_size)
28
      float sum = 0;
29
30
      for (int i = 0; i < buf_size; ++i)</pre>
31
           sum += buffer[i];
32
      return sum / (float)buf_size;
33
  }
34
```

Listing 6: Signal Processing.cpp

```
// A library containing simple DSP functions, for ADC filtering, buffer
comparisons and more
#ifndef SIGNAL_PROCESSING_H

#define SIGNAL_PROCESSING_H

template <typename T>
T FIR_filter(T *buffer, float *kernel, int buf_size, float kernel_sum);

template <typename T>
T average(T val1, T val2);

template <typename T>
T AVG_filter(T *buffer, int buf_size);

#endif
```

Listing 7: Signal\_Processing.h

#### 5.5 Debug.h

This file defines macros for enabling or disabling debug messages.

```
#ifndef DEBUG_H
#define DEBUG_H

// === Debug Flags ===

// ALWAYS LEAVE FALSE FOR GITHUB

#define DEBUG false // Overall debug functionality

#define DBC true // Debug CAN bus functionality, independent of DEBUG

#define DEBUG_PEDAL true && DEBUG
#define DEBUG_SIGNAL_PROC false && DEBUG
#define DEBUG_GENERAL true && DEBUG
#define DEBUG_PEDAL true && DEBUG
#define DEBUG_PEDAL true && DEBUG
#define DEBUG_CAN true && DEBUG
#define DEBUG_STATUS true && DEBUG
```

```
18 #if DEBUG_PEDAL
#define DBG_PEDAL(x) Serial.print(x)
20 #define DBGLN_PEDAL(x) Serial.println(x)
21 #else
  #define DBG PEDAL(x)
23 #define DBGLN_PEDAL(x)
24 #endif
25
26 #if DEBUG_SIGNAL_PROC
27 #define DBG_SIG(x) Serial.print(x)
28 #define DBGLN_SIG(x) Serial.println(x)
29 #else
30 #define DBG_SIG(x)
31 #define DBGLN_SIG(x)
32 #endif
34 #if DEBUG GENERAL
35 #define DBG_GENERAL(x) Serial.print(x)
36 #define DBGLN_GENERAL(x) Serial.println(x)
38 #define DBG_GENERAL(x)
39 #define DBGLN_GENERAL(x)
40 #endif
42 #if DEBUG PEDAL
43 #define DBG_PEDAL(x) Serial.print(x)
44 #define DBGLN_PEDAL(x) Serial.println(x)
  #else
46 #define DBG_PEDAL(x)
47 #define DBGLN_PEDAL(x)
48 #endif
49
50 #if DEBUG_CAN
51 #define DBG_CAN(x) Serial.print(x)
52 #define DBGLN_CAN(x) Serial.println(x)
53
  #else
54 #define DBG_CAN(x)
55 #define DBGLN_CAN(x)
56 #endif
57
58 #if DEBUG_STATUS
59 #define DBG_STATUS(x) Serial.print(x)
60 #define DBGLN_STATUS(x) Serial.println(x)
62 #define DBG_STATUS(x)
63 #define DBGLN_STATUS(x)
  #endif
  #endif // DEBUG_H
```

Listing 8: Debug.h

#### 5.6 pinMap.h

This file maps the pins used in the project to meaningful names.

```
1 #ifndef PINMAP_H
```

```
2 #define PINMAP_H
 #define BTN1 5
 #define BTN2 6
 #define BTN3 7
  #define BTN4 8
 // #define CS_CAN 14
10 #define CS_CAN 10 // For arduino testing
12 // #define APPS_5V 23
 // #define APPS_3V3 24
 // #define BRAKE_5V 25
15 // #define BRAKE_OUT 26
16 #define APPS_5V AO
                       // For arduino testing
17 #define APPS_3V3 A1 // For arduino testing
18 #define BRAKE 5V A2 // For arduino testing
19 #define BRAKE_OUT A3 // For arduino testing
 #define REVERSE_BUTTON A4 // For arduino testing
23 #define LED1 2
4 #define LED2 3
25 #define LED3 4
27 #endif // PINMAP_H
```

Listing 9: pinMap.h

## 6 PlatformIO Configuration

The platformio.ini file configures the PlatformIO environment for the project. It specifies the board, framework, and library dependencies.

```
; PlatformIO Project Configuration File
2
3
      Build options: build flags, source filter
      Upload options: custom upload port, speed and extra flags
      Library options: dependencies, extra library storages
      Advanced options: extra scripting
  ; Please visit documentation for the other options and examples
  ; https://docs.platformio.org/page/projectconf.html
 [env:uno]
12 platform = atmelavr
13 board = uno
14 framework = arduino
15 lib_deps = autowp/autowp-mcp25150^1.2.1
 build_flags =
16
      -Wall
17
      -pedantic
18
      -Wextra
```

Listing 10: platformio.ini

## 7 Future Development

- Add more CAN channels for BMS, data logger, and other components.
- Improve the torque curve for better performance.
- Fully implement reverse mode.

## 8 References

- PlatformIO Documentation
- GCC Header File Documentation