Pinball Pool Game - Coin Door Settings

December 24, 2021 12:32 PM

Pinball Pool Game Diagnostic mode Instructions

Open coin door with RPU code running

Press diagnostic switch to progress through all steps.

- It is recommended to check all settings before use on a new installation.
- Where indicated choosing 99 will select the default value for a game feature.
- Holding the credit button will increase settings for scores (button pushes 6-9), double click to reset to zero.
- At any point triggering the coin door slam switch will revert to Attract mode with any changes saved. You do not need to step through to the end.

Press number	Credit Display	Ball in Play	Action
1	00	01	Lamp test, credit button cycles through individual lamps
2			Display test, all displays cycling digits
3	00	03	Solenoid test
4	00	04	Switch test, can display up to 4 closed switches
5	00	05	Sound test, not applicable to Eight Ball Plus
6	01		Extra Ball reward score 1, credit button to set, double click to zero, hold to rapidly increase
7	02		Extra Ball reward score 2, credit button to set, double click to zero, hold to rapidly increase
8	03		Extra Ball reward score 3, credit button to set, double click to zero, hold to rapidly increase
9	04		High Score, credit button to set, double click to zero, hold to rapidly increase
10	05		Credits, credit button to set
11	06		Total Plays - audit only
12	07		Total Replays - audit only
13	08		High Score Beat - audit only
14	09		Chute 2 coins - audit only
15	10		Chute 1 coins - audit only
16	11		Chute 3 coins - audit only
17	12		Freeplay - toggle on/off (0 or 1)
18	13		Ball Save - Set # seconds, set to 99 for default
19	14		Chase Ball Duration - Set # seconds, set to 99 for default
20	15		Spinner Combo Duration - Set # seconds, set to 99 for default
21	16		Spinner Threshold - Set # spinner flips, set to 99 for default

22	17	 Pop Threshold - Set # pop bumper hits, set to 99 for default
23	18	 Next Ball Duration - Set # seconds, set to 99 for default
24	19	 Tilt Warnings - Set to 0,1,2, set to 99 for default
25	20	 Balls per game - Set to 3 or 5, set to 99 for default
26		Return to Attract mode