Modus operandi to get the information from the open platform (*Scenario Explorer*) into the modeling exercise

The following description refers to the folder structure in the GitHub repository of GUSTO, available here.

1. Download the data from Scenario Explorer into the subfolder 'files'.

It contains all information downloaded from the open platform. Note that the actual input file is located under 'Input'. However, the different scenarios and values of the open platform modify these values in 'Input'.

In order to download data from the open platform, run_Read_from_Open_Platform.py. The script should be included in the subfolder 'files' to write the data directly into the corresponding folder (see also step 2). Exemplarily, the following Figure 1 shows the variable LoadFactor|Electricity|Solar|Profile downloaded from the open platform in the extended IAMC format.

| model | ¥ | scenario | ¥ | region | ,Ŧ | variable | - | unit - | time | ¥ | value - |
|--------------|------|------------|------------|---------|----|--|-------|--------|--------------------------|----|---------|
| GUSTO | v1.0 | CS3_2030oE | Storyline | Austria | Π | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 00:00:00 +01: | 00 | |
| GUSTO | v1.0 | CS3_2030oE | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 01:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_20300E | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 02:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_20300E | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 03:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_2030oE | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 04:00:00 +01: | 00 | - 2 |
| GUSTO | v1.0 | CS3_20300E | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 05:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_2030oE | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 06:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_20300E | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 07:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_20300E | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 08:00:00 +01: | 00 | 0.02 |
| GUSTO | v1.0 | CS3_2030oE | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 09:00:00 +01: | 00 | 0.08 |
| GUSTO | v1.0 | CS3_20300E | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 10:00:00 +01: | 00 | 0.06 |
| GUSTO | v1.0 | CS3_20300E | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 11:00:00 +01: | 00 | 0.09 |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 12:00:00 +01: | 00 | 0.18 |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 13:00:00 +01: | 00 | 0.08 |
| GUSTO | v1.0 | CS3_20300E | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 14:00:00 +01: | 00 | 0.03 |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 15:00:00 +01: | 00 | 0.00 |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 16:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 17:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 18:00:00 +01: | 00 | 221 |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 19:00:00 +01: | 00 | |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 20:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_20300E | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 21:00:00 +01: | 00 | 9.73 |
| GUSTO | v1.0 | CS3_2030oE | _Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 22:00:00 +01: | 00 | - |
| GUSTO | v1.0 | CS3_2030oE | Storyline | Austria | | LoadFactor Electricity Solar Pro | ofile | % | 2030-01-01 23:00:00 +01: | 00 | - |

Figure 1 LoadFactor|Electricity|Solar|Profile in the extended IAMC format

2. Linking the information into the modeling task

The script *scenarios.py* (see directory *urbs/scenarios.py*) contains all assumptions, especially those that differ by different scenarios (or storylines). The previously collected information can be used directly as input data. This is again exemplary for the solar profile, as well as the electricity prices shown in Figure 2. Note that in this Python script all desired information can be inserted and considered.

```
def scenario_Norway(data, ub):
    _solar = pd.read_excel('files/NUTS2_loadfactor_solar.xlsx')
    _solar = _solar.loc[_solar['region'] == 'Norway|Vestmidt']
   data['supim']['LMAB1', 'Solar'] = _solar['value'].values
   data['supim']['LMAB2', 'Solar'] = _solar['value'].values
   data['supim']['LMAB3', 'Solar'] = _solar['value'].values
   data['supim']['LMAB4', 'Solar'] = _solar['value'].values
   data['supim']['LMAB5', 'Solar'] = _solar['value'].values
   data['supim']['LMAB6', 'Solar'] = _solar['value'].values
   data['supim']['LMAB7', 'Solar'] = _solar['value'].values
   data['supim']['LMAB8', 'Solar'] = _solar['value'].values
   data['supim']['LMAB9', 'Solar'] = _solar['value'].values
   data['supim']['LMAB10', 'Solar'] = _solar['value'].values
   _price = pd.read_excel('files/EMPSW_elprices_mean.xlsx')
    _price = _price.loc[_price['region'] == 'Norway|Vestmidt']['2030'].values
   data['buy_sell_price']['Elec buy',] = _price
   data['buy_sell_price']['Elec sell',] = _price * 0.98 # to prevent buying and selling at same time step.
   print(data['supim'])
```

Figure 2 Link the information via scenarios.py script into the modeling exercise

3. Write results into the extended IAMC format

After the model run (see *run_model.py*), the results for the modified electricity load profile are written directly into the extended IAMC format. Note that all results can be seen under *Outputs* and, if necessary, further results can be written into the necessary extended IAMC format.

Note that the corresponding changed scenarios still have to be defined in the run_model.py script (see Figure 3).

```
# B) run only maximum points of pareto front (three dimensions)

scenarios = []

[urbs.scenario_SocietalxCommitmentxIBERIANxCityEC, 'cost'],
    [urbs.scenario_SocietalxCommitmentxIBERIANxCityEC, 'local'],
    [urbs.scenario_SocietalxCommitmentxIBERIANxTownEC, 'cost'],
    [urbs.scenario_SocietalxCommitmentxIBERIANxTownEC, 'local'],
    [urbs.scenario_SocietalxCommitmentxIBERIANxMixedEC, 'cost'],
    [urbs.scenario_SocietalxCommitmentxIBERIANxMixedEC, 'local'],
    [urbs.scenario_SocietalxCommitmentxIBERIANxRuralEC, 'cost'],
    [urbs.scenario_SocietalxCommitmentxIBERIANxRuralEC, 'local']
```

Figure 3 Definition of the scenarios to run

The writing process into the format is executed by the command Elec_profile_to_ext_IAMC.write_to_iamc_format() within the run_model.py script and does not have to be started explicitly.