The Shell CPU

Datapath



Jonathan Rice Shelley II September 30, 2020

Version 1.0

1 Contents

- 1. Shell Datapath Overview
- 2. Component Descriptions
- 3. Datapath Register Transfers
- 4. CPU Control and Operation
- 5. Design Tradeoffs

2 Shell Datapath Overview

The Shell datapath is shown in full in figure 4. The CPUs system memory is based on the Harvard architecture separating data and program memory (Figure 1 and 2). In figure 3 the CPU is shown without the surrounding memory.

A high resolution picture of the full datapath can be found at this link.




Figure 1: Top level separation of CPU and memory.




Figure 2: System memory.




Figure 3: CPU structure.




Figure 4: Full CPU structure (rotated for increased resolution).

3 Component Descriptions

Description of inputs, outputs, and function of each component in the datapath.

3.1 Arithmetic Logic Unit




Figure 5: Arithmetic Logic Unit

Functional description

The arithmetic logic unit or ALU performs arithmetic operations on data in the CPU. The block is entirely combinational logic and controlled by its "op" signals. ALU op code signals are one hot. In the event that multiple signals are high priority will be taken to the op code signal that appears first in the IO table below.

IO table		
Inputs	Description	
inputA	16 bit bus, ALU operand	
inputB	16 bit bus, 2nd ALU operand	
op_add	if signal high add operands	
op_sub	if signal high subtract operands	
op_and	if signal high bit-wise and operands	
op_or	if signal high bit-wise or operands	
op_xor	if signal high bit-wise xor operands	
op_nand	if signal high bit-wise nand operands	
op_asr	if signal high arithmetic shift 1 bit right input A	
op_asl	if signal high arithmetic shift 1 bit left input A	
op_cmp	if signal high compare operands.	
Outputs	Description	
outputC	the 16 bit result of some operation on input A and B	

3.2 Simple Adder




Figure 6: Simple adder unit

Functional description

The simple adder block is used to sum values together within the CPU datapath. The block is used once to calculate PC + 1. The block is used a second time to find pc + imm for B-Type instructions.

IO table		
Inputs Description		
a	16 bit bus	
b	16 bit bus	
Outputs	Description	
с	16 bit bus, assigned to sum of a and b.	

3.3 Arithmetic Logic Unit Controller




Figure 7: Arithmetic Logic Unit Controller

Functional description

The arithmetic logic unit controller is used to interpret the ALU op codes from the CPU controller. The outputs of the arithmetic logic unit controller directly control what operation the ALU performs.

IO table		
Inputs	Description	
alu_op	ALU op code from CPU controller	
Outputs	Description	
op_add	add operands	
op_sub	subtract operands	
op_and	bit-wise and operands	
op_or	bit-wise or operands	
op_xor	bit-wise xor operands	
op_nand	bit-wise nand operands	
op_asr	arithmetic shift 1 bit right input A	
op_asl	arithmetic shift 1 bit left input A	
op_cmp	compare operands.	

3.4 Arithmetic Logic Unit Input Multiplexer




Figure 8: Arithmetic Logic Unit Input Multiplexer

Functional description

The arithmetic logic unit input multiplexer is used to mux the input to the 16-bit B operand of the ALU. The input to the ALU can be switched between the output of the GPR file or a ri_imm.

IO table		
Inputs	Description	
from_gpr	16-bit input from GPR file	
from_ri_imm	16-bit input from ri_imm	
sel	select line of multiplexer	
Outputs	Description	
to_alu	16-bit output of mux	

3.5 Comparator Status Register



Figure 9: Comparator Status Register

Functional description

The comparator status register stores the results of a comparison.

IO table		
Inputs	Description	
clk	CPU clk signal	
cmp_status_in	16-bit result of comparison from ALU	
wr_en	write enable line	
Outputs	Description	
eq_sig	High when comparison shows equality	
ne_sig	High when comparison shows inequality	
$\operatorname{gt_sig}$	High when comparison is greater than	
lt_sig	High when comparison is less than	

3.6 CPU Control Unit




Figure 10: CPU Control Unit

Functional description

The CPU control unit decodes instructions and configures the CPU to execute the instructions.

	IO table		
Inputs	Description		
instruction	16-bit instruction		
cmp_eq	status bit from last comparison		
cmp_ne	status bit from last comparison		
$\mathrm{cmp}_{ ext{-}\mathrm{gt}}$	status bit from last comparison		
cmp_lt	status bit from last comparison		
Outputs	Description		
dest_addr	Address of destination register		
$regA_addr$	Address of register A		
$regB_addr$	Address of register B		
alu_op	ALU op code		
reg_file_input_sel	select line for reg file input mux		
reg_file_wr	register file write line		
pc_ld_en	load PC reg enable line		
pc_en	enable PC increment signal		
data_mem_wr	write to data memory signal		
cmp_status_wr	write to comparator register signal		
$ri_imm[5:0]$	ri-type 6-bit immediate		
imm[10:0]	B-type 11 bit immediate		
alu_input_sel	ALU input mux select line		
pc_load_sel	program counter load input mux select line		
stack_ld	stack load input signal		
dec_stack	decrement stack input signal		
inc_stack	increment stack input signal		
stack_wr	enable writing to memory at stack pointer		
ri_imm_format_sel	ri-type format mux select line		

3.7 Data Memory



Figure 11: Data Memory

Functional description

Memory for stack and program data.

IO table		
Inputs	Description	
clk	CPU clk signal	
rd_addr	16-bit read address	
wr_addr	16-bit write address	
data_in	16-bit word to write	
stack_addr	16-bit stack pointer	
stack_wr_en	stack write enable	
wr_en	memory write enable	
Outputs	Description	
data_out	16-bit word from memory at wr_addr	
stack_out	16-bit word from memory at stack pointer	

3.8 11-bit Immediate Sign Extend



Figure 12: 11-bit Immediate Sign Extend

Functional description

Used to sign extend 11-bit immediates from B-type instructions.

IO table		
Inputs	Description	
imm	immediate from b-type instruction	
Outputs	Description	
s_ext_imm	sign extended immediate from b-type instruction	

3.9 Program Counter Load Multiplexer




Figure 13: Program Counter Load Multiplexer

Functional description

Used to multiplex inputs to PC load bus.

IO table		
Inputs	Description	
gpr_in	GPR file 16-bit output	
pc_imm_b	value of pc + immediate	
sel	multiplexer select signal	
Outputs	Description	
to_pc_ld	output value to PC load word port	

3.10 Program Counter Register



Figure 14: Program Counter Register

Functional description

Program counter used to keep the address of the next instruction in memory.

IO table		
Inputs	Description	
clk	CPU clock	
ld_val	16-bit word to load PC with	
ld_en	PC load enable	
en	enable PC increment.	
Outputs	Description	
ins_addr	address of the next instruction in memory	

3.11 Program Memory




Figure 15: Program Memory

Functional description

Program memory used to store program instructions.

IO table		
Inputs	Description	
clk	CPU clock	
ins_addr	instruction address	
Outputs	Description	
cur_ins	current instruction	

3.12 General Purpose Register File



Figure 16: General Purpose Register File

Functional description

GPR (General Purpose Register) file is used to store temporary values during computation.

IO table		
Inputs	Description	
clk	CPU clock	
read_addrA	GPR address	
$read_addrB$	GPR address	
$write_addrC$	GPR address	
regC	data word to be written to GPR	
wr_en	write enable	
Outputs	Description	
regA	contents of GPR at addrA	
regB	contents of GPR at addrB	

3.13 Register File Input Multiplexer




Figure 17: Register File Input Multiplexer

${\bf Functional\ description}$

Used to multiplex the data input to the GPR file.

IO table	
Inputs	Description
in_alu	16-bit output from ALU
data_mem	16-bit output from data memory
next_ins_addr	16-bit PC + 1
from_stack	16-bit word from stack
reg_input_sel	multiplexer select line
Outputs	Description
output_reg	16-bit output of multiplexer

3.14 RI-Type Zero Extend Immediate



Figure 18: RI-Type Zero Extend Immediate

Functional description

Used to zero extend the ri-type immediate field.

IO table	
Inputs Description	
imm	6-bit immediate
Outputs	Description
z_ext_imm	16-bit zero extended 6-bit immediate

3.15 RI-Type Immediate Format Multiplexer




Figure 19: RI-Type Immediate Format Multiplexer

Functional description

Multiplex RI-Type immediate between zero extended and upper 6-bit concatenation format.

IO table	
Inputs	Description
upper_concat_imm	16-bit concat immediate
$z_{\text{ext_imm}}$	16-bit zero extended immediate
sel	multiplexer select line
Outputs	Description
ri_imm	16-bit formatted ri-type immediate

3.16 RI-Type Immediate Upper 6-bit Concatenation



Figure 20: RI-Type Immediate Upper 6-bit Concatenation

Functional description

Concatenate 6-bit immediate with upper part of 16-bit register zero all lower bits.

IO table	
Inputs Description	
imm	6-bit immediate
Outputs	Description
upper_concat	16-bit formatted ri-type immediate

3.17 Stack Pointer Register




Figure 21: Stack Pointer Register

Functional description

Register holds stack pointer.

IO table		
Inputs	Description	
clk	CPU clk	
ld_val	word to be loaded into stack pointer	
ld_en	enable write to stack pointer register	
dec	decrement stack pointer	
inc	increment stack pointer	
Outputs	Description	
$stack_ptr$	16-bit stack pointer	

4 Datapath Register Transfers

The datapath register transfers section details the register transfers that take place for each instruction. In the below table R_n corresponds to registers in the GPR file.

No.	Instruction	Register Transfers	
1	hlt	PC => PC	
2	add R_1 , R_2 , R_3	$R_2, R_3 => ALU => R_3$	
3	sub R_1 , R_2 , R_3	$R_2, R_3 => ALU => R_3$	
4	and R_1, R_2, R_3	$R_2, R_3 => ALU => R_3$	
5	or R_1, R_2, R_3	$R_2, R_3 => ALU => R_3$	
6	$xor R_1, R_2, R_3$	$R_2, R_3 => ALU => R_3$	
7	nand R_1 , R_2 , R_3	$R_2, R_3 => ALU => R_3$	
8	$lw R_1, R_2$	$R_2 => Data Memory => R_1$	
9	sw R_1, R_2	$R_1, R_2 => Data Memory$	
10	asr R_1, R_2	$R_2 \Longrightarrow ALU \Longrightarrow R_1$	
11	asl R_1, R_2	$R_2 \Longrightarrow ALU \Longrightarrow R_1$	
12	cmp R_1, R_2	$R_1, R_2 => ALU => compare register$	
13	jalr R_1, R_2	$PC \Longrightarrow +1 \text{ adder} \Longrightarrow R_1 \mid R_2 \Longrightarrow PC$	
14	push R_1	$R_1 = $ data memory at addr SP	
15	pop R_1	data memory at addr SP $=> R_1$	
16	lsp R_1	$R_1 = $ Stack Pointer Register	
17	addi R_1 , imm	$R_1, imm => \text{zero extend} => \text{ALU} => R_1$	
18	subi R_1 , imm	R_1 , $imm =>$ zero extend $=>$ ALU $=>$ R_1	
19	lui R_1 , imm	R_1 , $imm =>$ zero extend $=>$ ALU $=>$ R_1	
20	beq imm	imm => sign extend => + current PC adder => PC	
21	bne imm	imm => sign extend => + current PC adder => PC	
22	bgt imm	imm => sign extend => + current PC adder => PC	
23	blt imm	imm => sign extend => + current PC adder => PC	

5 CPU Control and Operation

This section list all control signals and their values needed to perform each instruction in the Shell ISA.




Figure 22: Shell CPU Control Unit

To perform each instruction the combinational logic control unit shown above must decode the 16-bit instruction and configure its outputs to set the CPU into the desired state. Each instruction will configure the outputs of this block in a unique format. The outputs for proper control unit configuration for each instruction is listed below.

The table below describes the symbols used in the tables that describe the control unit output for each instruction. Each symbol will always correspond to 1 bit.

Control Truth Table Symbol Key	
Symbol	Description
0	0 bit / low signal
1	1 bit / high signal
X	don't care bit
n	value defined by field in instruction. Ex: (imm or GPR addresses)
{ ctrl_unit_input_sig_name }	{} denotes the use of a ctrl unit input signal

5.1 Halt S-Type Instruction

The halt instruction stops the CPU from executing instructions.

Signal	Binary value
$dest_addr[2:0]$	XXX
$regA_addr[2:0]$	xxx
$regB_addr[2:0]$	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	XX
reg_file_wr	0
pc_ld_en	0
pc_en	0
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	X
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.2 Add RRR-Type Instruction

The add instruction uses the ALU to add 2 registers from the GPR file and stores the result back in the GPR file

Signal	Binary value
dest_addr[2:0]	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	nnn
alu_op[3:0]	0000
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	0
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.3 Sub RRR-Type Instruction

The sub instruction uses the ALU to subtract 2 registers from the GPR file and stores the result back in the GPR file.

Signal	Binary value
$dest_addr[2:0]$	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	nnn
alu_op[3:0]	0001
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	0
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	x

5.4 And RRR-Type Instruction

The and instruction uses the ALU to bit-wise and 2 registers from the GPR file and stores the result back in the GPR file.

Signal	Binary value
dest_addr[2:0]	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	nnn
alu_op[3:0]	0010
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	0
pc_load_sel	X
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	x

5.5 Or RRR-Type Instruction

The or instruction uses the ALU to bit-wise or 2 registers from the GPR file and stores the result back in the GPR file.

Signal	Binary value
$dest_addr[2:0]$	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	nnn
alu_op[3:0]	0011
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	0
pc_load_sel	x
$stack_ld$	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.6 Xor RRR-Type Instruction

The xor instruction uses the ALU to bit-wise xor 2 registers from the GPR file and stores the result back in the GPR file.

	Ι
Signal	Binary value
$dest_addr[2:0]$	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	nnn
alu_op[3:0]	0100
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	0
pc_load_sel	X
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.7 Nand RRR-Type Instruction

The nand instruction uses the ALU to bit-wise nand 2 registers from the GPR file and stores the result back in the GPR file.

Signal	Binary value
dest_addr[2:0]	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	nnn
alu_op[3:0]	0101
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	0
pc_load_sel	X
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	x

5.8 Lw RR-Type Instruction

The lw instruction loads a 16-bit word from memory and stores it in the GPR file.

Signal	Binary value
dest_addr[2:0]	nnn
regA_addr[2:0]	nnn
regBaddr[2:0]	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	01
reg_file_wr	1
pc_ld_en	0
pc_en	1
$data_mem_wr$	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	X
pc_load_sel	X
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.9 Sw RR-Type Instruction

The sw instruction stores a 16-bit word at an address in data memory. The address and value stored are from the GPR file.

Signal	Binary value
dest_addr[2:0]	XXX
regA_addr[2:0]	nnn
$regB_addr[2:0]$	nnn
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	xx
reg_file_wr	0
pc_ld_en	0
pc_en	1
data_mem_wr	1
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	X
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	x

5.10 Asr RR-Type Instruction

The asr instruction performs an arithmetic shift right using the ALU.

Signal	Binary value
dest_addr[2:0]	nnn
regA_addr[2:0]	nnn
regB_addr[2:0]	xxx
alu_op[3:0]	0110
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	x
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.11 Asl RR-Type Instruction

The asl instruction performs an arithmetic shift left using the ALU.

Signal	Binary value
dest_addr[2:0]	nnn
regA_addr[2:0]	nnn
regBaddr[2:0]	xxx
alu_op[3:0]	0111
$reg_file_input_sel[1:0]$	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	x
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.12 Cmp RR-Type Instruction

Compare two registers using ALU store result in compare register.

Signal	Binary value
dest_addr[2:0]	XXX
regA_addr[2:0]	nnn
regBaddr[2:0]	nnn
alu_op[3:0]	1010
reg_file_input_sel[1:0]	XX
reg_file_wr	0
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	1
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	0
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.13 Jalr RR-Type Instruction

The jalr or (jump and link register) instruction jumps to an address and writes the old PC value + 1 into a specified register.

Signal	Binary value
dest_addr[2:0]	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	10
reg_file_wr	1
pc_ld_en	1
pc_en	0
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	x
pc_load_sel	0
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	x

5.14 Push R-Type Instruction

The push instruction puts a register value onto the stack and decrement the stack pointer.

Signal	Binary value
dest_addr[2:0]	XXX
$regA_addr[2:0]$	nnn
regBaddr[2:0]	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	XX
reg_file_wr	0
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	x
pc_load_sel	x
stack_ld	0
dec_stack	1
inc_stack	0
stack_wr	1
ri_imm_format_sel	X

5.15 Pop R-Type Instruction

The pop instruction gets a value off the stack to store in GPR file and increments the stack pointer.

Signal	Binary value
dest_addr[2:0]	nnn
regA_addr[2:0]	xxx
regB_addr[2:0]	xxx
alu_op[3:0]	xxxx
$reg_file_input_sel[1:0]$	11
reg_file_wr	1
pc_ld_en	0
pc_en	1
$data_mem_wr$	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	x
pc_load_sel	X
stack_ld	0
dec_stack	0
inc_stack	1
stack_wr	0
ri_imm_format_sel	X

5.16 Lsp R-Type Instruction

The lsp (load stack pointer) instruction is used to set the value of the stack pointer from a register in the GPR file.

Signal	Binary value
dest_addr[2:0]	XXX
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	xx
reg_file_wr	0
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	xxxxxxxxxx
alu_input_sel	X
pc_load_sel	x
stack_ld	1
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.17 Addi RI-Type Instruction

The addi instruction uses the ALU to add a 6 bit unsigned immediate to a register. The result is stored into a specified destination register.

Signal	Binary value
dest_addr[2:0]	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	xxx
alu_op[3:0]	0000
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
$data_mem_wr$	0
cmp_status_wr	0
ri_imm[5:0]	nnnnn
imm[10:0]	xxxxxxxxxx
alu_input_sel	1
pc_load_sel	X
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	1

5.18 Subi RI-Type Instruction

The subi instruction uses the ALU to subtract a 6 bit unsigned immediate to a register. The result is stored into a specified destination register.

Signal	Binary value
$dest_addr[2:0]$	nnn
$regA_addr[2:0]$	nnn
$regB_addr[2:0]$	xxx
alu_op[3:0]	0001
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	nnnnn
imm[10:0]	xxxxxxxxxx
alu_input_sel	1
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	1

5.19 Lui RI-Type Instruction

The lui (load upper immediate) instruction sets the upper 6-bits of a specified register in the GPR file.

Signal	Binary value
dest_addr[2:0]	nnn
$regA_addr[2:0]$	nnn
regB_addr[2:0]	000
alu_op[3:0]	0000
reg_file_input_sel[1:0]	00
reg_file_wr	1
pc_ld_en	0
pc_en	1
$data_mem_wr$	0
cmp_status_wr	0
ri_imm[5:0]	nnnnnn
imm[10:0]	xxxxxxxxxx
alu_input_sel	1
pc_load_sel	x
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	0

5.20 Beq B-Type Instruction

The beq (branch equal) instruction performs a jump with an 11 bit signed immediate when the eq_sig flag of the compare register is set high.

Signal	Binary value
dest_addr[2:0]	XXX
$regA_addr[2:0]$	xxx
$regB_addr[2:0]$	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	xx
reg_file_wr	0
pc_ld_en	$\{ cmp_eq \}$
pc_en	$\{ \neg cmp_eq \}$
$data_mem_wr$	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	nnnnnnnnn
alu_input_sel	xx
pc_load_sel	1
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.21 Bne B-Type Instruction

The bne (branch not equal) instruction performs a jump with an 11 bit signed immediate when the ne_sig flag of the compare register is set high.

Signal	Binary value
dest_addr[2:0]	XXX
regA_addr[2:0]	XXX
$regB_addr[2:0]$	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	xx
reg_file_wr	0
pc_ld_en	{ cmp_ne }
pc_en	$\{ \neg cmp_ne \}$
$data_mem_wr$	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	nnnnnnnnn
alu_input_sel	xx
pc_load_sel	1
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.22 Bgt B-Type Instruction

The bgt (branch greater than) instruction performs a jump with an 11 bit signed immediate when the gt_sig flag of the compare register is set high.

Signal	Binary value
$dest_addr[2:0]$	xxx
$regA_addr[2:0]$	xxx
$regB_addr[2:0]$	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	xx
reg_file_wr	0
pc_ld_en	{ cmp_gt }
pc_en	$\{ \neg \text{cmp_gt } \}$
$data_mem_wr$	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	nnnnnnnnn
alu_input_sel	xx
pc_load_sel	1
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	X

5.23 Blt B-Type Instruction

The blt (branch less than) instruction performs a jump with an 11 bit signed immediate when the lt_sig flag of the compare register is set high.

Signal	Binary value
dest_addr[2:0]	XXX
$regA_{-}addr[2:0]$	xxx
$regB_addr[2:0]$	xxx
alu_op[3:0]	xxxx
reg_file_input_sel[1:0]	xx
reg_file_wr	0
pc_ld_en	$\{ \text{ cmp_lt } \}$
pc_en	$\{ \neg \text{cmp_lt } \}$
data_mem_wr	0
cmp_status_wr	0
ri_imm[5:0]	xxxxxx
imm[10:0]	nnnnnnnnn
alu_input_sel	XX
pc_load_sel	1
stack_ld	0
dec_stack	0
inc_stack	0
stack_wr	0
ri_imm_format_sel	x

6 Design Tradeoffs

The Shell datapath design favors simplistic implementation of the instruction set. A single clock cycle design was used. On positive clock edges values are stored with edge triggered flip-flops. During the remaining clock cycle the computational logic decodes the instruction and performs necessary operations. Dedicated components were used to cut down on unnecessary complexity in the datapath. Due to the Shell CPUs single clock cycle design the clock must have a period greater than the slowest instruction. A stack was included in the datapath so that recursive subroutine calls can be easily implemented in software.