CSE 331/EEE 332 (Microprocessor Interfacing & Embedded System Lab)

Lab 03 : Conditional jumps/Unconditional jumps;

Procedures;

Instructions: MUL, DIV, CMP, SUB, AND, JZ, JMP

Lab Officer : Azmary Zannat Aurin

Topics to be covered in class today:

• Conditional Jumps/Unconditional Jumps

Procedures

• Instructions: CMP, AND, SUB, JZ, JMP

Instruction	Operands	Description
MUL	REG, REG	Multiplication.
	REG, memory	8 bit multiplication
		If we multiply two 8 bit unsigned positive numbers, we will get an unsigned 16 bit result. For this operation, we have to put one operand in accumulator register. The output of the multiplication will be stored in ax. 16 bit multiplication If we multiply two 16 bit unsigned positive numbers, we will get an unsigned 32 bit result. For this operation, we have to put one operand in accumulator register. The 32 bit result becomes available in the dx register and ax register. The lower 16 bit will be stored in ax register and the higher 16 bit will be stored in dx register. Example: MOV AL, 5 MOV DL, 6 MUL DL

DIV	REG, REG	Division.	
	REG, memory	8 bit division	
	rea, memory	If we divide a 16 bit unsign 8 bit unsigned positive nur division will be stored in remainder will be stored in AL = Quotient AH = Remainder 16 bit division	mber, the quotient of the al register and the
		If we divide a 32 bit unsign 16 bit unsigned positive nudivision will be stored in remainder will be stored in AX = Quotient DX = Remainder Example:	umber, the quotient of the ax register and the
		8 bit division	16 bit division
		MOV AX, 01234H	MOV DX, 01234H
		MOV BL, 03FH DIVBL; AX/BX	MOV AX, 05678H MOV BX, 09000H DIV BX ; DX:AX / BX
CMP	REG, memory	Compare.	
	memory, REG REG, REG memory, immediate REG, immediate	Algorithm:	
		operand1 - operand2	
		Result is not stored anywh	ere, flags are set (OF, SF,
		ZF, AF, PF, CF) according to Example:	result.
		MOV AL, 5	
		MOV BL, 5 CMP AL, BL ; AL = 5, ZF = 1	(so equal!)

SUB	REG, memory memory, REG REG,	Subtract.
	REG	Algorithm:
	memory, immediate REG, immediate	operand1 = operand1 - operand2
		Example:
		MOV AL, 5
		SUB AL, 1 ;AL=4
AND	REG, memory	Logical AND between all bits of two operands. Result
	memory, REG REG, REG	is stored in operand1. These rules apply:
	memory, immediate	,
	REG, immediate	1AND1=1
		1AND0=0
		0AND1=0
		OANDO=0
		Example:
		MOV AL, 'a' ; AL = 01100001b
		AND AL, 11011111b; AL = 01000001b ('A')

Jump Instruction

Jump Instructions are used for changing the flow of execution of instructions in the processor. If we want jump to any instruction in between the code, then this can be achieved by these instructions. There are two types of Jump instructions:

Unconditional Jump Instructions
Conditional Jump Instructions

Instruction	Operands	Description
JZ	Label	Short Jump if Zero (equal). Set by CMP, SUB, ADD, TEST, AND, OR, XOR instructions. Algorithm:
		if ZF = 1 then jump
		Example:
		.MODEL SMALL
		.STACK 100H .DATA
		.CODE
		MAIN PROC
		MOV AL, 5
		CMP AL, 5 JZ label1
		MOV DL, 1
		JMP exit
		label1:
		MOV DL, 0
		exit:
		ENDP MAIN
		END MAIN

JMP Label

Unconditional Jump.
Transfers control to another part of the program. 4-byte address

may be entered in this form: 1234h:5678h, first value is a segment second value is an offset.

Algorithm:

always jump

Example:

.MODEL SMALL

.STACK 100H

.DATA

.CODE

MAIN PROC

MOV AL, 5

JMP exit ; jump over 2

lines!

MOV AL, 0

exit:

ENDP MAIN

END MAIN

PUSH	Store 16 bit data into two locations of SSM (stack) pointed by SS:SP The data source may be: • 16 bit register (except IP, CS) • Two consecutive memory locations
	; assume ax = 4567H PUSH AX PUSH DS PUSH WORD PTR DS:[BX]
POP	Retrieve 16 bit from two locations of stack pointed by SS:SP The data destination may be: • 16 bit register • Two consecutive memory locations POP AX POP DS POP WORD PTR DS:[BX]

Difference between CMP and SUB

CMP: Comparison of two numbers, is carried out in the form of a subtraction to determine which of the operands has a greater value. After a CMP instruction, PSW or flag resister get updated. For example, if the operands have equal values, then ZF will be set to 1.

The CMP instruction does not modify the destination field

SUB: SUB instruction subtracts the source value from the destination. The logic of the SUB instruction is:

destination = destination - source

The SUB instruction modifies the destination field

Labels

- Labels mark places in a program which other instructions and directives reference
- Labels in the code segment always end with a colon
- Labels in the data segment never end with a colon
- Labels can be from 1 to 31 characters long and may consist of letters, digits, and the special characters?. @ _ \$ %
- If a period is used, it must be the first character
- · Labels must not begin with a digit
- The assembler is case insensitive

Legal and Illegal Labels

- Examples of legal names
 - COUNTER1
 - @character
 - SUM_OF_DIGITS
 - \$1000 o DONE?
 - .TEST
- Examples of illegal names
 - TWO WORDS contains a blank
 - 2abc begins with a digit
 - A45.28 . not first character
 - YOU&ME contains an illegal character

Example:

Start: mov mov jmp mov

ds, ax

Exit

cx, 10

Procedures

Procedure is a part of code that can be called from your program in order to make some specific task. Procedures make program more structural and easier to understand. Generally procedure returns to the same point from where it was called.

The syntax for procedure declaration:

name PROC ; code RET name ENDP

name - is the procedure name, the same name should be in the top and the bottom, this is used to check correct closing of procedures.

Probably, you already know that RET instruction is used to return to operating system. The same instruction is used to return from procedure (actually operating system sees your program as a special procedure).

PROC and ENDP are compiler directives, so they are not assembled into any real machine code.

Compiler just remembers the address of procedure.

CALL instruction is used to call a procedure.

Example:

.MODEL SMALL

.STACK 100H

.DATA

.CODE

M2 PROC

MULBL;AX=AL*BL.

RET

M2 ENDP MAIN PROC MOV AL, 1 MOV BL, 2 CALL m2; 1*2 = 2CALL m2; 2*2 = 4CALL m2; 4*2 = 8CALL m2; 8*2 = 16**ENDP MAIN END MAIN** To work with parameters like other languages you can use PUSH and POP instructions. Example: .MODEL SMALL .STACK 100H .DATA .CODE ADD_TWO PROC POP AX POP DX POP CX

PUSH AX

RET

ENDP ADD_TWO

ADD DX, CX

```
MAIN PROC
```

PUSH 2

PUSH 3

CALL ADD_TWO

ENDP MAIN

END MAIN

Task 1

Write a program that will count the number of characters in a string.

Task 2

Write a program that will concatenate (join) two strings. Make sure the input strings are not destroyed and the final answer must be inside a third array. Input from user not required. Create two strings in your program.

Example:

String 1: "Hello World, "

String 2: "this is Assembly Language Programming"