
PCB ROUTING TECHNIQUES

1. Component Placement



• Strategic Placement:

- a. Plan placement based on signal flow.
- b. Group components by function (analog, digital, power) to minimize interference.

• Minimize Trace Lengths:

a. Place components to shorten trace lengths.

• Sensitive Components:

a. Keep sensitive components away from high-frequency and high-power traces.

• Thermal Considerations:

a. Place heat-generating components to optimize thermal management.

• Accessibility:

a. Ensure critical components are accessible for testing and debugging.

• Power Supply Proximity:


a. Place power supply components close to the load to reduce voltage drop.

• Signal Path Optimization:


a. Arrange components to maintain a direct and clear signal path.

• Grounding:

a. Place grounding components close to related parts to minimize noise.



2. Trace Length



• Keep Traces Short:

a. Minimize trace lengths to reduce signal delay and interference.

• Consistent Lengths:

a. Maintain consistent lengths for parallel high-speed signals to ensure timing integrity.

• Direct Paths:


a. Use direct routing paths to minimize overall trace length.

• Avoid Loops:


a. Avoid unnecessary loops in trace routing to reduce inductance and noise.

• Length Matching:

a. Match lengths of differential pair traces (e.g., USB, HDMI) to maintain signal quality.



3. Trace Width and Clearance



Appropriate Widths:

a. Choose trace widths based on current carrying capacity and impedance requirements.

Clearance:

a. Maintain adequate spacing between traces to prevent crosstalk and shorts.

• High Current Traces:

a. Use wider traces for high-current paths to minimize resistance and heating.

• High-Frequency Signals:


a. Ensure consistent trace width for high-frequency signals to maintain impedance.

• Manufacturing Tolerances:


a. Adhere to manufacturer's specifications for minimum trace width and clearance.

Safety Standards:

a. Follow safety standards for spacing between high-voltage traces and other components.



4. Signal Integrity



• Uniform Trace Widths:

a. Use consistent trace widths to maintain controlled impedance.

• Avoid Sharp Bends:

a. Use smooth, gradual bends instead of sharp angles to prevent signal reflection.

• Differential Pair Routing:

a. Route differential pairs (e.g., LVDS, USB) with consistent spacing and parallelism.

• Minimize Via Usage:

a. Reduce the number of vias to avoid impedance discontinuities and signal degradation.

• Controlled Impedance:

a. Design traces with controlled impedance, especially for high-frequency signals.

• Proper Grounding:


a. Use continuous ground planes to provide a stable reference and reduce noise.

• Isolate High-Speed Traces:


a. Keep high-speed signal traces away from noisy components and power lines.

• Match Trace Lengths:

a. Ensure matched trace lengths for critical high-speed signals to maintain timing integrity.



5. Layer Management



• Separate Signal Types:

a. Use different layers for different signal types (e.g., analog, digital, power).

• Dedicated Power and Ground Planes:

a. Allocate entire layers for power and ground to ensure low impedance and stable reference.

• Signal Layer Arrangement:

a. Organize signal layers to minimize crosstalk and interference (e.g., high-speed signals between ground planes).

• Stack-Up Planning:

a. Plan the layer stack-up to balance signal integrity, thermal performance, and manufacturability.

• Minimize Layer Switching:

a. Reduce the number of layer changes for critical signals to maintain signal integrity.

• Adjacent Ground Planes:


a. Place ground planes adjacent to signal layers to provide consistent return paths.

• Isolation of Noisy Signals:


a. Isolate noisy signals on separate layers to prevent interference with sensitive signals.

• Thermal Management:

a. Use thermal vias and planes to manage heat dissipation across layers.



6. Via Placement



• Minimize Via Use:

a. Reduce the number of vias to avoid impedance discontinuities and signal integrity issues.

• Avoid Critical Paths:

a. Place vias away from high-frequency and high-speed signal paths to prevent signal degradation.

• Thermal Management:

a. Use thermal vias to help dissipate heat from high-power components.

• Ground and Power Connections:

a. Ensure robust connections with multiple vias for ground and power planes.

• Via-in-Pad Design:

a. Use via-in-pad for high-density designs but ensure proper filling and capping to avoid solder issues.

• Strategic Placement:


a. Place vias strategically to optimize routing efficiency and reduce trace length.

• Staggered Vias:


a. Use staggered vias for differential pairs to maintain trace length matching.

• Manufacturing Constraints:

a. Follow manufacturer guidelines for via sizes, aspect ratios, and annular ring requirements.



7. Power and Ground Distribution



• Dedicated Planes:

a. Use entire layers dedicated to power and ground to ensure low impedance and stable voltage distribution.

• Wide Traces:

a. Use wide traces for power and ground connections to minimize voltage drop and resistance.

• Short and Direct Paths:

a. Keep power and ground paths as short and direct as possible to reduce inductance and noise.

• Multiple Vias:

a. Use multiple vias to connect power and ground planes, improving current handling and thermal performance.

• Decoupling Capacitors:

a. Place decoupling capacitors close to IC power pins to filter noise and stabilize the power supply.

• Star Routing:


a. Implement star routing for power distribution to prevent ground loops and ensure even power distribution.

• Ground Plane Continuity:


a. Ensure continuity of ground planes across layers to provide a solid reference and reduce EMI.

Avoid Ground Loops:

a. Design the layout to avoid ground loops, which can introduce noise and interfere with signal integrity.



8. Crosstalk and Electromagnetic Interference (EMI)



• Adequate Spacing:

a. Maintain sufficient spacing between high-speed or high-current traces to reduce crosstalk.

• Shielding:

a. Use ground planes or guard traces to shield sensitive signals from noisy ones.

• Proper Trace Routing:

a. Route high-speed signals on internal layers between ground planes to reduce EMI.

• Differential Pairs:

a. Route differential pairs together with consistent spacing to cancel out noise.

• Perpendicular Routing:

a. Route adjacent signal layers perpendicularly to minimize coupling and crosstalk.

• Isolate Noisy Components:

a. Place noisy components away from sensitive circuits to reduce EMI.

• Decoupling Capacitors:

a. Use decoupling capacitors to filter noise on power lines and stabilize voltage.

• Minimize Loop Areas:


a. Reduce the loop area of signal paths to minimize the potential for EMI.

• Controlled Impedance:

a. Design traces with controlled impedance to maintain signal integrity and reduce reflections.

• Use of Ferrite Beads:

a. Incorporate ferrite beads on power lines to suppress high-frequency noise.



9. Routing Order

• Critical Signals First:

a. Route critical signals such as clocks and high-speed data lines first to ensure proper timing and signal integrity.

• Efficient Paths:

a. Plan efficient routing paths to minimize trace length and interference.

• High-Speed Signals:

a. Prioritize routing high-speed signals before lower-frequency signals to prevent signal degradation.

• Power and Ground Traces:

a. Route power and ground traces after critical signals to provide stable power distribution and grounding.

• Signal Groups:

a. Route signals in groups based on functionality to optimize signal flow and reduce crosstalk.

• Differential Pairs:

a. Route differential pairs together with consistent spacing to maintain signal integrity.


• Layer Switching:

a. Minimize layer changes for critical signals to avoid impedance mismatches.

• Final Routing Pass:

a. Fill in remaining routing areas with less critical signals, considering manufacturability and space constraints.

10. Decoupling Capacitors



Close Proximity:

a. Place decoupling capacitors as close as possible to the power pins of ICs to minimize loop inductance.

Across Power Rails:

a. Connect decoupling capacitors across the power rails of ICs to provide a stable power supply and filter out noise.

Multiple Capacitors:

a. Use multiple capacitors of different values (e.g., ceramic and electrolytic) to address a wide frequency range of noise.

• Diverse Capacitor Types:


a. Employ a combination of low-ESR ceramic capacitors for high-frequency noise and bulk electrolytic capacitors for low-frequency noise.

• Parallel Paths:

a. Place decoupling capacitors in parallel paths for high-current components to ensure adequate power delivery.

• Via Stitching:

a. Use via stitching around decoupling capacitors to enhance their performance and reduce parasitic inductance.




• Strategic Placement:


a. Distribute decoupling capacitors evenly across the PCB layout to provide uniform power distribution.

• Signal Integrity Consideration:

a. Ensure that decoupling capacitors do not interfere with signal traces and routing.



11. Thermal Management



• Component Placement:

a. Strategically place high-power components to optimize heat dissipation.

• Heat Dissipation Paths:

a. Route high-power traces to distribute heat evenly across the PCB.

• Thermal Vias:

a. Use thermal vias to connect heat-generating components to internal or external copper layers for improved heat dissipation.

• Thermal Relief:

a. Implement thermal relief connections for vias connected to copper pours to minimize thermal stress during soldering.

• Thermal Pads:

a. Use thermal pads or exposed copper areas to enhance heat transfer from components to the PCB.

• Keepout Zones:


a. Create keepout zones around heat-sensitive components to prevent them from being affected by nearby heat sources.

• Heat Sinks:


a. Utilize heat sinks on components with high thermal dissipation requirements to further enhance cooling.

• Simulation Tools:

a. Use thermal simulation tools to predict and optimize heat dissipation before PCB fabrication.



12. Design Rule Check (DRC)



Automated Verification:

a. Use DRC tools to automatically check the PCB design against predefined design rules and constraints.

• Electrical Integrity:

a. Ensure proper clearance between traces, minimum trace widths, and correct layer assignments to maintain electrical integrity.

• Manufacturability:

a. Verify design compliance with manufacturing constraints such as minimum annular ring size, drill-to-copper spacing, and solder mask clearances.

• Signal Integrity:

a. Check for impedance mismatches, signal length matching, and proper termination to maintain signal integrity.

• Layer Stackup:

a. Validate layer stackup configurations, including layer thicknesses, materials, and dielectric constants.

• Spacing and Clearance:


a. Verify adequate spacing and clearance between components, vias, and board edges to prevent shorts and ensure manufacturability.

• Mask and Silkscreen Alignment:

a. Check alignment of solder mask openings and silkscreen markings with component footprints to avoid misalignment during manufacturing.

• Comprehensive Analysis:

a. Conduct a comprehensive analysis of the entire PCB layout to identify and resolve potential design violations and errors.



REFERENCES

- 1. https://www.protoexpress.com/blog/component-placement-guidelines-pcb-design-assembly/#
- 2. https://www.protoexpress.com/blog/best-high-speed-pcb-routing-practices/
- 3. https://www.integrasources.com/blog/high-speed-pcb-design-guidelines/
- 4. https://www.autodesk.com/products/fusion-360/blog/trace-length-and-high-speed-designs/
- 5. https://www.protoexpress.com/blog/understanding-signal-integrity/
- 6. https://www.protoexpress.com/blog/best-high-speed-pcb-routing-practices/
- 7. https://circuitdigest.com/article/an-overview-of-layer-stack-management-in-pcb-design
- 8. https://docs.ultrazohm.com/hardware/altium/altium db lib/altium Layer Stack.html
- 9. https://www.protoexpress.com/blog/pcb-stack-up-plan-design-manufacture-repeat/
- 10. https://resources.altium.com/p/pcb-via
- 11. https://www.pcbgogo.com/blog/What Is Via in Pad .html

- 12. https://www.4pcb.com/blog/the-importance-of-power-and-ground-planes-in-pcb-design/
- 13. https://resources.altium.com/p/should-you-use-your-power-plane-as-a-return-path
- 14. https://www.autodesk.com/products/fusion-360/blog/electromagnetic-interference-emi-effects-on-circuit-board-pcb/
- 15. https://www.nextpcb.com/blog/pcb-crosstalk
- 16. https://www.protoexpress.com/blog/7-pcb-design-tips-solve-emi-emc-issues/
- 17. https://www.protoexpress.com/blog/decoupling-capacitor-use/
- 18. https://e2e.ti.com/blogs_/archives/b/precisionhub/posts/the-decoupling-capacitor-is-it-really-necessary
- 19. https://www.protoexpress.com/blog/12-pcb-thermal-management-techniques-to-reduce-pcb-heating/
- 20. https://www.powerelectronicsnews.com/high-power-dissipation-copper-filled-thermal-vias-by-kuprion/
- 21. https://www.pcbway.com/blog/PCB_Basic_Information/Copper_Coin_Embedded_PC
 B for Heat Dissipation PCB Knowledge 00c055cb.html
- 22. https://www.altium.com/documentation/altium-designer/pcb-design-rule-checking?version=18.1
- 23. https://www.altium.com/documentation/altium-designer/setting-up-running-pcb-design-rule-check