Hardware Root Of Trust

Chapter 5


[1] J. Szefer, "Principles of secure processor architecture design," Synth. Lect. Comput. Archit., vol. 13, no. 3, pp. 1–173, 2018.

The Root of Trust

- Measure the chain of trust
 - Trusted authenticated boot, remote attestation, and data sealing
 - Runtime attestation and continuous attestation
- Secure processor should ensure for TEE
 - **Authentication**: the processor should authenticate himself (to guarantee that the information coming from it can be trusted).
 - E.g., deriving asymmetric crypto keys from a manufacture dependent unique secret key
 - Confidentiality: data going out of processor should be protected.
 - E.g., For memory using a key created at boot time (ephemeral) for persistent keys are persistent and generated (in a systematic way)
 - Integrity: additional keys are required for integrity checking. Cryptographic hashing (one-way) from secret key to prevent tampering (e.g., replays)

The Processor Key (The root of trust)

- Kr is a unique key per chip: is the root of trust. Others derived from that with one-way hashing
- Never should leave the chip boundary
- Created at manufacturing time (e.g., eFUSE)
- Manufacturer shouldn't hold a copy of the key



Keys belong to TC, if TEE need keys, they will be generated from them


PKI and Secure Processors

How to tell if a processor is who it says he is?

 PKI is required to distributed the certificate of the public key of the processors

The manufacturer should keep a list of knowngood keys and the associated processors ID

- **K**_r is used to derive different pairs for **encryption** (K_{sk}, K_{pk}) or **signing** (K_{SigK}, K_{vk})
- ID, public (K_{pk}) and verification (K_{vk}) keys, and corresponding certificates, are generated at manufacture and given to the certificate authority
- Given some ID of a processor, the users can
 obtain from CA the certificates for that
 processor's keys



Aside: RSA and Asymmetric Cryptography

- Generate two large random primes, p and q, of approximately equal size such that their product n=pq is of the required bit length, e.g., 1024 bits.
- 2. Compute n=pq and $\phi=(p-1)(q-1)$
- Choose an integer e, $1 < e < \phi$, such that $gcd(e, \phi) = 1$
- 4. Compute the secret exponent d, $1 < d < \phi$, such that $ed = 1 \mod \phi$
- The public key is (e,n) and the private key (d,n). Keep other values secret.


- n is known as the modulus.
- e is known as the *public exponent* or *encryption exponent* or just the *exponent*.
- d is known as the secret exponent or decryption exponent.

Aside: RSA Example

- Choose p = 3 and q = 11
- Compute n = p * q = 3 * 11 = 33
- Compute $\varphi(n) = (p 1) * (q 1) = 2 * 10 = 20$
- Choose e such that $1 < e < \phi$ (n) and e and ϕ (n) are coprime. Let e
- Compute a value for d such that (d * e) % ϕ (n) = 1. One solution is d = 3 [(3 * 7) % 20 = 1]
- Public key is (e, n) => (7, 33)
- Private key is (d, n) => (3, 33)
- The encryption of m = 2 is $c = 2^7 \% 33 = 29$
- The decryption of c = 29 is $m = 29^3 \% 33 = 2$

Aside: Computational Cost of RSA


- Public key operations $O(n^2)$, Private Key operations $O(n^3)$
 - Very costly when size of the key increases




- Many A*B mod N operations
 - No support in current processors but SIMD (e.g., AVX) might help
 - External hardware support; e.g., PCI Cards, FPGA, ...
- ECDSA [Elliptic Curve Cryptography] is replacing RSA everywhere (224-bit ECDSA is equivalent to 2048-bit RSA)


Aside: Physically Unclonable functions (PUF)

- Circuits that can't be replicated because depends upon small variabilities during the manufacturing process (die-to-die variability)
 - Mainly random processes across wafer





Arbiter PUF: Which path is faster determining the output for the challenge (X)



Butterfly PUF:

Excitation in preset and clr creates instability in cross coupled inputs but settles in a stable output

Access to the Root Of Trust


- Although complex physical attacks and/or rogue manufacturer can compromise the Root of Trust, the most likely scenario is bugs in TCB
 - Low level code (e.g., UEFI) should be able to access secret keys (e.g., to sign digital messages generated by the processor)
 - Code is kept in flash memory
 - Bugs in that code can lead to exploits that can leak the secret key

Chain of Trust and Measurements

- When run TEE, is crucial to be correctly configured
 - A trusted small BIOS loaded at system boot (first thing to load!)
 - This piece can "measure" next piece to be loaded (e.g., firmware)
 - Firmware "measure" the OS that starts next
- Measure == act of generating a cryptographic hash of the code (and data) before it is executed
 - If measurement != expectations, tampering is detected
- Measurements can be chained (or completed) from multiple components.
 - Each measurement is "extend" with the next one in the chain (coined by TPM)
 - This idea is used by Trusted Platform Module (TPM): low cost dedicated to providing root of trust. Protects against software attacks (mainly rootkits), secure disk cyphering, machine authentication (e.g., windows hello)

Chain of Trust and Measurements

- Chains of trust can include untrusted levels
- Usually, only trusted components are measured
 - Only if software is part of TCB and TEE is measured



Trusted and Authenticated Boot


Trusted boot means system might boots only if all measurements are correct

Authenticated boot means users can access to all measurements taken during boot (but always boot if aren't correct)

- In trusted boot If measurements aren't correct no standardized actions
 - A system can stop executing or secret data won't be decrypted
 - But what if the system is part of a critical infrastructure?
 - But what is my laptop and I want to prevent Linux + passwd cracker to unencrypt my disk content?

Measurement Validation and Remote Attestation


- Main method: check measurements against a list of good values
 - But any change in the boot (e.g., change in the version of the loader)
 might completely change the resulting hash → Can't have all
 combinations of system software locally "tagged": Use PKI for key
 distribution



- (b) User can obtain certificates from a CA and validate the signatures of the measurements.
- (c) User can send some sensitive information to the TEE, by sending encrypted information (and decryption key protected with K_{pk}).
- (d) The user can also send to TEE keys needed for decryption of data stored on remote disk


(d)

Disk



Example: Remote Attestation with Intel SGX

Allows a hardware entity or a combination of hardware and software to gain a remote provider's (also known as the relying party) or producer's trust.





- Intel ME Core iX 11xxx
- Intel SPS All Xeon >D >2020
- (Server Platform Services)

Example: Remote Attestation with AMD SEV

https://arxiv.org/pdf/1908.11680.pdf

Cryptographic keys in SEV.





Sealing

- Act of encrypting some data with a key derived from a measurement.
- Unsealing, is the act of decrypting data with a key derived form a measurement.

- Tie the data to a specific hardware and software configuration.
 - For example, if hard drive data is sealed at shutdown (local or remote), then next time the system boots up, if there is any change to the measurements (e.g., any of the trusted software was somehow **changed**), then the proper decryption key **cannot be derived**, and data cannot be decrypted.
- This prevents malicious uses from accessing data if they changed the software while the system was turned off (e.g., replacing the boot disk)

Time-to-check to time-to-use attacks

- Measurement technique does not say anything about the code after it was measured.
 - It only is based on raw measurements of static code as it was right before the piece of software executed.
 - This leads to well-known class of Time-of-Check to Time-of-Use (TOC-TOU) problems
- The system may be correct at time t₀, but it may become compromised at time t₁
 - if user **asks for the values of measurements at some later time t₂**, he or she will get the hash value that states that system was okay at t₀, but no information about state at t₂ is gained
- One solution to this problem is to perform **continuous attestation** at system runtime.

Runtime Attestation and Continuous Monitoring of TCB and TEEs


- Monitoring of the execution of the system via co-processor
 - Validates continuously the execution path (combined with PMU)
- Observing the execution pattern (Basic Block size, branch predictor accuracy, performance metric ...) we can infer when a program deviates from expected behavior
 - Mostly applied to untrusted component (Use in TCB not explored)
- Using Control Flow Graph of the program (from the source code of the program)
 to check if there are deviations (valid only for software, not clear for hardware)
- Using PMU to detect anomalies can be easily defeated by hiding the attack "in the noise" (e.g., by carefully modifying slightly the normal execution characteristics)

PUFs and Root of Trust

- PUFs are impossible to replicate (even for the manufacturer) and provides a good fingerprint for the systems
 - Turns process variation problem into a virtue
- Can permanently bind hardware-software by condition TEE execution path (i.e., not only in measurements)
 - The PUF might generate a stream of outputs for the TEE
 - E.g., Generate a seed for a PRNG
 - E.g., Use for some form of indirection (DRAM PUF)

Limiting the Execution to Only Authorized Code

- TCB updates (or protected) software can be authenticated with a separate key (manufacturer dependent)
- Add public key to the processor at manufacture time
- Only software signed by manufacturer can be sent to the processor
- Code can be signed under demand using also processor keys (e.g. to prevent install certain firmware out of a particular time window)



Lock-In and Privacy Concerns

- User depends on manufacturer to send information to TEE
 - E.g. Software running inside SGX requires Intel signature

When TCB and TEE is authenticated, use processor specify keys that can be used by the Certification Authority to infer information about the systems requesting the update

- Direct Anonymous Attestation (DAA) on TPM addresses these issues (partially)
 - Camenisch-Lysyanskaya Signatures

Root of Trust Assumptions

- Unique key assumptions
 - Manufacturer can never reuse the same key or use PUF
- Protected root of trust assumption
 - Kr will never be disclosed
 - TCB never will leak it
- Fresh measurement assumption
 - Need to be fresh to prevent TOC-TOU attacks

Example Attack: AMD TCB exploit for attestation

- One Glitch to Rule Them All (2021) https://arxiv.org/abs/2108.04575
 - https://github.com/PSPReverse/amd-sev-migration-attack
 - Voltage glitching attack that allows an attacker to execute custom payloads on the AMD-SPs --> Extract keys to deploy "custom" firmware
 - Allow to access secured VM using live-migration
 - Allows to generate false attestation reports (in the "custom" firmware server) (because we can change root of trust and fake the secure protocol)
 - An attacker without physical access to the target host can use extracted endorsement keys to attack SEV-protected VM s

Example Attack : SGX Attacks

https://arxiv.org/pdf/2006.13598.pdf

319, pai, 2000.	1333		Impact						Mitigations				
Attacks (abbreviated titles)	Type	SGX Specific	Targeted attack	Page access pattern	Instruction trace	Instruction latency	Memory access pattern	Memory Contents	Fault Injection	Microcode patch	System design	Compiler/SDK	Application design
Controlled-Channel [9]	sec. III-A	•	•	•	0	0	0	0	0	0	0	● ^[52]	● ^[55]
Stealthy Page Table [10]	sec. III-A	•	•	•	0	0	0	0	0	0	0	● ^[52]	0
SGX-Step [11]	sec. III-A	•	0	•	•	•	0	0	0	0	\circ	$ullet_{[48]}^{[11]}$	0
Nemesis [12]	sec. III-A	•	•	0	0	•	0	0	0	0	\circ	● ^[50]	0
Off Limits [13]	sec. III-A	•	•	•	•	0	•	0	0	● ^[13]	\circ	0	● ^[13]
Leaky Cauldron [14]	sec. III-B	•	•	•	\circ	\circ	•	0	0	\circ	\circ	$ullet_{[51]}^{[50]}$	0
CacheZoom [20]	sec. III-B	•	•	\circ	\circ	\circ	ullet	0	\circ	0	0	$\bullet_{[51]}^{[50]}$	● ^[56]
Cache Attacks on SGX [21]	sec. III-B	•	•	\circ	\circ	\circ	•	\circ	\circ	\circ	0	0	● ^[56]
Malware Guard Extensions [22]	sec. III-B	•	•	0	0	0	•	0	\circ	\circ	● ^[22]	0	0
Software Grand Exposure [23]	sec. III-B	ullet	•	\circ	\circ	0	•	0	\circ	\circ	0	0	\bullet ^[23]
CacheQuote [24]	sec. III-B	•	•	\circ	0	0	•	0	\circ	\circ	● ^[24]	0	0
MemJam [25]	sec. III-B	0	•	0	0	0	•	0	\circ	0	0	● ^[49]	0
Branch Shadowing [26]	sec. III-C	•	•	\circ	•	\circ	0	\circ	\circ	\circ	0	$ullet_{[48]}^{[26]}$	0
BranchScope [27]	sec. III-C	0	•	0	•	\circ	0	0	\circ	\circ	0	$ullet_{[48]}^{[27]}$	0
Bluethunder [28]	sec. III-C	•	•	\circ	•	0	\circ	0	\circ	\circ	0	● ^[28]	0
SgxPectre [31]	sec. III-D	•	•	\circ	\circ	\circ	0	•	\circ	● ^[47]	\circ	0	0
SpectreRSB [32]	sec. III-D	0	•	0	\circ	\circ	0	•	0	0	0	0	● ^[32]
Spectre v1 [33]	sec. III-D	0	•	\circ	\circ	\circ	\circ	•	\circ	● ^[47]	\circ	0	0
Foreshadow-SGX [34]	sec. III-E	•	0	0	\circ	\circ	\circ	•	0	● ^[35]	\circ	0	0
RIDL [38]	sec. III-F	0	•	\circ	\circ	\circ	0	•	\circ	● ^[38]	\circ	0	0
ZombieLoad [39]	sec. III-F	0	•	0	0	0	0	•	0	● ^[39]	\circ	0	0
CacheOut [40]	sec. III-F	•	•	0	\circ	0	0	•	0		\circ	0	0
CrossTalk [41]	sec. III-F	•	0	\circ	\circ	\circ	\circ	•	0	● ^[41]	\circ	0	0
Plundervolt [44]	sec. III-G	•	0	0	0	0	0	0	•	● ^[44]	0	0	0