#### University Cote d'Azur

# Polytech Nice Sophia

# Department Engineering of Electronic Systems

# Labs Real Time Operating System

Fabrice MULLER

≇ : Fabrice.Muller@univ-cotedazur.fr

# Contents

Ι	Scheduling Theory	1
1	Scheduling           1.1 Scheduling Policies	
II	Espressif Framework	13
1	Framework	15
	1.1 Espressif IoT Development Framework	15
	1.2 Creation of GitHub repository for Labs	19
	1.3 Visual Studio Code with ESP-IDF	21
II	FreeRTOS	23
1	Task & Scheduling	25
	1.1 Task scheduling on one core (Lab1-1)	25
	1.2 Task scheduling on two cores (Lab1-2)	
	1.3 Approximated/Exactly periodic task (Lab1-3)	
	1.4 Task handler and dynamic priority (Lab1-4)	37
2	Message Queue & Interrupt service	39
	2.1 Single Message Queue (Lab2-1)	39
	2.2 Message Queue with TimeOut (Lab2-2)	42
	2.3 Blocking on single Queue (Lab2-3) $\dots \dots \dots \dots \dots \dots \dots \dots \dots \dots$	42
	2.4 Using message queue with interrupts (Lab2-4)	45
3	Semaphore & Mutex	47
	3.1 Specification of the application	47

	3.2	First Task synchronization (Lab3-1)	50
	3.3	Task synchronization with 2 semaphores (Lab3-2)	52
		Mutual Exclusion (Lab3-3)	
4	Dir	ect task notification	65
	4.1	Direct task notification (Lab4-1)	65
	4.2	Direct task notification with a event value (Lab4-2)	67
5	App	plication	69
	5.1	Specification of the application	69
	5.2	Implementation of the application (Lab5)	72
Γ	J A	Appendix	75
A	ESI	P32 Board	77
R	efere	nces	<b>7</b> 9

# Part I Scheduling Theory

## LAB N° 1

Scheduling

## 1.1 Scheduling Policies

We consider 5 tasks  $T_1$ ,  $T_2$ ,  $T_3$ ,  $T_4$ ,  $T_5$  whose Execution Times (ET) are as follows:  $ET(T_1) = 10$ ,  $ET(T_2) = 1$ ,  $ET(T_3) = 2$ ,  $ET(T_4) = 1$ ,  $ET(T_5) = 5$ . Give the scheduling corresponding to the following strategies. Give for each scheduling the Average Waiting Time AWT. In cases with interruption (preemption), give two calculations: a calculation where the context switch time is 0, and another where the context switch time takes 0.1 time unit. The arrival times (AT) is 0 except if they are specified.

1. FCFS (First Come First Serve), the order of arrival being  $T_1$ ,  $T_2$ ,  $T_3$ ,  $T_4$ ,  $T_5$  (cf figure 1.1).

2. SJF (Shortest Job First), (cf figure 1.2).

3. Scheduling with priority without preemption (Non Preemptive Priority scheduling), the priorities being as follows:  $P(T_1) = 2$ ,  $P(T_2) = 4$ ,  $P(T_3) = 2$ ,  $P(T_4) = 1$ ,  $P(T_5) = 3$ . A higher priority corresponds to a greater number (0 = lower priority). Always use FCFS for arrival order (cf figure 1.3).

- 4. RR (Round Robin). Always use FCFS for arrival order.
  - (a) With slot time = 1 and consider the following set of tasks that arrive at time 0ms. Complete the trace in the figure 1.4 and give the Average waiting time (AWT).

(b) With slot time = 1 and consider now the following tasks  $T_1, T_2, T_3, T_4, T_5$  arrive respectively at time 0ms, 1ms, 2ms, 3ms and 4ms. What is the Average waiting time with context switch time = 0 unit? Conclusion?

(c) With slot time = 2 and consider the following set of tasks that arrive at time 0ms. Complete the trace in the figure 1.5 and give the Average waiting time (AWT).

(d) With slot time = 2 and consider now the following tasks  $T_1, T_2, T_3, T_4, T_5$  arrive respectively at time 0ms, 1ms, 2ms, 3ms and 4ms. What is the Average waiting time with context switch time = 0 unit? Conclusion?

- (e) What is the conclusion about the time slot (quantum) and the waiting time?
- 5. SRTF (Shortest Remaining Time First), the arrival times (AT) of the tasks being the following:  $AT(T_1) = 0$ ,  $AT(T_2) = 1$ ,  $AT(T_3) = 2$ ,  $AT(T_4) = 3$ ,  $AT(T_5) = 4$  (cf figure 1.6).




FIGURE 1.1 - FCFS (First Come First Serve) trace.





FIGURE 1.2 – SJF (Shortest Job First) trace.



**FIGURE 1.3** – Non Preemptive Priority scheduling trace.




Figure 1.4 – Round Robin (RR) scheduling trace with slot times = 1.




Figure 1.5 – Round Robin (RR) scheduling trace with slot times = 2.




FIGURE 1.6 - SRTF (Shortest Remaining Time First) scheduling trace.

## 1.2 Schedulability

We consider 3 periodic tasks  $T_1$ ,  $T_2$  and  $T_3$  whose characteristics are indicated in the table 1.1. The period is equal to the deadline and the tasks are independent.

Task	Execution Time (ET)	Period (P)
$\overline{T_1}$	10	50
$T_2$	9	40
$T_3$	7	30

**Table 1.1** – Characteristics of tasks in milliseconds.

- 1. Show that these tasks can be scheduled according to the Rate Monotonic Scheduling (RMS) strategy.
- 2. We now change the Execution Time of the task  $T_3 = 9$ . Is this always schedulable according to the RMS?
- 3. Is this schedulable according to the EDF (Earliest Deadline First) scheduling for the previous question?
- 4. What is the least common multiple of the period in milliseconds for EDF scheduling (using Execution Time of the task  $T_3 = 9$ )?

# Part II Espressif Framework

LAB N° 1

Framework

#### Lab Objectives

- Understand the Espressif IoT Development Framework.
- Run a first program.
- Create an GitHub repository.
- Use the Microsoft Visual Studio Code with a dedicated ESP32 project template.

#### 1.1 Espressif IoT Development Framework

We will start by understanding the structure of the Espressif IDF framework using an example provided by Espressif.

#### 1.1.1 First look of the first example

Take the example « hello\_world » which displays the string « hello world! » and characteristics of the ESP32 board on the console. The example is located in the following directory:

```
esp32:~$ cp -R ~/esp/esp-idf/examples/get-started/hello_world hello_world esp32:~$ cd hello_world
```

The compilation is done from a Python script called *idf.py*. This script is located in ~/esp/esp-idf/tools/ and added in the path.

```
esp32:~/esp/esp-idf/examples/get-started/hello_world$ which idf.py/
/home/esp32/esp/esp-idf/tools/idf.py
```

```
esp32:~/esp/esp-idf/examples/get-started/hello_world$ env | grep esp-idf
IDF_TOOLS_EXPORT_CMD=/home/esp32/esp/esp-idf/export.sh
PWD=/home/esp32/esp/esp-idf/examples/get-started/hello_world
IDF_TOOLS_INSTALL_CMD=/home/esp32/esp/esp-idf/install.sh
IDF_PATH=/home/esp32/esp/esp-idf
PATH=/home/esp32/esp/esp-idf/components/esptool_py/esptool:/home/esp32/esp/esp-idf/
    components/espcoredump:/home/esp32/esp/esp-idf/components/partition_table/:/
    home/esp32/.espressif/tools/xtensa-esp32-elf/esp-2019r2-8.2.0/xtensa-esp32-elf/
    bin:/home/esp32/.espressif/tools/esp32ulp-elf/2.28.51.20170517/esp32ulp-elf-
    binutils/bin:/home/esp32/.espressif/tools/openocd-esp32/v0.10.0-esp32-20190313/
    openocd-esp32/bin:/home/esp32/.espressif/python_env/idf4.0_py3.6_env/bin:/home/
    esp32/esp/esp-idf/tools:/home/esp32/.local/bin:/usr/local/sbin:/usr/local/bin:/
    usr/sbin:/usr/bin:/sbin:/usr/games:/usr/local/games:/snap/bin
```

To display the help of the Python script, just type the name of the command as below. We will mainly use the following commands: build, flash, monitor, menuconfig, fullclean, size ...

```
esp32:~/esp/esp-idf/examples/get-started/hello_world$ idf.py
Checking Python dependencies...
Python requirements from /home/esp32/esp/esp-idf/requirements.txt are satisfied.
Usage: /home/esp32/esp/esp-idf/tools/idf.py [OPTIONS] COMMAND1 [ARGS]... [COMMAND2
   [ARGS]...]...
 ESP-IDF build management
Options:
 -b, --baud INTEGER
                                  Baud rate. This option can be used at most once
   either globally, or
                                  for one subcommand.
  -p, --port TEXT
                                  Serial port. This option can be used at most once
    either globally,
                                  or for one subcommand.
Commands:
                         Aliases: build. Build the project.
 all
 clean
                         Delete build output files from the build directory.
 flash
                         Flash the project.
                         Delete the entire build directory contents.
 fullclean
                         Run "menuconfig" project configuration tool.
 menuconfig
 monitor
                         Display serial output.
```

```
size Print basic size information about the app.
size-files Print per-source-file size information.
```

The C source files are usually located in the « main » folder. We see below the « hello\_world\_main.c » file. The other files will be studied later.

```
esp32:~/esp/esp-idf/examples/get-started/hello_world$ cd main
esp32:~/esp/esp-idf/examples/get-started/hello_world$ 11

total 20
drwxr-xr-x 2 esp32 esp32 4096 avril 2 15:31 ./
drwxr-xr-x 4 esp32 esp32 4096 mai 26 10:07 ../
-rw-r--r- 1 esp32 esp32 85 avril 2 15:31 CMakeLists.txt
-rw-r--r- 1 esp32 esp32 146 avril 2 15:31 component.mk
-rw-r--r- 1 esp32 esp32 1232 avril 2 15:31 hello_world_main.c
```

#### 1.1.2 Building the first example

The generation of the executable in this specific case is called **cross-compilation** because the program will not be performed on the computer but on the ESP32 board. We build the executable from the following command.

```
esp32:~/esp/esp-idf/examples/get-started/hello_world$ idf.py build
[59/62] Linking C static library esp-idf/spi_flash/libspi_flash.a
[60/62] Linking C static library esp-idf/main/libmain.a
[61/62] Linking C executable bootloader.elf
[62/62] Generating binary image from built executable
esptool.py v2.8
Generated /home/esp32/esp/esp-idf/examples/get-started/hello_world/build/bootloader
   /bootloader.bin
[820/820] Generating binary image from built executable
esptool.py v2.8
Generated /home/esp32/esp/esp-idf/examples/get-started/hello_world/build/hello-
   world.bin
Project build complete. To flash, run this command:
/home/esp32/.espressif/python_env/idf4.0_py3.6_env/bin/python ../../../components/
   esptool_py/esptool/esptool.py -p (PORT) -b 460800 --before default_reset --
   after hard_reset write_flash --flash_mode dio --flash_size detect --flash_freq
   40m 0x1000 build/bootloader/bootloader.bin 0x8000 build/partition_table/
   partition-table.bin 0x10000 build/hello-world.bin
or run 'idf.py -p (PORT) flash'
```

A new « build » folder appears. In this folder, you can see the « hello-world.elf » which will be flashed in the ESP32 board.

```
esp32:~/esp/esp-idf/examples/get-started/hello_world$ 11
total 56
drwxr-xr-x 4 esp32 esp32 4096 mai
                                   26 10:07 ./
drwxr-xr-x 74 esp32 esp32 4096 mai
                                   26 10:27 build/
-rw-r--r-- 1 esp32 esp32
                        234 avril 2 15:31 CMakeLists.txt
drwxr-xr-x 2 esp32 esp32 4096 avril 2 15:31 main/
-rw-r--r-- 1 esp32 esp32
                          183 avril 2 15:31 Makefile
                          170 avril 2 15:31 README.md
-rw-r--r-- 1 esp32 esp32
rw-r--r-- 1 esp32 esp32 25463 mai
                                   26 10:26 sdkconfig
esp32:~/esp/esp-idf/examples/get-started/hello_world$ cd build
esp32:~/esp/esp-idf/examples/get-started/hello_world/build$ 11 hello-world*
-rw-r--r-- 1 esp32 esp32 147232 mai
                                    26 10:27 hello-world.bin
-rwxr-xr-x 1 esp32 esp32 2451528 mai 26 10:27 hello-world.elf*
rw-r--r-- 1 esp32 esp32 1541555 mai
                                    26 10:27 hello-world.map
esp32:~/esp/esp-idf/examples/get-started/hello_world/build$ cd ..
```

#### 1.1.3 Running the first example on ESP32 board

You find details of the ESP32-PICO-KIT board in the Getting Started Guide. To run the program on the board, follow the procedure below :

• Connect the ESP32 card to the computer via USB (cf. figure 1.1)




FIGURE 1.1 – ESP32-PICO-KIT board connections.

- Identify the USB serial port (usually /dev/ttyUSB0)
  esp32:~/esp/esp-idf/examples/get-started/hello\_world\$ ls /dev/ttyUSB\*
  /dev/ttyUSB0
- Flash the board and push the BOOT button to launch the programming

```
esp32:~/esp/esp-idf/examples/get-started/hello_world$ idf.py -p /dev/ttyUSB0
   flash
esptool.py -p /dev/ttyUSBO -b 460800 --before default_reset --after
   hard_reset write_flash --flash_mode dio --flash_freq 40m --flash_size 2MB
    0x8000 partition_table/partition-table.bin 0x1000 bootloader/bootloader.
   bin 0x10000 hello-world.bin
esptool.py v2.8
Serial port /dev/ttyUSB0
Connecting.....
Detecting chip type... ESP32
Chip is ESP32-PICO-D4 (revision 1)
Compressed 147232 bytes to 76527...
Wrote 147232 bytes (76527 compressed) at 0x00010000 in 1.7 seconds (effective
    675.4 kbit/s)...
Hash of data verified.
Leaving...
Hard resetting via RTS pin...
Done
```

• Monitor console messages sent by the program running on the ESP32 card. To exit monitoring, typing « Ctrl+AltGr+| »

```
esp32:~/esp/esp-idf/examples/get-started/hello_world$ idf.py -p /dev/ttyUSB0
    monitor
...
I (294) spi_flash: flash io: dio
W (294) spi_flash: Detected size(4096k) larger than the size in the binary
    image header(2048k). Using the size in the binary image header.
I (304) cpu_start: Starting scheduler on PRO CPU.
I (0) cpu_start: Starting scheduler on APP CPU.
Hello world!
This is ESP32 chip with 2 CPU cores, WiFi/BT/BLE, silicon revision 1, 2MB
    embedded flash
Restarting in 10 seconds...
Restarting in 9 seconds...
Restarting in 8 seconds...
```

#### 1.2 Creation of GitHub repository for Labs

Firstly, in the WEB interface of GitHub (open with Google Chrome or another navigator), you have to create a new repositories in GitHub, for example « labs ». Configure your GitHub in private access with a README.md file as shown the figure 1.2

Secondly, in a terminal, follow the steps to clone your new GitHub repositories in your computer :




FIGURE 1.2 – Create a GitHub repository.

1. You must configure your name and email address for GIT.

```
esp32:~/$ git config --global user.name "your name"
esp32:~/$ git config --global user.email "your email address"
```

2. You can now clone your « labs » repository to the computer. To obtain the URL of your repository, copy the repository URL located on GitHub webpage. The example below shows you the principle when you have to replace <your owner> by your GitHub owner.

```
esp32:~/$ git clone https://github.com/<your owner>/labs
```

3. You must enter this command in the new « labs » repository to avoid typing your username and password each time in Visual Studio Code.

```
esp32:~/$ cd labs
esp32:~/labs$ git config credential.helper store
```

You have information for configuring GIT for your new project.

#### 1.3 Visual Studio Code with ESP-IDF

In order to develop applications in a user-friendly way, we use Microsoft Visual Studio Code throughout these Labs. Moreover, we use a Visual Studio Code project template located in GitHub: https://github.com/fmuller-pns/esp32-vscode-project-template.

To use the template:

• Go to your repository where we will create the first lab named « part1 iot framework ».

```
esp32:~$ cd labs
esp32:~/labs$ mkdir part1_iot_framework
esp32:~/labs$ cd part1_iot_framework
```

• Clone the template project named « Visual Studio Code Template for ESP32 »

```
esp32:~/labs/part1_iot_framework$ git clone https://github.com/fmuller-pns/esp32-vscode-project-template.git
Cloning into 'esp32-vscode-project-template'...
remote: Enumerating objects: 30, done.
remote: Counting objects: 100% (30/30), done.
remote: Compressing objects: 100% (23/23), done.
remote: Total 30 (delta 8), reused 23 (delta 4), pack-reused 0
Unpacking objects: 100% (30/30), done.
```

• List working directory

```
esp32:~/labs/part1_iot_framework$ 11
total 12
drwxr-xr-x 3 esp32 esp32 4096 mai 26 16:17 ./
drwxr-xr-x 24 esp32 esp32 4096 mai 26 16:16 ../
drwxr-xr-x 5 esp32 esp32 4096 mai 26 16:18 esp32-vscode-project-template/
```

• Rename the folder.

```
esp32:~/labs/part1_iot_framework$ mv esp32-vscode-project-template
lab1_framework
```

• Delete .git folder of the new project « lab1\_framework ». Be careful, do not delete the .git folder located in the « labs » folder.

```
esp32:~/labs/part1_iot_framework$ cd lab1_framework
esp32:~/labs/part1_iot_framework/lab1_framework$ rm -fR .git
```

• Open Visual Studio Code for the new project.

```
esp32:~/labs/part1_iot_framework/lab1_framework$ code .
```

- Follow the section Getting Started to run the program on the board.
- Change the message in the app main() function located in the main.c file.
- Build and run the program.
- You must commit and push the modification in GitHub. Follow the section Using GitHub with Visual Studio Code to do it.

Now, you are ready to use Visual Studio Code with ESP-IDF for other projects!

# Part III FreeRTOS

Task & Scheduling

#### Lab Objectives

- Creating, suspending and deleting a task.
- Understanding the scheduling of tasks and priority effect.
- Multi-cores scheduling
- Using Idle task.
- Task handler

#### 1.1 Task scheduling on one core (Lab1-1)

The entry point of an application is the  $app\_main()$  function. This function is actually a task of priority 1. We will usually create the other application tasks from the  $app\_main()$  task. We will create an application with 2 tasks (including  $app\_main()$  task), then 3 tasks running on 1 core in order to understand the behavior of the scheduler.

#### 1.1.1 Understanding the task scheduling

- 1. Create the « lab1-1\_1\_core\_sched » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Overwrite the « main.c » file by the provided code of the « lab1-1\_main.c » file.
- 3. Copy the provided « my\_helper\_fct.h » file to the « main » folder.
- 4. Copy the provided « lab1-1\_sdkconfig.defaults » file to the project folder and rename « sdkconfig.defaults ».
- 5. Answer the following questions:

• Study the parameters of the following function : xTaskCreate() and vTaskDelete(). Web help

- Study the following function : uxTaskPriorityGet(). Web help
- Study the following function : vTaskDelay(). Web help
- What do they do the following macros? DISPLAY() and DISPLAYB().
- Task 1 is an instance of the vTaskFunction(). Is that true?
- 6. Open the « sdkconfig.defaults » file. What does the CONFIG FREERTOS UNICORE parameter correspond to? Web help
- 7. What is the tick period in ms? see the CONFIG\_FREERTOS\_HZ parameter and Web help
- 8. Build and run the program.
- 9. Trace in the figure 1.1 the behavior of the  $app\_main()$  and  $Task\ 1$  tasks until 160 ticks.
- 10. Why the app main() task does not run?
- 11. Create a new instance Task 2 of the vTaskFunction() with the same priority of Task 1, i.e. priority=5.
- 12. Run the program. Comment on the behavior.




FIGURE 1.2 – Scheduling of 3 tasks.

13. We are now going to suspend the scheduler with 2 functions when creating the tasks.

```
void app_main(void) {
    ...
  vTaskSuspendAll();
  // Task creation ...
    ...
  xTaskResumeAll();
    ...
```

- 14. Run the program.
- 15. For this scenario, trace in the figure 1.2 the behavior of the  $app\_main()$ ,  $Task\ 1$  and  $Task\ 2$  tasks until 160 ticks.
- 16. Comment on the behavior. Why the app main() task does not run?
- 17. Change the priority=6 for the Task 2. Run the program and comment on the behavior for this scenario.
- 18. We are now going to add delay on vTaskFunction() after the simulation of computation time.

```
void vTaskFunction(void *pvParameters) {
...
for (;; ) {
   DISPLAY("Run computation of %s", pcTaskName);

   /* Delay for simulating a computation */
   for (ul = 0; ul < mainDELAY_LOOP_COUNT; ul++) {
   }

   // Add Delay of 400 ms
   DISPLAY("Delay of %s", pcTaskName);
   vTaskDelay(400 / portTICK_PERIOD_MS);
   ...</pre>
```

19. Trace in the figure 1.3 the behavior of the  $app\_main()$ ,  $Task\ 1$  and  $Task\ 2$  tasks until 160 ticks.

#### 1.1.2 Using trace information

It is possible to get information about the tasks of the application using the vTaskList() function (Web help).


1. Copy the code provided in the «lab1-1\_add\_vtasklist.c» file to print trace information as below. Note that size of the buffer is approximately 40 bytes per task.

- 2. The 2 first parameters are compulsory to use the vTaskList() function. The last parameter is used to print the code id. We active the 3 parameters. 2 solutions:
  - Using the menuconfig command and go to Component config/FreeRTOS/Enable FreeRTOS trace facility, Enable FreeRTOS stats formatting functions and Enable display of xCoreID in vTaskList.
  - Add these lines below in the «sdkconfig.defaults» file (provided in *lab1-1\_config\_trace\_information.txt* file) and delete the «sdkconfig» to take into account the modifications.

```
# Trace facility to extract trace information
CONFIG_FREERTOS_USE_TRACE_FACILITY=y
CONFIG_FREERTOS_USE_STATS_FORMATTING_FUNCTIONS=y
CONFIG_FREERTOS_VTASKLIST_INCLUDE_COREID=y
```

3. Run the program. Copy the trace information. The *stack* column is the amount of free stack space in bytes there has been since the task was created.

4. How many tasks are there?



**FIGURE 1.4** – Scheduling of 3 tasks with task delay.

- 5. What is the highest priority task?
- 6. What does the main task correspond to?
- 7. What is the role of the  $ipc\theta$  task? Web help
- 8. What is the role of the esp timer task? Web help
- 9. What is the role of the Tmr Svc task? Web help 1 and Web help 2
- 10. What is the role of the *IDLE0* task? What is its priority? Web help
- 11. The default stack size is 4000 bytes. Change the constant  $STACK\_SIZE = 1400$  bytes. What is the problem? Change the size to the nearest hundredth to avoid the problem.

#### 1.1.3 Idle and Tick Task Hooks

An idle task hook is a function that is called during each cycle of the idle task. To use them, we will modify the configuration.

1. Add the two hook functions provided in the «lab1-1 add idle hook.c» file.

```
bool vApplicationIdleHook ( void ){
  DISPLAY ("IDLE");
  return true;
}

void vApplicationTickHook ( void ){
}
```

2. Why are there 2 hook functions? What is the difference? Web help 1 and Web help 2

- 3. The first parameter is compulsory to use the hooks functions. The second parameter adjusts the stack size depending on the behavior of the hook functions. 2 solutions:
  - Using the menuconfig command and go to Component config/FreeRTOS/Use FreeRTOS legacy hooks.
  - Add these lines below in the « sdkconfig.defaults » file (provided in *lab1-1\_config\_idle\_hook.txt* file) and delete the « sdkconfig » to take into account the modifications.

```
# allows add hook functions
CONFIG_FREERTOS_LEGACY_HOOKS=y
CONFIG_FREERTOS_IDLE_TASK_STACKSIZE=4096
```

- 4. Run the program. What do you see for the *Idle* and *app main* tasks?
- 5. Modify the task delay of vTaskFunction() function to 400ms instead of 100ms. What do you see for *Idle* and *app\_main* tasks? Conclusion?
- 6. Trace in the figure 1.4 the behavior of tasks until 160 ticks.

### 1.2 Task scheduling on two cores (Lab1-2)

the ESP32 has 1 or 2 cores. It is possible to choose on which core the task should be mapped or to let the scheduler choose. We will also see another solution to use the *idle* task without using the configuration but an API.

- 1. Create the «lab1-2\_2\_cores\_sched » lab from «esp32-vscode-project-template » GitHub repository.
- 2. Overwrite the « main.c » file by the provided code of the « lab1-2 main.c » file.
- 3. Copy the provided « my helper fct.h » file to the « main » folder.
- 4. Copy the provided « lab1-2\_sdkconfig.defaults » file to the project folder and rename « sdkconfig.defaults ».
- 5. Study the following function: xTaskCreatePinnedToCore(). Web help

6. Open the «sdkconfig.defaults» file and check the CONFIG\_FREERTOS\_UNICORE parameter is configured for one core.

```
CONFIG_FREERTOS_UNICORE=y
```

### 1.2.1 Task scheduling scenarios

We are going to test different scheduling scenarios according to the priorities of the tasks and the number of cores on which the tasks will be executed. In order to facilitate the different scenarios to be executed, we will use the preprocessor macros as below:

```
//#define DIFF_PRIORITY

#define PINNED_TO_CORE 0x00

// 0x00: Task 1: Core 0, Task 2: Core 0

// 0x01: Task 1: Core 0, Task 2: Core 1

// 0x10: Task 1: Core 1, Task 2: Core 0

// 0x11: Task 1: Core 1, Task 2: Core 1

//#define IDLE_HOOKS

//#define TASK_DELAY
```

We will start by taking the first 2 scenarios from the previous lab with one core.

1. Run the program; priority(Task 1) = priority(Task 2) = 5. Copy the trace and explain it (refer to the scenario question 15).

2. Uncomment  $DIFF\_PRIORITY$ . Run the program; priority(Task 1) = 5, priority(Task 2) = 6. Copy the trace and explain it (refer to scenario question 17).

We are now going to use the 2 cores. To do this, change directly the parameter  $CONFIG\_FREERTOS\_UNICORE = n$  in skdconfig file or use the graphical menu config. Run the 4 scenarios, copy the trace till 160 ticks (1600 ms) and comment it.

• Scenario nº 1 : Task 1 : Core 0, Task 2 : Core 0

 $\bullet$  Scenario nº 2 : Task 1 : Core 0, Task 2 : Core 1

 $\bullet$  Scenario nº 3 : Task 1 : Core 1, Task 2 : Core 0

 $\bullet$  Scenario nº 4 : Task 1 : Core 1, Task 2 : Core 1.




FIGURE 1.5 – Scheduling on 2 cores with 4 tasks.

For the last scenario  $n^{\circ} 5$ , we are going to add a task on *core*  $\theta$  using task mapping of scenario  $n^{\circ} 4$ .

- 1. Add a Task 3 on core 0 with priority = 1.
- 2. Trace in the figure 1.5 the behavior of the tasks until 160 ticks.

#### 1.2.2 Idle Task Hook from API

The disadvantage of configuring the hook functions from the configuration menu is the declaration of the 2 functions while generally the vApplicationIdleHook() function is the only useful function. Thus, it is possible to use an API which allows adding only the vApplicationIdleHook() function.

- 1. Uncomment the *IDLE\_HOOKS* preprocessor macro. We use the previous scenario no 5.
- 2. Study the following function:  $esp\_register\_freertos\_idle\_hook\_for\_cpu()$ . Web help
- 3. Run the program and comment the behavior. What do you notice about the execution of the *IDLE1* task?
- 4. Uncomment the  $TASK\_DELAY$  preprocessor macro.
- 5. Run the program and comment the new behavior, in particular the *IDLE1* task.

## 1.3 Approximated/Exactly periodic task (Lab1-3)

In some applications it is important to have tasks with an exact period. We will compare the use of the TaskDelay() function which allows you to wait for a certain time and the TaskDelayUntil() function which allows you to adjust the delay according to the time spent.

- 1. Duplicate the «lab1-2 2 cores sched» folder to «lab1-3 periodic task».
- 2. Check that you have uncommented the  $DIFF\_PRIORITY$ ,  $IDLE\_HOOKS$  and  $TASK\_DELAY$  preprocessor macro. Set the  $PINNED\_TO\_CORE$  macro to 0x00 to run all tasks on  $PRO\_CPU$  (Core 0).
- 3. Change the behavior of the vTaskFunction() task as below. Do not build the project.

```
#ifdef TASK_DELAY
  /* Approximated/Periodic Delay */
#ifdef PERIODIC_TASK_DELAY
```


```
DISPLAY("Periodic Delay of %s", pcTaskName);
vTaskDelayUntil(&xLastWakeTime, pdMS_TO_TICKS(300));
#else
   DISPLAY("Approximated Delay of %s", pcTaskName);
vTaskDelay(pdMS_TO_TICKS(300));
#endif
#endif
```

- 4. What does it do the following macro pdMS TO TICKS()?
- 5. Study the vTaskDelayUntil() function. Web help
- 6. Build the project and add the missing code to correct the compilation error.
- 7. Run the program and comment the behavior. What is the interval/approximated period of Tasks 1,2 and 3? Use the tick number from the display of « Run computation of Task X » (X = 1,2 or 3) comment.
- 8. Uncomment the PERIODIC TASK DELAY preprocessor macro.
- 9. Run the program and comment the behavior. What is the interval/period of Tasks 1,2 and 3? Use again the tick number from the display of « Run computation of Task  $X \gg (X = 1,2 \text{ or } 3)$  comment.

## 1.4 Task handler and dynamic priority (Lab1-4)

During the execution of the application, it is sometimes useful to modify the priority of a task or any other actions. To do this, it is necessary to get the handler of the task on which we have to operate these actions.

- 1. Create the « lab1-4\_task\_handler\_priority » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Overwrite the « main.c » file by the provided code of the « lab1-4 main.c » file.
- 3. Copy the provided « my helper fct.h » file to the « main » folder.



# Message Queue & Interrupt service

# Lab Objectives

- Using message queue API.
- Using message queue with interrupts

# 2.1 Single Message Queue (Lab2-1)

We want to create 3 tasks. The functions implementing the tasks will be named Task1() (priority=2, periodic : 500ms), Task2() (priority=2) and Task3() (priority=3) respectively. Each task will only displays string to the terminal with DISPLAY() macro and then block.

- 1. Create the « lab2-1\_single\_msg\_queue » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Copy the provided « my\_helper\_fct.h » file to the « main » folder.
- 3. Copy the provided « lab2-1\_sdk config.defaults » file to the project folder and rename « sdk config.defaults » .
- 4. Append the content of add includes c file to the start of the main c file.
- 5. Study the following function : xQueueSend(), xQueueReceive(). Web help 1, Web help 2
  - Task 3 blocks for 100ms, displays string to the terminal and then simulates a computation of 20ms (2 ticks).

```
// Task blocked during 100 ms
vTaskDelay(pdMS_TO_TICKS(100));
DISPLAY(...);
// Compute time : 2 ticks or 20 ms
COMPUTE_IN_TICK(2);
```

• Task 1 should be periodic with a periodicity of 500ms. It post in a message queue for task 2, check the result of the post (Failed or posted message), simulates a computation of 40ms (4 ticks) and wait for next period. Note that the write function in the queue should not be blocking.

```
// Post
uint32_t result = xQueueSend(...);
// Check result
if (result) ...
// Compute time : 4 ticks or 40 ms
COMPUTE_IN_TICK(4);
// block periodically : 500ms
vTaskDelayUntil(...);
```

• Task 2 waits for a message through the message queue, displays the task number and message received and then simulates a computation of 30ms (3 ticks).

```
// Wait for message
...
// display task number and message
DISPLAY(...);
// Compute time : 3 ticks or 30 ms
COMPUTE_IN_TICK(4);
```

- Don't forget to create a message queue.
- 6. Build and run the program.
- 7. Trace in the figure 2.1 the behavior of the 3 tasks until 160 ticks.
- 8. What is the period of the task 2?




FIGURE 2.1 – Message queue and 3 tasks.

# 2.2 Message Queue with TimeOut (Lab2-2)

The concept of timeout only applies to blocking system calls. When a task is blocked, it will wake up (go to the ready state) automatically after a period of time called Timeout, even if the expected event has not happened.

- Duplicate the « lab2-1\_single\_msg\_queue » folder to « lab2-2\_single\_msg\_queue\_timeout ».
- Force Task 2 to wake up every 300ms using the Timeout associated with the xQueue-Receive() function as below.

```
if (xQueueReceive(...)) {
   DISPLAYI(TAG, "Task %d, mess = %d", *pultaskNumber, value);
   COMPUTE_IN_TICK(3);
}
else {
   DISPLAYE(TAG, "Task %d, Timeout!", *pultaskNumber);
   COMPUTE_IN_TICK(1);
}
```

- Build and run the program.
- Trace in the figure 2.3 the behavior of the 3 tasks until 160 ticks.

# 2.3 Blocking on single Queue (Lab2-3)

We want to illustrate the problems of writing/reading queue messages and the impact on the scheduling of tasks. The figure 2.2 illustrates the application. The message queue contains items of integer type.





FIGURE 2.2 – Blocking on single queue.



**FIGURE 2.3** – Message queue with timeout and 3 tasks.

### 2.3.1 Blocking on Queue Reads

1. Create the « lab2-3\_single\_msg\_queue\_blocked » lab from « esp32-vscode-project-template » GitHub repository.

- 2. Copy the provided « my\_helper\_fct.h » file to the « main » folder.
- 3. Copy the provided « lab2-3\_sdkconfig.defaults » file to the project folder and rename « sdkconfig.defaults ».
- 4. Overwrite the « main.c » file by the provided code of the « lab2-1 main.c » file.
- 5. Complete the code. For the moment, initialize the constants as below:

```
const uint32_t SENDER_TASK_PRIORITY = 3;
const uint32_t RECEIVER_TASK_PRIORITY = 3;
const uint32_t MESS_QUEUE_MAX_LENGTH = 10;
const uint32_t SENDER_TASK_NUMBER = 3;
const uint32_t RECEIVER_TASK_NUMBER = 3;
```

- 6. Build and run the program.
- 7. Explain the behavior.
- 8. Modify the priority of receiver task to 5 and run the program.
- 9. Explain the new behavior.
- 10. Modify the priority of *sender task* to 5 and the priority of *receiver task* to 3. Run the program.
- 11. Explain the new behavior.

### 2.3.2 Blocking on Queue Writes

- 1. Modify the priority of sender task to 5 and the priority of receiver task to 3.
- 2. Modify the capacity of the message queue to 2 (i.e.  $MESS\ QUEUE\ MAX\ LENGTH=2)$

- 3. Explain the problem.
- 4. How to correct the problem by adjusting the priority of tasks?

## 2.4 Using message queue with interrupts (Lab2-4)

We will take over the lab ??. The figure 2.4 illustrates the application we want to achieve. When we press the push button, it will trigger an interrupt (pos edge) that will send a message containing the GPIO pin number to the *BounceTask()* task. If the button is not pressed after 5 seconds, a message is displayed indicating that the button must be pressed to trigger the interrupt. A simple way is to use the timeout of the message queue received function.




FIGURE 2.4 – Interrupt application with message queue.

The interrupt is reduced to this code below.

```
// Count ISR insterrupt
static volatile uint32_t isrCount=0;

static void IRAM_ATTR my_isr_handler(void *args) {
  int pinNumber = (int)args;
  isrCount++;
  xQueueSendFromISR(xMsgQ, &pinNumber, NULL);
}
```

- 1. Write the  $app\_main()$  function based on the code of the  $app\_main()$  task from the lab ??.
- 2. Write the *vBounceTask()* task inspired based on code of the *gpio switch isr handler()* interrupt from the lab ??.

3. Build and run the program.

Semaphore & Mutex

# Lab Objectives

- Using semaphore API.
- Using Mutex

# 3.1 Specification of the application

We want to implement the functional structure (cf. figure 3.1) using FreeRTOS.




FIGURE 3.1 – Functional description.

The behavioral description of tasks is presented below in algorithm form. *Table* is an array of integer values that can represent a signal, such as a ramp. Its size is a constant (TABLE\_SIZE) which can be modified during the tests. During initialization, it takes the

```
values [0,1,2,..., TABLE\_SIZE-1]. Use TABLE_SIZE = 400.
Do not forget to use the pdMS\_TO\_TICKS(iTime\ time) macro to convert time in millisecond to tick number.
```

#### 3.1.1 Timer task

This is a task that performs a TaskDelay() and generates the synchronization (semaphore) via Clk. The function computeTime() simulates a execution time in millisecond.

```
Task Timer is
    Properties: Priority = 5
Out    : Clk is event

Cycle :
    waitForPeriod(250 ms);
    computeTime(20 ms);
    print("Task Timer : give sem");
    notify(Clk);
    end
end
```

**Algorithm 1:** Timer algorithm.

#### 3.1.2 IncTable task

It is a temporary action activated by Clk. An constNumber is passed by the parameters of the task. Every 5 activations, the task increments by the constNumber for each element of Table. We simulate a computation time by the computeTime() pseudo function. Its functional behavior is as follows:

```
Task IncTable is
   Properties: Priority = 4
              : Clk is event
   In
              : Table is array[0 to TABLE SIZE-1] of integer
   ActivationNumber := 0;
   Cycle Clk:
      if ActivationNumber = 0 then
         for index := 0 to TABLE SIZE-1 do
            Table[index] := Table[index] + constNumber;
         end
         computeTime(50 ms);
         ActivationNumber := 4;
         ActivationNumber := ActivationNumber - 1;
      end
   end
end
```

**Algorithm 2:** IncTable algorithm.

#### 3.1.3 DecTable task

```
Its functional behavior is as follows:

Task DecTable is

Properties: Priority = 4

In : Clk is event

In/Out : Table is array[0 to TABLE_SIZE-1] of integer

Cycle Clk:

for index := 0 to TABLE_SIZE-1 do

Table[index] := Table[index] - 1;

end

computeTime(50 ms);

end

end
```

**Algorithm 3:** DecTable algorithm.

### 3.1.4 Inspector task

It is a task which constantly checks the consistency of the Table and displays an error message when an inconsistency is found in the Table (exit on the program, use exit(1) function). For this, it takes the first value of the Table as a reference (reference = Table[0]) and checks each element of Table in accordance with its reference (Table[index] = reference + index). When the Table has been fully browsed, the cycle begins again (a new reference is

taken and the Table is checked again). Its functional behavior is as follows:

```
Task Inspector is
   Properties: Priority = 4
   In
               : Clk is event
   In
               : Table is array[0 to TABLE SIZE-1] of integer
   ActivationNumber := 0;
   Cycle Clk:
      print("Task Inspector is checking.");
      reference := Table |0|;
      error := false;
      for index := 1 to TABLE SIZE-1 do
          smallComputeTime(100 us);
          if Table[index] \neq (reference + index) then
             error := true;
          end
      end
      print("Task Inspector ended its checking.");
      if error = true then
          print(TAG, "Consistency error in the Table variable.");
          exit();
      end
   end
end
```

**Algorithm 4:** Inspector algorithm.

## 3.2 First Task synchronization (Lab3-1)

Firstly, we will only implement the Timer, DecTable and IncTable tasks as well as the Clk and Table relationships. The computeTime() function can be implemented by the  $COM-PUTE\_IN\_TICK()$  macro (1 tick = 10ms) and the print() function by DISPLAY() macro.

### 3.2.1 Writing the application

- 1. Create the « lab3-1\_one\_sem\_clk » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Copy the provided « lab3-1\_sdkconfig.defaults » file to the project folder and rename « sdkconfig.defaults ».
- 3. Copy the provided « my helper fct.h » file to the « main » folder.
- 4. Overwrite the « main.c » file by the provided code of the « lab3-1 main.c » file.
- 5. Write the program with the behavior of these 3 tasks and 1 semaphore (*xSemClk*) using the algorithms proposed above. All the tasks are created on the *Core\_0*. Below is a creation reminder for a semaphore.

```
/* Creating Binary semaphore */
SemaphoreHandle_t xSemClk;
xSemClk = xSemaphoreCreateBinary();
/* Using semaphore */
xSemaphoreGive(xSemClk);
xSemaphoreTake(xSemClk, portMAX_DELAY);
```

6. Build the program without running it.

### 3.2.2 Scenarios with one clock semaphore

We will perform scenarios described in the Table 3.1 in order to identify problems and improve the program later. The task priority of Timer is 5 and run on  $Core_{-}0$ .

Scenario	IncTable task	DecTable task
1	Prio(4), Core(0)	Prio(4), Core(0)
2	Prio(3), Core(0)	Prio(4), Core(0)
3	Prio(4), Core(0)	Prio(4),Core(1)
4	Prio(3), Core(0)	Prio(4), Core(1)

**Table 3.1** – Scenarios for task synchronization.

**Scenario 1:** Run the program, copy the console, trace in the figure 3.2 the behavior of the 3 tasks until 160 ticks and explain the problem.

Scenario 2: Run the program, copy the console and explain the problem.

**Scenario 3:** Run the program, copy the console and explain the problem.

Scenario 4: Run the program, copy the console and explain the problem.

# 3.3 Task synchronization with 2 semaphores (Lab3-2)

We identified different issues in the previous section. We will perform again the scenarios described in the Table 3.1.

- 1. Duplicate the « lab3-1\_one\_sem\_clk » folder to « lab3-2\_two\_sem\_clk ».
- 2. Correct the clock program to send 2 separate semaphores (xSemIncTab and xSemDec-Tab) to IncTable and DecTable tasks.

**Scenario 1:** Run the program, copy the console, trace in the figure 3.3 the behavior of the 3 tasks until 160 ticks and explain the behavior.





FIGURE 3.2 – Scenario 1 : Priority(DecTable=4, IncTable=4), Core(DecTable=0, IncTable=0).



**Scenario 3**: Run the program, copy the console, trace in the figure 3.5 the behavior of the 3 tasks until 160 ticks and explain the behavior.

Scenario 4: Run the program, copy the console and explain the behavior.




FIGURE 3.3 – Scenario 1 : Priority(DecTable=4, IncTable=4), Core(DecTable=0, IncTable=0).




FIGURE 3.4 – Scenario 2: Priority(DecTable=4, IncTable=3), Core(DecTable=0, IncTable=0).




FIGURE 3.5 – Scenario 3: Priority(DecTable=4, IncTable=4), Core(DecTable=1, IncTable=0).

# 3.4 Mutual Exclusion (Lab3-3)

We now add the *Inspector* task. We will perform the program with the task priorities described in the Table 3.2.

Timer task	IncTable task	DecTable task	Inspector task
Prio(5), Core(0)	Prio(3), Core(0)	Prio(3), Core(0)	Prio(4), Core(0)

Table 3.2 – Task priorities with mutex.

- 1. Duplicate the « lab3-1\_one\_sem\_clk » folder to « lab3-2\_two\_sem\_clk ».
- 2. Add the *Inspector* task.
- 3. Run the program, copy the console and explain the behavior. What is the problem?

- 4. Correct the problem of initialization.
- 5. Run the program, copy the console and explain the behavior. What is the problem?

- 6. Choose a new priority of the *Inspector* task to solve the problem.
- 7. Run the program, copy the console until 40 ticks, trace in the figure 3.6 the behavior of the 3 tasks until 40 ticks and explain the behavior.

8. Modify the *Inspector* task by adding a *Mutex* to manage access to the critical area. Below is a creation reminder for a Mutex.

```
/* Mutex */
SemaphoreHandle_t xSemMutex;
xSemMutex = xSemaphoreCreateMutex();
/* Using Mutex */
xSemaphoreGive(xSemMutex);
xSemaphoreTake(xSemMutex, portMAX_DELAY);
```

9. Run the program, copy the console, trace in the figure 3.7 the behavior of the 3 tasks until 40 ticks and explain the behavior and the effect of the Mutex.

10. Change the priority of *Inspector* task to 4. Run the program, copy the console until 40 ticks. What is the problem?

11. We decide to change the *Inspector* task to *Core\_1*. Run the program, copy the console until 40 ticks. What is the problem?

12. We now decide to add a delay of 2 ticks after giving the mutex (using vTaskDelay() function). Run the program, copy the console, trace in the figure 3.8 the behavior of the 3 tasks and Mutex until 90 ticks and explain the behavior.




FIGURE 3.6 - Program with Task inspector.




FIGURE 3.7 – Program with Task inspector on the Core\_0 and Mutex.




FIGURE 3.8 – Program with Task inspector on the Core\_1 and Mutex.

Direct task notification

### Lab Objectives

- Using task notification instead of semaphore.
- Using event group for a notification.

## 4.1 Direct task notification (Lab4-1)

A direct to task notification is an event sent directly to a task, rather than indirectly to a task via an intermediary object such as a queue, event group or semaphore. The direct to task notification is faster than using an intermediary objects and has a RAM Footprint benefits.

- $\bullet$  Duplicate the « lab3-2 \_two \_sem \_clk » folder to « lab4-1 \_two \_notifications \_clk ».
- Answer the following questions:
  - Study the parameters of the xTaskNotifyGive() function. Web help
  - Study the parameters of the ulTaskNotifyTake() function. Web help
- Replace the two separate semaphores (i.e. notification of the *IncTable* and *DecTable* tasks) by a the *direct to task notification* mechanism. For the *ulTaskNotifyTake()* function, we set the first parameter *xClearCountOnExit* to *TRUE*. Print the return value (pending event counter) of *ulTaskNotifyTake()* function for each task.

- In the *Timer* task, add a new *give()* notification to *IncTable* task. So, you have 2 notifications in a row to the *IncTable* task.
- Run the program and explain the behavior.

• We set now the first parameter xClearCountOnExit to FALSE for the ulTaskNotify-Take() function. What is the difference of behavior regarding to the previous question?

LAB 4 67

## 4.2 Direct task notification with a event value (Lab4-2)

To illustrate the principle, we are going to modify the algorithm of the *Timer* task. Its functional behavior is as follows:

```
Task Timer is
   Properties: Priority = 5, ACTION = eSetBits
   Out
              : Clk is event
   Cycle:
      waitForPeriod(250 ms);
      computeTime(20 ms);
      print("Task Timer : Notify Give (count=\%d)", count);
      // IncTable task notifications
      notify(incTableHandler, (0x01 « count), eSetBits);
      notify(incTableHandler, (0x02 « count), ACTION);
      // DecTable task notification
      notify(decTableHandler, (0x01 « count), eSetValueWithoutOverwrite);
      // counter modulo 4
      count = (count + 1)
   end
```

**Algorithm 5:** New Timer algorithm.

- 1. Duplicate the « lab4-1\_two\_notifications\_clk » folder to « lab4-2 two notifications clk2 ».
- 2. Answer the following questions:

end

- Study the parameters of the xTaskNotify() function. Web help
- Study the parameters of the xTaskNotifyWait() function. Web help
- 3. Modify the code of *Timer* task.
  - The ACTION property can be a constant value and can take the eSetBits, eSet-ValueWithoutOverwrite or eSetValueWithOverwrite value.
  - We set by default the ACTION property to eSetBits.
  - What is the best value of the first parameter (ulBitsToClearOnEntry) of the xTask-NotifyWait() function?

- We set the second parameter (ulBitsToClearOnExit) of the xTaskNotifyWait() function to 0.
- 4. Run the program, copy the console until 107 ticks and explain the behavior, in particular the pending counter value in each 2 tasks.

5. We set the *ACTION* property to *eSetValueWithoutOverwrite*. Run the program, copy the console until 107 ticks and explain the behavior.

6. We set the ACTION property to eSetValueWithOverwrite. Run the program, copy the console until 107 ticks and explain the behavior.

**Application** 

## Lab Objectives

- Use the knowledge previously seen on freertos services
- Using GPIO
- Using Interrupt

# 5.1 Specification of the application

We want to implement the functional structure depicted in figure 5.1.

### 5.1.1 Scan task

The task is activated on ScanH event. It acquires the value of the Value variable, compares it to high and low thresholds. Value being a theoretical output of a Digital/Analog converter not available for this Lab. It is possible to simulate its evolution by a random generation made by ScanH when activated.

The rand() function allows you to generate a number between 0 and RAND\_MAX. So you just need, by rule of three, to bring the result between 0 and 100 and to set the low threshold at 15 and the threshold at 85.

If one of the thresholds is exceeded, a message of *High alarm* or *Low alarm* type is sent to the *Mess* queue, accompanied by the threshold value of *Value* variable. Otherwise, the value of *Value* variable is assigned to *Sample Value*.

```
static const uint32_t VALUE_MAX = 100;
static const uint32_t LOW_TRIG = 15;
static const uint32_t HIGH_TRIG = 85;
```




Figure 5.1 - Functional description.

```
int iValue = rand() / (RAND_MAX / VALUE_MAX);
if (iValue < LOW_TRIG) {
     // Low Alarm
}
else if (iValue > HIGH_TRIG) {
     // High Alarm
}
else {
     // No Alarm
}
```

### 5.1.2 Monitoring task

The task is activated on MonitoringH event. It sends messages of Monitoring type in the Mess queue. These messages contain the value of the variable Sample Value. Thus, the structure of Mess queue can be described as follows:

```
typedef enum typeInfo { Alarm, Monitoring };
typedef struct
{
   enum typeInfo xInfo;
   int xValue;
} typeMessage;
```

### 5.1.3 Timer task

The Timer task generates a periodic H event of 10ms.

#### 5.1.4 Divider task

The Divider task performs a division of H event by 5 to generate ScanH event and a division by 18 to generate MonitoringH event.

### 5.1.5 User task

The task is activated by the keyboard. It allows the user to print a packet of characters on the terminal (called *Packet Edition*). These characters are edited by packet, the end of a packet corresponding to the character @ (for example, a packet is « it is an example@ » as depicted Listing 5.1). When entering a character packet (*Packet Edition* mode), the *Output* function should not display its messages on the terminal and the *PacketEditionLed* is set to 1 (the green led is ON). After entering the character @ (end of *Packet Edition* mode), it can display as many messages as necessary, until the user enters the next character. The characters can be entered using the *getch()* function. An example of use is depicted below:

```
/* Scan keyboard every 50 ms */
while (car != '@') {
  car = getch();
  if (car != 0xff) {
    printf("%c", car);
    }
  vTaskDelay(pdMS_TO_TICKS(50));
}
```

Another solution for exiting *Packet Edition* mode is to press the push button that triggers an interrupt (named *Button interrupt*). This interrupt sends an event (semaphore) to the *User* task so that it can exit *Packet Edition* mode.

### 5.1.6 Output task

The task displays a formatted message of the *Mess* queue as depicted in the terminal in Listing 5.1. When the message is an alarm, the *AlarmLed* must be set to 1 (the red led is ON).

**Listing 5.1** – Console example of the application

```
13:0> Monitoring: Value = 69

203:0> Monitoring: Value = 55

393:0> Monitoring: Value = 20

583:0> Monitoring: Value = 84

613:0> Alarm: Value = 6

733:0> Alarm: Value = 87

773:0> Monitoring: Value = 85
```

```
853:0>
        Alarm: Value = 98
913:0>
        Alarm: Value = 8
963:0>
       Monitoring: Value = 15
973:0>
        Alarm: Value = 90
1033:0> Alarm: Value = 10
1093:0> Alarm: Value = 92
1153:0> Monitoring: Value = 50
1213:0> Alarm: Value = 87
1343:0> Monitoring: Value = 69
User mode
hello !@
End User mode
2393:0> Alarm: Value = 3
2393:0> Monitoring: Value = 15
2393:0> Alarm: Value = 9
```

## 5.2 Implementation of the application (Lab5)

- 1. Create the « lab5\_application » lab from « esp32-vscode-project-template » GitHub repository.
- 2. Copy the provided « my\_helper\_fct.h » file to the « main » folder.
- 3. Overwrite the « main.c » file by the provided code of the « lab5\_main.c » file.
- 4. Create a « sdkconfig.defaults » file with right parameters.
- 5. Write the program for *Timer*, *Divider*, *Scan* and *Monitoring* tasks. The capacity of *Mess* queue is 5. The tasks are mapped on different cores referenced in the figure 5.1.
- 6. Build to check that is no compilation error.

In order to validate the behavior of the application and to clearly highlight the management of Mess queue, we can proceed as below:

- 1. Validate the functional structure with only the *Timer*, *Divider*, *Scan* and *Monito-ring* tasks. Check that after a number of message submissions corresponding to the maximum capacity of the *Mess* queue, the *Monitoring* and *Scan* tasks are blocked.
- 2. Wire the 2 leds on the board.
- 3. Add the *Output* task. We will check that the *Monitoring* and *Scan* tasks are no longer blocked. Only the *Output* task can be blocked on an empty *Mess* queue. Check the behavior of the red led.
- 4. Add the *User* task without using interrupt. Note that the *getch()* function also uses the terminal as the *printf()* function. You must protect the simultaneous write on the terminal. Check the application and green led behaviors.
- 5. Wire the push button on the board.

6. Add the *button interrupt* function and check the behavior. The name of the *give()* function is different when called from an interrupt (Web help).

Part IV
Appendix

# ANNEXE A

### ESP32 Board




FIGURE A.1 – Pin description of ESP32-PICO-D4 board.

	References