```
! CHRONOAMPEROMETRY (CA)
! This is a test program for UWED to make basic CA recordings
! Written by Alar Ainla, 2016-2018. Whitesides Group, Harvard.
! -----
! OPERATION PARAMETERS
InitV=-0.1 ! [V] This is measurement potential
timeStep=25 ! [ms] timestep between measurements divided by 2.
! E.g. this is 50ms timestep between measurements
mTime=30
        ! [s] Total measurement time
! -----
! PROGRAM CODE
DIM nrDataPoints AS LONG
nrDataPoints=mTime*1000/(2*timeStep) ! Total number of points
DIM nrScans AS INTEGER
nrScans=CINT(nrDataPoints/1000)+1 ! 1000 per scan (1000 points is maximum per scan)
DIM time0 AS LONG
! Here we lock working electrode potential W[d]=22500 W[V]=1.5031
! And only varied is Reference electrode potential
! Constants then according to calibration
! ADC[d]=(ADC[V])*2.01513E4+2.38491E2
! ADC[V]=(ADC[d]-2.38491E2)/2.01513E4
! Curr[uA]=0.00608*(dADC-30694)-0.04 ! Working electrode current
! (W-R)[V]=R[d]*(-6.64898E-5)+1.50310 ! Working electrode potential vs ref
Rslope=1.5040E4 ! This is number of digits per volt, when Ref is changed
! Calculate required data structure
DIM initW AS LONG
initW=22500 ! This is now constant and not calculated
DIM initR AS LONG
!initR=22606 ! This should start as close to zero as possible
initR=22606-Rslope*InitV ! This is the potential value
initR0=22606
nrSteps1=1000
nrSteps2=nrDataPoints MOD 1000
DIM nrSteps(nrScans) AS INTEGER
FOR i=1 TO nrScans-1
nrSteps(i)=nrSteps1
NEXT i
nrSteps(nrScans)=nrSteps2
! Output these to console for feedback
PRINT "InitW"
PRINT initW
PRINT "InitR"
PRINT initR
PRINT "stepR"
PRINT stepR
```

PRINT "nrSteps"

```
PRINT "nrDataPoints"
PRINT nrDataPoints
! Resulting data storage arrays
DIM Vw(nrDataPoints) AS DOUBLE ! Potential in volts
DIM IuA(nrDataPoint) AS DOUBLE ! Electrode current in uA
DIM dWe(nrDataPoints) AS LONG! Working electrode as set digital value
DIM dRe(nrDataPoints) AS LONG! Reference electrode as set digital value
DIM dADC(nrDataPoints) AS LONG! ADC value
DIM Ts(nrDataPoints) AS LONG ! Time step
DIM Ni(nrDataPoints) AS INTEGER! Index of point in scan
DIM DPi AS INTEGER! Data point counter
DIM SCi AS INTEGER! Scan counter
DIM ScanRunning AS INTEGER ! if 0 does not run, if 1 running
ScanRunning=0
DIM lastIndex AS INTEGER! Last receiveing Index, to avoid double reading
lastIndex=0
! -- GUI --
! - Initialize basic GUI -
DIM startButton AS Button ! This button starts the measurement
DIM myMess AS Label! This is text message area
DIM p1 AS Plot! This is the result plot
DIM pCA AS PlotPoint! This is one dataset
DIM myCA(nrDataPoints,2)
FOR i=1 TO nrDataPoints
    myCA(i,1)=0
    myCA(i,2)=0
NEXT i
p1=Graphics.newPlot
pCA=p1.newPlot(myCA)
p1.setView(0,-100,mTime,100,0)
p1.setXaxisLabel("Time (s)")
p1.setYaxisLabel("Current working electrode (μA)")
p1.setTitle("Electrochemical CA with UWED")
startButton=Graphics.newButton(10,10)
startButton.setTitle("Start")
myMess=Graphics.newLabel(110,10,200,20)
myMess.setText("....")
System.ShowGraphics(1)
! -- BLE --
print "Hello BLE"
DIM bm AS BLEPeripheral
ble.startble
DIM uuid(0) AS STRING
DIM services(1) AS STRING
DIM bleWriteChar AS BLECharacteristic
ble.startscan(uuid)
END
! FUNCTIONS
```

PRINT nrSteps PRINT "nrScans" PRINT nrScans

```
SUB InitializeUWED()
    DPi=0 ! No data points yet
    SCi=0 ! Scan counter
    ! Make graph empty
    FOR i=1 TO nrDataPoints
        myCA(i,1)=0
        myCA(i,2)=0
   NEXT i
    ! Start setting up experiment in UWED
    sendToUWED("A("&STR(initR)&")")
    sendToUWED("B("&STR(initW)&")")
    sendToUWED("E("&STR(timeStep)&")")
    sendToUWED("D(3)")
    sendToUWED("C(1)")
END SUB
SUB InitializeScan()
    SCi=SCi+1 ! Increase scan counter
    IF SCi>nrScans THEN! If scan counter is larger than number of scans, then DONE
        sendToUWED("A("&STR(0)&")")
        sendToUWED("B("&STR(0)&")")
        system.wait(0.5) ! Wait a bit
        sendToUWED("C(0)") ! Put UWED to potentiometric (off state)
        ! Save data
        OPEN "CAData.txt" FOR OUTPUT AS #1
        FOR i=1 TO DPi
            PRINT #1, STR(dRe(i))&" "&STR(DWe(i))&" "&STR(dADC(i))&_
                " "&STR(Ts(i))&" "&STR(Ni(i))
        NEXT i
        CLOSE #1
        ! Send now data over email to server
        DIM em AS Email
        DIM em_mess AS STRING
        em_mess="This is data from CA measurement from iPhone"
        em=System.newEmail("email@emailserver.com","CA Data", em_mess)
        em.addAttachment("CAData.txt", "text/plain")
        em.send
        myMess.setText("DONE")
        ScanRunning=0
    ELSE! Initialize new scan
        ! Increase same amount both steps
        sendToUWED("G("&STR(0)&")") ! Do not change potential
        sendToUWED("I("&STR(0)&")") ! Do not change potential
        sendToUWED("L("&STR(nrSteps(SCi))&")") ! Number of steps
        sendToUWED("M()") ! Run the sequence
        ScanRunning=1
    END IF
END SUB
! - Process incoming data
SUB procData(input_array() AS INTEGER)
    PRINT "Index: "&CHR(input_array(1)) ! Feedback to console
    ! First check that there is no dublication
    IF(input_array(1)=lastIndex) THEN
        GOTO OutSub! If same as last time do nothing
    END IF
```

```
lastIndex=input_array(1)
    ! Now look if new data came M character on second position (This is data then)
    IF(input_array(2)=ASC("M"))THEN ! New data came
        IF ScanRunning=1 THEN! Only if scan is running there is something to come
            DPi=DPi+1
            dRe(DPi)=ConvertToNumberBin(input_array,3,4)
            dADC(DPi)=ConvertToNumberBin(input_array,5,6)
            DPi=DPi+1
            dRe(DPi)=ConvertToNumberBin(input_array,7,8)
            dADC(DPi)=ConvertToNumberBin(input_array,9,10)
            Ts(DPi)=ConvertToNumberBin(input_array,11,14)
            Ts(DPi-1)=Ts(DPi)-timeStep
            dWe(DPi)=ConvertToNumberBin(input_array,15,16)
            dWe(DPi-1)=dWe(DPi)
            Ni(DPi)=ConvertToNumberBin(input_array, 17, 18)
            Ni(DPi-1)=Ni(DPi)
            ! Do the math for visualization
            ! ODD
            VoltW=dRe(DPi-1)*(-6.64898E-5)+1.50310! Working electrode potential vs ref
            Curr=0.00608*(dADC(DPi-1)-30694)-0.04! Current in uA
            IF DPi=2 THEN
                time0=Ts(1)
            END IF
            myCA(DPi-1,1)=(Ts(DPi-1)-time0)/1000
            myCA(DPi-1,2)=Curr
            ! EVEN
            VoltW=dRe(DPi)*(-6.64898E-5)+1.50310 ! Working electrode pot vs ref
            Curr=0.00608*(dADC(DPi)-30694)-0.04 ! Current in uA
            myCA(DPi, 1) = (Ts(DPi) - time0)/1000
            myCA(DPi,2)=Curr
            ! Show graph
            pCA.setPoints(myCA)
            p1.setView(0,minY(myCA),mTime,maxY(myCA),0)
        END IF
    END IF
    ! If end of the scan start new
    IF (input_array(2)=ASC("m")) THEN ! End of scan
        InitializeScan ! Start next scan
    END IF
    ! In other cases do nothing
OutSub:
END SUB
! - Convert to Number from String source - currently not used
FUNCTION ConvertToNumberStr(input_array() AS INTEGER, _
                            begi AS INTEGER,
                            endi AS INTEGER) AS LONG
    DIM nets AS STRING
    nets=""
    FOR i=begi TO endi
        nets=nets & chr(input array(i))
    NEXT i
    ConvertToNumberStr=VAL(nets)
END FUNCTION
! - Convert to Number from Binary source - used in data receiving
FUNCTION ConvertToNumberBin(input_array() AS INTEGER, _
```

begi AS INTEGER, _

```
endi AS INTEGER) AS LONG
```

```
DIM sum AS LONG
    sum=input_array(begi)
    FOR i=begi+1 TO endi
        sum=sum*256
        sum=sum+input_array(i)
   NEXT i
    ConvertToNumberBin=sum
END FUNCTION
 EVENTS
! When button is clicked
SUB touchUpInside(crtl AS Button, when AS DOUBLE)
    IF crtl=startButton THEN ! Send now
        myMess.setText("Start the scan")
        InitializeUWED
        InitializeScan
    END IF
END SUB
! BLE EVENTS and FUNCTIONS
! - Send command to UWED
SUB sendToUWED(inp AS STRING)
    DIM ax(LEN(inp)) AS INTEGER
    FOR i=1 TO LEN(INP)
        ax(i)=ASC(MID(inp,i,1))
   NEXT
bm.writeCharacteristic(bleWriteChar,ax)
END SUB
! - First when device is discovered
SUB BLEDiscoveredPeripheral (
                                time AS DOUBLE, _
                                peripheral AS BLEPeripheral, _
                                services() AS STRING,
                                advertisements(,) AS STRING, _
                                 rssi)
    PRINT "Device Found";
    IF peripheral.bleName="UWED" THEN! Right device found connect to the device
        bm=peripheral
        ble.connect(bm)
        ble.stopScan ! Do not look any further
        print "Device is UWED"
    END IF
END SUB
! - When information about the device is fetched
SUB BLEPeripheralInfo(
                        time AS DOUBLE,
                        peripheral AS BLEPeripheral, _
                        kind AS INTEGER,
                        message AS STRING, _
                        err AS LONG)
    IF kind=1 THEN ! Connection completed
        peripheral.discoverServices(uuid)
    ELSE IF kind=2 OR kind=3 THEN! Connection lost
```

```
ble.connect(bm)
    ELSE IF kind=4 THEN! Service dound
        DIM avServ(1) AS bleservice
        avServ=peripheral.services
        FOR a=1 TO UBOUND(services,1)
            FOR a=1 TO UBOUND(services,1)
                IF avServ(a).uuid="2220" THEN! If right service id has been found
                    peripheral.discoverCharacteristics(uuid, avServ(a))
                    print "Service discovered"
                END IF
            NEXT
       NEXT
    END IF
END SUB
! - When information about service is obtained
SUB BLEServiceInfo( time AS DOUBLE, _
                    peripheral AS BLEPeripheral, _
                    service AS BLEService, _
                    kind AS INTEGER, _
                    message AS STRING,
                    err AS LONG)
    IF kind=1 THEN
        DIM chx(1) AS blecharacteristic
        chx=service.characteristics
        FOR i=1 TO UBOUND(chx,1)
            IF service.uuid="2220" THEN
                IF chx(i).uuid="2221" THEN
                    peripheral.setNotify(chx(i),1) ! Notify if changes
                    print "Read characteristic found"
                ELSE IF chx(i).uuid="2222" THEN
                    bleWriteChar=chx(i)
                    print "Write characteristic found"
                END IF
                myMess.setText("BLE CONNECTED!")
            END IF
       NEXT
    END IF
END SUB
! - If BLE Characteristic info comes
SUB BLECharacteristicInfo( time AS DOUBLE, _
                            peripheral AS BLEPeripheral, _
                            characteristic AS BLECharacteristic, _
                            kind AS INTEGER, _
                            message AS STRING, _
                            err AS LONG)
    IF kind=2 THEN
        IF characteristic.uuid="2221" THEN
            DIM value(1) AS INTEGER
            value=characteristic.value
            procData(value)
        END IF
    END IF
END SUB
```

! HELPING FUNCTIONS

```
! - Find minimum value in the array (for auto scaling of plots)
FUNCTION minY(inarray() as DOUBLE) AS DOUBLE
    a=inarray(1,2)
    for i=1 to DPi
        if a>inarray(i,2) then
            a=inarray(i,2)
        end if
    next
   minY=a
end function
! - Find maximum value in the array (for auto scaling of plots)
function maxY(inarray() as DOUBLE) AS DOUBLE
    a=inarray(1,2)
    for i=1 to DPi
        if a<inarray(i,2) then
            a=inarray(i,2)
        end if
    next
    maxY=a
end function
! - END OF THE CODE -
```