
Primitive Logic Functions


Switch representation of a 2-input AND function.



A 3-input version could be constructed by adding a third switch in series with the first two

CS1026

Switch representation of a 2-input OR function



CS1026


Logic Gate

In electronics, a logic gate is an idealized or physical device implementing a Boolean function; that is, it performs a logical operation on one or more logical inputs, and produces a single logical output.


Depending on the context, the term may refer to an ideal logic gate, one that has for instance zero rise time and unlimited fan-out, or it may refer to a non-ideal physical device

CS1026

BUF and NOT functions



Inverter Delay



 t_{pdr} : rising propagation delay


• From input to rising output crossing $V_{DD}/2$

 t_{pdf} : falling propagation delay


• From input to falling output crossing $V_{DD}/2$

Pico is a unit prefix in the metric system denoting one trillionth, a factor of 10^-12 (0.00000000000001). this was one of the original 12 prefixes defined in 1960 when the International System of Units was established.


Two NOT functions connected in series



AND, OR, and XOR functions.





NAND, NOR, and XNOR functions



Eight simple functions (BUF, NOT, AND, NAND, OR, NOR, XOR, and XNOR) from which everything else is constructed

Construct all of the above functions using one or more NAND gates (or one or more NOR gates)





In the NASA Apollo space missions to the moon in the 1960s and 1970s, all on board computations for primary guidance, navigation and control were provided by a small custom processor called "The Apollo Guidance Computer". It used wire wrap circuit boards whose only logic elements were three-input NOR gates