





EECS 370 - Lecture 3









Instruction Set Architecture (ISA) Design Lectures

"People who are really serious about software should make their own hardware." — Alan Kav

- Lecture 2: ISA storage types, binary and addressing modes
- Lecture 3: LC2K

· Pretty self-explanatory

- Lecture 4 : ARM
- Lecture 5 : Converting C to assembly basic blocks
- Lecture 6 : Converting C to assembly functions

LC2K Instruction Overview: add

• What if we want to do other arithmetic operations?

• Multiply? You'll figure this out for P1m

Negate? In 2's complement, bitwise-NOT followed by + 1

•Subtract? Same as adding, but with a negated second operand

• Lecture 7: Translation software; libraries, memory layout



Live Poll + Q&A: slido.com #eecs370

Poll and Q&A Link



LC2KISA LC2K Processor 52 bit processor to SSA 2H 52 bit 8th data: legister width, date • 62-bit processor \$ 534 21748 1545 OX 000 000 000 000 000 0000 ano an ano ano • Integer registers are 32 bits 8 registers

- - register 0 always gives the value 0
- supports 65536 words of memory (addressable space)
 8 instructions in the following common categories:
- - Arithmetic: add
 - Logical: nor
 - · Data transfer: lw, sw
 - · Conditional branch: beq
 - Unconditional branch (jump) and link: jalr
 - Other: halt, noop





add 1 2 3 // r3 = r1 + r2

LC2K Instruction Overview: nor

nor 1 2 3 // r3 = ~(r1 | r2)

- · Treats each source operand as binary number
- · Performs bitwise NOR for each pair of bits • E.g. if

r1 = 60 = **0b**0000 0000 0000 0000 0000 0000 0011 1100 r2 = 13 = **0b**0000_0000_0000_0000_0000_0000_1101

then

r3 = 0b1111_1111_1111_1111_1111_11100_0010

register file

2340

- · What if we want other logical operations?

 - NOT? nor something with itself
 AND? Can be done using De Morgan's Law (review if needed)

LC2K Instruction Overview: lw/sw te-tadbless bot land 给 regB

GLOBAL: nt main() {
GLOBAL = GLOBAL*2

0.1,1000 // r1 = mem[1000+r0]add 1 1 2 90 // r2 = 2*r1add: rep (= repA+) sw 0 2 1000 // mem[1000+r0] = r2

- lw "load word"
 - Loads a word (4 bytes) from a specified address into a register
- sw "store word"
 - · stores a word (4 bytes) from a register into a specified address
- Unlike add/nor, last operand here is **not** a register index
 - An immediate value: a number encoded directly in the instruction
- · LC2K uses base+offset addressing
 - base register is first operand (if 0, then address = offset)


Non-Zero Displacement

· Consider this code:

struct My_Struct { int tot; //... int val;

My_Struct a; a.tot += a.val;







memory

- If a register holds the starting address of "a"...
 - · Then the specific values needed are at a slight offset
- Base + Displacement
- · reg value + immed

LC2K Instruction Overview: beq

rept rept offset beq 1 2 7 // if (reg1==reg2), PC=PC+1+7

- if reg A= reg B NPC t= Hoffet (本教徒), 只不协约
 Remember: each line in assembly corresponds to a memory address offet)
- "Program Counter" (PC) keeps track of address of current instruction
- Normally increments by 1 🗳
- "Branch if equal" (beq) allows us to change PC a different amount if 2 registers are equal
- Allows us to implement if/else statements, for/while loops
- (example later)







LC2K Instruction Overview: the others

- jair; used for function calls and returns
 - · It's a bit complicated: we'll discuss later
- halt: ends the program
- noop:
 - "no operation"
 - · Doesn't do anything
 - (We'll see later why this can be useful)

Note on Practical ISAs

- LC2K is made up for this class
- It's intended to be as simple as possible
 - · Makes most of our projects less tedious
 - · However, corresponding assembly code is bloated
- Practical ISAs will add many more instructions
 - · Often hundreds, maybe thousands
 - · Although functionally redundant, programs will be faster and easier to write






Agenda

- LC2K Instruction Overview
- · Assembling LC2K into machine code
- Project 1a Overview
- Bonus Problems

Instruction Encoding

- · Remember: computer doesn't understand text
 - · Only understands 0s and 1s
- In order to execute our programs, assembly instructions must be converted into
 - Corresponding numbers called the machine code
- Let's see how this is done with LC2K instructions



LC2KISA

LC2KISA

15-0




LC2KISA

, 8 thes

Instruction Encoding

• Instruction set architecture defines the mapping of assembly instructions to machine code



Instruction Formats

• Tells you which bit positions mean what

• R (register) type instructions (add, nor)

Ahex标: OxOOSCOWT

31-25 24-22 21-19 18-16 15-3 2-0 unused unused destR opcode regA regB 100 001

• I (immediate) type instructions (lw, sw, beq) 31-25 21-19 18-16 24-22

offset unused opcode regA regB

15-0

LC2KISA

Instruction Formats



(4) • O type instructions (halt, noop)



Bit Encodings

- Most significant bits (besides unused 31-25) consist of the operation code or opcode

 - Indicates what type of operation LC2K has 8 instructions, so we need $\log_2 8 = 3$ bits for the opcode
- Opcode encodings
 - add (000), nor (001), lw (010), sw (011), beq (100), jalr (101), halt (110), noop (111)
- Register values
 - 8 registers, so $log_2 8 = 3$ bits for each register index
 - Just encode the register number (r2 = 010)
- · Immediate values
 - Just encode the values in 2's complement format







Fun with 2's Complement Numbers

- What is the range of representation of a 4-bit 2's complement number?
 - [-8, 7] (corresponding to 1000 and 0111)
- What is the range of representation of an n-bit 2's complement number?
 - [-2⁽ⁿ⁻¹⁾, 2⁽ⁿ⁻¹⁾ 1]

• Add 1:


- · Useful trick: You can negate a 2's complement number by inverting all the bits and adding 1.
 - · 5 is represented as


0101 1010

· Negate each bit:

1011 = -8 + 2 + 1 = -5

LC2KISA






LC2KISA

Convert to Hex → 0x005C0007 Convert to Dec → 6029319

Example Encoding - lw



Convert to Dec → 11206648

int GLOBAL = 7;

Another way to think about the assembler

- · Each line of assembly code corresponds to a number
 - "add 0 0 0" is just 0.
 - "lw 5 2 -8" is 11206648
- We only write in assembly because it's easier to read and write

.fill

• I also might want a number, to be, well, a number.

• Maybe I want the number 7 as a data element I can use

- .fill tells the assembler to put a number instead of an instruction
- The syntax is just ".fill 7".

• Question:

000 ...000 111 (instruction 位=7

• What do ".fill 7" and "add 0 0 7" have in common?

.fill with lw / sw

address: 0 1w · We most often use .fill along with lw or sw

· Remember: every line in an assembly program corresponds to an address in

• When an instruction is to be executed, that address is sent to memory

• ".fill 71" is address 2, meaning mem[2]=71

• "lw 0 1 2" loads the contents of mem[2] into register 1

8454146 25165824

.fill 71

adres: I halt

, 2

IMPORTANT


.fill



- It does not have a corresponding opcode
- It should be used to initialize data in your program
 - If your PC ever points to it, something has probably gone wrong
- But if the PC DOES point to it, it will treat it as whatever type of instruction encodes to that number


Labels in LC2K

- · The code on the right is awkward
 - · Need to count lines to see what it's doing
- Labels make code easier to read/write
- Label definition: listed to the left of the opcode
 - Can be defined on any line (only once)
- Label use: replaces offset value in lw/sw/beq instructions (any number)
- For lw/sw, assembler will replace label use with the line number of definition
 - · In this example, data is on line 2









Exercise

· What are the values of the labels here?



Poll: What are the labels replaced with?

Agenda

- LC2K Instruction Overview
- Assembling LC2K into machine code
- Project 1a Overview
- Bonus Problems

Programming Assignment #1

) machine wde

- Write an assembler to convert input (assembly language program) to output (machine code version of program) • "1a"
- Write a behavioral simulator to run the machine code version of the program (printing the contents of the registers and memory after each instruction executes
 - "1s"
- Write an efficient LC2K assembly language program to multiply two numbers

Agenda

- LC2K Instruction Overview
- Assembling LC2K into machine code
- Project 1a Overview
- Bonus Problems


Extra Problem 1



- Compute the encoding in Hex for:
 - add 3 7 3 (r3 = r3 + r7) (add = 000)
 - sw 1 5 67 (M[r1+67] = r5) (sw = 011)

31-25	24-22	21-19	18-16	15-3	2-0	
unused	opcode	regA	regB	unused	destR	
0000000	000	011	111	000000	011	
31-25	24-22	21-19	18-16		15-0	
unused	opcode	regA	regB	offset		
0000000	011	0.01	101	00000000	0000000001000011	

Extra problem 2



- What does that program do?
- · Be aware that a beq uses PC-relative addressing.
 - Be sure to carefully read the example in project 1.