streamout

Generated by Doxygen 1.9.3

1 Hierarchical Index	1
1.1 Class Hierarchy	1
2 Class Index	1
2.1 Class List	1
3 File Index	2
3.1 File List	2
4 Class Documentation	3
4.1 Buffer Class Reference	3
4.1.1 Detailed Description	4
4.1.2 Constructor & Destructor Documentation	4
4.1.3 Member Function Documentation	5
4.2 BufferLooper< SOURCE, DESTINATION > Class Template Reference	6
4.2.1 Detailed Description	7
4.2.2 Constructor & Destructor Documentation	7
4.2.3 Member Function Documentation	7
4.3 BufferLooperCounter Struct Reference	10
4.3.1 Detailed Description	11
4.3.2 Member Function Documentation	11
4.3.3 Member Data Documentation	11
4.4 DIF Class Reference	12
4.4.1 Detailed Description	13
4.4.2 Member Function Documentation	13
4.5 DIFPtr Class Reference	15
4.5.1 Detailed Description	16
4.5.2 Member Function Documentation	16
4.6 DIFSlowControl Class Reference	21
4.6.1 Detailed Description	21
4.6.2 Constructor & Destructor Documentation	21
4.6.3 Member Function Documentation	22
4.7 Event Class Reference	24
4.7.1 Detailed Description	24
4.7.2 Member Function Documentation	24
4.8 Hit Class Reference	25
4.8.1 Detailed Description	25
4.8.2 Member Function Documentation	26
4.9 Interface Class Reference	29
4.9.1 Detailed Description	29
4.9.2 Constructor & Destructor Documentation	29
4.9.3 Member Function Documentation	30
4.10 InterfaceReader Class Reference	32

	4.10.1 Detailed Description	32
	4.10.2 Constructor & Destructor Documentation	32
	4.10.3 Member Data Documentation	33
	4.11 InterfaceWriter Class Reference	33
	4.11.1 Detailed Description	33
	4.11.2 Constructor & Destructor Documentation	33
	4.11.3 Member Function Documentation	34
	4.12 RawBufferNavigator Class Reference	35
	4.12.1 Detailed Description	35
	4.12.2 Constructor & Destructor Documentation	35
	4.12.3 Member Function Documentation	36
	4.13 RawdataReader Class Reference	39
	4.13.1 Detailed Description	39
	4.13.2 Constructor & Destructor Documentation	39
	4.13.3 Member Function Documentation	40
	4.14 ROOTWriter Class Reference	42
	4.14.1 Detailed Description	43
	4.14.2 Constructor & Destructor Documentation	43
	4.14.3 Member Function Documentation	43
	4.15 textDump Class Reference	46
	4.15.1 Detailed Description	46
	4.15.2 Constructor & Destructor Documentation	46
	4.15.3 Member Function Documentation	47
	4.16 Timer Class Reference	48
	4.16.1 Detailed Description	48
	4.16.2 Member Function Documentation	49
	4.17 Version Class Reference	49
	4.17.1 Detailed Description	50
	4.17.2 Constructor & Destructor Documentation	50
	4.17.3 Member Function Documentation	50
6 E	File Documentation	51
31	5.1 libs/core/include/Bits.h File Reference	51 51
	5.1.1 Detailed Description	52
	5.1.2 Typedef Documentation	52
	5.1.3 Function Documentation	52
	5.2 Bits.h	53
	5.3 libs/core/include/Buffer.h File Reference	53 53
	5.4 Buffer.h	53 54
	5.5 libs/core/include/BufferLooper.h File Reference	
	5.5.1 Detailed Description	54

5.6 BufferLooper.h
5.7 libs/core/include/BufferLooperCounter.h File Reference
5.7.1 Detailed Description
5.8 BufferLooperCounter.h
5.9 libs/core/include/DetectorId.h File Reference
5.9.1 Detailed Description
5.9.2 Enumeration Type Documentation
5.10 DetectorId.h
5.11 libs/core/include/DIFPtr.h File Reference
5.11.1 Detailed Description
5.12 DIFPtr.h
5.13 libs/core/include/DIFSlowControl.h File Reference
5.13.1 Detailed Description
5.13.2 Function Documentation
5.14 DIFSlowControl.h
5.15 libs/core/include/Filesystem.h File Reference
5.15.1 Detailed Description
5.15.2 Function Documentation
5.16 Filesystem.h
5.17 libs/core/include/Formatters.h File Reference
5.17.1 Detailed Description
5.17.2 Function Documentation
5.18 Formatters.h
5.19 libs/core/include/Interface.h File Reference
5.19.1 Detailed Description
5.19.2 Enumeration Type Documentation
5.20 Interface.h
5.21 libs/core/include/RawBufferNavigator.h File Reference
5.21.1 Detailed Description
5.22 RawBufferNavigator.h
5.23 libs/core/include/Timer.h File Reference
5.23.1 Detailed Description
5.24 Timer.h
5.25 libs/core/include/Utilities.h File Reference
5.25.1 Detailed Description
5.25.2 Function Documentation
5.26 Utilities.h
5.27 libs/core/include/Version.h File Reference
5.27.1 Detailed Description
5.28 Version.h
5.29 libs/core/include/Words.h File Reference
5.29.1 Detailed Description

5.29.2 Enumeration Type Documentation	76
5.30 Words.h	77
5.31 libs/core/src/Bits.cc File Reference	77
5.31.1 Detailed Description	77
5.31.2 Function Documentation	78
5.32 Bits.cc	78
5.33 libs/core/src/BufferLooperCounter.cc File Reference	78
5.34 BufferLooperCounter.cc	78
5.35 libs/core/src/DIFSlowControl.cc File Reference	79
5.35.1 Detailed Description	79
5.35.2 Function Documentation	79
5.36 DIFSlowControl.cc	79
5.37 libs/core/src/Filesystem.cc File Reference	82
5.37.1 Detailed Description	83
5.37.2 Function Documentation	83
5.38 Filesystem.cc	84
5.39 libs/core/src/Formatters.cc File Reference	84
5.39.1 Detailed Description	85
5.39.2 Function Documentation	85
5.40 Formatters.cc	89
5.41 libs/core/src/RawBufferNavigator.cc File Reference	90
5.41.1 Detailed Description	90
5.42 RawBufferNavigator.cc	90
5.43 libs/core/src/Version.cc File Reference	92
5.43.1 Detailed Description	92
5.44 Version.cc	92
5.45 libs/interface/Dump/include/textDump.h File Reference	93
5.45.1 Detailed Description	93
5.46 textDump.h	93
5.47 libs/interface/Dump/src/textDump.cc File Reference	93
5.47.1 Detailed Description	94
5.48 textDump.cc	94
5.49 libs/interface/LCIO/include/LCIOWriter.h File Reference	94
5.49.1 Detailed Description	94
5.50 LCIOWriter.h	94
5.51 libs/interface/LCIO/src/LCIOWriter.cc File Reference	95
5.51.1 Detailed Description	95
5.52 LCIOWriter.cc	95
5.53 libs/interface/RawDataReader/include/RawdataReader.h File Reference	95
5.53.1 Detailed Description	95
5.54 RawdataReader.h	96
5.55 libs/interface/RawDataReader/src/RawdataReader.cc File Reference	96

1 Hierarchical Index

5.55.1 Detailed Description	96
5.56 RawdataReader.cc	97
5.57 libs/interface/ROOT/include/DIF.h File Reference	98
5.57.1 Detailed Description	98
5.57.2 Typedef Documentation	99
5.58 DIF.h	99
5.59 libs/interface/ROOT/include/DIFLinkDef.h File Reference	99
5.59.1 Detailed Description	99
5.60 DIFLinkDef.h	00
5.61 libs/interface/ROOT/include/Event.h File Reference	00
5.61.1 Detailed Description	00
5.61.2 Typedef Documentation	00
5.62 Event.h	01
5.63 libs/interface/ROOT/include/EventLinkDef.h File Reference	01
5.63.1 Detailed Description	01
5.64 EventLinkDef.h	01
5.65 libs/interface/ROOT/include/Hit.h File Reference	01
5.65.1 Detailed Description	02
5.66 Hit.h	02
5.67 libs/interface/ROOT/include/HitLinkDef.h File Reference	02
5.67.1 Detailed Description	02
5.68 HitLinkDef.h	03
5.69 libs/interface/ROOT/include/ROOTWriter.h File Reference	03
5.70 ROOTWriter.h	03
5.71 libs/interface/ROOT/src/DIF.cc File Reference	04
5.71.1 Detailed Description	04
5.72 DIF.cc	04
5.73 libs/interface/ROOT/src/Event.cc File Reference	04
5.73.1 Detailed Description	04
5.74 Event.cc	05
5.75 libs/interface/ROOT/src/Hit.cc File Reference	05
5.75.1 Detailed Description	05
5.76 Hit.cc	05
5.77 libs/interface/ROOT/src/ROOTWriter.cc File Reference	06
5.77.1 Detailed Description	06
5.78 ROOTWriter.cc	06

1 Hierarchical Index

1.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

Buffer	
BufferLooper< SOURCE, DESTINATION >	
BufferLooperCounter	10
DIFPtr	15
DIFSlowControl	21
Interface	29
InterfaceReader	32
RawdataReader	39
InterfaceWriter	33
ROOTWriter	42
textDump	46
RawBufferNavigator	35
Timer TObject	48
DIF	12
Event	24
Hit semver::version	25
Version	49

2 Class Index

2.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

Buffer	•
BufferLooper < SOURCE, DESTINATION >	•
BufferLooperCounter	10
DIF	12
DIFPtr	15
DIFSlowControl	2 1
Event	24
Hit	25
Interface	29

3 File Index 3

InterfaceReader	32
InterfaceWriter	33
RawBufferNavigator	35
RawdataReader	39
ROOTWriter	42
textDump	46
Timer	48
Version	49
3 File Index	
3.1 File List	
Here is a list of all files with brief descriptions:	
libs/core/include/Bits.h	51
libs/core/include/Buffer.h	53
libs/core/include/BufferLooper.h	54
libs/core/include/BufferLooperCounter.h	57
libs/core/include/Detectorld.h	58
libs/core/include/DIFPtr.h	59
libs/core/include/DIFSlowControl.h	62
libs/core/include/Filesystem.h	63
libs/core/include/Formatters.h	65
libs/core/include/Interface.h	69
libs/core/include/RawBufferNavigator.h	72
libs/core/include/Timer.h	73
libs/core/include/Utilities.h	73
libs/core/include/Version.h	74
libs/core/include/Words.h	75
libs/core/src/Bits.cc	77
libs/core/src/BufferLooperCounter.cc	78
libs/core/src/DIFSlowControl.cc	79
libs/core/src/Filesystem.cc	82

libs/core/src/Formatters.cc	84
libs/core/src/RawBufferNavigator.cc	90
libs/core/src/Version.cc	92
libs/interface/Dump/include/textDump.h	93
libs/interface/Dump/src/textDump.cc	93
libs/interface/LCIO/include/LCIOWriter.h	94
libs/interface/LCIO/src/LCIOWriter.cc	95
libs/interface/RawDataReader/include/RawdataReader.h	95
libs/interface/RawDataReader/src/RawdataReader.cc	96
libs/interface/ROOT/include/DIF.h	98
libs/interface/ROOT/include/DIFLinkDef.h	99
libs/interface/ROOT/include/Event.h	100
libs/interface/ROOT/include/EventLinkDef.h	101
libs/interface/ROOT/include/Hit.h	101
libs/interface/ROOT/include/HitLinkDef.h	102
libs/interface/ROOT/include/ROOTWriter.h	103
libs/interface/ROOT/src/DIF.cc	104
libs/interface/ROOT/src/Event.cc	104
libs/interface/ROOT/src/Hit.cc	105
libs/interface/ROOT/src/ROOTWriter.cc	106

4 Class Documentation

4.1 Buffer Class Reference

#include <libs/core/include/Buffer.h>

Public Member Functions

- Buffer ()
- virtual \sim Buffer ()
- Buffer (const bit8_t b[], const std::size_t &i)
- Buffer (const char b[], const std::size_t &i)

Buffer (const std::array< T, N > &rawdata)

- template<typename T >
 Buffer (const std::vector< T > &rawdata)
- template<typename T , std::size_t N>

```
• std::size_t size () const
```

- std::size_t capacity () const
- void set (unsigned char *b)
- bit8_t * begin () const
- bit8_t * end () const
- bit8_t & operator[] (const std::size_t &pos)
- bit8_t & operator[] (const std::size_t &pos) const
- void setSize (const std::size_t &size)

4.1.1 Detailed Description

Definition at line 14 of file Buffer.h.

4.1.2 Constructor & Destructor Documentation

```
4.1.2.1 Buffer() [1/5] Buffer::Buffer ( ) [inline]
Definition at line 17 of file Buffer.h.
00017 : m_Buffer(nullptr), m_Size(0), m_Capacity(0) {}
4.1.2.2 \sim Buffer() virtual Buffer::\sim Buffer() [inline], [virtual]
Definition at line 18 of file Buffer.h.
00018 {}
4.1.2.3 Buffer() [2/5] Buffer::Buffer (
              const bit8_t b[],
              const std::size_t & i ) [inline]
Definition at line 19 of file Buffer.h.
00019 : m_Buffer(const_cast < bit8_t* > (&b[0])), m_Size(i), m_Capacity(i) {}
4.1.2.4 Buffer() [3/5] Buffer::Buffer (
              const char b[],
              const std::size_t & i ) [inline]
Definition at line 20 of file Buffer.h.
00020 : m_Buffer(const_cast<bit8_t*>(reinterpret_cast<const bit8_t*>(&b[0]))), m_Size(i * sizeof(char)),
      m_Capacity(i * sizeof(char)) {}
```

```
4.1.2.5 Buffer() [4/5] template<typename T >
Buffer::Buffer (
             const std::vector< T > & rawdata ) [inline]
Definition at line 21 of file Buffer.h.
00021 : m_Buffer(const_cast<bit8_t*>(reinterpret_cast<const bit8_t*>(rawdata.data()))),
     m_Size(rawdata.size() * sizeof(T)), m_Capacity(rawdata.capacity() * sizeof(T)) {}
4.1.2.6 Buffer() [5/5] template<typename T , std::size_t N>
Buffer::Buffer (
             const std::array< T, N > & rawdata ) [inline]
Definition at line 22 of file Buffer.h.
4.1.3 Member Function Documentation
4.1.3.1 begin() bit8_t * Buffer::begin ( ) const [inline]
Definition at line 28 of file Buffer.h.
00028 { return m_Buffer; }
4.1.3.2 capacity() std::size_t Buffer::capacity ( ) const [inline]
Definition at line 25 of file Buffer.h.
00025 { return m_Capacity; }
4.1.3.3 end() bit8_t * Buffer::end ( ) const [inline]
Definition at line 29 of file Buffer.h.
00029 { return m_Buffer + m_Size; }
4.1.3.4 operator[]() [1/2] bit8_t & Buffer::operator[] (
             const std::size_t & pos ) [inline]
Definition at line 30 of file Buffer.h.
00030 { return m_Buffer[pos]; }
```

The documentation for this class was generated from the following file:

• libs/core/include/Buffer.h

4.2 BufferLooper < SOURCE, DESTINATION > Class Template Reference

#include <libs/core/include/BufferLooper.h>

Public Member Functions

- BufferLooper (SOURCE &source, DESTINATION &dest, bool debug=false)
- void addSink (const spdlog::sink ptr &sink, const spdlog::level::level enum &level=spdlog::get level())
- void loop (const std::uint32_t &m_NbrEventsToProcess=0)
- void printAllCounters ()
- std::shared_ptr< spdlog::logger > log ()
- void setDetectorIDs (const std::vector< DetectorID > &detectorIDs)

4.2.1 Detailed Description

```
template < typename SOURCE, typename DESTINATION > class BufferLooper < SOURCE, DESTINATION >
```

Definition at line 27 of file BufferLooper.h.

4.2.2 Constructor & Destructor Documentation

00203 { return m_Logger; }

```
\textbf{4.2.2.1} \quad \textbf{BufferLooper()} \quad \texttt{template} < \texttt{typename SOURCE , typename DESTINATION} >
BufferLooper < SOURCE, DESTINATION >::BufferLooper (
               SOURCE & source,
               DESTINATION & dest.
               bool debug = false ) [inline]
Definition at line 30 of file BufferLooper.h.
00030
                                                                             : m Source(source),
      m_Destination(dest), m_Debug(debug)
00031
00032
          m_Logger = spdlog::create<spdlog::sinks::null_sink_mt>("streamout");
00033
          if(!spdlog::get("streamout")) { spdlog::register_logger(m_Logger); }
00034
         m_Source.setLogger(m_Logger);
00035
         m_Destination.setLogger(m_Logger);
00036
4.2.3 Member Function Documentation
4.2.3.1 addSink() template<typename SOURCE , typename DESTINATION >
void BufferLooper< SOURCE, DESTINATION >::addSink (
               const spdlog::sink_ptr & sink,
               const spdlog::level::level_enum & level = spdlog::get_level() ) [inline]
Definition at line 38 of file BufferLooper.h.
00039
00040
          sink->set_level(level);
00041
         m_Sinks.push_back(sink);
m_Logger = std::make_shared<spdlog::logger>("streamout", begin(m_Sinks), end(m_Sinks));
00042
00043
          m_Source.setLogger(m_Logger);
00044
         m_Destination.setLogger(m_Logger);
00045
4.2.3.2 log() template<typename SOURCE , typename DESTINATION >
std::shared_ptr< spdlog::logger > BufferLooper< SOURCE, DESTINATION >::log ( ) [inline]
Definition at line 203 of file BufferLooper.h.
```

```
4.2.3.3 loop() template<typename SOURCE , typename DESTINATION >
void BufferLooper< SOURCE, DESTINATION >::loop (
                     const std::uint32_t & m_NbrEventsToProcess = 0 ) [inline]
START EVENT ///
START DIF ///
START FRAME ///
START FRAME ///
START DIF ///
START EVENT ///
Definition at line 47 of file BufferLooper.h.
00049
              // clang-format off
00050
              fmt::print(fg(fmt::color::medium_orchid) | fmt::emphasis::bold,
00051
                          "\n"
00052 " SSSSSSSSSSSSSS
        tttt\n"
ttt:::t\n"
00054 "S:::::SSSSSS::::::S t::::t
        t::::t\n"
00055 "S:::::S
                          SSSSSSS t::::t
         t::::t\n"
                         00056 "S::::S
                                                                                                                       aaaaaaaaaaaa
mmmmmm mmmmmm 00057 "S:::::S t::
                                                                                             ee::::::ee a::::::a
        mm :: :: :: mm \quad oo :: :: :: :: oo \ u :: :: u \qquad u :: :: ut :: :: :: :: t \backslash n "
00059 " SS::::::SSSSStttttt::::::tttttt rr:::::rrrrrr:::::re:::::e
00065 "S::::::SSSSSS:::::S tt:::::::::tr:::::r
                                                                                            e::::::eeeeeeeea:::::aaaaa::::::a m::::m
        ee:::::::tt\n"
eeeeeeeeeee aaaaaaaaa aaaammmmmm
                                                           uuuuuuuu uuuu ttttttttt {}\n"
        mmmmmm ooooooooo
00068 "\n",
00069 \ \texttt{fmt::format(fg(fmt::color::red)} \ | \ \texttt{fmt::emphasis::bold,} \ \texttt{"v{}",} \ \texttt{streamout\_version.to\_string()));}
00070
           // clang-format on
00071
              log() -> info("Streamout Version : {}", streamout_version.to_string());
log() -> info("Using InterfaceReader {} version {}", m_Source.getName(),
00072
00073
        m_Source.getVersion().to_string());
              log() -> info("Using InterfaceWriter {} version {}", m_Destination.getName(),
        m_Destination.getVersion().to_string());
00075
00076
               if(!m_Destination.checkCompatibility(m_Source.getName(), m_Source.getVersion().to_string()))
00077
00078
                 log()->critical("{} version {} is not compatible with {} version {} ! ", m_Source.getName(),
        m_Source.getVersion().to_string(), m_Destination.getName(), m_Destination.getVersion().to_string());
00079
                 log()->info("Compatible Interfaces for {} are", m_Destination.getName());
08000
                 for(std::map<std::string, std::string>::iterator it = m_Destination.getCompatibility().begin();
         it != m\_Destination.getCompatibility().end(); ++it) { log()->info("{} version {}", it->first, log()->info("{} version {}", it->first, log()->info("{} version {} v
        it->second): }
00081
                std::exit(-1);
00082
00083
               if(!m_DetectorIDs.empty())
00084
00085
                 std::string ids;
00086
                 for(std::vector<DetectorID>::const_iterator it = m_DetectorIDs.cbegin(); it !=
        m_DetectorIDs.cend(); ++it) ids += std::to_string(static_cast<std::uint16_t>(*it)) + ";";
00087
                log()->info("Detector ID(s) other than {} will be ignored", ids);
00088
```

```
log()->info("*****
00090
          RawBufferNavigator bufferNavigator(m_Logger);
00091
          Timer
                              timer;
00092
          timer.start():
00093
          m Source.start();
00094
          m Destination.start();
00095
          while (m_Source.nextEvent() && m_NbrEventsToProcess >= m_NbrEvents)
00096
00098
             m_Source.startEvent();
00099
            m_Destination.startEvent();
00101
00102
            m Logger->warn("===*** Event {} ***===", m NbrEvents);
00103
             while (m_Source.nextDIFbuffer())
00104
00105
               const Buffer& buffer = m_Source.getBuffer();
00106
              \verb|bufferNavigator.setBuffer(buffer);|\\
00107
              if(std::find(m_DetectorIDs.begin(), m_DetectorIDs.end(),
      static_cast<DetectorID>(bufferNavigator.getDetectorID())) == m_DetectorIDs.end())
00108
              {
00109
                m_Logger->debug("Ignoring detector ID : {}", bufferNavigator.getDetectorID());
00110
00111
              }
00112
              bit8_t* debug_variable_1 = buffer.end();
bit8_t* debug_variable_2 = bufferNavigator.getDIFBuffer().end();
if(debug_variable_1 != debug_variable_2) m_Logger->info("DIF BUFFER END {} {} ",
00113
00114
00115
      fmt::ptr(debug_variable_1), fmt::ptr(debug_variable_2));
00116
              if(m_Debug) assert(debug_variable_1 == debug_variable_2);
00117
00118
              std::int32_t idstart = bufferNavigator.getStartOfPayload();
00119
              if (m Debug && idstart == -1) m Logger->info(to hex(buffer));
00120
              c.DIFStarter[idstart]++;
00121
               if(!bufferNavigator.validBuffer())
00122
00123
                m_Logger->error("!bufferNavigator.validBuffer()");
00124
                continue;
00125
              }
00128
              m_Source.startDIF();
00129
              m_Destination.startDIF();
00131
00132
              DIFPtr& d = bufferNavigator.getDIFPtr();
              c.DIFPtrValueAtReturnedPos[bufferNavigator.getDIFBufferStart()[d.getGetFramePtrReturn()]]++;
00133
00134
               if(m_Debug) assert(bufferNavigator.getDIFBufferStart()[d.getGetFramePtrReturn()] == 0xa0);
               c.SizeAfterDIFPtr[bufferNavigator.getSizeAfterDIFPtr()]++;
00135
00136
               m_Destination.processDIF(d);
00137
               for(std::size_t i = 0; i < d.getNumberOfFrames(); ++i)</pre>
00138
               {
00140
                m Source.startFrame();
00141
                 m Destination.startFrame();
00143
                 m_Destination.processFrame(d, i);
00144
                 for(std::size_t j = 0; j < DU::NUMBER_PAD; ++j)</pre>
00145
00146
                   if(d.getThresholdStatus(i, j) != 0)
00147
                   {
00148
                    m Source.startPad();
                     m_Destination.startPad();
00150
                     m_Destination.processPadInFrame(d, i, j);
00151
                     m_Source.endPad();
                     m_Destination.endPad();
00152
00153
                   }
00154
00156
                 m_Source.endFrame();
00157
                 m_Destination.endFrame();
00159
00160
00161
              bool processSC = false;
               if (bufferNavigator.hasSlowControlData())
00162
00163
              {
00164
                 c.hasSlowControl++;
00165
                processSC = true;
00166
00167
               if(bufferNavigator.badSCData())
00168
                 c.hasBadSlowControl++;
00169
00170
                processSC = false;
00171
00172
               if(processSC) { m_Destination.processSlowControl(bufferNavigator.getSCBuffer()); }
00173
00174
              Buffer end = bufferNavigator.getEndOfAllData():
00175
              c.SizeAfterAllData[eod.size()]++;
              bit8_t* debug_variable_3 = eod.end();
00176
               if(debug_variable_1 != debug_variable_3) m_Logger->info("END DATA BUFFER END {} {}",
00177
      fmt::ptr(debug_variable_1), fmt::ptr(debug_variable_3));
00178
               if(m_Debug) assert(debug_variable_1 == debug_variable_3);
              if(eod.size() != 0) m_Logger->info("End of Data remaining stuff : {}", to_hex(eod));
00179
00180
```

```
int nonzeroCount = 0;
              for(bit8_t* it = eod.begin(); it != eod.end(); it++)
if(static_cast<int>(*it) != 0) nonzeroCount++;
00182
00183
00184
               c.NonZeroValusAtEndOfData[nonzeroCount]++;
00186
              m_Source.endDIF();
            m_Destination.endDIF();
} // end of DIF while loop
00187
00189
00190
            m_Logger->warn("===*** Event {} ***===", m_NbrEvents);
00191
            m_NbrEvents++;
00193
            m_Source.endEvent();
00194
            m_Destination.endEvent();
00196
          } // end of event while loop
00197
          m_Destination.end();
00198
          m_Source.end();
00199
          timer.stop();
          fmt::print("=== elapsed time {}ms ({}ms/event) ===\n", timer.getElapsedTime() / 1000,
00200
      timer.getElapsedTime() / (1000 * m_NbrEvents));
00201
```

```
4.2.3.4 printAllCounters() template<typename SOURCE, typename DESTINATION > void BufferLooper< SOURCE, DESTINATION >::printAllCounters ( ) [inline]
```

Definition at line 202 of file BufferLooper.h.

```
00202 { c.printAllCounters(); }
```

```
Definition at line 205 of file BufferLooper.h.
00205 { m_DetectorIDs = detectorIDs; }
```

The documentation for this class was generated from the following file:

• libs/core/include/BufferLooper.h

4.3 BufferLooperCounter Struct Reference

#include <libs/core/include/BufferLooperCounter.h>

Public Member Functions

- void printCounter (const std::string &description, const std::map< int, int > &m)
- void printAllCounters ()

Public Attributes

- int hasSlowControl = 0
- int hasBadSlowControl = 0
- std::map< int, int > DIFStarter
- std::map< int, int > DIFPtrValueAtReturnedPos
- std::map< int, int > SizeAfterDIFPtr
- std::map< int, int > SizeAfterAllData
- std::map< int, int > NonZeroValusAtEndOfData

4.3.1 Detailed Description

Definition at line 11 of file BufferLooperCounter.h.

4.3.2 Member Function Documentation

4.3.2.1 printAllCounters() void BufferLooperCounter::printAllCounters ()

Definition at line 9 of file BufferLooperCounter.cc.

```
00010 {
00011    fmt::print("BUFFER LOOP FINAL STATISTICS : \n");
00012    printCounter("Start of DIF header", DIFStarter);
00013    printCounter("Value after DIF data are processed", DIFPtrValueAtReturnedPos);
00014    printCounter("Size remaining in buffer after end of DIF data", SizeAfterDIFPtr);
00015    fmt::print("Number of Slow Control found {} out of which {} are bad\n", hasSlowControl,
    hasBadSlowControl);
00016    printCounter("Size remaining after all of data have been processed", SizeAfterAllData);
00017    printCounter("Number on non zero values in end of data buffer", NonZeroValusAtEndOfData);
00018 }
```

Definition at line 20 of file BufferLooperCounter.cc.

```
00021 {
00022     std::string out{"statistics for " + description + " : \n"};
00023     for(std::map<int, int>::const_iterator it = m.begin(); it != m.end(); it++)
00024     {
00025         if(it != m.begin()) out += ",";
00026         out += " [" + std::to_string(it->first) + "]=" + std::to_string(it->second);
00027     }
00028     out += "\n";
00029     fmt::print(out);
00030 }
```

4.3.3 Member Data Documentation

4.3.3.1 DIFPtrValueAtReturnedPos std::map<int, int> BufferLooperCounter::DIFPtrValueAt↔ ReturnedPos

Definition at line 17 of file BufferLooperCounter.h.

4.3.3.2 DIFStarter std::map<int, int> BufferLooperCounter::DIFStarter

Definition at line 16 of file BufferLooperCounter.h.

4.4 DIF Class Reference 13

4.3.3.3 hasBadSlowControl int BufferLooperCounter::hasBadSlowControl = 0

Definition at line 15 of file BufferLooperCounter.h.

4.3.3.4 hasSlowControl int BufferLooperCounter::hasSlowControl = 0

Definition at line 14 of file BufferLooperCounter.h.

4.3.3.5 NonZeroValusAtEndOfData std::map<int, int> BufferLooperCounter::NonZeroValusAtEnd← OfData

Definition at line 20 of file BufferLooperCounter.h.

4.3.3.6 SizeAfterAllData std::map<int, int> BufferLooperCounter::SizeAfterAllData

Definition at line 19 of file BufferLooperCounter.h.

4.3.3.7 SizeAfterDIFPtr std::map<int, int> BufferLooperCounter::SizeAfterDIFPtr

Definition at line 18 of file BufferLooperCounter.h.

The documentation for this struct was generated from the following files:

- libs/core/include/BufferLooperCounter.h
- libs/core/src/BufferLooperCounter.cc

4.4 DIF Class Reference

#include <libs/interface/ROOT/include/DIF.h>

Inheritance diagram for DIF:



Public Member Functions

```
• void clear ()
```

- void addHit (const Hit &)
- void setID (const std::uint8 t &)
- std::uint8_t getID () const
- void setDTC (const std::uint32_t &)
- std::uint32_t getDTC () const
- void setGTC (const std::uint32_t &)
- std::uint32_t getGTC () const
- void setDIFBCID (const std::uint32_t &)
- std::uint32_t getDIFBCID () const
- void setAbsoluteBCID (const std::uint64_t &)
- std::uint64_t getAbsoluteBCID () const
- std::vector< Hit >::const_iterator cbegin () const
- std::vector< Hit >::const_iterator cend () const

4.4.1 Detailed Description

Definition at line 16 of file DIF.h.

4.4.2 Member Function Documentation

```
\textbf{4.4.2.2 cbegin()} \quad \texttt{std::vector} < \\ \texttt{Hit} > :: \texttt{const\_iterator} \\ \\ \texttt{DIF::cbegin ( )} \\ \\ \texttt{const} \\ \\ \texttt{A.4.2.2} \\ \\ \texttt{Const\_iterator} \\ \texttt{DIF::cbegin ( )} \\ \\ \texttt{const\_iterator} \\ \texttt{DIF::cbegin ( )} \\ \\ \texttt{const\_iterator} \\ \texttt{DIF::cbegin ( )} \\ \texttt{const\_iterator} \\ \texttt{const\_
```

```
Definition at line 32 of file DIF.cc.
00032 { return m_Hits.cbegin(); }
```

```
\textbf{4.4.2.3} \quad \textbf{cend()} \quad \texttt{std::vector} < \\ \texttt{Hit} > :: \texttt{const\_iterator} \\ \\ \texttt{DIF::cend} \\ \text{( ) } \\ \texttt{const} \\ \\ \text{} \\ \text{( ) } \\ \text{
```

```
Definition at line 34 of file DIF.cc. 00034 { return m_Hits.cend(); }
```

4.4 DIF Class Reference 15

```
4.4.2.4 clear() void DIF::clear ()
Definition at line 36 of file DIF.cc.
00036 { m_Hits.clear(); }
4.4.2.5 getAbsoluteBCID() std::uint64_t DIF::getAbsoluteBCID ( ) const
Definition at line 30 of file DIF.cc.
00030 { return m_AbsoluteBCID; }
4.4.2.6 getDIFBCID() std::uint32_t DIF::getDIFBCID ( ) const
Definition at line 26 of file DIF.cc.
00026 { return m_DIFBCID; }
4.4.2.7 getDTC() std::uint32_t DIF::getDTC ( ) const
Definition at line 18 of file DIF.cc.
00018 { return m_DTC; }
4.4.2.8 getGTC() std::uint32_t DIF::getGTC ( ) const
Definition at line 22 of file DIF.cc.
00022 { return m_GTC; }
4.4.2.9 getID() std::uint8_t DIF::getID ( ) const
Definition at line 14 of file DIF.cc.
00014 { return m_ID; }
4.4.2.10 setAbsoluteBCID() void DIF::setAbsoluteBCID (
              const std::uint64_t & absolutebcid )
Definition at line 28 of file DIF.cc.
00028 { m_AbsoluteBCID = absolutebcid; }
```

```
4.4.2.11 setDIFBCID() void DIF::setDIFBCID (
              const std::uint32_t & difbcid )
Definition at line 24 of file DIF.cc.
00024 { m_DIFBCID = difbcid; }
4.4.2.12 setDTC() void DIF::setDTC (
              const std::uint32_t & dtc )
Definition at line 16 of file DIF.cc.
00016 { m_DTC = dtc; }
4.4.2.13 setGTC() void DIF::setGTC (
              const std::uint32_t & gtc )
Definition at line 20 of file DIF.cc.
00020 { m_GTC = gtc; }
4.4.2.14 setID() void DIF::setID (
              const std::uint8_t & id )
Definition at line 12 of file DIF.cc.
00012 { m_ID = id; }
```

The documentation for this class was generated from the following files:

- libs/interface/ROOT/include/DIF.h
- libs/interface/ROOT/src/DIF.cc

4.5 DIFPtr Class Reference

#include <libs/core/include/DIFPtr.h>

Public Member Functions

- void setBuffer (unsigned char *, const std::uint32_t &)
- bit8_t * getPtr () const
- std::uint32 t getGetFramePtrReturn () const
- std::vector < bit8_t * > & getFramesVector ()
- std::vector< bit8_t * > & getLinesVector ()
- std::uint32_t getID () const
- std::uint32_t getDTC () const
- std::uint32 t getGTC () const
- std::uint64_t getAbsoluteBCID () const
- std::uint32 t getBCID () const
- std::uint32_t getLines () const
- bool hasLine (const std::uint32_t &) const
- std::uint32_t getTASU1 () const
- std::uint32_t getTASU2 () const
- std::uint32_t getTDIF () const
- float getTemperatureDIF () const
- float getTemperatureASU1 () const
- float getTemperatureASU2 () const
- bool hasTemperature () const
- bool hasAnalogReadout () const
- std::uint32_t getNumberOfFrames () const
- bit8_t * getFramePtr (const std::uint32_t &) const
- std::uint32_t getFrameAsicHeader (const std::uint32_t &) const
- std::uint32 t getFrameBCID (const std::uint32 t &) const
- std::uint32_t getFrameTimeToTrigger (const std::uint32_t &) const
- bool getFrameLevel (const std::uint32_t &, const std::uint32_t &, const std::uint32_t &) const
- std::uint32_t getDIFid () const
- std::uint32_t getASICid (const std::uint32_t &) const
- std::uint32_t getThresholdStatus (const std::uint32_t &, const std::uint32_t &) const

4.5.1 Detailed Description

Definition at line 18 of file DIFPtr.h.

4.5.2 Member Function Documentation

4.5.2.1 getAbsoluteBCID() std::uint64_t DIFPtr::getAbsoluteBCID () const [inline]

```
Definition at line 95 of file DIFPtr.h.
```

```
4.5.2.2 getASICid() uint32_t DIFPtr::getASICid (
                const std::uint32_t & i ) const [inline]
Definition at line 141 of file DIFPtr.h.
00141 { return getFrameAsicHeader(i) & 0xFF; }
4.5.2.3 getBCID() std::uint32_t DIFPtr::getBCID ( ) const [inline]
Definition at line 102 of file DIFPtr.h.
00102 { return (theDIF_[DU::BCID_SHIFT] « 16) + (theDIF_[DU::BCID_SHIFT + 1] « 8) + theDIF_[DU::BCID_SHIFT + 2]; }
4.5.2.4 getDIFid() uint32_t DIFPtr::getDIFid ( ) const [inline]
Definition at line 139 of file DIFPtr.h.
00139 { return getID() & 0xFF; }
4.5.2.5 getDTC() std::uint32_t DIFPtr::getDTC ( ) const [inline]
Definition at line 91 of file DIFPtr.h.
00091 { return (theDIF_[DU::DTC_SHIFT] « 24) + (theDIF_[DU::DTC_SHIFT + 1] « 16) + (theDIF_[DU::DTC_SHIFT + 2] « 8) + theDIF_[DU::DTC_SHIFT + 3]; }
\textbf{4.5.2.6} \quad \textbf{getFrameAsicHeader()} \quad \texttt{std::uint32\_t DIFPtr::getFrameAsicHeader ()}
                const std::uint32_t & i ) const [inline]
Definition at line 128 of file DIFPtr.h.
00128 { return getFrameAsicHeaderInternal(theFrames_[i]); }
4.5.2.7 getFrameBCID() std::uint32_t DIFPtr::getFrameBCID (
                const std::uint32_t & i ) const [inline]
Definition at line 130 of file DIFPtr.h.
00130 { return GrayToBin((theFrames_[i][DU::FRAME_BCID_SHIFT] « 16) + (theFrames_[i][DU::FRAME_BCID_SHIFT + 1] « 8) + theFrames_[i][DU::FRAME_BCID_SHIFT + 2]); }
\textbf{4.5.2.8} \quad \textbf{getFrameLevel()} \quad \texttt{bool DIFPtr::getFrameLevel (}
                const std::uint32_t & i,
                const std::uint32_t & ipad,
                const std::uint32_t & ilevel ) const [inline]
Definition at line 134 of file DIFPtr.h.
       return ((theFrames_[i][DU::FRAME_DATA_SHIFT + ((3 - ipad / 16) * 4 + (ipad % 16) / 4)] » (7 -
(((ipad % 16) % 4) * 2 + ilevel))) & 0x1);
00137 }
```

```
4.5.2.9 getFramePtr() bit8_t * DIFPtr::getFramePtr (
              const std::uint32_t & i ) const [inline]
Definition at line 126 of file DIFPtr.h.
00126 { return theFrames_[i]; }
4.5.2.10 getFramesVector() std::vector < bit8_t * > & DIFPtr::getFramesVector ( ) [inline]
Definition at line 85 of file DIFPtr.h.
00085 { return theFrames_; }
4.5.2.11 getFrameTimeToTrigger() std::uint32_t DIFPtr::getFrameTimeToTrigger (
              const std::uint32_t & i ) const [inline]
Definition at line 132 of file DIFPtr.h.
00132 { return getBCID() - getFrameBCID(i); }
4.5.2.12 getGetFramePtrReturn() std::uint32_t DIFPtr::getGetFramePtrReturn ( ) const [inline]
Definition at line 83 of file DIFPtr.h.
00083 { return theGetFramePtrReturn_; }
4.5.2.13 getGTC() std::uint32_t DIFPtr::getGTC ( ) const [inline]
Definition at line 93 of file DIFPtr.h.
00093 { return (theDIF_[DU::GTC_SHIFT] « 24) + (theDIF_[DU::GTC_SHIFT + 1] « 16) + (theDIF_[DU::GTC_SHIFT + 2] « 8) + theDIF_[DU::GTC_SHIFT + 3]; }
4.5.2.14 getID() std::uint32_t DIFPtr::getID ( ) const [inline]
Definition at line 89 of file DIFPtr.h.
00089 { return theDIF_[DU::ID_SHIFT]; }
4.5.2.15 qetLines() std::uint32_t DIFPtr::qetLines ( ) const [inline]
Definition at line 104 of file DIFPtr.h.
00104 { return (theDIF_[DU::LINES_SHIFT] » 4) & 0x5; }
```

```
4.5.2.16 getLinesVector() std::vector< bit8_t * > & DIFPtr::getLinesVector ( ) [inline]
Definition at line 87 of file DIFPtr.h.
00087 { return theLines_; }
4.5.2.17 getNumberOfFrames() std::uint32_t DIFPtr::getNumberOfFrames ( ) const [inline]
Definition at line 124 of file DIFPtr.h.
00124 { return theFrames_.size(); }
\textbf{4.5.2.18} \quad \textbf{getPtr()} \quad \texttt{bit8\_t} \, * \, \texttt{DIFPtr::} \texttt{getPtr} \, \, ( \, \, ) \, \, \texttt{const} \quad \texttt{[inline]}
Definition at line 81 of file DIFPtr.h.
00081 { return theDIF_; }
4.5.2.19 getTASU1() std::uint32_t DIFPtr::getTASU1 ( ) const [inline]
Definition at line 108 of file DIFPtr.h.
O0108 { return (theDIF_[DU::TASU1_SHIFT] « 24) + (theDIF_[DU::TASU1_SHIFT + 1] « 16) + (theDIF_[DU::TASU1_SHIFT + 2] « 8) + theDIF_[DU::TASU1_SHIFT + 3]; }
4.5.2.20 getTASU2() std::uint32_t DIFPtr::getTASU2 ( ) const [inline]
Definition at line 110 of file DIFPtr.h.
00110 { return (theDIF_[DU::TASU2_SHIFT] « 24) + (theDIF_[DU::TASU2_SHIFT + 1] « 16) + (theDIF_[DU::TASU2_SHIFT + 2] « 8) + theDIF_[DU::TASU2_SHIFT + 3]; }
4.5.2.21 getTDIF() std::uint32_t DIFPtr::getTDIF ( ) const [inline]
Definition at line 112 of file DIFPtr.h.
00112 { return theDIF_[DU::TDIF_SHIFT]; }
4.5.2.22 getTemperatureASU1() float DIFPtr::getTemperatureASU1 ( ) const [inline]
Definition at line 116 of file DIFPtr.h.
00116 { return (getTASU1() » 3) * 0.0625; }
```

```
4.5.2.23 getTemperatureASU2() float DIFPtr::getTemperatureASU2 ( ) const [inline]
Definition at line 118 of file DIFPtr.h.
00118 { return (getTASU2() » 3) * 0.0625; }
4.5.2.24 getTemperatureDIF() float DIFPtr::getTemperatureDIF ( ) const [inline]
Definition at line 114 of file DIFPtr.h.
00114 { return 0.508 * getTDIF() - 9.659; }
\textbf{4.5.2.25} \quad \textbf{getThresholdStatus()} \quad \texttt{uint32\_t DIFPtr::} \texttt{getThresholdStatus ()}
               const std::uint32_t & i,
               const std::uint32_t & ipad ) const [inline]
Definition at line 143 of file DIFPtr.h.
00143 { return (((std::uint32_t)getFrameLevel(i, ipad, 1)) « 1) | ((std::uint32_t)getFrameLevel(i, ipad, 0)); }
4.5.2.26 hasAnalogReadout() bool DIFPtr::hasAnalogReadout ( ) const [inline]
Definition at line 122 of file DIFPtr.h.
00122 { return getLines() != 0; }
4.5.2.27 hasLine() bool DIFPtr::hasLine (
               const std::uint32_t & line ) const [inline]
Definition at line 106 of file DIFPtr.h.
00106 { return ((theDIF_[DU::LINES_SHIFT] » line) & 0x1); }
4.5.2.28 hasTemperature() bool DIFPtr::hasTemperature ( ) const [inline]
Definition at line 120 of file DIFPtr.h.
00120 { return (theDIF_[0] == DU::START_OF_DIF_TEMP); }
```

Definition at line 65 of file DIFPtr.h.

```
00067
        theFrames_.clear();
00068
        theLines_.clear();
theSize_ = max_size;
theDIF_ = p;
00069
00070
00071
00072
00073
          theGetFramePtrReturn_ = getFramePtr();
00074
00075
        catch(const std::string& e)
00076
00077
           spdlog::get("streamout")->error(" DIF {} T ? {} {} ", getID(), hasTemperature(), e);
00078
00079 }
```

The documentation for this class was generated from the following file:

• libs/core/include/DIFPtr.h

4.6 DIFSlowControl Class Reference

#include <libs/core/include/DIFSlowControl.h>

Public Member Functions

- DIFSlowControl (const std::uint8_t &version, const std::uint8_t &DIFid, unsigned char *buf)
 Constructor.
- std::uint8_t getDIFId ()

get DIF id

std::map< int, std::map< std::string, int > > getChipsMap ()

Get chips map

 $\bullet \ \ \mathsf{std} :: \mathsf{map} < \mathsf{std} :: \mathsf{string}, \ \mathsf{int} > \mathsf{getChipSlowControl} \ (\mathsf{const} \ \mathsf{int} \ \& \mathsf{asicid}) \\$

Get one chip map.

- int getChipSlowControl (const std::int8_t &asicid, const std::string ¶m)
 - Get one Chip value.
- std::map< int, std::map< std::string, int > :::const_iterator cbegin () const
- std::map< int, std::map< std::string, int > >::const_iterator_cend () const_

4.6.1 Detailed Description

Definition at line 13 of file DIFSlowControl.h.

4.6.2 Constructor & Destructor Documentation

```
4.6.2.1 DIFSlowControl() DIFSlowControl::DIFSlowControl ( const std::uint8_t & version, const std::uint8_t & DIFid, unsigned char * buf)
```

Constructor.

Parameters

version	Data format version
DIFid	DIF id
buf	Pointer to the Raw data buffer

Definition at line 7 of file DIFSlowControl.cc.

```
m_Version(version), m_DIFId(DIfId), m_AsicType(2)
00008 {
00009
         if(cbuf[0] != 0xb1) return;
00010
         int header_shift{6};
00011
         if (m_Version < 8) m_NbrAsic = cbuf[5];</pre>
00012
00013
           m_DIFId
                         = cbuf[1];
= cbuf[2];
00014
00015
           m NbrAsic
00016
           header_shift = 3;
00017
00018
         int size_hardroc1 = m_NbrAsic * 72 + header_shift + 1;
00019
         if(cbuf[size_hardroc1 - 1] != 0xal) size_hardroc1 = 0;
00020
         int size_hardroc2 = m_NbrAsic * 109 + header_shift + 1;
if(cbuf[size_hardroc2 - 1] != 0xal) size_hardroc2 = 0;
if(size_hardroc1 != 0)
00021
00022
00023
00024
         FillHR1(header_shift, cbuf);
00025
00026
           m_AsicType = 1;
00027
00028
         else if(size_hardroc2 != 0)
00029
           FillHR2(header_shift, cbuf);
00030
00031
           return;
00032 }
```

4.6.3 Member Function Documentation

```
4.6.3.1 cbegin() std::map< int, std::map< std::string, int > >::const_iterator DIFSlow← Control::cbegin ( ) const [inline]
```

Definition at line 47 of file DIFSlowControl.h.

```
00047 { return m_MapSC.cbegin(); }
```

4.6.3.2 cend() std::map< int, std::map< std::string, int > >::const_iterator DIFSlowControl ← ::cend () const [inline]

Definition at line 49 of file DIFSlowControl.h.

```
00049 { return m_MapSC.cend(); }
```

Get one chip map.

Parameters

```
asicid ASIC ID
```

Returns

a map of <string (parameter name),int (parameter value) >

Definition at line 38 of file DIFSlowControl.cc.

```
00038 { return m_MapSC[asicid]; }
```

4.6.3.4 getChipSlowControl() [2/2] int DIFSlowControl::getChipSlowControl (const std::int8_t & asicid, const std::string & param) [inline]

Get one Chip value.

Parameters

asicid	ASic ID
param	Parameter name

Definition at line 40 of file DIFSlowControl.cc.

```
00040 { return getChipSlowControl(asicid)[param]; }
```

4.6.3.5 getChipsMap() std::map< int, std::map< std::string, int >> DIFSlowControl::get \leftarrow ChipsMap () [inline]

Get chips map.

Returns

a map of < Asic Id, map of < string (parameter name),int (parameter value) >

Definition at line 36 of file DIFSlowControl.cc.

```
00036 { return m_MapSC; }
```

4.6.3.6 getDIFId() std::uint8_t DIFSlowControl::getDIFId () [inline]

get DIF id

Definition at line 34 of file DIFSlowControl.cc.

```
00034 { return m_DIFId; }
```

The documentation for this class was generated from the following files:

- libs/core/include/DIFSlowControl.h
- libs/core/src/DIFSlowControl.cc

4.7 Event Class Reference

#include <libs/interface/ROOT/include/Event.h>

Inheritance diagram for Event:



Public Member Functions

- void clear ()
- void addDIF (const DIF &dif)
- std::map< std::uint8_t, DIF >::const_iterator cbegin () const
- std::map< std::uint8_t, DIF >::const_iterator cend () const

4.7.1 Detailed Description

Definition at line 15 of file Event.h.

4.7.2 Member Function Documentation

```
4.7.2.2 cbegin() std::map< std::uint8_t, DIF >::const_iterator Event::cbegin ( ) const
```

```
Definition at line 12 of file Event.cc. 00012 { return DIFs.cbegin(); }
```

```
4.7.2.3 cend() std::map< std::uint8_t, DIF >::const_iterator Event::cend ( ) const
```

```
Definition at line 14 of file Event.cc. 00014 { return DIFs.cend(); }
```

4.7.2.4 clear() void Event::clear ()

Definition at line 8 of file Event.cc. 00008 { DIFs.clear(); }

The documentation for this class was generated from the following files:

- libs/interface/ROOT/include/Event.h
- libs/interface/ROOT/src/Event.cc

4.8 Hit Class Reference

#include <libs/interface/ROOT/include/Hit.h>

Inheritance diagram for Hit:



Public Member Functions

- void clear ()
- void setDIF (const std::uint8_t &)
- void setASIC (const std::uint8_t &)
- void setChannel (const std::uint8_t &)
- void setThreshold (const std::uint8_t &)
- void setDTC (const std::uint32_t &)
- void setGTC (const std::uint32_t &)
- void setDIFBCID (const std::uint32_t &)
- void setFrameBCID (const std::uint32_t &)
- void setTimestamp (const std::uint32_t &)
- void setAbsoluteBCID (const std::uint64_t &)
- std::uint8_t getDIFid () const
- std::uint8_t getASICid () const
- std::uint8_t getChannel () const
- std::uint8_t getThreshold () const
- std::uint32_t getDTC () const
- std::uint32_t getGTC () const
- std::uint32_t getDIFBCID () const
- std::uint32_t getFrameBCID () const
- std::uint32_t getTimestamp () const
- std::uint64_t getAbsoluteBCID () const

4.8.1 Detailed Description

Definition at line 10 of file Hit.h.

4.8 Hit Class Reference 27

4.8.2 Member Function Documentation

```
4.8.2.1 clear() void Hit::clear ()
Definition at line 7 of file Hit.cc.
00008 {
00009
       m_DIF
00010
       m_ASIC
00011
       m_Channel
00012
       m_Threshold
                     = 0;
00013
       m_DTC
                      = 0;
                      = 0;
00014
       m_GTC
00015
       m_DIFBCID
                      = 0;
00016
       m_FrameBCID
                     = 0;
       m_Timestamp
00018 m_AbsoluteBCID = 0;
00019 }
4.8.2.2 getAbsoluteBCID() std::uint64_t Hit::getAbsoluteBCID ( ) const
Definition at line 59 of file Hit.cc.
00059 { return m_AbsoluteBCID; }
4.8.2.3 getASICid() std::uint8_t Hit::getASICid ( ) const
Definition at line 43 of file Hit.cc.
00043 { return m_ASIC; }
4.8.2.4 getChannel() std::uint8_t Hit::getChannel ( ) const
Definition at line 45 of file Hit.cc.
00045 { return m_Channel; }
4.8.2.5 getDIFBCID() std::uint32_t Hit::getDIFBCID ( ) const
Definition at line 53 of file Hit.cc.
00053 { return m_DIFBCID; }
4.8.2.6 getDIFid() std::uint8_t Hit::getDIFid ( ) const
Definition at line 41 of file Hit.cc.
```

00041 { return m_DIF; }

```
4.8.2.7 getDTC() std::uint32_t Hit::getDTC ( ) const
Definition at line 49 of file Hit.cc.
00049 { return m_DTC; }
\textbf{4.8.2.8} \quad \textbf{getFrameBCID()} \quad \texttt{std::uint32\_t Hit::getFrameBCID ()} \quad \texttt{const}
Definition at line 55 of file Hit.cc.
00055 { return m_FrameBCID; }
\textbf{4.8.2.9} \quad \textbf{getGTC()} \quad \texttt{std::uint32\_t Hit::getGTC ()} \quad \texttt{const}
Definition at line 51 of file Hit.cc.
00051 { return m_GTC; }
4.8.2.10 getThreshold() std::uint8_t Hit::getThreshold ( ) const
Definition at line 47 of file Hit.cc.
00047 { return m_Threshold; }
4.8.2.11 getTimestamp() std::uint32_t Hit::getTimestamp ( ) const
Definition at line 57 of file Hit.cc.
00057 { return m_Timestamp; }
4.8.2.12 setAbsoluteBCID() void Hit::setAbsoluteBCID (
                const std::uint64_t & absolutebcid )
Definition at line 39 of file Hit.cc.
00039 { m_AbsoluteBCID = absolutebcid; }
4.8.2.13 setASIC() void Hit::setASIC (
                const std::uint8_t & asic )
Definition at line 23 of file Hit.cc.
00023 { m_ASIC = asic; }
```

4.8 Hit Class Reference 29

```
4.8.2.14 setChannel() void Hit::setChannel (
              const std::uint8_t & channel )
Definition at line 25 of file Hit.cc.
00025 { m_Channel = channel; }
4.8.2.15 setDIF() void Hit::setDIF (
              const std::uint8_t & dif )
Definition at line 21 of file Hit.cc.
00021 { m_DIF = dif; }
4.8.2.16 setDIFBCID() void Hit::setDIFBCID (
              const std::uint32_t & difbcid )
Definition at line 33 of file Hit.cc.
00033 { m_DIFBCID = difbcid; }
4.8.2.17 setDTC() void Hit::setDTC (
              const std::uint32_t & dtc )
Definition at line 29 of file Hit.cc.
00029 { m_DTC = dtc; }
4.8.2.18 setFrameBCID() void Hit::setFrameBCID (
              const std::uint32_t & framebcid )
Definition at line 35 of file Hit.cc.
00035 { m_FrameBCID = framebcid; }
4.8.2.19 setGTC() void Hit::setGTC (
              const std::uint32_t & gtc )
Definition at line 31 of file Hit.cc.
00031 { m_GTC = gtc; }
4.8.2.20 setThreshold() void Hit::setThreshold (
              const std::uint8_t & threshold )
Definition at line 27 of file Hit.cc.
00027 { m_Threshold = threshold; }
```


The documentation for this class was generated from the following files:

- libs/interface/ROOT/include/Hit.h
- libs/interface/ROOT/src/Hit.cc

4.9 Interface Class Reference

#include <libs/core/include/Interface.h>

Inheritance diagram for Interface:



Public Member Functions

- Interface (const std::string &name, const std::string &version, const InterfaceType &type)
- virtual ∼Interface ()=default
- virtual void startEvent ()
- virtual void endEvent ()
- virtual void startDIF ()
- virtual void endDIF ()
- virtual void startFrame ()
- virtual void endFrame ()
- virtual void startPad ()
- virtual void endPad ()
- std::shared ptr< spdlog::logger > & log ()
- void setLogger (const std::shared_ptr< spdlog::logger > &logger)
- std::string getName ()
- Version getVersion ()

4.9.1 Detailed Description

Definition at line 39 of file Interface.h.

4.9.2 Constructor & Destructor Documentation

```
4.9.2.1 Interface() Interface::Interface (
              const std::string & name,
              const std::string & version,
              const InterfaceType & type ) [inline]
Definition at line 42 of file Interface.h.
00042 : m_Name(name), m_Version(version) {}
4.9.2.2 \simInterface() virtual Interface::\simInterface ( ) [virtual], [default]
4.9.3 Member Function Documentation
4.9.3.1 endDIF() virtual void Interface::endDIF ( ) [inline], [virtual]
Reimplemented in ROOTWriter.
Definition at line 47 of file Interface.h.
00047 {}
4.9.3.2 endEvent() virtual void Interface::endEvent ( ) [inline], [virtual]
Reimplemented in ROOTWriter.
Definition at line 45 of file Interface.h.
00045 {}
4.9.3.3 endFrame() virtual void Interface::endFrame ( ) [inline], [virtual]
Reimplemented in ROOTWriter.
Definition at line 49 of file Interface.h.
00049 {}
4.9.3.4 endPad() virtual void Interface::endPad ( ) [inline], [virtual]
Reimplemented in ROOTWriter.
Definition at line 51 of file Interface.h.
00051 {}
```

```
4.9.3.5 getName() std::string Interface::getName ( ) [inline]
Definition at line 54 of file Interface.h.
00054 { return m_Name; }
4.9.3.6 getVersion() Version Interface::getVersion ( ) [inline]
Definition at line 55 of file Interface.h.
00055 { return m_Version; }
4.9.3.7 log() std::shared_ptr< spdlog::logger > & Interface::log ( ) [inline]
Definition at line 52 of file Interface.h.
00052 { return m_Logger; }
\textbf{4.9.3.8} \quad \textbf{setLogger()} \quad \texttt{void Interface::setLogger (}
              const std::shared_ptr< spdlog::logger > & logger ) [inline]
Definition at line 53 of file Interface.h.
00053 { m_Logger = logger; }
4.9.3.9 startDIF() virtual void Interface::startDIF ( ) [inline], [virtual]
Reimplemented in ROOTWriter.
Definition at line 46 of file Interface.h.
00046 {}
4.9.3.10 startEvent() virtual void Interface::startEvent () [inline], [virtual]
Reimplemented in ROOTWriter.
Definition at line 44 of file Interface.h.
00044 {}
4.9.3.11 startFrame() virtual void Interface::startFrame ( ) [inline], [virtual]
Reimplemented in ROOTWriter.
Definition at line 48 of file Interface.h.
00048 {}
```

```
4.9.3.12 startPad() virtual void Interface::startPad ( ) [inline], [virtual]
```

Reimplemented in ROOTWriter.

Definition at line 50 of file Interface.h.


The documentation for this class was generated from the following file:

• libs/core/include/Interface.h

4.10 InterfaceReader Class Reference

```
#include <libs/core/include/Interface.h>
```

Inheritance diagram for InterfaceReader:



Public Member Functions

- InterfaceReader (const std::string &name, const std::string &version)
- virtual ∼InterfaceReader ()=default

Protected Attributes

• Buffer m_Buffer

4.10.1 Detailed Description

Definition at line 64 of file Interface.h.

4.10.2 Constructor & Destructor Documentation

4.10.2.2 ~InterfaceReader() virtual InterfaceReader::~InterfaceReader () [virtual], [default]

4.10.3 Member Data Documentation

4.10.3.1 m_Buffer Buffer InterfaceReader::m_Buffer [protected]

Definition at line 71 of file Interface.h.


The documentation for this class was generated from the following file:

• libs/core/include/Interface.h

4.11 InterfaceWriter Class Reference

#include <libs/core/include/Interface.h>

Inheritance diagram for InterfaceWriter:



Public Member Functions

- InterfaceWriter (const std::string &name, const std::string &version)
- void addCompatibility (const std::string &name, const std::string &version)
- std::map< std::string, std::string > getCompatibility ()
- bool checkCompatibility (const std::string &name, const std::string &version)
- virtual \sim InterfaceWriter ()=default

4.11.1 Detailed Description

Definition at line 74 of file Interface.h.

4.11.2 Constructor & Destructor Documentation

```
4.11.2.1 InterfaceWriter() InterfaceWriter::InterfaceWriter (
              const std::string & name,
              const std::string & version ) [inline]
Definition at line 77 of file Interface.h.
00077 : Interface(name, version, InterfaceType::Writer) {}
4.11.2.2 ~InterfaceWriter() virtual InterfaceWriter::~InterfaceWriter ( ) [virtual], [default]
4.11.3 Member Function Documentation
4.11.3.1 addCompatibility() void InterfaceWriter::addCompatibility (
              const std::string & name,
              const std::string & version ) [inline]
Definition at line 79 of file Interface.h.
00079 { m_Compatible[name] = version; }
4.11.3.2 checkCompatibility() bool InterfaceWriter::checkCompatibility (
              const std::string & name,
              const std::string & version ) [inline]
Definition at line 83 of file Interface.h.
00084
         if(m_Compatible.find(name) != m_Compatible.end())
00085
00086
00087
                          ran = semver::range::detail::range(m_Compatible[name]);
00088
           semver::version ver = semver::version(version);
00089
           if(ran.satisfies(ver, false)) return true;
00090
00091
            return false;
00092
00093
        else
00094
           return false;
00095
```

```
4.11.3.3 getCompatibility() std::map< std::string > InterfaceWriter::getCompatibility ( ) [inline]
```

Definition at line 81 of file Interface.h.

00081 { return m_Compatible; }

The documentation for this class was generated from the following file:

libs/core/include/Interface.h

4.12 RawBufferNavigator Class Reference

#include <libs/core/include/RawBufferNavigator.h>

Public Member Functions

- RawBufferNavigator (const std::shared_ptr< spdlog::logger > &)
- ∼RawBufferNavigator ()=default
- RawBufferNavigator (const Buffer &b)
- void setBuffer (const Buffer &b)
- std::uint8_t getDetectorID ()
- bool validBuffer ()
- bit8 t * getDIFBufferStart ()
- std::uint32_t getDIFBufferSize ()
- Buffer getDIFBuffer ()
- DIFPtr & getDIFPtr ()
- std::uint32_t getEndOfDIFData ()
- std::uint32 t getSizeAfterDIFPtr ()
- std::uint32_t getDIF_CRC ()
- bool hasSlowControlData ()
- Buffer getSCBuffer ()
- bool badSCData ()
- Buffer getEndOfAllData ()
- std::int32_t getStartOfPayload ()

Static Public Member Functions

· static void StartAt (const int &start)

4.12.1 Detailed Description

Definition at line 14 of file RawBufferNavigator.h.

4.12.2 Constructor & Destructor Documentation

4.12.2.2 ~ RawBufferNavigator() RawBufferNavigator::~RawBufferNavigator () [default]

```
4.12.2.3 RawBufferNavigator() [2/2] RawBufferNavigator::RawBufferNavigator (
                const Buffer & b ) [explicit]
Definition at line 40 of file RawBufferNavigator.cc.
00040 : m_Buffer(b) { setBuffer(b); }
4.12.3 Member Function Documentation
4.12.3.1 badSCData() bool RawBufferNavigator::badSCData ( )
Definition at line 79 of file RawBufferNavigator.cc.
00080 {
00081
         setSCBuffer();
00082
        return m_BadSCdata;
00083 }
4.12.3.2 getDetectorID() std::uint8_t RawBufferNavigator::getDetectorID ( )
Definition at line 42 of file RawBufferNavigator.cc.
00042 { return m_Buffer[0]; }
4.12.3.3 getDIF_CRC() std::uint32_t RawBufferNavigator::getDIF_CRC ( )
Definition at line 62 of file RawBufferNavigator.cc.
00063 {
00064
        uint32_t i{getEndOfDIFData()};
        uint32_t ret{0};
ret |= ((m_Buffer.begin()[i - 2]) « 8);
ret |= m_Buffer.begin()[i - 1];
00065
00066
00068
        return ret;
00069 }
\textbf{4.12.3.4} \quad \textbf{getDIFBuffer()} \quad \texttt{Buffer} \quad \texttt{RawBufferNavigator::getDIFBuffer ()}
Definition at line 50 of file RawBufferNavigator.cc.
00050 { return Buffer(getDIFBufferStart(), getDIFBufferSize()); }
\textbf{4.12.3.5} \quad \textbf{getDIFBufferSize()} \quad \texttt{std::uint32\_t} \quad \texttt{RawBufferNavigator::getDIFBufferSize} \quad \textbf{()}
Definition at line 48 of file RawBufferNavigator.cc.
00048 { return m_Buffer.size() - m_StartPayload; }
```

```
4.12.3.6 getDIFBufferStart() bit8_t * RawBufferNavigator::getDIFBufferStart ( )
Definition at line 46 of file RawBufferNavigator.cc.
00046 { return & (m_Buffer.begin()[m_StartPayload]); }
\textbf{4.12.3.7} \quad \textbf{getDIFPtr()} \quad \textbf{DIFPtr \& RawBufferNavigator::getDIFPtr ()}
Definition at line 52 of file RawBufferNavigator.cc.
00053 {
       m_TheDIFPtr.setBuffer(getDIFBufferStart(), getDIFBufferSize());
00054
00055
       return m_TheDIFPtr;
00056 }
4.12.3.8 getEndOfAllData() Buffer RawBufferNavigator::getEndOfAllData ()
Definition at line 118 of file RawBufferNavigator.cc.
00120
        setSCBuffer();
        if(hasSlowControlData() && !m_BadSCdata) { return Buffer(&(m_SCbuffer.begin()[m_SCbuffer.size()]),
00121
      getSizeAfterDIFPtr() - 3 - m_SCbuffer.size()); }
          return Buffer(&(getDIFBufferStart()[getEndOfDIFData()]), getSizeAfterDIFPtr() - 3); // remove the
      2 bytes for CRC and the DIF trailer
00124 }
4.12.3.9 getEndOfDIFData() std::uint32_t RawBufferNavigator::getEndOfDIFData ( )
Definition at line 58 of file RawBufferNavigator.cc.
00058 { return getDIFPtr().getGetFramePtrReturn() + 3; }
4.12.3.10 getSCBuffer() Buffer RawBufferNavigator::getSCBuffer ( )
Definition at line 73 of file RawBufferNavigator.cc.
00074 {
        setSCBuffer();
00076
       return m_SCbuffer;
00077 }
4.12.3.11 getSizeAfterDIFPtr() std::uint32_t RawBufferNavigator::getSizeAfterDIFPtr ( )
Definition at line 60 of file RawBufferNavigator.cc.
00060 { return getDIFBufferSize() - getDIFPtr().getGetFramePtrReturn(); }
```

4.12.3.12 getStartOfPayload() std::int32_t RawBufferNavigator::getStartOfPayload ()

Definition at line 12 of file RawBufferNavigator.cc.

```
00014
        for(std::size_t i = m_Start; i < m_Buffer.size(); i++)</pre>
00015
00016
          if(m_Buffer[i] == DU::START_OF_DIF || m_Buffer[i] == DU::START_OF_DIF_TEMP)
00018
            m_StartPayload = i;
00019
            return m_StartPayload;
00020
         }
00021
00022 m_{startPayload} = -1;
00023
       return m_StartPayload;
00024 }
```

4.12.3.13 hasSlowControlData() bool RawBufferNavigator::hasSlowControlData ()

Definition at line 71 of file RawBufferNavigator.cc.

```
00071 { return getDIFBufferStart()[getEndOfDIFData()] == 0xb1; }
```

```
4.12.3.14 setBuffer() void RawBufferNavigator::setBuffer ( const Buffer & b )
```

Definition at line 33 of file RawBufferNavigator.cc.

```
00034 {
00035    m_BadSCdata = false;
00036    m_Buffer = b;
00037    // m_DIFstartIndex = getStartOfPayload();
00038 }
```

```
4.12.3.15 StartAt() void RawBufferNavigator::StartAt ( const int & start ) [static]
```

Definition at line 28 of file RawBufferNavigator.cc.

```
00029 {
00030    if(start >= 0) m_Start = start;
00031 }
```

4.12.3.16 validBuffer() bool RawBufferNavigator::validBuffer ()

```
Definition at line 44 of file RawBufferNavigator.cc. 00044 { return m_StartPayload != -1; }
```


The documentation for this class was generated from the following files:

- libs/core/include/RawBufferNavigator.h
- libs/core/src/RawBufferNavigator.cc

4.13 RawdataReader Class Reference

#include <libs/interface/RawDataReader/include/RawdataReader.h>

Inheritance diagram for RawdataReader:



Public Member Functions

- RawdataReader (const char *fileName)
- void start ()
- void end ()
- float getFileSize ()
- void openFile (const std::string &fileName)
- void closeFile ()
- bool nextEvent ()
- bool nextDIFbuffer ()
- const Buffer & getBuffer ()
- virtual ∼RawdataReader ()

Static Public Member Functions

• static void setDefaultBufferSize (const std::size_t &size)

Additional Inherited Members

4.13.1 Detailed Description

Definition at line 17 of file RawdataReader.h.

4.13.2 Constructor & Destructor Documentation

```
4.13.2.2 ~RawdataReader() virtual RawdataReader::~RawdataReader ( ) [inline], [virtual]
```

Definition at line 29 of file RawdataReader.h. 00029 { closeFile(); }

4.13.3 Member Function Documentation

4.13.3.1 closeFile() void RawdataReader::closeFile ()

Definition at line 42 of file RawdataReader.cc.

4.13.3.2 end() void RawdataReader::end ()

Definition at line 24 of file RawdataReader.cc.

```
00024 { closeFile(); }
```

4.13.3.3 getBuffer() const Buffer & RawdataReader::getBuffer ()

Definition at line 117 of file RawdataReader.cc.

```
00118 {
00119 uncompress();
00120 return m_Buffer;
00121 }
```

4.13.3.4 getFileSize() float RawdataReader::getFileSize ()

Definition at line 125 of file RawdataReader.cc.

```
00125 { return m_FileSize; }
```

4.13.3.5 nextDIFbuffer() bool RawdataReader::nextDIFbuffer ()

Definition at line 90 of file RawdataReader.cc.

```
00091 {
00092
00093
00094
           static int DIF_processed{0};
00095
           if(DIF_processed >= m_NumberOfDIF)
00096
00097
             DIF_processed = 0;
00098
             return false:
00099
00100
           else
00101
           {
00102
             DIF_processed++;
00103
             std::uint32_t bsize{0};
             m_FileStream.read(reinterpret_cast<char*>(&bsize), sizeof(std::uint32_t));
m_FileStream.read(reinterpret_cast<char*>(&m_buf[0]), bsize);
00104
00105
00106
             m_Buffer = Buffer(m_buf);
00107
00108
00109
         catch(const std::ios_base::failure& e)
00110
           log()->error("Caught an ios_base::failure in openFile : {}", e.what());
00111
00112
           return false;
00113
00114
         return true;
00115 }
```

4.13.3.6 nextEvent() bool RawdataReader::nextEvent ()

Definition at line 76 of file RawdataReader.cc.

4.13.3.7 openFile() void RawdataReader::openFile (const std::string & fileName)

Definition at line 55 of file RawdataReader.cc.

```
00056 {
00057
00058
00059
           m_FileStream.rdbuf()->pubsetbuf(0, 0);
00060
           m_FileStream.exceptions(std::ifstream::failbit | std::ifstream::badbit);
00061
            \texttt{m\_FileStream.open(fileName.c\_str(), std::ios::in | std::ios::binary | std::ios::ate);} \quad // \  \, \texttt{Start at} 
      the end to directly calculate the size of the file then come back to beginning m_FileStream.rdbuf()->pubsetbuf(0, 0);
00062
00063
           if (m_FileStream.is_open())
00064
00065
             setFileSize(m_FileStream.tellg());
00066
             m_FileStream.seekg(0, std::ios::beg);
00067
00068
00069
        catch(const std::ios_base::failure& e)
00070
00071
           log()->error("Caught an ios_base::failure in openFile : {}", e.what());
00072
00073
00074 }
```

The documentation for this class was generated from the following files:


- libs/interface/RawDataReader/include/RawdataReader.h
- libs/interface/RawDataReader/src/RawdataReader.cc

4.14 ROOTWriter Class Reference

#include <libs/interface/ROOT/include/ROOTWriter.h>

Inheritance diagram for ROOTWriter:

00022 { openFile(m_Filename); }



Public Member Functions

- ROOTWriter ()
- void setFilename (const std::string &)
- void start ()
- void processDIF (const DIFPtr &)
- void processFrame (const DIFPtr &, const std::uint32_t &frameIndex)
- void processPadInFrame (const DIFPtr &, const std::uint32_t &frameIndex, const std::uint32_t &channel← Index)
- void processSlowControl (const Buffer &)
- void end ()
- virtual void startEvent ()
- virtual void endEvent ()
- virtual void startDIF ()
- virtual void endDIF ()
- virtual void startFrame ()
- virtual void endFrame ()
- virtual void startPad ()
- virtual void endPad ()

4.14.1 Detailed Description

Definition at line 18 of file ROOTWriter.h.

4.14.2 Constructor & Destructor Documentation

```
4.14.2.1 ROOTWriter() ROOTWriter::ROOTWriter ( )

Definition at line 10 of file ROOTWriter.cc.
00010 : InterfaceWriter("ROOTWriter", "1.0.0") { addCompatibility("RawdataReader", ">=1.0.0"); }
```

4.14.3 Member Function Documentation

```
4.14.3.1 end() void ROOTWriter::end ()
```

Definition at line 19 of file ROOTWriter.cc.

4.14.3.2 endDIF() void ROOTWriter::endDIF () [virtual]

Reimplemented from Interface.

Definition at line 75 of file ROOTWriter.cc.

4.14.3.3 endEvent() void ROOTWriter::endEvent () [virtual]

Reimplemented from Interface.

```
Definition at line 63 of file ROOTWriter.cc.
```

```
4.14.3.4 endFrame() void ROOTWriter::endFrame ( ) [virtual]
```

Reimplemented from Interface.

```
Definition at line 87 of file ROOTWriter.cc.
```

4.14.3.5 endPad() void ROOTWriter::endPad () [virtual]

Reimplemented from Interface.

Definition at line 95 of file ROOTWriter.cc.

00095 {}

```
4.14.3.6 processDIF() void ROOTWriter::processDIF ( const DIFPtr & d )
```

Definition at line 30 of file ROOTWriter.cc.

```
00031 {
00032    m_DIF->setID(d.getDIFid());
00033    m_DIF->setDTC(d.getDTC());
00034    m_DIF->setDTC(d.getGTC());
00035    m_DIF->setDIFBCID(d.getBCID());
00036    m_DIF->setAbsoluteBCID(d.getAbsoluteBCID());
00037 }
```

4.14.3.7 processFrame() void ROOTWriter::processFrame (

```
const DIFPtr & d,
const std::uint32_t & frameIndex )
```

Definition at line 39 of file ROOTWriter.cc.

```
00040 {
        m_Hit->setDIF(d.getDIFid());
00041
00042
        m_Hit->setASIC(d.getASICid(frameIndex));
00043
       m_Hit->setDTC(d.getDTC());
00044
        m_Hit->setGTC(d.getGTC());
00045
        m_Hit->setDIFBCID(d.getBCID());
00046
        m_Hit->setAbsoluteBCID(d.getAbsoluteBCID());
00047
        m_Hit->setFrameBCID(d.getFrameBCID(frameIndex));
00048
       m_Hit->setTimestamp(d.getFrameTimeToTrigger(frameIndex));
00049 }
```

4.14.3.8 processPadInFrame() void ROOTWriter::processPadInFrame (

```
const DIFPtr & d,
const std::uint32_t & frameIndex,
const std::uint32_t & channelIndex )
```

Definition at line 51 of file ROOTWriter.cc.

```
00052 {
00053    m_Hit->setChannel(channelIndex);
00054    m_Hit->setThreshold(static_cast<std::uint8_t>(d.getThresholdStatus(frameIndex, channelIndex)));
00055 }
```

00085 }

```
4.14.3.9 processSlowControl() void ROOTWriter::processSlowControl (
                const Buffer & ) [inline]
Definition at line 29 of file ROOTWriter.h.
4.14.3.10 setFilename() void ROOTWriter::setFilename (
                const std::string & filename )
Definition at line 8 of file ROOTWriter.cc.
00008 { m_Filename = filename; }
4.14.3.11 start() void ROOTWriter::start ( )
Definition at line 12 of file ROOTWriter.cc.
00013 {
      m_File = TFile::Open(m_Filename.c_str(), "RECREATE", m_Filename.c_str(),
ROOT::CompressionSettings(ROOT::kZLIB, 5));
m_Tree = new TTree("RawData", "Raw SDHCAL data tree");
00014
00015
00016 m_Tree->Branch("Events", &m_Event, 512000, 99);
00017 }
4.14.3.12 startDIF() void ROOTWriter::startDIF ( ) [virtual]
Reimplemented from Interface.
Definition at line 69 of file ROOTWriter.cc.
00071
        m_DIF = new DIF();
00072 // m_DIF->clear();
00073 }
4.14.3.13 startEvent() void ROOTWriter::startEvent ( ) [virtual]
Reimplemented from Interface.
Definition at line 57 of file ROOTWriter.cc.
00058 {
00059  m_Event = new Event();
00060
        // m_Event->clear();
00061 }
\textbf{4.14.3.14} \quad \textbf{startFrame()} \quad \texttt{void ROOTWriter::startFrame ()} \quad \texttt{[virtual]}
Reimplemented from Interface.
Definition at line 81 of file ROOTWriter.cc.
00082 {
00083 m_Hit = new Hit();
00084 // m_Hit->clear();
```

4.14.3.15 startPad() void ROOTWriter::startPad () [virtual]

Reimplemented from Interface.

Definition at line 93 of file ROOTWriter.cc.


The documentation for this class was generated from the following files:

- libs/interface/ROOT/include/ROOTWriter.h
- libs/interface/ROOT/src/ROOTWriter.cc

4.15 textDump Class Reference

#include <libs/interface/Dump/include/textDump.h>

Inheritance diagram for textDump:



Public Member Functions

- textDump ()
- void start ()
- void processDIF (const DIFPtr &)
- void processFrame (const DIFPtr &, uint32_t frameIndex)
- void processPadInFrame (const DIFPtr &, uint32_t frameIndex, uint32_t channelIndex)
- void processSlowControl (Buffer)
- void end ()
- std::shared_ptr< spdlog::logger > & print ()
- void setLevel (const spdlog::level::level_enum &level)

4.15.1 Detailed Description

Definition at line 14 of file textDump.h.

4.15.2 Constructor & Destructor Documentation

```
4.15.2.1 textDump() textDump::textDump ()
```

```
Definition at line 9 of file textDump.cc.
```

4.15.3 Member Function Documentation

```
4.15.3.1 end() void textDump::end ( )
```

```
Definition at line 33 of file textDump.cc.
```

```
00033 { print()->info("textDump end of report"); }
```

```
4.15.3.2 print() std::shared_ptr< spdlog::logger > & textDump::print ( ) [inline]
```

Definition at line 24 of file textDump.h.

```
00024 { return m_InternalLogger; }
```

```
4.15.3.3 processDIF() void textDump::processDIF ( const DIFPtr & d )
```

```
Definition at line 19 of file textDump.cc.
```

4.15.3.4 processFrame() void textDump::processFrame (

```
const DIFPtr & d,
uint32_t frameIndex )
```

Definition at line 21 of file textDump.cc.

```
4.15.3.5 processPadInFrame() void textDump::processPadInFrame (
            const DIFPtr & d,
            uint32_t frameIndex,
            uint32_t channelIndex )
Definition at line 26 of file textDump.cc.
      {}", channelIndex, d.getThresholdStatus(frameIndex, channelIndex)); }
00029 }
4.15.3.6 processSlowControl() void textDump::processSlowControl (
            Buffer )
Definition at line 31 of file textDump.cc.
00031 { print()->error("textDump::processSlowControl not implemented yet."); }
4.15.3.7 setLevel() void textDump::setLevel (
            const spdlog::level::level_enum & level ) [inline]
Definition at line 25 of file textDump.h.
00025 { m_InternalLogger->set_level(level); }
4.15.3.8 start() void textDump::start ()
Definition at line 17 of file textDump.cc.
00017 { print()->info("Will dump bunch of DIF data"); }
```

The documentation for this class was generated from the following files:

- libs/interface/Dump/include/textDump.h
- libs/interface/Dump/src/textDump.cc

4.16 Timer Class Reference

#include <libs/core/include/Timer.h>

Public Member Functions

- void start ()
- void stop ()
- float getElapsedTime ()

4.16.1 Detailed Description

Definition at line 9 of file Timer.h.

4.16.2 Member Function Documentation

```
4.16.2.1 getElapsedTime() float Timer::getElapsedTime ( ) [inline]

Definition at line 14 of file Timer.h.
00014 { return std::chrono::duration_cast<std::chrono::microseconds>(m_StopTime - m_StartTime).count(); }

4.16.2.2 start() void Timer::start ( ) [inline]

Definition at line 12 of file Timer.h.
00012 { m_StartTime = std::chrono::high_resolution_clock::now(); }

4.16.2.3 stop() void Timer::stop ( ) [inline]

Definition at line 13 of file Timer.h.
00013 { m_StopTime = std::chrono::high_resolution_clock::now(); }
```


libs/core/include/Timer.h

4.17 Version Class Reference

#include <libs/core/include/Version.h>

The documentation for this class was generated from the following file:

Inheritance diagram for Version:



Public Member Functions

- Version (const std::uint8_t &mj, const std::uint8_t &mn, const std::uint8_t &pt, const semver::prerelease &prt=semver::prerelease::none, const std::uint8_t &prn=0) noexcept
- Version (const std::string_view &str)
- Version ()=default
- std::uint8_t getMajor ()
- std::uint8_t getMinor ()
- std::uint8_t getPatch ()
- std::string getPreRelease ()
- std::uint8_t getPreReleaseNumber ()

4.17.1 Detailed Description

Definition at line 11 of file Version.h.

4.17.2 Constructor & Destructor Documentation

```
4.17.2.1 Version() [1/3] Version::Version (
              const std::uint8_t & mj,
              const std::uint8_t & mn,
              const std::uint8_t & pt,
              const semver::prerelease & prt = semver::prerelease::none,
              const std::uint8_t & prn = 0 ) [inline], [noexcept]
Definition at line 14 of file Version.h.
00014 : semver::version(mj, mn, pt, prt, prn) {}
4.17.2.2 Version() [2/3] Version::Version (
              const std::string_view & str ) [inline], [explicit]
Definition at line 15 of file Version.h.
00015 : semver::version(str) {}
4.17.2.3 Version() [3/3] Version::Version ( ) [default]
4.17.3 Member Function Documentation
\textbf{4.17.3.1} \quad \textbf{getMajor()} \quad \texttt{std::uint8\_t Version::getMajor ( )}
Definition at line 9 of file Version.cc.
00009 { return major; }
4.17.3.2 getMinor() std::uint8_t Version::getMinor ( )
Definition at line 11 of file Version.cc.
00011 { return minor; }
```

```
4.17.3.3 getPatch() std::uint8_t Version::getPatch ( )
```

```
Definition at line 13 of file Version.cc. 00013 { return patch; }
```

4.17.3.4 getPreRelease() std::string Version::getPreRelease ()

Definition at line 15 of file Version.cc.

4.17.3.5 getPreReleaseNumber() std::uint8_t Version::getPreReleaseNumber ()

```
Definition at line 27 of file Version.cc.
00027 { return prerelease_number; }
```

The documentation for this class was generated from the following files:

- libs/core/include/Version.h
- libs/core/src/Version.cc

5 File Documentation

5.1 libs/core/include/Bits.h File Reference

```
#include <cstdint>
#include <iosfwd>
```

Typedefs

```
using bit8_t = std::uint8_tusing bit16_t = std::uint16_t
```

- using bit32 t = std::uint32 t
- using bit64_t = std::uint64_t

Functions

std::ostream & operator << (std::ostream &os, const bit8_t &c)
 Stream operator to print bit8_t aka std::uint8_t and not char or unsigned char.

5.1.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Bits.h.

5.1.2 Typedef Documentation

```
\textbf{5.1.2.1} \quad \textbf{bit16\_t} \quad \texttt{using bit16\_t} = \texttt{std::uint16\_t}
```

Definition at line 11 of file Bits.h.

```
5.1.2.2 bit32_t using bit32_t = std::uint32_t
```

Definition at line 12 of file Bits.h.

```
5.1.2.3 bit64_t using bit64_t = std::uint64_t
```

Definition at line 13 of file Bits.h.

```
5.1.2.4 bit8_t using bit8_t = std::uint8_t
```

Definition at line 10 of file Bits.h.

5.1.3 Function Documentation

```
5.1.3.1 operator << () std::ostream & operator << ( std::ostream & os, const bit8_t & c )
```

Stream operator to print bit8_t aka std::uint8_t and not char or unsigned char.

```
Definition at line 8 of file Bits.cc. 00008 { return os « c + 0; }
```

5.2 Bits.h

Go to the documentation of this file.

```
00005 #pragma once
00006
00007 #include <cstdint>
00008 #include <iosfwd>
00009
00010 using bit8_t = std::uint8_t; /*<! type to represent 8bits words (1 byte) */
00011 using bit16_t = std::uint16_t; /*<! type to represent 16bits words (2 bytes) */
00012 using bit32_t = std::uint32_t; /*<! type to represent 32bits words (4 bytes) */
00013 using bit64_t = std::uint64_t; /*<! type to represent 64bits words (8 bytes) */
00014
00016 std::ostream& operator*(std::ostream& os, const bit8_t& c);
```

5.3 libs/core/include/Buffer.h File Reference

```
#include "Bits.h"
#include <array>
#include <string>
#include <vector>
```

Classes

class Buffer

5.3.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde A.Pingault L.Mirabito

See also

https://github.com/apingault/Trivent4HEP

Definition in file Buffer.h.

5.4 Buffer.h

Go to the documentation of this file.

```
00001
00006 #pragma once
00007
00008 #include "Bits.h"
00009
00010 #include <array>
00011 #include <string>
00012 #include <vector>
00013
00014 class Buffer
00015 {
00016 public:
00017 Buffer() : m_Buffer(nullptr), m_Size(0), m_Capacity(0) {}
00018 virtual ~Buffer() {}
00019 Buffer(const bit8_t b[], const std::size_t& i) : m_Buffer(const_cast<bit8_t*>(&b[0])), m_Size(i), m_Capacity(i) {}
```

```
Buffer(const char b[], const std::size_t& i) : m_Buffer(const_cast<bit8_t*>(reinterpret_cast<const</pre>
      bit8_t*>(&b[0]))), m_Size(i * sizeof(char)), m_Capacity(i * sizeof(char)) {}
       template<typename T> Buffer(const std::vector<T>& rawdata) :
      m_Buffer(const_cast<bit8_t*>(reinterpret_cast<const bit8_t*>(rawdata.data()))), m_Size(rawdata.size())
      * sizeof(T)), m_Capacity(rawdata.capacity() * sizeof(T)) {}
template<typename T, std::size_t N> Buffer(const std::array<T, N>& rawdata) :
m_Buffer(const_cast<bit8_t*>(reinterpret_cast<const bit8_t*>(rawdata.data()))), m_Size(rawdata.size())
00022
       * sizeof(T)), m_Capacity(rawdata.size() * sizeof(T)) {}
00023
00024
        std::size_t size()const { return m_Size; }
00025
        std::size_t capacity()const { return m_Capacity; }
00026
                 set (unsigned char* b) { m_Buffer = b; }
        void
00028
        bit8_t* begin()const { return m_Buffer; }
00029
        bit8_t* end()const { return m_Buffer + m_Size; }
00030
        bit8_t& operator[](const std::size_t& pos) { return m_Buffer[pos]; }
00031
        bit8_t& operator[](const std::size_t& pos)const { return m_Buffer[pos]; }
00032
        void setSize(const std::size_t& size) { m_Size = size; }
00034
00035 private:
       bit8_t*
00036
                     m_Buffer{nullptr};
        std::size_t m_Size{0};
00037
00038
        std::size_t m_Capacity{0};
00039 };
```

5.5 libs/core/include/BufferLooper.h File Reference

```
#include "AppVersion.h"
#include "Buffer.h"
#include "BufferLooperCounter.h"
#include "DetectorId.h"
#include "Formatters.h"
#include "RawBufferNavigator.h"
#include "Timer.h"
#include "Words.h"
#include <algorithm>
#include <cassert>
#include <fmt/color.h>
#include <map>
#include <memory>
#include <spdlog/sinks/null_sink.h>
#include <spdlog/spdlog.h>
#include <string>
#include <vector>
```

Classes

class BufferLooper< SOURCE, DESTINATION >

5.5.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file BufferLooper.h.

5.6 BufferLooper.h

Go to the documentation of this file.

```
00005 #pragma once
00006
00007 #include "AppVersion.h"
00008 #include "Buffer.h"
00009 #include "BufferLooperCounter.h"
00010 #include "DetectorId.h"
00011 #include "Formatters.h"
00012 #include "RawBufferNavigator.h" 00013 #include "Timer.h"
00014 #include "Words.h"
00015
00016 #include <algorithm>
00017 #include <cassert
00018 #include <fmt/color.h>
00019 #include <map>
00020 #include <memory>
00021 #include <spdlog/sinks/null sink.h>
00022 #include <spdlog/spdlog.h>
00023 #include <string>
00024 #include <vector>
00025 // function to loop on buffers
00026
00027 template<typename SOURCE, typename DESTINATION> class BufferLooper
00028 1
00029 public:
     BufferLooper(SOURCE& source, DESTINATION& dest, bool debug = false) : m_Source(source),
    m_Destination(dest), m_Debug(debug)
00031
00032
       m_Logger = spdlog::create<spdlog::sinks::null_sink_mt>("streamout");
00033
       if(!spdlog::get("streamout")) { spdlog::register_logger(m_Logger); }
00034
       m Source.setLogger(m Logger);
00035
       m_Destination.setLogger(m_Logger);
00036
00037
00038
     void addSink(const spdlog::sink_ptr& sink, const spdlog::level_:level_enum& level =
    spdlog::get_level())
00039
00040
       sink->set level(level);
00041
       m_Sinks.push_back(sink);
00042
       m_Logger = std::make_shared<spdlog::logger>("streamout", begin(m_Sinks), end(m_Sinks));
00043
       m_Source.setLogger(m_Logger);
00044
       m_Destination.setLogger(m_Logger);
00045
00046
00047
      void loop(const std::uint32_t& m_NbrEventsToProcess = 0)
     {
    // clang-format off
00048
00049
       fmt::print(fg(fmt::color::medium_orchid) | fmt::emphasis::bold,
00050
             "\n"
00051
00052 " SSSSSSSSSSSSSS
ttt:::t\n"
00054 "S:::::SSSSSS::::::S t::::t
    t::::t\n"
00055 "S:::::S
              SSSSSSS t::::t
    t::::t\n"
            00056 "S::::S
           mmmmmmm
    mmmmmmm
    00057 "S:::::S
00058 " S::::SSSS t:::::::::t r::::::::r e:::::eeeee:::::eeaaaaaaaaa:::::a
    u::::ut::::::::::t\n"
00059 " SS::::::SSSSStttttt::::::tttttt rr:::::rrrrr:::::re:::::e
r:::::re::::::eeeeee:::::e aaaaaaa:::::a
u::::u t:::::t\n"
       SSS:::::::SS t::::t
                                r:::::r
    " SSS::::::SS t::::t r::::r
m:::::mmm:::::mmm:::::mo::::0 0:::0u:::u
                                         u::::u
    00061 "
e:::::eeeeeeeeee a::::aaaa:::::a m::::m
                                                             a::::a
                                                                     a:::::a m:::::m
m::::m m::::mo::::o o::::ou:::::uuuu::::::
00064 "SSSSSSS S:::::S t:::::tttt:::::tr:::::r
                                                             a::::a a:::::a m::::m
                                               e::::::e
                                            t:::::tttt::::t\n"
          m::::m
e::::::eeeeeeeea:::::aaaa::::::a m::::m
                                             tt::::::t\n"
    m::::m m::::m oo
          tttttttttt rrrrrr
                                                   eeeeeeeeeee aaaaaaaaa aaammmmmm
                                              ttttttttttt {}\n"
    mmmmmm ooooooooo
                              uuuuuuuu uuuu
00068 "\n",
```

5.6 BufferLooper.h 57

```
00069 fmt::format(fg(fmt::color::red) | fmt::emphasis::bold, "v{}", streamout_version.to_string()));
                // clang-format on
                00071
                log() ->info("Streamout Version : {}", streamout_version.to_string());
log() ->info("Using InterfaceReader {} version {}", m_Source.getName(),
00072
00073
         m Source.getVersion().to string());
                log() -> info("Using InterfaceWriter {} version {}", m_Destination.getName(),
         m_Destination.getVersion().to_string());
00075
00076
                if(!m_Destination.checkCompatibility(m_Source.getName(), m_Source.getVersion().to_string()))
00077
                   \log() ->critical("{} version {} is not compatible with {} version {} ! ", m_Source.getName(),
00078
         m_Source.getVersion().to_string(), m_Destination.getName(), m_Destination.getVersion().to_string());
    log()->info("Compatible Interfaces for {} are", m_Destination.getName());
00079
00080
                   for(std::map<std::string, std::string>::iterator it = m_Destination.getCompatibility().begin();
          it != m\_Destination.getCompatibility().end(); ++it) { log()->info("{} version {}", it->first, log()->info("{} version {}", it->first, log()->info("{} version {} v
         it->second): }
00081
                  std::exit(-1);
00082
00083
                if(!m_DetectorIDs.empty())
00084
00085
                   std::string ids;
00086
                   for(std::vector<DetectorID>::const_iterator it = m_DetectorIDs.cbegin(); it !=
          \texttt{m\_DetectorIDs.cend(); ++it)} \quad \texttt{ids += std::to\_string(static\_cast<std::uint16\_t>(*it)) + ";"; \texttt{m\_DetectorIDs.cend(); ++it)} \\
00087
                   log()->info("Detector ID(s) other than {} will be ignored", ids);
00088
00089
00090
                RawBufferNavigator bufferNavigator(m_Logger);
00091
                Timer
                                               timer;
00092
                timer.start();
00093
                m Source.start();
00094
                m_Destination.start();
00095
                while (m_Source.nextEvent() && m_NbrEventsToProcess >= m_NbrEvents)
00096
00098
                   m_Source.startEvent();
00099
                   m Destination.startEvent();
00101
00102
                   m_Logger->warn("===*** Event {} ***===", m_NbrEvents);
00103
                   while (m_Source.nextDIFbuffer())
00104
00105
                      const Buffer& buffer = m_Source.getBuffer();
                      bufferNavigator.setBuffer(buffer);
00106
                      if(std::find(m DetectorIDs.begin(), m DetectorIDs.end(),
00107
         static_cast<DetectorID>(bufferNavigator.getDetectorID())) == m_DetectorIDs.end())
00108
                     {
00109
                         m_Logger->debug("Ignoring detector ID : {}", bufferNavigator.getDetectorID());
00110
00111
                      }
00112
00113
                      bit8_t* debug_variable_1 = buffer.end();
                      bit8_t* debug_variable_2 = bufferNavigator.getDIFBuffer().end();
00114
                       if(debug_variable_1 != debug_variable_2) m_Logger->info("DIF BUFFER END {} {}",
00115
         fmt::ptr(debug_variable_1), fmt::ptr(debug_variable_2));
00116
                      if(m_Debug) assert(debug_variable_1 == debug_variable_2);
00117
00118
                      std::int32 t idstart = bufferNavigator.getStartOfPayload();
                      if(m_Debug && idstart == -1) m_Logger->info(to_hex(buffer));
00119
                      c.DIFStarter[idstart]++;
00120
00121
                       if(!bufferNavigator.validBuffer())
00122
                      {
00123
                         m Logger->error("!bufferNavigator.validBuffer()");
00124
                         continue;
00125
00126
00128
                      m_Source.startDIF();
00129
                      m_Destination.startDIF();
00131
                      DIFPtr& d = bufferNavigator.getDIFPtr();
00132
00133
                      c.DIFPtrValueAtReturnedPos[bufferNavigator.getDIFBufferStart()[d.getGetFramePtrReturn()]]++;
                       if(m_Debug) assert(bufferNavigator.getDIFBufferStart()[d.getGetFramePtrReturn()] == 0xa0);
00134
00135
                       c.SizeAfterDIFPtr[bufferNavigator.getSizeAfterDIFPtr()]++;
00136
                      m_Destination.processDIF(d);
00137
                       for(std::size_t i = 0; i < d.getNumberOfFrames(); ++i)</pre>
00138
00140
                          m Source.startFrame();
00141
                          m_Destination.startFrame();
00143
                          m_Destination.processFrame(d, i);
00144
                          for(std::size_t j = 0; j < DU::NUMBER_PAD; ++j)</pre>
00145
00146
                             if(d.getThresholdStatus(i, j) != 0)
00147
                                m_Source.startPad();
00148
00149
                                m_Destination.startPad();
00150
                                m_Destination.processPadInFrame(d, i, j);
00151
                                m_Source.endPad();
00152
                                m_Destination.endPad();
00153
```

```
00156
                 m_Source.endFrame();
00157
                 m_Destination.endFrame();
00159
00160
               bool processSC = false;
00161
               if (bufferNavigator.hasSlowControlData())
00162
00163
00164
                 c.hasSlowControl++;
00165
                processSC = true;
00166
00167
               if(bufferNavigator.badSCData())
00168
              {
00169
                c.hasBadSlowControl++;
00170
                processSC = false;
00171
               if(processSC) { m_Destination.processSlowControl(bufferNavigator.getSCBuffer()); }
00172
00173
               Buffer eod = bufferNavigator.getEndOfAllData();
00175
               c.SizeAfterAllData[eod.size()]++;
00176
               bit8_t* debug_variable_3 = eod.end();
00177
               if(debug_variable_1 != debug_variable_3) m_Logger->info("END DATA BUFFER END {} {}",
      fmt::ptr(debug_variable_1), fmt::ptr(debug_variable_3));
00178
              if(m_Debug) assert(debug_variable_1 == debug_variable_3);
if(eod.size() != 0) m_Logger->info("End of Data remaining stuff : {}", to_hex(eod));
00179
00180
00181
               int nonzeroCount = 0;
              for(bit8_t* it = eod.begin(); it != eod.end(); it++)
  if(static_cast<int>(*it) != 0) nonzeroCount++;
00182
00183
00184
              c.NonZeroValusAtEndOfData[nonzeroCount]++;
00186
              m_Source.endDIF();
00187
              m_Destination.endDIF();
00189
            } // end of DIF while loop
00190
            m_Logger->warn("===*** Event {} ***===", m_NbrEvents);
00191
            m_NbrEvents++;
00193
            m_Source.endEvent();
          m_Destination.endEvent();
} // end of event while loop
00194
00196
00197
          m_Destination.end();
00198
          m_Source.end();
00199
          timer.stop();
          fmt::print("=== elapsed time {}ms ({}ms/event) ===\n", timer.getElapsedTime() / 1000,
00200
      timer.getElapsedTime() / (1000 * m_NbrEvents));
00201
00202
                                           printAllCounters() { c.printAllCounters(); }
00203
        std::shared_ptr<spdlog::logger> log() { return m_Logger; }
00204
00205
        void setDetectorIDs(const std::vector<DetectorID>& detectorIDs) { m_DetectorIDs = detectorIDs; }
00206
00207 private:
00208
        std::vector<DetectorID>
                                          m_DetectorIDs;
00209
        std::shared_ptr<spdlog::logger> m_Logger{nullptr};
00210
        std::vector<spdlog::sink_ptr>    m_Sinks;
00211
        BufferLooperCounter
00212
        SOURCE&
                                          m_Source{nullptr};
00213
        DESTINATION&
                                          m_Destination{nullptr};
00214
        bool
                                          m_Debug{false};
00215
        std::uint32_t
                                          m_NbrEvents{1};
00216 };
```

5.7 libs/core/include/BufferLooperCounter.h File Reference

```
#include <map>
#include <memory>
#include <string>
```

Classes

• struct BufferLooperCounter

5.7.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file BufferLooperCounter.h.

5.8 BufferLooperCounter.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include <map>
00008 #include <memory>
00009 #include <string>
00010
00011 struct BufferLooperCounter
00012 {
00013 public:
00015 pdb110
00014 int
00015 int
                                    hasSlowControl
                                    hasBadSlowControl = 0;
00016
          std::map<int, int> DIFStarter;
00017 std::map<int, int> DIFPtrValueAtReturnedPos;

00018 std::map<int, int> SizeAfterDIFPtr;

00019 std::map<int, int> SizeAfterAllData;

00020 std::map<int, int> NonZeroValusAtEndOfData;
00021
00022
         void printCounter(const std::string& description, const std::map<int, int>& m);
00023
         void printAllCounters();
00024 };
```

5.9 libs/core/include/DetectorId.h File Reference

```
#include <cstdint>
```

Enumerations

• enum class DetectorID: std::uint16_t { HARDROC = 100, HARDROC_NEW = 150, RUNHEADER = 255 }

5.9.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file DetectorId.h.

5.9.2 Enumeration Type Documentation

5.9.2.1 DetectorID enum class DetectorID : std::uint16_t [strong]

Enumerator

HARDROC	
HARDROC_NEW	
RUNHEADER	

Definition at line 9 of file DetectorId.h.

5.10 Detectorld.h

Go to the documentation of this file.

```
00001

00005 #pragma once

00006

00007 #include <cstdint>

00008

00009 enum class DetectorID : std::uint16_t

00010 {

00011 HARDROC = 100,

00012 HARDROC_NEW = 150,

00013 RUNHEADER = 255

00014 };
```

5.11 libs/core/include/DIFPtr.h File Reference

```
#include "Bits.h"
#include "Formatters.h"
#include "Utilities.h"
#include "Words.h"
#include <cstdint>
#include <iostream>
#include <spdlog/spdlog.h>
#include <string>
#include <vector>
```

Classes

• class DIFPtr

5.11.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file DIFPtr.h.

5.12 DIFPtr.h 61

5.12 DIFPtr.h

Go to the documentation of this file.

```
00005 #pragma once
00006
00007 #include "Bits.h"
00008 #include "Formatters.h"
00009 #include "Utilities.h"
00010 #include "Words.h'
00011
00012 #include <cstdint>
00013 #include <iostream>
00014 #include <spdlog/spdlog.h>
00015 #include <string>
00016 #include <vector>
00018 class DIFPtr
00019 {
00020 public:
00021
       void
                              setBuffer(unsigned char*, const std::uint32 t&);
00022
        bit8_t*
                              getPtr() const;
00023
        std::uint32_t
                              getGetFramePtrReturn() const;
        std::vector<bit8_t*>& getFramesVector();
00024
00025
        std::vector<bit8_t*>& getLinesVector();
00026
        std::uint32_t
                              getID() const;
00027
        std::uint32 t
                              getDTC() const;
getGTC() const;
00028
        std::uint32 t
00029
        std::uint64_t
                              getAbsoluteBCID() const;
00030
        std::uint32_t
                               getBCID() const;
00031
        std::uint32_t
                               getLines() const;
00032
        bool
                               hasLine(const std::uint32_t&) const;
        std::uint32 t
00033
                               getTASU1() const;
00034
                               getTASU2() const;
        std::uint32 t
00035
        std::uint32 t
                               getTDIF() const;
00036
        float
                               getTemperatureDIF() const;
00037
        float
                               getTemperatureASU1() const;
00038
        float
                               getTemperatureASU2() const;
00039
        hoo1
                               hasTemperature() const;
00040
                               hasAnalogReadout() const;
        bool
00041
        std::uint32_t
                               getNumberOfFrames() const;
00042
        bit8_t*
                               getFramePtr(const std::uint32_t&) const;
00043
        std::uint32 t
                               getFrameAsicHeader(const std::uint32_t&) const;
00044
        std::uint32_t
                               getFrameBCID(const std::uint32_t&) const;
00045
        std::uint32_t
                               getFrameTimeToTrigger(const std::uint32_t&) const;
00046
                               getFrameLevel(const std::uint32_t&, const std::uint32_t&, const
       bool
     std::uint32_t&) const;
00047
       // Addition by GG
00048
        std::uint32_t
                               getDIFid() const;
00049
        std::uint32_t
                               getASICid(const std::uint32_t&) const;
00050
       std::uint32 t
                              getThresholdStatus(const std::uint32_t&, const std::uint32_t&) const;
00051
00052 private:
       std::uint32_t
                             getAnalogPtr(const std::uint32_t& idx = 0);
00053
                              getFrameAsicHeaderInternal(const unsigned char* framePtr) const;
00054
        std::uint32_t
00055
        std::uint32_t
                              getFramePtr();
00056
        std::uint32_t
                              theSize_{0};
00057
        std::uint32_t
                             theGetFramePtrReturn_{0};
00058
        bit8 t*
                             theDIF_{nullptr};
00059
        std::vector<bit8_t*> theFrames_;
00060
        std::vector<bit8_t*> theLines_;
00061 };
00062
00063 inline std::uint32_t DIFPtr::getFrameAsicHeaderInternal(const bit8_t* framePtr)const { return
      (framePtr[DU::FRAME ASIC HEADER SHIFT]); }
00064
00065 inline void DIFPtr::setBuffer(bit8_t* p, const std::uint32_t& max_size)
00066 {
00067
        theFrames_.clear();
00068
        theLines_.clear();
        theSize_ = max_size;
theDIF_ = p;
00069
00070
00071
00072
00073
         theGetFramePtrReturn_ = getFramePtr();
00074
00075
        catch (const std::string& e)
00076
00077
          spdlog::get("streamout")->error(" DIF {} T ? {} {} ", getID(), hasTemperature(), e);
00078
00079 }
08000
00081 inline bit8 t* DIFPtr::getPtr()const { return theDIF ; }
00082
00083 inline std::uint32_t DIFPtr::getGetFramePtrReturn()const { return theGetFramePtrReturn_; }
00084
```

```
00085 inline std::vector<bit8_t*>& DIFPtr::getFramesVector() { return theFrames_; }
00086
00087 inline std::vector<bit8_t*>& DIFPtr::getLinesVector() { return theLines_; }
00088
00089 inline std::uint32_t DIFPtr::getID()const { return theDIF [DU::ID SHIFT1: }
00090
00091 inline std::uint32_t DIFPtr::getDTC()const { return (theDIF_[DU::DTC_SHIFT] « 24) +
      (theDIF_[DU::DTC_SHIFT + 1] « 16) + (theDIF_[DU::DTC_SHIFT + 2] « 8) + theDIF_[DU::DTC_SHIFT + 3]; }
00092
00093 inline std::uint32_t DIFPtr::getGTC()const { return (theDIF_[DU::GTC_SHIFT] « 24) + (theDIF_[DU::GTC_SHIFT + 1] « 16) + (theDIF_[DU::GTC_SHIFT + 2] « 8) + theDIF_[DU::GTC_SHIFT + 3]; }
00094
00095 inline std::uint64_t DIFPtr::getAbsoluteBCID()const
00096 {
00097
        std::uint64_t LBC = ((theDIF_[DU::ABCID_SHIFT] « 16) | (theDIF_[DU::ABCID_SHIFT + 1] « 8) |
      (theDIF_[DU::ABCID_SHIFT + 2])) * 16777216ULL /* to shift the value from the 24 first bits*/
+ ((theDIF_[DU::ABCID_SHIFT + 3] « 16) | (theDIF_[DU::ABCID_SHIFT + 4] « 8) |
00098
      (theDIF [DU::ABCID SHIFT + 5]));
00099
        return LBC;
00100 }
00101
00102 inline std::uint32_t DIFPtr::getBCID()const { return (theDIF_[DU::BCID_SHIFT] « 16) +
      (theDIF_[DU::BCID_SHIFT + 1] « 8) + theDIF_[DU::BCID_SHIFT + 2]; }
00103
00104 inline std::uint32_t DIFPtr::getLines()const { return (theDIF_[DU::LINES_SHIFT] » 4) & 0x5; }
00106 inline bool DIFPtr::hasLine(const std::uint32_t& line)const { return ((theDIF_[DU::LINES_SHIFT] »
      line) & 0x1); }
00107
00108 inline std::uint32_t DIFPtr::getTASU1()const { return (theDIF_[DU::TASU1_SHIFT] « 24) +
      (theDIF_[DU::TASU1_SHIFT + 1] « 16) + (theDIF_[DU::TASU1_SHIFT + 2] « 8) + theDIF_[DU::TASU1_SHIFT +
      31; }
00109
00110 inline std::uint32_t DIFPtr::getTASU2()const { return (theDIF_[DU::TASU2_SHIFT] « 24) +
       (theDIF_[DU::TASU2_SHIFT + 1] « 16) + (theDIF_[DU::TASU2_SHIFT + 2] « 8) + theDIF_[DU::TASU2_SHIFT +
00111
00112 inline std::uint32_t DIFPtr::getTDIF()const { return theDIF_[DU::TDIF_SHIFT]; }
00113
00114 inline float DIFPtr::getTemperatureDIF()const { return 0.508 * getTDIF() - 9.659; }
00115
00116 inline float DIFPtr::getTemperatureASU1()const { return (getTASU1() » 3) * 0.0625; }
00117
00118 inline float DIFPtr::getTemperatureASU2()const { return (getTASU2() » 3) * 0.0625; }
00120 inline bool DIFPtr::hasTemperature()const { return (theDIF_[0] == DU::START_OF_DIF_TEMP); }
00121
00122 inline bool DIFPtr::hasAnalogReadout()const { return getLines() != 0; }
00123
00124 inline std::uint32 t DIFPtr::getNumberOfFrames()const { return theFrames .size(); }
00125
00126 inline bit8_t* DIFPtr::getFramePtr(const std::uint32_t& i)const { return theFrames_[i]; }
00127
00128 inline std::uint32 t DIFPtr::getFrameAsicHeader(const std::uint32 t& i)const { return
      getFrameAsicHeaderInternal(theFrames_[i]); }
00129
00130 inline std::uint32_t DIFPtr::getFrameBCID(const std::uint32_t& i)const { return
      GrayToBin((theFrames_[i][DU::FRAME_BCID_SHIFT] « 16) + (theFrames_[i][DU::FRAME_BCID_SHIFT + 1] « 8) +
      theFrames_[i][DU::FRAME_BCID_SHIFT + 2]); }
00131
00132 inline std::uint32 t DIFPtr::getFrameTimeToTrigger(const std::uint32 t& i)const { return getBCID() -
      getFrameBCID(i); }
00133
00134 inline bool DIFPtr::getFrameLevel(const std::uint32_t& i, const std::uint32_t& ipad, const
      std::uint32_t& ilevel)const
00135 {
00136
        return ((theFrames_[i][DU::FRAME_DATA_SHIFT + ((3 - ipad / 16) * 4 + (ipad % 16) / 4)] » (7 -
      (((ipad % 16) % 4) * 2 + ilevel))) & 0x1);
00137 }
00138 // Addition by GG
00139 inline uint32_t DIFPtr::getDIFid()const { return getID() & 0xFF; }
00140
00141 inline uint32_t DIFPtr::getASICid(const std::uint32_t& i)const { return getFrameAsicHeader(i) & 0xFF;
00142
00143 inline uint32_t DIFPtr::getThresholdStatus(const std::uint32_t& i, const std::uint32_t& ipad)const {
      return (((std::uint32_t)getFrameLevel(i, ipad, 1)) « 1) | ((std::uint32_t)getFrameLevel(i, ipad, 0));
00144
00145 inline std::uint32 t DTFPtr::getFramePtr()
00146 {
00147
        std::uint32_t fshift{0};
00148
        if (DATA FORMAT VERSION >= 13)
00149
          fshift = DU::LINES_SHIFT + 1;
if(hasTemperature()) fshift = DU::TDIF_SHIFT + 1;
00150
00151
                                                                    // jenlev 1
00152
          if(hasAnalogReadout()) fshift = getAnalogPtr(fshift); // to be implemented
```

```
00153
00154
00155
           fshift = DU::BCID_SHIFT + 3;
         if (theDIF_[fshift] != DU::START_OF_FRAME)
00156
00157
         std::cout « "This is not a start of frame " « to_hex(theDIF_[fshift]) « " \n";
00158
00159
           return fshift;
00160
00161
00162
           if(theDIF_[fshift] == DU::END_OF_DIF) return fshift;
           if(theDIF_[fshift] == DU::START_OF_FRAME) fshift++;
if(theDIF_[fshift] == DU::END_OF_FRAME)
00163
00164
00165
00166
00167
              continue;
00168
           std::uint32_t header = getFrameAsicHeaderInternal(&theDIF_[fshift]);
if(header == DU::END_OF_FRAME) return (fshift + 2);
if(header < 1 || header > 48) { throw header + " Header problem " + fshift; }
00169
00170
           theFrames_.push_back(&theDIF_[fshift]);
fshift += DU::FRAME_SIZE;
00172
00173
00174
           if(fshift > theSize_)
00175
00176
             std::cout « "fshift " « fshift « " exceed " « theSize_ « "\n";
00177
             return fshift;
00178
00179
            if(theDIF_[fshift] == DU::END_OF_FRAME) fshift++;
00180 } while(true);
00181 }
00182
00183 inline std::uint32_t DIFPtr::getAnalogPtr(const std::uint32_t& idx)
00184 {
00185
        std::uint32_t fshift{idx};
00186
         if(theDIF_[fshift] != DU::START_OF_LINES) return fshift;
00187
         fshift++;
         while(theDIF_[fshift] != DU::END_OF_LINES)
00188
00189
         theLines_.push_back(&theDIF_[fshift]);
00190
          std::uint32_t nchip{theDIF_[fshift]};
fshift += 1 + nchip * 64 * 2;
00191
00192
00193
00194
        return fshift++;
00195 }
```

5.13 libs/core/include/DIFSlowControl.h File Reference

```
#include <bitset>
#include <cstdint>
#include <iosfwd>
#include <map>
#include <string>
```

Classes

class DIFSlowControl

Functions

• std::string to_string (const DIFSlowControl &c)

5.13.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file DIFSlowControl.h.

5.13.2 Function Documentation

5.14 DIFSlowControl.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include <bitset>
00008 #include <cstdint>
00009 #include <iosfwd>
00010 #include <map>
00011 #include <string>
00012
00013 class DIFSlowControl
00014 (
00015 public:
00017
00022
        DIFSlowControl(const std::uint8_t& version, const std::uint8_t& DIFid, unsigned char* buf);
00023
00025
       std::uint8_t getDIFId();
00026
00028
00031
        std::map<int, std::map<std::string, int> getChipsMap();
00032
00034
00038
        std::map<std::string, int> getChipSlowControl(const int& asicid);
00039
00041
00045
        int getChipSlowControl(const std::int8 t& asicid, const std::string& param);
00046
00047
        std::map<int, std::map<std::string, int»::const_iterator cbegin()const { return m_MapSC.cbegin(); }
00048
00049
        std::map<int, std::map<std::string, int»::const_iterator cend()const { return m_MapSC.cend(); }
00050
00051 private:
00053
        DIFSlowControl() = delete;
00055
        void FillHR1(const int& header_shift, unsigned char* cbuf);
       void FillHR2(const int& header_shift, unsigned char* cbuf);
void FillAsicHR1(const std::bitset<72 * 8>& bs);
00057
00059
00061
       void FillAsicHR2(const std::bitset<109 * 8>& bs);
00062
00063
                                                    m_DIFId{0};
       unsigned int
00064
        unsigned int
                                                    m_Version{0};
00065
        unsigned int
                                                    m_AsicType{0}; // asicType_
00066
        unsigned int
                                                    m_NbrAsic{0};
00067
        std::map<int, std::map<std::string, int> m_MapSC;
00068 };
00069
00070 std::string to_string(const DIFSlowControl& c);
```

5.15 libs/core/include/Filesystem.h File Reference

```
#include <string>
```

Functions

- std::string path (const std::string &)
- std::string extension (const std::string &)
- std::string filename (const std::string &)

5.15.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Filesystem.h.

5.15.2 Function Documentation

Definition at line 19 of file Filesystem.cc.

```
00021 std::size_t position = file.find_last_of(".");
00022 std::size_t pos = file.find_last_of("\\/");
00023 return (std::string::npos == pos) ? file.substr(0, position) : file.substr(pos + 1, position - pos - 1);
00024 }
```

Definition at line 7 of file Filesystem.cc.

```
00008 {
00009     std::size_t pos = file.find_last_of("\\/");
00010     return (std::string::npos == pos) ? "" : file.substr(0, pos);
00011 }
```

5.16 Filesystem.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include <string>
00008
00009 std::string path(const std::string&);
00010 std::string extension(const std::string&);
00011 std::string filename(const std::string&);
```

5.17 libs/core/include/Formatters.h File Reference

```
#include "Bits.h"
#include <iosfwd>
#include <string>
```

Functions

```
    std::string to dec (const Buffer &b, const std::size t &begin=0, const std::size t &end=-1)

std::string to_dec (const bit8_t &)

    std::string to_dec (const bit16_t &)

    std::string to_dec (const bit32_t &)

    std::string to dec (const bit64 t &)

• std::string to_hex (const Buffer &b, const std::size_t &begin=0, const std::size_t &end=-1)
std::string to_hex (const bit8_t &)

    std::string to_hex (const bit16_t &)

std::string to_hex (const bit32_t &)

    std::string to_hex (const bit64_t &)

• std::string to_bin (const Buffer &b, const std::size_t &begin=0, const std::size_t &end=-1)
• std::string to bin (const bit8 t &)

    std::string to_bin (const bit16_t &)

    std::string to_bin (const bit32_t &)

• std::string to_bin (const bit64_t &)

    std::string to_oct (const Buffer &b, const std::size_t &begin=0, const std::size_t &end=-1)

std::string to_oct (const bit8_t &)

    std::string to_oct (const bit16_t &)

    std::string to_oct (const bit32_t &)

    std::string to_oct (const bit64_t &)
```

5.17.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Formatters.h.

5.17.2 Function Documentation

```
5.17.2.1 to_bin() [1/5] std::string to_bin (
               const bit16_t & b )
Definition at line 71 of file Formatters.cc.
00071 { return fmt::format("{:#016b}", b); }
5.17.2.2 to bin() [2/5] std::string to_bin (
               const bit32_t & b )
Definition at line 73 of file Formatters.cc.
00073 { return fmt::format("{:#032b}", b); }
5.17.2.3 to_bin() [3/5] std::string to_bin (
               const bit64_t & b )
Definition at line 75 of file Formatters.cc.
00075 { return fmt::format("{:#064b}", b); }
5.17.2.4 to_bin() [4/5] std::string to_bin (
               const bit8_t & b )
Definition at line 69 of file Formatters.cc.
00069 { return fmt::format("{:#08b}", b); }
5.17.2.5 to_bin() [5/5] std::string to_bin (
               const Buffer & b,
               const std::size_t & begin = 0,
               const std::size_t & end = -1)
Definition at line 56 of file Formatters.cc.
00057 {
       std::size_t iend = end;
00059
        <u>if(iend == -1) iend = b.size();</u>
00060
       std::string ret;
00061
        for(std::size_t k = begin; k < iend; k++)</pre>
       ret += to_bin(b[k]);
ret += " - ";
}
00062
00063
00064
00065
00066
       return ret;
00067 }
5.17.2.6 to_dec() [1/5] std::string to_dec (
               const bit16_t & b )
Definition at line 29 of file Formatters.cc.
00029 { return fmt::format("{:#d}", b); }
```

```
5.17.2.7 to_dec() [2/5] std::string to_dec (
               const bit32_t & b )
Definition at line 31 of file Formatters.cc.
00031 { return fmt::format("{:#d}", b); }
5.17.2.8 to dec() [3/5] std::string to_dec (
               const bit64_t & b )
Definition at line 33 of file Formatters.cc.
00033 { return fmt::format("{:#d}", b); }
5.17.2.9 to_dec() [4/5] std::string to_dec (
               const bit8_t & b )
Definition at line 27 of file Formatters.cc.
00027 { return fmt::format("{:#d}", b); }
5.17.2.10 to_dec() [5/5] std::string to_dec (
               const Buffer & b,
               const std::size_t & begin = 0,
               const std::size_t & end = -1)
Definition at line 14 of file Formatters.cc.
00015 {
00016
        std::size_t iend = end;
00017
        if(iend == -1) iend = b.size();
       std::string ret;
for(std::size_t k = begin; k < iend; k++)
00018
00019
00020
        ret += to_dec(b[k]);
ret += " - ";
00021
00022
00023
00024
       return ret;
00025 }
5.17.2.11 to_hex() [1/5] std::string to_hex (
               const bit16_t & b )
Definition at line 50 of file Formatters.cc.
00050 { return fmt::format("{:#04x}", b); }
5.17.2.12 to_hex() [2/5] std::string to_hex (
               const bit32_t & b )
Definition at line 52 of file Formatters.cc.
00052 { return fmt::format("{:#08x}", b); }
```

```
5.17.2.13 to_hex() [3/5] std::string to_hex (
               const bit64_t & b )
Definition at line 54 of file Formatters.cc.
00054 { return fmt::format("{:#016x}", b); }
5.17.2.14 to_hex() [4/5] std::string to_hex (
               const bit8_t & b )
Definition at line 48 of file Formatters.cc.
00048 { return fmt::format("{:#02x}", b); }
5.17.2.15 to_hex() [5/5] std::string to_hex (
               const Buffer & b,
               const std::size_t & begin = 0,
               const std::size_t & end = -1)
Definition at line 35 of file Formatters.cc.
       std::size_t iend = end;
if(iend == -1) iend = b.size();
std::string ret;
00037
00038
00039
00040
       for(std::size_t k = begin; k < iend; k++)</pre>
00045 return ret;
00046 }
5.17.2.16 to_oct() [1/5] std::string to_oct (
               const bit16_t & b )
Definition at line 92 of file Formatters.cc.
00092 { return fmt::format("{:#080}", b); }
5.17.2.17 to_oct() [2/5] std::string to_oct (
               const bit32_t & b )
Definition at line 94 of file Formatters.cc.
00094 { return fmt::format("{:#0160}", b); }
5.17.2.18 to_oct() [3/5] std::string to_oct (
               const bit64_t & b )
Definition at line 96 of file Formatters.cc.
00096 { return fmt::format("{:#0320}", b); }
```

```
5.17.2.19 to_oct() [4/5] std::string to_oct (
              const bit8_t & b )
Definition at line 90 of file Formatters.cc.
00090 { return fmt::format("{:#040}", b); }
5.17.2.20 to_oct() [5/5] std::string to_oct (
              const Buffer & b,
              const std::size_t & begin = 0,
              const std::size_t & end = -1)
Definition at line 77 of file Formatters.cc.
        std::size_t iend = end;
08000
        if(iend == -1) iend = b.size();
00081
        std::string ret;
        for(std::size_t k = begin; k < iend; k++)</pre>
00082
00083
00084
         ret += to oct(b[k]);
        ret += " - ";
00085
00086
00087
       return ret;
00088 }
```

5.18 Formatters.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include "Bits.h"
80000
00009 #include <iosfwd>
00010 #include <string>
00011
00012 class Buffer;
00014 std::string to_dec(const Buffer& b, const std::size_t& begin = 0, const std::size_t& end = -1);
00015 std::string to_dec(const bit8_t&);
00016 std::string to_dec(const bit16_t&);
00017 std::string to_dec(const bit32_t&);
00018 std::string to_dec(const bit64_t&);
00020 std::string to_hex(const Buffer& b, const std::size_t& begin = 0, const std::size_t& end = -1);
00021 std::string to_hex(const bit8_t&);
00022 std::string to_hex(const bit16_t&);
00023 std::string to_hex(const bit32_t&);
00024 std::string to_hex(const bit64_t&);
00025
00026 std::string to_bin(const Buffer& b, const std::size_t& begin = 0, const std::size_t& end = -1);
00027 std::string to_bin(const bit8_t&);
00028 std::string to_bin(const bit16_t&);
00029 std::string to_bin(const bit32_t&);
00030 std::string to_bin(const bit64_t&);
00031
00032 std::string to_oct(const Buffer& b, const std::size_t& begin = 0, const std::size_t& end = -1);
00033 std::string to_oct(const bit8_t&);
00034 std::string to_oct(const bit16_t&);
00035 std::string to_oct(const bit32_t&);
00036 std::string to_oct(const bit64_t&);
```

5.19 libs/core/include/Interface.h File Reference

```
#include "AppVersion.h"
#include "Buffer.h"
#include "Version.h"
```

```
#include <iostream>
#include <map>
#include <memory>
#include <semver.hpp>
#include <spdlog/logger.h>
#include <string>
```

Classes

- · class Interface
- · class InterfaceReader
- · class InterfaceWriter

Enumerations

enum class InterfaceType { Unknown = 0 , Reader = 1 , Writer = 2 }
 template class should implement void SOURCE::start(); bool SOURCE::next(); void SOURCE::end(); const Buffer&
 SOURCE::getBuffer();

5.19.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Interface.h.

5.19.2 Enumeration Type Documentation

5.19.2.1 InterfaceType enum class InterfaceType [strong]

template class should implement void SOURCE::start(); bool SOURCE::next(); void SOURCE::end(); const Buffer& SOURCE::getBuffer();

void DESTINATION::begin(); void DESTINATION::processDIF(const DIFPtr&); void DESTINATION::process Frame(const DIFPtr&,const std::uint32_t& frameIndex); void DESTINATION::processPadInFrame(const DIFPtr&,const std::uint32_t& frameIndex,const std::uint32_t& channeIIndex); void DESTINATION::processSlowControl(const Buffer&); void DESTINATION::end();

Enumerator

Unknown	
Reader	
Writer	

Definition at line 32 of file Interface.h.

5.20 Interface.h

```
00001
00004 #pragma once
00005
00006 #include "AppVersion.h"
00007 #include "Buffer.h"
00008 #include "Version.h"
00009
00010 #include <iostream>
00011 #include <map>
00012 #include <memory>
00013 #include <semver.hpp>
00014 #include <spdlog/logger.h>
00015 #include <string>
00016
00032 enum class InterfaceType
00033 {
00034
        Unknown = 0,
       Reader = 1,
Writer = 2
00035
00036
00037 };
00038
00039 class Interface
00040 {
00041 public:
        Interface(const std::string& name, const std::string& version, const InterfaceType& type) :
     m_Name(name), m_Version(version) {}
00043
        virtual ~Interface() = default;
       virtual void
00044
                                           startEvent() {}
00045
        virtual void
                                           endEvent() {}
00046
        virtual void
                                           startDIF() {}
00047
        virtual void
                                           endDIF() {}
00048
        virtual void
                                           startFrame() {}
00049
        virtual void
                                           endFrame() {}
00050
       virtual void
                                           startPad() {}
00051
        virtual void
                                           endPad() {}
00052
        std::shared_ptr<spdlog::logger>& log() { return m_Logger; }
00053
                                          setLogger(const std::shared_ptr<spdlog::logger>& logger) { m_Logger
      = logger; }
00054
        std::string
                                           getName() { return m_Name; }
getVersion() { return m_Version; }
00055
        Version
00056
00058
        std::shared_ptr<spdlog::logger> m_Logger{nullptr};
00059
        std::string
                                          m_Name;
00060
        Version
                                          m_Version;
00061
                                         m_Type{InterfaceType::Unknown};
       InterfaceType
00062 };
00063
00064 class InterfaceReader : public Interface
00065 {
00066 public:
       InterfaceReader(const std::string& name, const std::string& version) : Interface(name, version,
00067
     InterfaceType::Reader) {}
00068
       virtual ~InterfaceReader() = default;
00069
00070 protected:
00071
        Buffer m_Buffer;
00072 };
00073
00074 class InterfaceWriter : public Interface
00075 {
00076 public:
00077
        InterfaceWriter(const std::string& name, const std::string& version) : Interface(name, version,
      InterfaceType::Writer) {}
00078
        void addCompatibility(const std::string& name, const std::string& version) { m_Compatible[name] =
00079
08000
00081
        std::map<std::string, std::string> getCompatibility() { return m_Compatible; }
00082
00083
        bool checkCompatibility (const std::string& name, const std::string& version)
00084
00085
          if (m_Compatible.find(name) != m_Compatible.end())
```

```
00086
          {
00087
                            ran = semver::range::detail::range(m_Compatible[name]);
00088
            semver::version ver = semver::version(version);
00089
            if(ran.satisfies(ver, false)) return true;
00090
            else
00091
             return false:
00092
00093
         else
00094
           return false;
00095
00096
00097
       virtual ~InterfaceWriter() = default;
00098
00099 private:
00100
       std::map<std::string, std::string> m_Compatible;
00101 };
```

5.21 libs/core/include/RawBufferNavigator.h File Reference

```
#include "Buffer.h"
#include "DIFPtr.h"
#include "spdlog/spdlog.h"
#include <memory>
```

Classes

· class RawBufferNavigator

5.21.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file RawBufferNavigator.h.

5.22 RawBufferNavigator.h

```
00001
00005 #pragma once
00006
00007 #include "Buffer.h"
00008 #include "DIFPtr.h"
00009 #include "spdlog/spdlog.h"
00010
00011 #include <memory>
00012
00013 // class to navigate in the raw data buffer
00014 class RawBufferNavigator
00015 {
00016 public:
00017
      explicit RawBufferNavigator(const std::shared_ptr<spdlog::logger>&);
00018
        ~RawBufferNavigator() = default;
        explicit RawBufferNavigator(const Buffer& b);
00019
                      setBuffer(const Buffer& b);
00020
        void
        std::uint8_t getDetectorID();
bool validBuffer();
bit8_t* getDIFBufferStart();
00022
00023
00024
        std::uint32_t getDIFBufferSize();
       Buffer getDIFBuffer();
DIFPtr& getDIFPtr();
00025
00026
        std::uint32_t getEndOfDIFData();
       std::uint32_t getSizeAfterDIFPtr();
```

```
std::uint32_t getDIF_CRC();
        bool badSCData();
Buffer getEndOfAllData();
Buffer getEndOfAllData();
00030
00031
00032
        Buffer getEndOfAllData();
static void StartAt(const int& start);
std::int32_t getStartOfPayload();
00033
00034
00035
00036
00037 private:
00038
        std::shared_ptr<spdlog::logger> m_Logger{nullptr};
00039
                                                setSCBuffer();
         void
00040
         Buffer
                                                m_Buffer;
00041
         Buffer
                                                m_SCbuffer;
00042
         std::int32_t
                                               m_StartPayload{-1};
00043
         DIFPtr
                                               m_TheDIFPtr;
00044
        bool
                                               m_BadSCdata{false};
00045
         static int
                                               m_Start;
00046 };
```

5.23 libs/core/include/Timer.h File Reference

#include <chrono>

Classes

class Timer

5.23.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Timer.h.

5.24 Timer.h

Go to the documentation of this file.

5.25 libs/core/include/Utilities.h File Reference

#include <cstdint>

5.26 Utilities.h 75

Functions

std::uint64_t GrayToBin (const std::uint64_t &n)

5.25.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Utilities.h.

5.25.2 Function Documentation

```
5.25.2.1 GrayToBin() std::uint64_t GrayToBin ( const std::uint64_t & n ) [inline]
```

Definition at line 9 of file Utilities.h.

```
00010 {
00011
         std::uint64_t ish{1};
         std::uint64_t anss{n};
std::uint64_t idiv{0};
00012
00013
00014
         std::uint64_t ishmax{sizeof(std::uint64_t) * 8};
00015
         while(true)
00016
           idiv = anss » ish;
anss ^= idiv;
if(idiv <= 1 || ish == ishmax) return anss;</pre>
00017
00018
00019
           ish «= 1;
00020
00021 }
00022 }
```

5.26 Utilities.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include <cstdint>
80000
00009 inline std::uint64_t GrayToBin(const std::uint64_t& n)
00010 {
00011 std::uint64_t ish{1};
00012 std::uint64_t anss{n};
00013
        std::uint64_t idiv{0};
00014
        std::uint64_t ishmax{sizeof(std::uint64_t) * 8};
00015
        while (true)
00016
00017
          idiv = anss » ish;
00018
         anss ^= idiv;
          if(idiv <= 1 || ish == ishmax) return anss;</pre>
00019
00020
          ish «= 1;
00021 }
00022 }
```

5.27 libs/core/include/Version.h File Reference

```
#include <cstdint>
#include <semver.hpp>
#include <string>
```

Classes

class Version

5.27.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Version.h.

5.28 Version.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include <cstdint>
00008 #include <semver.hpp>
00009 #include <string>
00010
00011 class Version : public semver::version
00012 {
00013 public:
00014
        Version(const std::uint8_t& mj, const std::uint8_t& mn, const std::uint8_t& pt, const
      semver::prerelease@ prt = semver::prerelease::none, const std::uint8_t@ prn = 0) noexcept :
semver::version(mj, mn, pt, prt, prn) {}

00015 explicit Version(const std::string_view& str) : semver::version(str) {}
         Version() = default;
00017
        std::uint8_t getMajor();
00018
        std::uint8_t getMinor();
00019    std::uint8_t getPatch();
00020    std::string getPreRelease();
00021    std::uint8_t getPreReleaseNumber();
00022 };
```

5.29 libs/core/include/Words.h File Reference

#include <cstdint>

Enumerations

```
    enum DU: std::uint8_t {
        START_OF_DIF = 0xB0 , START_OF_DIF_TEMP = 0xBB , END_OF_DIF = 0xA0 , START_OF_LINES = 0xC4 ,
        END_OF_LINES = 0xD4 , START_OF_FRAME = 0xB4 , END_OF_FRAME = 0xA3 , ID_SHIFT = 1 ,
        DTC_SHIFT = 2 , GTC_SHIFT = 10 , ABCID_SHIFT = 14 , BCID_SHIFT = 20 ,
        LINES_SHIFT = 23 , TASU1_SHIFT = 24 , TASU2_SHIFT = 28 , TDIF_SHIFT = 32 ,
        FRAME_ASIC_HEADER_SHIFT = 0 , FRAME_BCID_SHIFT = 1 , FRAME_DATA_SHIFT = 4 , FRAME_SIZE = 20 ,
        NUMBER_PAD = 64 }
```

5.29.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Words.h.

5.29.2 Enumeration Type Documentation

5.29.2.1 DU enum DU : std::uint8_t

Enumerator

START_OF_DIF	
START_OF_DIF_TEMP	
END_OF_DIF	
START_OF_LINES	
END_OF_LINES	
START_OF_FRAME	
END_OF_FRAME	
ID_SHIFT	
DTC_SHIFT	
GTC SHIFT	
ABCID_SHIFT	
BCID_SHIFT	
LINES_SHIFT	
TASU1_SHIFT	
TASU2_SHIFT	
TDIF_SHIFT	
FRAME_ASIC_HEADER_SHIFT	
FRAME_BCID_SHIFT	
FRAME_DATA_SHIFT	
FRAME_SIZE	
NUMBER_PAD	_
L	_

Definition at line 9 of file Words.h.

```
00010 {
00011 START_OF_DIF = 0xB0,
00012 START_OF_DIF_TEMP = 0xBB,
00013 END_OF_DIF = 0xA0,
00014 START_OF_LINES = 0xC4,
00015 END_OF_LINES = 0xD4,
00016
00017 START_OF_FRAME = 0xB4,
00018 END_OF_FRAME = 0xA3,
00019
00020 ID_SHIFT = 1,
00021 DTC_SHIFT = 2,
00022 GTC_SHIFT = 10,
00023 ABCID_SHIFT = 14,
00024 BCID_SHIFT = 14,
00024 BCID_SHIFT = 20,
00025 LINES_SHIFT = 23,
00026 TASUI_SHIFT = 24,
```

```
00027 TASU2_SHIFT = 28,

00028 TDIF_SHIFT = 32,

00029

00030 FRAME_ASIC_HEADER_SHIFT = 0,

00031 FRAME_BCID_SHIFT = 1,

00032 FRAME_DATA_SHIFT = 4,

00033 FRAME_SIZE = 20,

00034 00035 NUMBER_PAD = 64

00036 };
```

5.30 Words.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include <cstdint>
80000
00009 enum DU : std::uint8_t
00010 {
        START_OF_DIF
                         = 0xB0,
00012
        START_OF_DIF_TEMP = 0xBB,
       END_OF_DIF = 0xA0,
START_OF_LINES = 0xC4,
END_OF_LINES = 0xD4,
00013
00014
        END_OF_LINES
00015
00016
00017
       START_OF_FRAME = 0xB4,
00018
       END_OF_FRAME = 0xA3,
00019
00020
00021
        ID SHIFT
       DTC_SHIFT = 2,
GTC_SHIFT = 10,
00022
00023
        ABCID_SHIFT = 14,
00024
        BCID_SHIFT = 20,
        LINES_SHIFT = 23,
00025
       TASU1_SHIFT = 24,
TASU2_SHIFT = 28,
00026
00027
00028
        TDIF_SHIFT = 32,
00029
00030
       FRAME_ASIC_HEADER_SHIFT = 0,
00031
        FRAME_BCID_SHIFT
00032
        FRAME_DATA_SHIFT
00033
       FRAME_SIZE
00034
00035
        NUMBER_PAD = 64
00036 };
```

5.31 libs/core/src/Bits.cc File Reference

```
#include "Bits.h"
```

Functions

std::ostream & operator << (std::ostream &os, const bit8_t &c)
 Stream operator to print bit8_t aka std::uint8_t and not char or unsigned char.

5.31.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Bits.cc.

5.32 Bits.cc 79

5.31.2 Function Documentation

```
5.31.2.1 operator<<() std::ostream & operator<< ( std::ostream & os, const bit8_t & c )
```

Stream operator to print bit8_t aka std::uint8_t and not char or unsigned char.

```
Definition at line 8 of file Bits.cc.
00008 { return os « c + 0; }
```

5.32 Bits.cc

Go to the documentation of this file.

```
00001
00006 #include "Bits.h"
00007
00008 std::ostream& operator«(std::ostream& os, const bit8_t& c) { return os « c + 0; }
```

5.33 libs/core/src/BufferLooperCounter.cc File Reference

```
#include "BufferLooperCounter.h"
#include <fmt/core.h>
```

5.34 BufferLooperCounter.cc

```
Go to the documentation of this file.
```

```
00001
00005 #include "BufferLooperCounter.h"
00006
00007 #include <fmt/core.h>
80000
00009 void BufferLooperCounter::printAllCounters()
00010 {
00011
        fmt::print("BUFFER LOOP FINAL STATISTICS : \n");
        printCounter("Start of DIF header", DIFStarter);
printCounter("Value after DIF data are processed", DIFPtrValueAtReturnedPos);
00012
00014
        printCounter("Size remaining in buffer after end of DIF data", SizeAfterDIFPtr);
00015
        fmt::print("Number of Slow Control found {} out of which {} are bad\n", hasSlowControl,
      hasBadSlowControl);
       printCounter("Size remaining after all of data have been processed", SizeAfterAllData);
00016
00017
        printCounter("Number on non zero values in end of data buffer", NonZeroValusAtEndOfData);
00018 }
00020 void BufferLooperCounter::printCounter(const std::string& description, const std::map<int, int>& m)
00021 {
        std::string out{"statistics for " + description + " : \n"};
00022
00023
        for(std::map<int, int>::const_iterator it = m.begin(); it != m.end(); it++)
00024
       {
00025
          if(it != m.begin()) out += ",";
00026
         out += " [" + std::to_string(it->first) + "]=" + std::to_string(it->second);
00027
       out += "\n";
00028
       fmt::print(out);
00029
00030 }
```

5.35 libs/core/src/DIFSlowControl.cc File Reference

```
#include "DIFSlowControl.h"
```

Functions

• std::string to_string (const DIFSlowControl &c)

5.35.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file DIFSlowControl.cc.

5.35.2 Function Documentation

```
5.35.2.1 to_string() std::string to_string ( const DIFSlowControl & c )
```

Definition at line 256 of file DIFSlowControl.cc.

```
00257 {
00258     std::string ret;
00259     for(std::map<int, std::map<std::string, int»::const_iterator it = c.cbegin(); it != c.cend(); it++)
00260     {
          ret += "ASIC " + std::to_string(it->first) + " :\n";
          for(std::map<std::string, int>::const_iterator jt = (it->second).begin(); jt !=
               (it->second).end(); jt++) ret += jt->first + " : " + std::to_string(jt->second) + "\n";
00263     }
00264     return ret;
00265 }
```

5.36 DIFSlowControl.cc

```
00001
00005 #include "DIFSlowControl.h"
00006
00007 DIFSlowControl::DIFSlowControl(const std::uint8_t& version, const std::uint8_t& DIfId, unsigned char*
      cbuf) : m_Version(version), m_DIFId(DIfId), m_AsicType(2)
00008 {
00009
        if(cbuf[0] != 0xb1) return;
00010
        int header_shift{6};
00011
        if (m_Version < 8) m_NbrAsic = cbuf[5];</pre>
00012
00013
        m_DIFId
00014
                      = cbuf[1];
                     = cbuf[2];
00015
         m NbrAsic
00016
         header_shift = 3;
00017
00018
       int size_hardroc1 = m_NbrAsic * 72 + header_shift + 1;
00019
       if (cbuf[size_hardroc1 - 1] != 0xa1) size_hardroc1 = 0;
00020
00021
       int size_hardroc2 = m_NbrAsic * 109 + header_shift + 1;
00022
       if (cbuf[size_hardroc2 - 1] != 0xa1) size_hardroc2 = 0;
       if(size_hardroc1 != 0)
00023
```

5.36 DIFSlowControl.cc 81

```
00024
        {
00025
          FillHR1 (header_shift, cbuf);
00026
          m_AsicType = 1;
00027
        else if(size_hardroc2 != 0)
00028
          FillHR2(header_shift, cbuf);
00029
        else
00031
          return;
00032 }
00033
00034 inline std::uint8_t DIFSlowControl::getDIFId() { return m_DIFId; }
00035
00036 inline std::map<int, std::map<std::string, int» DIFSlowControl::getChipsMap() { return m_MapSC; }
00037
00038 inline std::map<std::string, int> DIFSlowControl::getChipSlowControl(const int& asicid) { return
      m_MapSC[asicid]; }
00039
00040 inline int DIFSlowControl::getChipSlowControl(const std::int8_t& asicid, const std::string& param) {
      return getChipSlowControl(asicid)[param]; }
00041
00042 void DIFSlowControl::FillHR1(const int& header_shift, unsigned char* cbuf)
00043 {
00044
        int nasic{cbuf[header shift - 1]};
00045
        int idx{header_shift};
for(int k = 0; k < nasic; k++)</pre>
00046
00047
00048
          std::bitset<72 * 8> bs;
00049
           // printf("%x %x \n",cbuf[idx+k*72+69],cbuf[idx+k*72+70]);
00050
           for (int 1 = 71; 1 >= 0; 1--)
00051
             // printf("%d %x : %d -->",l,cbuf[idx+k*72+1],(71-1)*8);
00052
00053
             for (int m = 0; m < 8; m++)
00054
00055
               if(((1 < m) \& cbuf[idx + k * 72 + 1]) != 0) bs.set((71 - 1) * 8 + m, 1);
00056
               bs.set((71 - 1) * 8 + m, 0);
// printf("%d",(int) bs[(71-1)*8+m]);
00057
00058
00059
00060
             // printf("\n");
00061
00062
          FillAsicHR1(bs);
        }
00063
00064 }
00065
00066 void DIFSlowControl::FillHR2(const int& header_shift, unsigned char* cbuf)
00067 {
00068
         // int scsize1=cbuf[header_shift-1] *109+(header_shift-1) +2;
00069
        int nasic{cbuf[header_shift - 1]};
00070
        int idx{header_shift};
// std::cout«" DIFSlowControl::FillHR nasic "«nasic«std::endl;
00071
00072
         for (int k = 0; k < nasic; k++)
00073
00074
           std::bitset<109 * 8> bs;
           // printf("%x %x \n",cbuf[idx+k*109+69],cbuf[idx+k*109+70]); for(int 1 = 108; 1 >= 0; 1--)
00075
00076
00077
           {
00078
                 printf("%d %x : %d -->",l,cbuf[idx+k*109+1],(71-1)*8);
00079
             for (int m = 0; m < 8; m++)
00080
               if(((1 \times m) \& cbuf[idx + k * 109 + 1]) != 0) bs.set((108 - 1) * 8 + m, 1);
00081
00082
               else
                 bs.set((108 - 1) \star 8 + m, 0);
00083
00084
               // printf("%d",(int) bs[(71-1)*8+m]);
00085
00086
             // printf("\n");
00087
00088
          FillAsicHR2(bs);
00089
        }
00090 }
00091
00092 void DIFSlowControl::FillAsicHR1(const std::bitset<72 * 8>& bs)
00093 {
00094
         // Asic Id
00095
        int asicid{0};
        for(int j = 0; j < 8; j++)
  if(bs[j + 9] != 0) asicid += (1 « (7 - j));</pre>
00096
00097
00098
        std::map<std::string, int> mAsic;
00099
        // Slow Control
mAsic["SSCO"]
00100
                                 = static_cast<int>(bs[575]);
        mAsic["SSC1"]
00101
                                 = static_cast<int>(bs[574]);
        mAsic["SSC2"]
                                 = static_cast<int>(bs[573]);
00102
00103
        mAsic["Choix_caisson"] = static_cast<int>(bs[572]);
        mAsic["SW_50k"]
                                 = static_cast<int>(bs[571]);
00104
00105
        mAsic["SW_100k"]
                                 = static_cast<int>(bs[570]);
        mAsic["SW_100f"]
00106
                                 = static_cast<int>(bs[569]);
        mAsic["SW 50f"]
                                 = static_cast<int>(bs[568]);
00107
00108
```

```
mAsic["Valid_DC"] = static_cast<int>(bs[567]);
mAsic["ON_Discri"] = static_cast<int>(bs[566]);
00110
          mAsic["ON_Fsb"] = static_cast<int>(bs[565]);
mAsic["ON_Otaq"] = static_cast<int>(bs[564]);
00111
00112
          mAsic["ON_W"]
                                   = static_cast<int>(bs[563]);
00113
          mAsic["ON_Ss"]
                                  = static_cast<int>(bs[562]);
00114
                                 = static_cast<int>(bs[561]);
= static_cast<int>(bs[560]);
          mAsic["ON_Buf"]
00115
00116
          mAsic["ON_Paf"]
00117
          // Gain
00118
          for (int i = 0; i < 64; i++)
00119
           00120
00121
00122
00123
00124
00125
00126
          mAsic["ON_Otabg"] = static_cast<int>(bs[111]);
mAsic["ON_Dac"] = static_cast<int>(bs[110]);
mAsic["ON_Otadac"] = static_cast<int>(bs[109]);
00128
00129
00130
00131
          // DAC
          int dac1{0};
for(int j = 0; j < 10; j++)
  if(bs[j + 99] != 0) dac1 += (1 « j);</pre>
00132
00133
00134
00135
          mAsic["DAC1"] = dac1;
00136
          int dac0{0};
          for(int j = 0; j < 10; j++)
  if(bs[j + 89] != 0) dac0 += (1 « j);</pre>
00137
00138
          mAsic["DAC0"]
00139
                                        = dac0;
00140
          mAsic["EN_Raz_Ext"]
                                           = static_cast<int>(bs[23]);
          mAsic["EN_Raz_Int"]
                                           = static_cast<int>(bs[22]);
00141
00142
          mAsic["EN_Out_Raz_Int"] = static_cast<int>(bs[21]);
          mAsic["EN_Trig_Ext"]
mAsic["EN_Trig_Int"]
                                          = static_cast<int>(bs[20]);
00143
                                          = static_cast<int>(bs[19]);
00144
         mAsic["EN_Out_Trig_Int"] = static_cast<int>(bs[18]);
mAsic["Bypass_Chip"] = static_cast<int>(bs[17]);
00145
                                          = static_cast<int>(bs[17]);
00147
          mAsic["HardrocHeader"]
                                           = static_cast<int>(asicid);
00148
          mAsic["EN_Out_Discri"]
                                           = static_cast<int>(bs[8]);
00149
          mAsic["EN_Transmit_On"] = static_cast<int>(bs[7]);
          mAsic["EN_Dout"]
00150
                                          = static_cast<int>(bs[6]);
          mAsic["EN RamFull"]
                                          = static_cast<int>(bs[5]);
00151
00152
         m_MapSC[asicid]
                                           = mAsic;
00153 }
00154
00155 void DIFSlowControl::FillAsicHR2(const std::bitset<109 * 8>& bs)
00156 {
00157
          int asicid(0):
          for(int j = 0; j < 8; j++)
  if(bs[j + (108 - 7) * 8 + 2] != 0) asicid += (1 « (7 - j));</pre>
00158
00159
          std::map<std::string, int> mAsic;
00160
00161
          for(int i = 0; i < 64; i++)
00162
            int gain{0};
00163
00164
            int mask{0};
            Int mask();
mAsic["Channel_" + std::to_string(i) + "_" + "cTest"] = bs[i];
for(int j = 0; j < 8; j++)
    if(bs[64 + i * 8 + j] != 0) gain += (1 « j);
mAsic["Channel_" + std::to_string(i) + "_" + "Gain"] = gain;
for(it j = 0; j < 2; j = 0;</pre>
00166
00167
00168
            for(int j = 0; j < 3; j++)

if(bs[8 * 77 + 2 + i * 3 + j] != 0) mask += (1 « j);

mAsic["Channel_" + std::to_string(i) + "_" + "Mask"] = mask;
00169
00170
00171
00172
00173
          mAsic["PwrOnPA"] = static_cast<int>(bs[8 * 72]);
00174
          mAsic["Cmdb3SS"] = static\_cast < int > (bs[8 * 72 + 1]);
          mAsic["Cmdb2SS"] = static_cast<int>(bs[8 * 72 + 2]);
00175
          mAsic["Cmdb1SS"] = static_cast<int>(bs[8 * 72 + 3]);
00176
          mAsic["Cmdb0SS"] = static_cast<int>(bs[8 * 72 + 4]);
00177
          mAsic["SwSsc0"] = static_cast < int > (bs[8 * 72 + 5]);
00178
00179
          mAsic["SwSsc1"] = static_cast < int > (bs[8 * 72 + 6]);
00180
          mAsic["SwSsc2"] = static_cast < int > (bs[8 * 72 + 7]);
00181
          mAsic["PwrOnBuff"] = static_cast<int>(bs[8 * 73]);
00182
         mAsic["PwrOnSS"] = static_cast<int>(bs[8 * 73 + 1]);
mAsic["PwrOnW"] = static_cast<int>(bs[8 * 73 + 2]);
00183
00184
00185
          mAsic["Cmdb3Fsb2"] = static_cast<int>(bs[8 * 73 + 3]);
          mAsic["Cmdb2Fsb2"] = static_cast<int>(bs[8 * 73 + 4]);
mAsic["Cmdb1Fsb2"] = static_cast<int>(bs[8 * 73 + 5]);
00186
00187
          \texttt{mAsic}[\texttt{"Cmdb0Fsb2"}] = \texttt{static\_cast} < \texttt{int} > (\texttt{bs}[8 * 73 + 6]);
00188
          mAsic["Sw50k2"]
                                  = static_cast<int>(bs[8 * 73 + 7]);
00189
00190
          mAsic["Sw100k2"] = static_cast<int>(bs[8 * 74]);
mAsic["Sw100f2"] = static_cast<int>(bs[8 * 74 + 1]);
mAsic["Sw50f2"] = static_cast<int>(bs[8 * 74 + 2]);
00191
00192
00193
          mAsic["Cmdb3Fsb1"] = static_cast<int>(bs[8 * 74 + 3]);
00194
00195
          mAsic["Cmdb2Fsb1"] = static_cast<int>(bs[8 * 74 + 4]);
```

```
mAsic["Cmdb1Fsb1"] = static_cast<int>(bs[8 * 74 + 5]);
         mAsic["Cmdb0Fsb1"] = static_cast<int>(bs[8 * 74 + 6]);
00197
         mAsic["Sw50k1"]
00198
                               = static_cast<int>(bs[8 * 74 + 7]);
00199
00200
        mAsic["Sw100k1"] = static\_cast < int > (bs[8 * 75]);
        mAsic["Sw100f1"] = static_cast<int>(bs[8 * 75 + 1]);
mAsic["Sw50f1"] = static_cast<int>(bs[8 * 75 + 2]);
mAsic["Sel0"] = static_cast<int>(bs[8 * 75 + 2]);
mAsic["Sel1"] = static_cast<int>(bs[8 * 75 + 3]);
00201
00202
00203
         mAsic["Sell1"]
00204
                               = static_cast<int>(bs[8 * 75 + 4]);
         mAsic["PwrOnFsb"] = static_cast<int>(bs[8 * 75 + 5]);
00205
        mAsic["PwrOnFsb1"] = static_cast<int>(bs[8 * 75 + 6]);
00206
        mAsic["PwrOnFsb2"] = static_cast<int>(bs[8 * 75 + 7]);
00207
00208
                               = static_cast<int>(bs[8 * 76]);
00209
         mAsic["Sw50k0"]
00210
         mAsic["Sw100k0"]
                                 = static_cast<int>(bs[8 \star 76 +
         masic["Sw100f0"] = static_cast<int>(bs[8 * 76 + 1]);
masic["Sw50f0"] = static_cast<int>(bs[8 * 76 + 2]);
masic["Sw50f0"] = static_cast<int>(bs[8 * 76 + 3]);
00211
00212
         mAsic["EnOtaQ"]
                                 = static_cast<int>(bs[8 * 76 + 4]);
00213
        mAsic["OtaQ_PwrADC"] = static_cast<int>(bs[8 * 76 + 5]);
00214
        mAsic["Discri_PwrA"] = static_cast<int>(bs[8 * 76 + 6]);
00215
00216
                                 = static_cast<int>(bs[8 * 76 + 7]);
        mAsic["Discri2"]
00217
        mAsic["Discril"]
00218
                                  = static_cast<int>(bs[8 * 77]);
        mAsic["RS_or_Discri"] = static_cast<int>(bs[8 * 77 + 1]);
00219
00220
00221
         mAsic["Header"] = asicid;
00222
         for (int i = 0; i < 3; i++)
00223
00224
           int B = 0;
          for (int j = 0; j < 10; j++)
if (bs[8 * 102 + 2 + i * 10 + j] != 0) B += (1 « j);
00225
00226
00227
           mAsic["B" + std::to_string(i)] = B;
00228
00229
00230
        mAsic["Smalldac"] = static_cast<int>(bs[8 * 106]);
         mAsic["DacSw"]
                               = static_cast<int>(bs[8 * 106 + 1]);
00231
        mAsic["OtagBgSw"] = static_cast<int>(bs[8 * 106 + 2]);
00232
        masic["Trig2b"] = static_cast<int>(bs[8 * 106 + 4]);
masic["Trig0b"] = static_cast<int>(bs[8 * 106 + 4]);
masic["Trig0b"] = static_cast<int>(bs[8 * 106 + 5]);
00233
00234
00235
         mAsic["EnTrigOut"] = static_cast<int>(bs[8 * 106 + 6]);
00236
        mAsic["DiscrOrOr"] = static_cast<int>(bs[8 * 106 + 7]);
00237
00238
00239
        mAsic["TrigExtVal"]
                                  = static_cast<int>(bs[8 * 107]);
        mAsic["RazChnIntVal"] = static_cast<int>(bs[8 * 107 + 1]);
00240
00241
         mAsic["RazChnExtVal"] = static\_cast < int > (bs[8 * 107 + 2]);
        mAsic["ScOn"]
                              = static_cast<int>(bs[8 * 107 + 3]);
= static_cast<int>(bs[8 * 107 + 4]);
00242
00243
        mAsic["CLKMux"]
00244
         // EnoCDout1b EnoCDout2b EnoCTransmitOn1b EnoCTransmitOn2b EnoCChipsatb SelStartReadout
00245
      SelEndReadout
00246 mAsic["SelEndReadout"]
                                       = static_cast<int>(bs[8 * 108 + 1]);
         mAsic["SelStartReadout"] = static_cast<int>(bs[8 * 108 + 2]);
00247
        mAsic["EnoCchipsatb"] = static_cast<int>(bs[8 * 108 + 3]);
mAsic["EnoCTransmitOn2b"] = static_cast<int>(bs[8 * 108 + 4]);
00248
00249
00250
        mAsic["EnOCTransmitOn1b"] = static_cast<int>(bs[8 * 108 + 5]);
        00252
00253
        m_MapSC[asicid]
00254 }
00255
00256 std::string to_string(const DIFSlowControl& c)
00257 {
00258 std::string ret;
00259
        for(std::map<int, std::map<std::string, int»::const_iterator it = c.cbegin(); it != c.cend(); it++)</pre>
00260
         ret += "ASIC " + std::to_string(it->first) + " :\n";
for(std::max/std::string);
00261
      for (std::map<std::string, int>::const_iterator jt = (it->second).begin(); jt !=
(it->second).end(); jt++) ret += jt->first + " : " + std::to_string(jt->second) + "\n";
00262
00264
00265 }
```

5.37 libs/core/src/Filesystem.cc File Reference

#include "Filesystem.h"

Functions

• std::string path (const std::string &file)

- std::string extension (const std::string &file)
- std::string filename (const std::string &file)

5.37.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Filesystem.cc.

5.37.2 Function Documentation

```
5.37.2.1 extension() std::string extension (
              const std::string & file )
Definition at line 13 of file Filesystem.cc.
       std::size_t position = file.find_last_of(".");
return (std::string::npos == position || position == 0) ? "" : file.substr(position + 1);
00015
00016
00017 }
5.37.2.2 filename() std::string filename (
             const std::string & file )
Definition at line 19 of file Filesystem.cc.
00020 {
00024 }
5.37.2.3 path() std::string path (
              const std::string & file )
Definition at line 7 of file Filesystem.cc.
00008 {
       std::size_t pos = file.find_last_of("\\/");
return (std::string::npos == pos) ? "" : file.substr(0, pos);
00009
00010
00011 }
```

5.38 Filesystem.cc 85

5.38 Filesystem.cc

Go to the documentation of this file.

```
00005 #include "Filesystem.h"
00006
00007 std::string path(const std::string& file)
00008 {
         std::size_t pos = file.find_last_of("\\/");
return (std::string::npos == pos) ? "" : file.substr(0, pos);
00009
00010
00011 }
00012
00013 std::string extension(const std::string& file)
00014 {
         std::size_t position = file.find_last_of(".");
00015
         return (std::string::npos == position || position == 0) ? "" : file.substr(position + 1);
00016
00017 }
00019 std::string filename(const std::string& file)
00020 {
         std::size_t position = file.find_last_of(".");
std::size_t pos = file.find_last_of("\\/");
return (std::string::npos == pos) ? file.substr(0, position) : file.substr(pos + 1, position - pos
00021
00022
00023
00024 }
```

5.39 libs/core/src/Formatters.cc File Reference

```
#include "Formatters.h"
#include "Bits.h"
#include "Buffer.h"
#include "Words.h"
#include <fmt/format.h>
```

Functions

```
• std::string to_dec (const Buffer &b, const std::size_t &begin, const std::size_t &end)
• std::string to dec (const bit8 t &b)

    std::string to dec (const bit16 t &b)

    std::string to_dec (const bit32_t &b)

    std::string to_dec (const bit64_t &b)

    std::string to_hex (const Buffer &b, const std::size_t &begin, const std::size_t &end)

• std::string to_hex (const bit8_t &b)

    std::string to_hex (const bit16_t &b)

• std::string to_hex (const bit32_t &b)

    std::string to hex (const bit64 t &b)

    std::string to_bin (const Buffer &b, const std::size_t &begin, const std::size_t &end)

    std::string to_bin (const bit8_t &b)

    std::string to_bin (const bit16_t &b)

    std::string to_bin (const bit32_t &b)

• std::string to bin (const bit64 t &b)

    std::string to_oct (const Buffer &b, const std::size_t &begin, const std::size_t &end)

    std::string to_oct (const bit8_t &b)

    std::string to_oct (const bit16_t &b)

    std::string to_oct (const bit32_t &b)

    std::string to oct (const bit64 t &b)
```

5.39.1 Detailed Description

```
Copyright
```

2022 G.Grenier F.Lagarde

Definition in file Formatters.cc.

5.39.2 Function Documentation

00069 { return fmt::format("{:#08b}", b); }

```
5.39.2.5 to_bin() [5/5] std::string to_bin (
                const Buffer & b,
                const std::size_t & begin,
                const std::size_t & end )
Definition at line 56 of file Formatters.cc.
 00057 {
        std::size_t iend = end;
if(iend == -1) iend = b.size();
 00058
 00059
 00060
        std::string ret;
00063 ret += to_bin(b[k]);
00064 ret += " - ";
00065 }
00066 return ret;
 00061
         for(std::size_t k = begin; k < iend; k++)</pre>
5.39.2.6 to dec() [1/5] std::string to_dec (
                const bit16_t & b )
Definition at line 29 of file Formatters.cc.
 00029 { return fmt::format("{:#d}", b); }
5.39.2.7 to dec() [2/5] std::string to_dec (
                const bit32_t & b )
Definition at line 31 of file Formatters.cc.
00031 { return fmt::format("{:#d}", b); }
5.39.2.8 to_dec() [3/5] std::string to_dec (
                const bit64_t & b )
Definition at line 33 of file Formatters.cc.
00033 { return fmt::format("{:#d}", b); }
5.39.2.9 to_dec() [4/5] std::string to_dec (
                const bit8_t & b )
Definition at line 27 of file Formatters.cc.
```

00027 { return fmt::format("{:#d}", b); }

```
5.39.2.10 to_dec() [5/5] std::string to_dec (
                const Buffer & b,
                const std::size_t & begin,
                const std::size_t & end )
Definition at line 14 of file Formatters.cc.
 00015 {
        std::size_t iend = end;
if(iend == -1) iend = b.size();
 00016
 00017
        std::string ret;
00021 ret += to_dec(b[k]);

00022 ret += " - ";

00023 }

00024 return ret;
 00019
         for(std::size_t k = begin; k < iend; k++)</pre>
5.39.2.11 to_hex() [1/5] std::string to_hex (
                const bit16_t & b )
Definition at line 50 of file Formatters.cc.
 00050 { return fmt::format("{:#04x}", b); }
5.39.2.12 to_hex() [2/5] std::string to_hex (
                const bit32_t & b )
Definition at line 52 of file Formatters.cc.
00052 { return fmt::format("{:#08x}", b); }
5.39.2.13 to hex() [3/5] std::string to_hex (
                const bit64_t & b )
Definition at line 54 of file Formatters.cc.
00054 { return fmt::format("{:#016x}", b); }
5.39.2.14 to_hex() [4/5] std::string to_hex (
                const bit8_t & b )
Definition at line 48 of file Formatters.cc.
00048 { return fmt::format("{:#02x}", b); }
```

```
5.39.2.15 to_hex() [5/5] std::string to_hex (
                const Buffer & b,
                const std::size_t & begin,
                const std::size_t & end )
Definition at line 35 of file Formatters.cc.
 00036 {
         std::size_t iend = end;
if(iend == -1) iend = b.size();
 00037
 00038
         std::string ret;
00042 ret += to_hex(b[k]);

00043 ret += " - ";

00044 }

00045 return ret;
 00040
         for(std::size_t k = begin; k < iend; k++)</pre>
5.39.2.16 to_oct() [1/5] std::string to_oct (
                const bit16_t & b )
Definition at line 92 of file Formatters.cc.
 00092 { return fmt::format("{:#080}", b); }
5.39.2.17 to_oct() [2/5] std::string to_oct (
                const bit32_t & b )
Definition at line 94 of file Formatters.cc.
00094 { return fmt::format("{:#0160}", b); }
5.39.2.18 to_oct() [3/5] std::string to_oct (
                const bit64_t & b )
Definition at line 96 of file Formatters.cc.
00096 { return fmt::format("{:#0320}", b); }
5.39.2.19 to_oct() [4/5] std::string to_oct (
                const bit8_t & b )
Definition at line 90 of file Formatters.cc.
```

00090 { return fmt::format("{:#040}", b); }

```
5.39.2.20 to_oct() [5/5] std::string to_oct (
               const Buffer & b,
              const std::size_t & begin,
               const std::size_t & end )
Definition at line 77 of file Formatters.cc.
00078 {
        std::size_t iend = end;
08000
        if (iend == -1) iend = b.size();
00081
        std::string ret;
00082
        for(std::size_t k = begin; k < iend; k++)</pre>
00083
00084
         ret += to_oct(b[k]);
00085
         ret += " - ";
00086
00087
        return ret;
00088 }
```

5.40 Formatters.cc

```
00001
00006 #include "Formatters.h"
00007
00008 #include "Bits.h"
00000 #include "Buffer.h"
00010 #include "Words.h"
00011
00012 #include <fmt/format.h>
00013
00014 std::string to_dec(const Buffer& b, const std::size_t& begin, const std::size_t& end)
00015 {
00016
        std::size_t iend = end;
        if(iend == -1) iend = b.size();
00017
00018
        std::string ret;
00019
        for(std::size_t k = begin; k < iend; k++)</pre>
       ret += to_dec(b[k]);
ret += " - ";
}
00020
00021
00022
00023
00024
        return ret:
00025 }
00026
00027 std::string to_dec(const bit8_t& b) { return fmt::format("{:#d}", b); }
00028
00029 std::string to_dec(const bit16_t& b) { return fmt::format("{:#d}", b); }
00030
00031 std::string to_dec(const bit32_t& b) { return fmt::format("{:#d}", b); }
00032
00033 std::string to_dec(const bit64_t& b) { return fmt::format("{:#d}", b); }
00034
00035 std::string to_hex(const Buffer& b, const std::size_t& begin, const std::size_t& end)
00036 {
00037
        std::size_t iend = end;
00038
        <u>if</u>(iend == -1) iend = b.size();
        std::string ret;
00039
00040
        for(std::size_t k = begin; k < iend; k++)</pre>
00041
00042
          ret += to hex(b[k]);
        ret += " - ";
00043
00044
00045
        return ret;
00046 }
00047
00048 std::string to_hex(const bit8_t& b) { return fmt::format("{:#02x}", b); }
00049
00050 std::string to_hex(const bit16_t& b) { return fmt::format("{:#04x}", b); }
00051
00052 std::string to_hex(const bit32_t& b) { return fmt::format("{:#08x}", b); }
00053
00054 std::string to_hex(const bit64_t& b) { return fmt::format("{:\#016x}", b); }
00055
00056 std::string to_bin(const Buffer& b, const std::size_t& begin, const std::size_t& end)
00057 {
        std::size_t iend = end;
00058
00059
        if(iend == -1) iend = b.size();
        std::string ret;
for(std::size_t k = begin; k < iend; k++)</pre>
00060
00061
00062
        {
00063
          ret += to_bin(b[k]);
```

```
00064
         ret += " - ";
00065
00066
00067 }
00068
00069 std::string to_bin(const bit8_t& b) { return fmt::format("{:#08b}", b); }
00071 std::string to_bin(const bit16_t& b) { return fmt::format("{:#016b}", b); }
00072
00073 std::string to_bin(const bit32_t& b) { return fmt::format("{:#032b}", b); }
00074
00075 std::string to_bin(const bit64_t& b) { return fmt::format("{:#064b}", b); }
00076
00077 std::string to_oct(const Buffer& b, const std::size_t& begin, const std::size_t& end)
00078 {
00079
        std::size_t iend = end;
08000
        if(iend == -1) iend = b.size();
00081
       std::string ret;
00082
       for(std::size_t k = begin; k < iend; k++)</pre>
00083
        ret += to_oct(b[k]);
ret += " - ";
00084
00085
00086
00087
       return ret;
00088 }
00089
00090 std::string to_oct(const bit8_t& b) { return fmt::format("{:#040}", b); }
00091
00092 std::string to_oct(const bit16_t& b) { return fmt::format("{:#080}", b); }
00093
00094 std::string to_oct(const bit32_t& b) { return fmt::format("{:#0160}", b); }
00095
00096 std::string to_oct(const bit64_t& b) { return fmt::format("{:#0320}", b); }
```

5.41 libs/core/src/RawBufferNavigator.cc File Reference

```
#include "RawBufferNavigator.h"
#include "Words.h"
#include "spdlog/spdlog.h"
```

5.41.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file RawBufferNavigator.cc.

5.42 RawBufferNavigator.cc

```
00001
00005 #include "RawBufferNavigator.h"
00006
00007 #include "Words.h"
00008 #include "spdlog/spdlog.h"
00009
00010 RawBufferNavigator::RawBufferNavigator(const std::shared_ptr<spdlog::logger>& logger) { m_Logger =
00011
00012 std::int32_t RawBufferNavigator::getStartOfPayload()
00013 {
00014
        for(std::size_t i = m_Start; i < m_Buffer.size(); i++)</pre>
00015
          if(m_Buffer[i] == DU::START_OF_DIF || m_Buffer[i] == DU::START_OF_DIF_TEMP)
00016
00017
00018
           m_StartPayload = i;
00019
            return m_StartPayload;
```

```
00020
          }
00021
00022
        m_StartPayload = -1;
00023
        return m_StartPayload;
00024 }
00025
00026 int RawBufferNavigator::m_Start = 92;
00027
00028 void RawBufferNavigator::StartAt(const int& start)
00029 {
00030
        if(start >= 0) m_Start = start;
00031 }
00032
00033 void RawBufferNavigator::setBuffer(const Buffer& b)
00034 {
00035
        m_BadSCdata = false;
00036
        m Buffer
                    = h:
00037
        // m DIFstartIndex = getStartOfPayload();
00038 }
00039
00040 RawBufferNavigator::RawBufferNavigator(const Buffer&b) : m_Buffer(b) { setBuffer(b); }
00041
00042 std::uint8_t RawBufferNavigator::getDetectorID() { return m_Buffer[0]; }
00043
00044 bool RawBufferNavigator::validBuffer() { return m_StartPayload != -1; }
00046 bit8_t* RawBufferNavigator::getDIFBufferStart() { return & (m_Buffer.begin()[m_StartPayload]); }
00047
00048 std::uint32_t RawBufferNavigator::getDIFBufferSize() { return m_Buffer.size() - m_StartPayload; }
00049
00050 Buffer RawBufferNavigator::getDIFBuffer() { return Buffer(getDIFBufferStart(), getDIFBufferSize()); }
00051
00052 DIFPtr& RawBufferNavigator::getDIFPtr()
00053 {
00054
        m_TheDIFPtr.setBuffer(getDIFBufferStart(), getDIFBufferSize());
00055
        return m_TheDIFPtr;
00056 }
00057
00058 std::uint32_t RawBufferNavigator::getEndOfDIFData() { return getDIFPtr().getGetFramePtrReturn() + 3; }
00059
00060 std::uint32_t RawBufferNavigator::getSizeAfterDIFPtr() { return getDIFBufferSize() -
      getDIFPtr().getGetFramePtrReturn(); }
00061
00062 std::uint32_t RawBufferNavigator::getDIF_CRC()
00063 {
00064
        uint32_t i{getEndOfDIFData()};
00065
        uint32_t ret{0};
00066
       ret |= ((m_Buffer.begin()[i - 2]) « 8);
        ret |= m_Buffer.begin()[i - 1];
00067
00068
        return ret;
00069 }
00070
00071 bool RawBufferNavigator::hasSlowControlData() { return getDIFBufferStart()[getEndOfDIFData()] == 0xbl;
00072
00073 Buffer RawBufferNavigator::getSCBuffer()
00074 {
00075
        setSCBuffer();
00076
       return m_SCbuffer;
00077 }
00078
00079 bool RawBufferNavigator::badSCData()
00080 {
00081
       setSCBuffer();
00082
        return m_BadSCdata;
00083 }
00084
00085 void RawBufferNavigator::setSCBuffer()
00086 {
00087
        if(!hasSlowControlData()) return;
00088
        if (m_SCbuffer.size() != 0) return; // deja fait
00089
        if (m BadSCdata) return;
00090
        m_SCbuffer.set(&(getDIFBufferStart()[getEndOfDIFData()]));
00091
        // compute Slow Control size
       std::size_t maxsize{m_Buffer.size() - m_StartPayload - getEndOfDIFData() + 1}; // should I +1 here
00092
00093
        uint32_t
                    k{1};
00094
        uint32_t
                    dif_ID{m_SCbuffer[1]};
00095
        uint32 t
                    chipSize{m_SCbuffer[3]};
     while((dif_ID != 0xal && m_SCbuffer[k] != 0xal && k < maxsize) || (dif_ID == 0xal && m_SCbuffer[k +
2] == chipSize && k < maxsize))</pre>
00096
00097
        {
          k += 2; // DIF ID + ASIC Header
uint32_t scsize = m_SCbuffer[k];
00098
00099
00100
          if(scsize != 74 && scsize != 109)
00101
00102
            m_Logger->error("PROBLEM WITH SC SIZE {}", scsize);
```

```
00103
00104
          m_BadSCdata = true;
00105
          break;
00106
                     // skip size bit
00107
        k++:
        k += scsize; // skip the data
00108
00109
00110
       00111
00112
00113
        m BadSCdata = true;
00114
        m_Logger->error("PROBLEM SC TRAILER NOT FOUND ");
00115
00116 }
00117
00118 Buffer RawBufferNavigator::getEndOfAllData()
00119 {
00120
      setSCBuffer();
       if(hasSlowControlData() && !m_BadSCdata) { return Buffer(&(m_SCbuffer.begin()[m_SCbuffer.size()]),
     getSizeAfterDIFPtr() - 3 - m_SCbuffer.size()); }
00122 else
00123
        return Buffer(&(getDIFBufferStart()[getEndOfDIFData()]), getSizeAfterDIFPtr() - 3); // remove the
     \ensuremath{\text{2}} bytes for CRC and the DIF trailer
00124 }
```

5.43 libs/core/src/Version.cc File Reference

```
#include "Version.h"
```

5.43.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Version.cc.

5.44 Version.cc

```
00001
00005 #include "Version.h"
00007 const static Version streamout_version;
80000
00009 std::uint8_t Version::getMajor() { return major; }
00010
00011 std::uint8_t Version::getMinor() { return minor; }
00012
00013 std::uint8_t Version::getPatch() { return patch; }
00014
00015 std::string Version::getPreRelease()
00016 {
00017
        switch(prerelease_type)
00018
00019
          case semver::prerelease::alpha: return "alpha";
00020
          case semver::prerelease::beta: return "beta";
          case semver::prerelease::rc: return "rc";
case semver::prerelease::none: return "";
default: return "";
00021
00022
00023
00024
00025 }
00026
00027 std::uint8_t Version::getPreReleaseNumber() {    return prerelease_number; }
```

5.45 libs/interface/Dump/include/textDump.h File Reference

```
#include "DIFPtr.h"
#include "Interface.h"
#include "spdlog/sinks/stdout_color_sinks.h"
#include <memory>
#include <spdlog/logger.h>
```

Classes

· class textDump

5.45.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file textDump.h.

5.46 textDump.h

Go to the documentation of this file.

```
00005 #pragma once
00006
00007 #include "DIFPtr.h"
00008 #include "Interface.h"
00009 #include "spdlog/sinks/stdout_color_sinks.h"
00010
00011 #include <memory>
00012 #include <spdlog/logger.h>
00013
00014 class textDump : public InterfaceWriter
00015 {
00016 public:
00017
        textDump();
00018
       void
                                          processDIF(const DIFPtr&);
00019
        void
00020
                                          processFrame(const DIFPtr&, uint32_t frameIndex);
       void
                                          processPadInFrame(const DIFPtr&, uint32_t frameIndex, uint32_t
00021
       void
     channelIndex);
00022 void
                                          processSlowControl(Buffer);
00023
        void
                                           end();
00024 std::shared_ptr<spdlog::logger>& print() { return m_InternalLogger; }
00025
                                          setLevel(const spdlog::level::level_enum& level) {
        void
     m_InternalLogger->set_level(level); }
00026
00027 private:
,, This class the interface.
        // This class is a dumb class to print on terminal so we need the logger + the standard one given by
       std::shared_ptr<spdlog::logger> m_InternalLogger{nullptr};
00030 };
```

5.47 libs/interface/Dump/src/textDump.cc File Reference

```
#include "textDump.h"
#include "DIFPtr.h"
```

5.48 textDump.cc 95

5.47.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file textDump.cc.

5.48 textDump.cc

Go to the documentation of this file.

```
00001
00005 #include "textDump.h"
00006
00007 #include "DIFPtr.h"
00009 textDump::textDump() : InterfaceWriter("textDump", "1.0.0")
00010 {
00011
        m_InternalLogger = std::make_shared<spdlog::logger>("textDump",
std::make_shared<spdlog::sinks::stdout_color_sink_mt>());
00012 m_InternalLogger->set_level(spdlog::level::trace);
        addCompatibility("RawdataReader", ">=1.0.0");
addCompatibility("DIFdataExample", ">=1.0.0");
00014
00015 }
00016
00017 void textDump::start() { print()->info("Will dump bunch of DIF data"); }
00018
00019 void textDump::processDIF(const DIFPtr& d) { print()->info("DIF_ID : {}, DTC : {}, GTC : {}, DIF BCID
      {}, Absolute BCID: {}, Nbr frames {}", d.getDIFid(), d.getDTC(), d.getGTC(), d.getBCID(),
      d.getAbsoluteBCID(), d.getNumberOfFrames()); }
00020
00021 void textDump::processFrame(const DIFPtr& d, uint32_t frameIndex)
00022 {
        print()->info("\tDisplaying frame number {}: ASIC ID {}, Frame BCID {}, Frame Time To Trigger
00023
      (a.k.a timestamp) is {}", frameIndex, d.getASICid(frameIndex), d.getFrameBCID(frameIndex),
      d.getFrameTimeToTrigger(frameIndex));
00024 }
00025
00026 void textDump::processPadInFrame(const DIFPtr& d, uint32_t frameIndex, uint32_t channelIndex)
00027 {
00028
         if(d.getThresholdStatus(frameIndex, channelIndex) > 0) { print()->info("\t\tChannel {}, Threshold
      {}", channelIndex, d.getThresholdStatus(frameIndex, channelIndex)); }
00029 }
00030
00031 void textDump::processSlowControl(Buffer) { print()->error("textDump::processSlowControl not
      implemented vet."); }
00033 void textDump::end() { print()->info("textDump end of report"); }
```

5.49 libs/interface/LCIO/include/LCIOWriter.h File Reference

5.49.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file LCIOWriter.h.

5.50 LCIOWriter.h

```
00001
00005 #pragma once
```

5.51 libs/interface/LCIO/src/LCIOWriter.cc File Reference

5.51.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file LCIOWriter.cc.

5.52 LCIOWriter.cc

Go to the documentation of this file.

5.53 libs/interface/RawDataReader/include/RawdataReader.h File Reference

```
#include "Interface.h"
#include <array>
#include <cstdint>
#include <fstream>
#include <string>
#include <vector>
```

Classes

class RawdataReader

5.53.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file RawdataReader.h.

5.54 RawdataReader.h 97

5.54 RawdataReader.h

```
Go to the documentation of this file.
```

```
00005 #pragma once
00006
00007 #include "Interface.h"
80000
00009 #include <arrav>
00010 #include <cstdint>
00011 #include <fstream>
00012 #include <string>
00013 #include <vector>
00014
00015 class Buffer;
00016
00017 class RawdataReader : public InterfaceReader
00018 {
00019 public:
00020
        explicit RawdataReader(const char* fileName);
00021
        void start();
        end();
float     getFileSize();
void     openFile(const std::string& fileName);
void     closeFile();
bool     nextEvent();
bool     nextDIFPuffor();
00022
00023
00024
00025
00026
00027
                        nextDIFbuffer();
        const Buffer& getBuffer();
virtual ~RawdataReader() { closeFile(); }
00028
00029
00030
        static void setDefaultBufferSize(const std::size_t& size);
00031
00032 private:
uncompress();
        std::ifstream
                              m_FileStream;
00035
                               setFileSize(const std::size t& size);
        void
        static std::size_t m_BufferSize;
                       __urrerSize;
m_FileSize{0};
m_NumberOffTT
00037
        std::size_t
00038
        std::uint32_t
                               m_NumberOfDIF{0};
00039
        std::uint32_t
                              m_EventNumber{0};
        std::vector<bit8_t> m_buf;
00040
00041
        std::string
                              m_Filename;
00042 };
```

5.55 libs/interface/RawDataReader/src/RawdataReader.cc File Reference

```
#include "RawdataReader.h"
#include <cstdint>
#include <cstring>
#include <stdexcept>
#include <zlib.h>
```

5.55.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file RawdataReader.cc.

5.56 RawdataReader.cc

```
00004 #include "RawdataReader.h"
00005
00006 #include <cstdint>
00007 #include <cstring>
00008 #include <stdexcept>
00009 #include <zlib.h>
00010
00012 std::size_t RawdataReader::m_BufferSize = 0x100000;
00013
00014 void RawdataReader::setDefaultBufferSize(const std::size t& size) { m BufferSize = size; }
00015
00016 RawdataReader::RawdataReader(const char* fileName) : InterfaceReader("RawdataReader", "1.0.0")
00017 {
      m_buf.reserve(m_BufferSize);
00018
00019
       m_Filename = fileName;
00020 }
00021
00022 void RawdataReader::start() { openFile(m_Filename); }
00024 void RawdataReader::end() { closeFile(); }
00025
00026 void RawdataReader::uncompress()
00027 {
00028
       static const std::size_t size_buffer{0x20000};
00029
       std::size_t
                                shift{3 * sizeof(std::uint32_t) + sizeof(std::uint64_t)};
00030
       static bit8_t
                                obuf[size_buffer];
00031
       unsigned long
                                size_buffer_end{0x20000}; // NOLINT(runtime/int)
00032
       std::int8_t
                               rc = ::uncompress(obuf, &size_buffer_end, &m_Buffer[shift], m_Buffer.size()
     - shift);
00033
       switch(rc)
00034
00035
         case Z_OK: break;
00036
        default: throw "decompress error"; break;
00037
00038
       memcpy(&m_Buffer[shift], obuf, size_buffer_end);
00039
       m Buffer.setSize(size buffer end + shift);
00040 }
00041
00042 void RawdataReader::closeFile()
00043 {
00044
00045
       {
00046
         if(m FileStream.is open()) m FileStream.close();
00047
00048
       catch(const std::ios_base::failure& e)
00049
00050
         log()->error("Caught an ios_base::failure in closeFile : {} {}", e.what(), e.code().value());
00051
         throw;
00052
00053 }
00054
00055 void RawdataReader::openFile(const std::string& fileName)
00056 {
00057
00058
       {
00059
         m_FileStream.rdbuf()->pubsetbuf(0, 0);
00060
         m_FileStream.exceptions(std::ifstream::failbit | std::ifstream::badbit);
         m_FileStream.open(fileName.c_str(), std::ios::in | std::ios::binary | std::ios::ate); // Start at
00061
     the end to directly calculate the size of the file then come back to beginning
00062
         m_FileStream.rdbuf()->pubsetbuf(0, 0);
00063
          if (m FileStream.is open())
00064
00065
           setFileSize(m_FileStream.tellg());
00066
           m_FileStream.seekg(0, std::ios::beg);
00067
00068
00069
       catch (const std::ios base::failure& e)
00070
00071
         log()->error("Caught an ios_base::failure in openFile : {}", e.what());
00072
00073
00074 }
00075
00076 bool RawdataReader::nextEvent()
00077 {
00078
00079
08000
         00081
         m_FileStream.read(reinterpret_cast<char*>(&m_NumberOfDIF), sizeof(std::uint32_t));
00082
       1
00083
       catch(const std::ios_base::failure& e)
00084
       {
```

```
00085
         return false;
00086
00087
       return true;
00088 }
00089
00090 bool RawdataReader::nextDIFbuffer()
00091 {
00092
00093
00094
         static int DIF_processed{0};
         if(DIF_processed >= m_NumberOfDIF)
00095
00096
00097
           DIF_processed = 0;
          return false;
00098
00099
00100
         else
00101
00102
           DIF processed++;
00103
           std::uint32_t bsize{0};
00104
           m_FileStream.read(reinterpret_cast<char*>(&bsize), sizeof(std::uint32_t));
00105
           m_FileStream.read(reinterpret_cast<char*>(&m_buf[0]), bsize);
00106
           m_Buffer = Buffer(m_buf);
00107
         }
00108
00109
       catch(const std::ios_base::failure& e)
00110
00111
          log()->error("Caught an ios_base::failure in openFile : {}", e.what());
00112
        return false;
00113
00114
       return true;
00115 }
00116
00117 const Buffer& RawdataReader::getBuffer()
00118 {
00119
       uncompress();
00120
       return m_Buffer;
00121 }
00123 void RawdataReader::setFileSize(const std::size_t& size) { m_FileSize = size; }
00125 float RawdataReader::getFileSize() { return m_FileSize; }
```

5.57 libs/interface/ROOT/include/DIF.h File Reference

```
#include "Hit.h"
#include <TObject.h>
#include <cstdint>
#include <map>
#include <vector>
```

Classes

• class DIF

Typedefs

• using Hits_const_iterator = std::vector< Hit >::const_iterator

5.57.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file DIF.h.

5.57.2 Typedef Documentation

5.57.2.1 Hits_const_iterator using Hits_const_iterator = std::vector<Hit>::const_iterator

Definition at line 14 of file DIF.h.

5.58 DIF.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include "Hit.h"
80000
00009 #include <TObject.h>
00010 #include <cstdint>
00011 #include <map>
00012 #include <vector>
00014 using Hits_const_iterator = std::vector<Hit>::const_iterator;
00015
00016 class DIF : public TObject
00017
00018 public:
00019
       void
                                          clear();
00020
                                          addHit(const Hit&);
        void
00021
        void
                                          setID(const std::uint8_t&);
00022
       std::uint8_t
                                          getID() const;
00023
                                         setDTC(const std::uint32_t&);
getDTC() const;
        void
00024
       std::uint32 t
00025
                                          setGTC(const std::uint32_t&);
        void
00026
        std::uint32_t
                                          getGTC() const;
00027
        void
                                          setDIFBCID(const std::uint32_t&);
                                          getDIFBCID() const;
setAbsoluteBCID(const std::uint64_t&);
00028
        std::uint32_t
00029
        void
00030
                                          getAbsoluteBCID() const;
       std::uint64 t
00031
        std::vector<Hit>::const_iterator cbegin() const;
00032
       std::vector<Hit>::const_iterator cend() const;
00033
00034 private:
00035 std::uint8_t
                         m_ID{0};
                         m_DTC{0};
00036
       std::uint32 t
00037
       std::uint32_t
                         m_GTC{0};
00038
       std::uint32_t
                         m_DIFBCID{0};
00039
       std::uint64_t
                         m_AbsoluteBCID{0};
       std::vector<Hit> m_Hits;
00040
00041
       ClassDef(DIF, 1);
00042 };
```

5.59 libs/interface/ROOT/include/DIFLinkDef.h File Reference

#include <vector>

5.59.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file DIFLinkDef.h.

5.60 DIFLinkDef.h

5.60 DIFLinkDef.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006 #include <vector>
00007
00008 #ifdef __CLING__
00009 #pragma link C++ class DIF;
00010 #pragma link C++ class Hit;
00011 #pragma link C++ class std::vector < Hit>;
00012 #endif
```

5.61 libs/interface/ROOT/include/Event.h File Reference

```
#include "DIF.h"
#include <TObject.h>
#include <cstdint>
#include <map>
```

Classes

class Event

Typedefs

• using DIFs_const_iterator = std::map< std::uint8_t, DIF >::const_iterator

5.61.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Event.h.

5.61.2 Typedef Documentation

```
5.61.2.1 DIFs_const_iterator using DIFs_const_iterator = std::map<std::uint8_t, DIF>::const_← iterator
```

Definition at line 13 of file Event.h.

5.62 Event.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include "DIF.h"
80000
00009 #include <TObject.h>
00010 #include <cstdint>
00011 #include <map>
00012
00013 using DIFs_const_iterator = std::map<std::uint8_t, DIF>::const_iterator;
00014
00015 class Event : public TObject
00016 {
00017 public:
00018 void
00019 void
                                                               clear();
                                                               addDIF(const DIF& dif);
00020 std::map<std::uint8_t, DIF>::const_iterator cbegin() const;
00021 std::map<std::uint8_t, DIF>::const_iterator cend() const;
00022
00023 private:
00024 std::map<std::uint8_t, DIF> DIFs;
00025 ClassDef(Event, 1);
00026 };
```

5.63 libs/interface/ROOT/include/EventLinkDef.h File Reference

```
#include <cstdint>
#include <map>
#include <vector>
```

5.63.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file EventLinkDef.h.

5.64 EventLinkDef.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006 #include <cstdint>
00007 #include <map>
00008 #include <vector>
00009 #ifdef __CLING__
00010 #pragma link C++ class DIF;
00011 #pragma link C++ class std::vector < DIF>;
00012 #pragma link C++ class std::vector < Hit>;
00013 #pragma link C++ class std::vector < Hit>;
00014 #pragma link C++ class Event;
00015 #pragma link C++ class std::vector < Event>;
00016 #pragma link C++ class std::vector < Std::vector < Event>;
00017 #pragma link C++ class std::vector < Std::vector < Event>;
00017 #pragma link C++ class std::vector < Std
```

5.65 libs/interface/ROOT/include/Hit.h File Reference

```
#include <TObject.h>
#include <cstdint>
```

5.66 Hit.h 103

Classes

· class Hit

5.65.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Hit.h.

5.66 Hit.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006
00007 #include <TObject.h>
00008 #include <cstdint>
00009
00010 class Hit : public TObject
          void      clear();
void      setDIF(const std::uint8_t&);
void      setASIC(const std::uint8_t&);
void      setChannel(const std::uint8_t&);
void      setThreshold(const std::uint8_t&);
void      setDTC(const std::uint32_t&);
void      setGTC(const std::uint32_t&);
void      setDIFBCID(const std::uint32_t&);
void      setFrameBCID(const std::uint32_t&);
void      setTimestamp(const std::uint32_t&)
void
00011 {
00012 public:
00013
00015
00016
00017
00018
00019
00020
                              setFrameBCID(const std::uint32_t&);
setTimestamp(const std::uint32_t&);
00021
00022
00023
           void
                                 setAbsoluteBCID(const std::uint64_t&);
           std::uint8_t
std::uint8_t
std::uint8_t
std::uint8_t
std::uint8_t
std::uint8_t
std::uint8_t
00024
00025
00027
00028
           std::uint32_t getDTC() const;
00029
           std::uint32_t getGTC() const;
           std::uint32_t getDIFBCID() const;
std::uint32_t getFrameBCID() const;
00030
00031
00032 std::uint32_t getTimestamp() const;
00033
           std::uint64_t getAbsoluteBCID() const;
00034
00035 private:
00036 std::uint8_t m_DIF{0};
00037 std::uint8_t m_ASIC{0}
           std::uint8_t m_ASIC{0};
std::uint8_t m_Channel{0};
00038
00039
           std::uint8_t m_Threshold{0};
00040
           std::uint32_t m_DTC{0};
00041
           std::uint32_t m_GTC{0};
00042
           std::uint32_t m_DIFBCID{0};
00043
           std::uint32_t m_FrameBCID{0};
00044
           std::uint32_t m_Timestamp{0};
00045
            std::uint64_t m_AbsoluteBCID{0};
00046
          ClassDef(Hit, 1);
00047 };
```

5.67 libs/interface/ROOT/include/HitLinkDef.h File Reference

5.67.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file HitLinkDef.h.

5.68 HitLinkDef.h

Go to the documentation of this file.

```
00001
00005 #pragma once
00006 #ifdef __CLING__
00007 #pragma link C++ class Hit;
00008 #endif
```

5.69 libs/interface/ROOT/include/ROOTWriter.h File Reference

```
#include "Buffer.h"
#include "DIFPtr.h"
#include "Event.h"
#include "Interface.h"
#include <TFile.h>
#include <TTree.h>
#include <string>
#include <vector>
```

Classes

• class ROOTWriter

5.70 ROOTWriter.h

```
00006 #pragma once
00007
00008 #include "Buffer.h"
00009 #include "DIFPtr.h"
00010 #include "Event.h"
00011 #include "Interface.h"
00012
00013 #include <TFile.h>
00014 #include <TTree.h>
00015 #include <string>
00016 #include <vector>
00017
00018 class ROOTWriter : public InterfaceWriter
00019 {
00020 public:
00021 ROOTWriter();
00022
00023
        void setFilename(const std::string&);
00024
       void start();
00025
00026 void processDIF(const DIFPtr&);
00027 void processFrame(const DIFPtr&, const std::uint32_t& frameIndex);
00028 void processPadInFrame(const DIFPtr&, const std::uint32_t& frameIndex, const std::uint32_t&
     channelIndex);
00029 void processSlowControl(const Buffer&) { ; }
00030 void end();
00031
00032
        virtual void startEvent();
00033
        virtual void endEvent();
00034
        virtual void startDIF();
00035
        virtual void endDIF();
00036
        virtual void startFrame();
00037
        virtual void endFrame();
00038
        virtual void startPad();
00039
       virtual void endPad();
00040
00041 private:
00042 TFile*
                   m_File{nullptr};
00043
        TTree*
                    m_Tree{nullptr};
00044
        Event*
                     m_Event{nullptr};
00045
        DTF*
                     m_DIF{nullptr};
00046
       Hit*
                     m Hit {nullptr};
00047 std::string m_Filename;
00048 };
```

5.71 libs/interface/ROOT/src/DIF.cc File Reference

```
#include "DIF.h"
#include <cstdint>
```

5.71.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file DIF.cc.

5.72 DIF.cc

Go to the documentation of this file.

```
00006 #include "DIF.h"
00007
00008 #include <cstdint>
00009
00010 void DIF::addHit(const Hit& hit) { m_Hits.push_back(hit); }
00011
00012 void DIF::setID(const std::uint8_t& id) { m_ID = id; }
00013
00014 std::uint8_t DIF::getID()const { return m_ID; }
00015
00016 void DIF::setDTC(const std::uint32_t& dtc) { m_DTC = dtc; }
00017
00018 std::uint32_t DIF::getDTC()const { return m_DTC; }
00019
00020 void DIF::setGTC(const std::uint32_t& gtc) { m_GTC = gtc; }
00021
00022 std::uint32_t DIF::getGTC()const { return m_GTC; }
00023
00024 void DIF::setDIFBCID(const std::uint32_t& difbcid) { m_DIFBCID = difbcid; }
00025
00026 std::uint32_t DIF::getDIFBCID()const { return m_DIFBCID; }
00027
00028 void DIF::setAbsoluteBCID(const std::uint64_t& absolutebcid) { m_AbsoluteBCID = absolutebcid; }
00029
00030 std::uint64_t DIF::getAbsoluteBCID()const { return m_AbsoluteBCID; }
00031
00032 std::vector<Hit>::const_iterator DIF::cbegin()const { return m_Hits.cbegin(); }
00033
00034 std::vector<Hit>::const_iterator DIF::cend()const { return m_Hits.cend(); }
00036 void DIF::clear() { m_Hits.clear(); }
```

5.73 libs/interface/ROOT/src/Event.cc File Reference

```
#include "Event.h"
```

5.73.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Event.cc.

5.74 Event.cc

Go to the documentation of this file.

```
00001
00006 #include "Event.h"
00007
00008 void Event::clear() { DIFs.clear(); }
00009
00010 void Event::addDIF(const DIF& dif) { DIFs[dif.getID()] = dif; }
00011
00012 std::map<std::uint8_t, DIF>::const_iterator Event::cbegin()const { return DIFs.cbegin(); }
00013
00014 std::map<std::uint8_t, DIF>::const_iterator Event::cend()const { return DIFs.cend(); }
```

5.75 libs/interface/ROOT/src/Hit.cc File Reference

```
#include "Hit.h"
```

5.75.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file Hit.cc.

5.76 Hit.cc

```
00001
00006 #include "Hit.h"
00007 void Hit::clear()
00008 {
00009
       m DIF
                       = 0;
                       = 0;
00010
       m_ASIC
00011
       m_Channel
00012
        {\tt m\_Threshold}
                       = 0;
00013
       m_DTC
                       = 0:
       m_GTC
00014
                       = 0;
       m_DIFBCID
00015
                       = 0;
00016
       m_FrameBCID
                      = 0;
00017
        m_Timestamp
       m_AbsoluteBCID = 0;
00018
00019 }
00020
00021 void Hit::setDIF(const std::uint8_t& dif) { m_DIF = dif; }
00022
00023 void Hit::setASIC(const std::uint8_t& asic) { m_ASIC = asic; }
00024
00025 void Hit::setChannel(const std::uint8_t& channel) { m_Channel = channel; }
00026
00027 void Hit::setThreshold(const std::uint8_t& threshold) { m_Threshold = threshold; }
00028
00029 void Hit::setDTC(const std::uint32_t& dtc) { m_DTC = dtc; }
00030
00031 void Hit::setGTC(const std::uint32_t& gtc) { m_GTC = gtc; }
00032
00033 void Hit::setDIFBCID(const std::uint32_t& difbcid) { m_DIFBCID = difbcid; }
00034
00035 void Hit::setFrameBCID(const std::uint32_t& framebcid) { m_FrameBCID = framebcid; }
00036
00037 void Hit::setTimestamp(const std::uint32_t& timestamp) { m_Timestamp = timestamp; }
00038
00039 void Hit::setAbsoluteBCID(const std::uint64_t& absolutebcid) { m_AbsoluteBCID = absolutebcid; }
00040
00041 std::uint8_t Hit::getDIFid()const { return m_DIF; }
00042
```

```
00043 std::uint8_t Hit::getASICid()const { return m_ASIC; }
00044
00045 std::uint8_t Hit::getChannel()const { return m_Channel; }
00046
00047 std::uint8_t Hit::getThreshold()const { return m_Threshold; }
00048
00049 std::uint32_t Hit::getDTC()const { return m_DTC; }
00050
00051 std::uint32_t Hit::getGTC()const { return m_GTC; }
00052
00053 std::uint32_t Hit::getDIFBCID()const { return m_DIFBCID; }
00054
00055 std::uint32_t Hit::getFrameBCID()const { return m_FrameBCID; }
00056
00057 std::uint32_t Hit::getTimestamp()const { return m_Timestamp; }
00058
00059 std::uint64_t Hit::getAbsoluteBCID()const { return m_AbsoluteBCID; }
```

5.77 libs/interface/ROOT/src/ROOTWriter.cc File Reference

```
#include "ROOTWriter.h"
```

5.77.1 Detailed Description

Copyright

2022 G.Grenier F.Lagarde

Definition in file ROOTWriter.cc.

5.78 ROOTWriter.cc

```
00001
00006 #include "ROOTWriter.h"
00007
00008 void ROOTWriter::setFilename(const std::string& filename) { m_Filename = filename; }
00009
00010 ROOTWriter::ROOTWriter() : InterfaceWriter("ROOTWriter", "1.0.0") { addCompatibility("RawdataReader",
      ">=1.0.0"); }
00011
00012 void ROOTWriter::start()
00013 {
        m_File = TFile::Open(m_Filename.c_str(), "RECREATE", m_Filename.c_str(),
00014
     ROOT::CompressionSettings(ROOT::kZLIB, 5));
00015 m_Tree = new TTree("RawData", "Raw SDHCAL data tree");
00016
       m_Tree->Branch("Events", &m_Event, 512000, 99);
00017 }
00018
00019 void ROOTWriter::end()
00020 {
00021
        if (m_Tree) m_Tree->Write();
00022
        if (m_File)
00023
00024
         m_File->Write();
00025
         m_File->Close();
00026
00027
       if (m_File) delete m_File;
00028 }
00029
00030 void ROOTWriter::processDIF(const DIFPtr& d)
00031 {
00032
       m_DIF->setID(d.getDIFid());
00033
        m_DIF->setDTC(d.getDTC());
00034
        m_DIF->setGTC(d.getGTC());
        m_DIF->setDIFBCID(d.getBCID());
00035
00036
       m_DIF->setAbsoluteBCID(d.getAbsoluteBCID());
00037 }
00038
```

```
00039 void ROOTWriter::processFrame(const DIFPtr& d, const std::uint32_t& frameIndex)
00040 {
00041
        m_Hit->setDIF(d.getDIFid());
00042
        m_Hit->setASIC(d.getASICid(frameIndex));
        m_Hit->setDTC(d.getDTC());
00043
        m_Hit->setGTC(d.getGTC());
00044
        m_Hit->setDIFBCID(d.getBCID());
00046
        m_Hit->setAbsoluteBCID(d.getAbsoluteBCID());
00047
        m_Hit->setFrameBCID(d.getFrameBCID(frameIndex));
00048
        m_Hit->setTimestamp(d.getFrameTimeToTrigger(frameIndex));
00049 }
00050
00051 void ROOTWriter::processPadInFrame(const DIFPtr& d, const std::uint32_t& frameIndex, const
      std::uint32_t& channelIndex)
00052 {
00053
        m_Hit->setChannel(channelIndex);
       \verb|m_Hit->setThreshold(static_cast<std::uint8_t>(d.getThresholdStatus(frameIndex, channelIndex)))||
00054
00055 }
00056
00057 void ROOTWriter::startEvent()
00058 {
00059
       m_Event = new Event();
00060
       // m_Event->clear();
00061 }
00062
00063 void ROOTWriter::endEvent()
00064 {
00065 m_Tree->Fill();
00066
       if (m_Event) delete m_Event;
00067 }
00068
00069 void ROOTWriter::startDIF()
00070 {
00071
       m_DIF = new DIF();
00072
       // m_DIF->clear();
00073 }
00074
00075 void ROOTWriter::endDIF()
00076 {
00077 m_Event->addDIF(*m_DIF);
00078 delete m_DIF;
00079 }
00080
00081 void ROOTWriter::startFrame()
00082 {
00083
       m_Hit = new Hit();
00084 // m_Hit->clear();
00085 }
00086
00087 void ROOTWriter::endFrame()
00088 {
00089 m_DIF->addHit(*m_Hit);
00090
       delete m_Hit;
00091 }
00092
00093 void ROOTWriter::startPad() {}
00094
00095 void ROOTWriter::endPad() {}
```