

GAZEBO

2022

INFO 802

Master Advanced Mechatronics

Luc Marechal








Gazebo Turtlebot3








Robotic simulation scenarios









More Info and tutorials http://gazebosim.org/tutorials http://wiki.ros.org/rviz/Tutorials







Gazebo – TurtleBot3 Simulation

- A multi-robot simulator
- Capable of simulating a population of robots, sensors and objects, in 3D
- Includes an accurate simulation of rigid-body physics and generates realistic sensor feedback
- Allows code designed to operate a physical robot to be executed in an artificial environment
- Gazebo is under active development at the OSRF (Open Source Robotics Foundation)



More Info and tutorials http://gazebosim.org/tutorials







Gazebo and TurtleBot3

- Read docs on Gazebo (and Rviz as well if you want to have a larger view of ROS capabilities).
- Launch Gazebo with the turtlebot_world environment (the turtlebot_house might be too heavy for your computer but you can try) and:
 - the Waffle robot
 - the Burger robot
- What are the differences for these robots?
- Are they using the same topics on Gazebo? Is there any differences?
- Move manually the TurtleBot3 using teleop_key
- Show the rqt graph to see the topics and nodes







Gazebo – TurtleBot3 Simulation

Launch Gazebo

> roslaunch turtlebot3_gazebo turtlebot3_autorace.launch


(also try : turtlebot3 house.launch)

Display the image from the robot

- > rostopic list # check where the image is published
- > rosrun image_view image_view image:=/camera/rgb/image_raw

Move the robot with keyboard

> roslaunch turtlebot3_teleop turtlebot3_teleop_key.launch



```
Control Your Turtlebot!

Moving around:

u i o
j k l
m , .

q/z : increase/decrease max speeds by 10%
w/x : increase/decrease only linear speed by 10%
e/c : increase/decrease only angular speed by 10%
space key, k : force stop
anything else : stop smoothly

CTRL-C to quit

currently: speed 0.2 turn 1
```







Gazebo – TurtleBot3 Simulation

Node and topic

```
> rqt_graph
                                                                               /joint_states
                                                                                 /odom
                                         /rpms
           /turtlebot3 lds
                                                                             /cmd_vel_rc100
                                         /scan
     /turtlebot3_teleop_keyboard
                                       /cmd_vel
                                                       /turtlebot3 core
                                                                                  /imu
                                                                                   /tf
                                                                               /diagnostics
                                                                              /sensor state
```

```
luc@USMB:~$ rostopic list
/camera/camera_info
/camera/image
camera/image/compressed
/camera/image/compressed/parameter_descriptions
/camera/image/compressed/parameter_updates
/camera/image/compressedDepth
/camera/image/compressedDepth/parameter descriptions
/camera/image/compressedDepth/parameter_updates
camera/image/theora
/camera/image/theora/parameter_descriptions
/camera/image/theora/parameter_updates
/camera/parameter descriptions
/camera/parameter_updates
/clock
/cmd vel
/gazebo/link_states
/gazebo/model states
/gazebo/parameter_descriptions
/gazebo/parameter_updates
/gazebo/set_link_state
/gazebo/set_model_state
/imu
/joint_states
/odom
/rosout
/rosout_agg
/scan
/tf
```







Gazebo - TurtleBot3 Simulation

Odometry

To make a TurtleBot move in ROS we need to publish:

Twist messages to the topic /cmd_vel

 To get a TurtleBot position and orientation in ROS we need to subscribe:

to the topic /odom and read Odometry message

 Odometry is part of nav_msg message package (don't forget to add import nav_msg.msg in your code header)

> rosmsg show Odometry

```
luc@USMB:~$ rosmsg show Odometry
[nav_msgs/Odometry]:
std_msgs/Header header
 uint32 seq
 time stamp
 string frame_id
string child_frame_id
geometry msgs/PoseWithCovariance pose
 geometry_msgs/Pose pose
   geometry_msgs/Point position
     float64 x
     float64 v
     float64 z
   geometry_msgs/Quaternion orientation
     float64 x
     float64 y
     float64 z
     float64 w
 float64[36] covariance
geometry msgs/TwistWithCovariance twist
 geometry_msgs/Twist twist
   geometry_msgs/Vector3 linear
     float64 x
     float64 y
     float64 z
   geometry_msgs/Vector3 angular
     float64 x
     float64 y
     float64 z
 float64[36] covariance
```







Gazebo and TurtleBot3

- Move TurtleBot3 Waffle using publisher node
 - Create your own package named Tutorial_TurtleBot
 (Recall: New packages must be created in the src folder from catkin_ws)
 - Create your own Python script for moving TurtleBot3 with two arguments Linear velocity and Angular Velocity
- Getting laser data of the Waffle using ROS commands and Python script
 - Create a new node to subscribe to the topic scan and get the information from the laser sensor.
 - Named it get laser data.py
 - We want to get the value of the scanner in front of the robot ----> msg.range[0]

LaserScan

https://youtu.be/tEayzulupxE

https://youtu.be/kze3Z8rTkZo







move_turtlebot (Python)

move turtlebot.py

```
#! /usr/bin/python3
import rospy
from geometry msgs.msg import Twist
import sys
def move turtlebot(lin vel, ang vel):
    rospy.init node('move turtlebot', anonymous=False)
    pub = rospy.Publisher('/cmd_vel_mux/input/teleop', Twist, queue_size=10)
    rate = rospy.Rate(1) # 1hz
   vel = Twist()
    while not rospy.is shutdown():
        vel.linear.x = lin vel
        vel.angular.z = ang vel
        pub.publish(vel)
        rate.sleep()
if name == ' main ':
    try:
        move_turtlebot(float(sys.argv[1]),float(sys.argv[2]))
    except rospy.ROSInterruptException:
        pass
```





Getting laser data

- Laser data is published on the topic scan. Therefore, to access this data
 we have to subscribe to this topic, obtain the required data and use it for
 our desired application.
- Obtain information about the topic (in a separate window):

```
$ rostopic list
$ rostopic info scan
$ rosmsg show LaserScan
$ rostopic echo scan
```





http://docs.ros.org/api/sensor_msgs/html/msg/LaserScan.html

Raw Message Definition

```
# Single scan from a planar laser range-finder
# If you have another ranging device with different behavior (e.g. a sonar
# array), please find or create a different message, since applications
# will make fairly laser-specific assumptions about this data
                         # timestamp in the header is the acquisition time of
Header header
                         # the first ray in the scan.
                         # in frame frame id, angles are measured around
                         # the positive Z axis (counterclockwise, if Z is up)
                         # with zero angle being forward along the x axis
float32 angle min
                         # start angle of the scan [rad]
float32 angle max
                        # end angle of the scan [rad]
float32 angle increment # angular distance between measurements [rad]
                        # time between measurements [seconds] - if your scanner
float32 time increment
                         # is moving, this will be used in interpolating position
                         # of 3d points
float32 scan time
                         # time between scans [seconds]
float32 range min
                         # minimum range value [m]
float32 range max
                         # maximum range value [m]
                         # range data [m] (Note: values < range min or > range max should be discarded)
float32[] ranges
float32[] intensities
                         # intensity data [device-specific units]. If your
                         # device does not provide intensities, please leave
                         # the array empty.
```







```
std_msgs/Header header
float32 angle_min
float32 angle_max
float32 inrement
float32 scan_time
float32 range_min
float32 range_max
float32[] ranges
float32[] intensities

(distance in meter to an object)

ranges = [inf, 50.3, 2.1,...,2.6, 0.4,]

example : to get the 3<sup>rd</sup> value of the table In: ranges[3]

Out: 2.1
```

To retrieve the range to the nearest obstacle directly in front of the robot, we will select the middle element of the ranges array:

```
range_ahead = msg.ranges[len(msg.ranges)/2]
```

Or, to return the range of the closest obstacle detected by the scanner: closest_range = min(msg.ranges)





LaserScan

 Create a new node laser_data.py to subscribe to the topic scan and get the information from the Lidar sensor

```
#! /usr/bin/python3
import rospy
from sensor msgs.msg import LaserScan
import sys
def scan callback(msg):
    front_distance = int(len(msg.ranges)/2)
    range ahead = msg.ranges[front distance]
    rospy.loginfo("range ahead = %0.2f\n",range ahead)
def read laser():
    rospy.init node('Turtlebot3 Read Laser', anonymous=False)
    rospy.Subscriber('scan', LaserScan, scan callback)
    rospy.spin()
if __name__ == '__main__':
    read laser()
```







Getting laser data

 Create a new node to subscribe to the topic scan and get the information from the laser sensor.

```
gedit laser data.py
         #! /usr/bin/env python
         import rospy
         from sensor msgs.msg import LaserScan
         def callback(msg):
                                  # Define a function called 'callback' that receives a parameter named 'msg'
             print('======')
             print('s1 [0]')
                                  #value front-direction laser beam
             print msg.ranges[0]
                                  # print the distance to an obstacle in front of the robot. the sensor returns a vector
                                  # of 359 values, being the initial value the corresponding to the front of the robot
             print('s2 [90]')
             print msg.ranges[90]
             print('s3 [180]')
             print msg.ranges[180]
             print('s4 [270]')
             print msg.ranges[270]
             print('s5 [359]')
             print msg.ranges[359]
         rospy.init_node('laser_data')
                                                           # Initiate a Node called 'laser_data'
         sub = rospy.Subscriber('scan', LaserScan, callback) # Create a Subscriber to the laser/scan topci
         rospy.spin()
```





Gazebo and TurtleBot3

- Make robot avoid obstacles in front of him
 - Make the robot to stop when an obstacle in front of the robot is closer than 0.5 m

Hints:

- Create a node which is a publisher and subscriber at the same time.
- The node should subscribe to the topic scan and publish on the topic cmd_vel
- Use the code implemented in the previous scripts and put everything together.
- Use conditionals to make the robot behave as you want







Gazebo and TurtleBot3

You will find help in this Book in the Chapter 7 Wander-bot

