MemoryAllocationRoutines

5.3

Generated by Doxygen 1.8.14

Contents

1	Mod	lule Ind	ex		1
	1.1	Modul	es		1
2	Nam	nespace	Index		3
	2.1	Names	space List		3
3	Hier	archica	l Index		5
	3.1	Class	Hierarchy		5
4	Data	Struct	ure Index		7
	4.1	Data S	Structures		7
5	File	Index			9
	5.1	File Lis	st		9
6	Mod	lule Dod	cumentati	on	11
	6.1	Extern	ally-usable	e macros	11
		6.1.1	Detailed	Description	12
		6.1.2	Macro D	efinition Documentation	12
			6.1.2.1	JEOD_ALLOC_CLASS_ARRAY	12
			6.1.2.2	JEOD_ALLOC_CLASS_MULTI_POINTER_ARRAY	13
			6.1.2.3	JEOD_ALLOC_CLASS_OBJECT	13
			6.1.2.4	JEOD_ALLOC_CLASS_POINTER_ARRAY	14
			6.1.2.5	JEOD_ALLOC_PRIM_ARRAY	14
			6.1.2.6	JEOD_ALLOC_PRIM_OBJECT	15
			6.1.2.7	JEOD_DELETE_2D	16

ii CONTENTS

			6.1.2.8	JEOD_DELETE_ARRAY	16
			6.1.2.9	JEOD_DELETE_OBJECT	17
			6.1.2.10	JEOD_DEREGISTER_CHECKPOINTABLE	17
			6.1.2.11	JEOD_IS_ALLOCATED	18
			6.1.2.12	JEOD_MEMORY_DEBUG	18
			6.1.2.13	JEOD_REGISTER_CHECKPOINTABLE	19
			6.1.2.14	JEOD_REGISTER_CLASS	19
			6.1.2.15	JEOD_REGISTER_INCOMPLETE_CLASS	20
			6.1.2.16	JEOD_REGISTER_NONEXPORTED_CLASS	20
6.	2 I	nterna	l macros		21
	6	5.2.1	Detailed	Description	21
	6	5.2.2	Macro De	efinition Documentation	21
			6.2.2.1	JEOD_ALLOC_ARRAY_INTERNAL	21
			6.2.2.2	JEOD_ALLOC_OBJECT_FILL	22
			6.2.2.3	JEOD_ALLOC_OBJECT_INTERNAL	22
			6.2.2.4	JEOD_ALLOC_POINTER_FILL	22
			6.2.2.5	JEOD_ALLOC_PRIMITIVE_FILL	23
			6.2.2.6	JEOD_CREATE_MEMORY	23
			6.2.2.7	JEOD_DELETE_INTERNAL	23
6.	3 8	Suppor	t classes		25
	6	5.3.1	Detailed	Description	25
	6	5.3.2	Macro De	efinition Documentation	25
			6.3.2.1	STDC_LIMIT_MACROS	25
6.	4 N	Models			26
	6	5.4.1	Detailed	Description	26
6.	.5 L	Jtils .			27
	6	5.5.1	Detailed	Description	27
6.	6 N	Memor	y		28
	6	5.6.1	Detailed	Description	29

CONTENTS

7	Nam	espace	Documentation	31
	7.1	jeod N	amespace Reference	31
		7.1.1	Detailed Description	32
		7.1.2	Typedef Documentation	32
			7.1.2.1 AllocTable	33
			7.1.2.2 TypeTable	33
		7.1.3	Function Documentation	33
			7.1.3.1 jeod_alloc_construct_array()	33
			7.1.3.2 jeod_alloc_destruct_array()	34
			7.1.3.3 jeod_alloc_get_allocated_pointer()	34
		7.1.4	Variable Documentation	35
			7.1.4.1 MAGICO	35
			7.1.4.2 MAGIC1	35
8	Data	Struct	ure Documentation	37
	8.1	jeod::J	eodMemoryTypeDescriptor::attr Struct Reference	37
		8.1.1	Detailed Description	37
	8.2	jeod::J	eodAllocHelperAllocatedPointer< T, is_poly > Class Template Reference	37
		8.2.1	Detailed Description	37
		8.2.2	Member Function Documentation	38
			8.2.2.1 cast()	38
	8.3	jeod::J	eodAllocHelperAllocatedPointer< T, true > Class Template Reference	38
		8.3.1	Detailed Description	39
		8.3.2	Member Function Documentation	39
			8.3.2.1 cast()	39
	8.4	jeod::J	eodAllocHelperConstructDestruct< T, is_class, is_abstract > Class Template Reference	39
		8.4.1	Detailed Description	40
		8.4.2	Member Function Documentation	40
			8.4.2.1 construct()	40
			8.4.2.2 destruct()	41
	8.5	jeod::J	eodAllocHelperConstructDestruct< T, false, is_abstract > Class Template Reference	41

iv CONTENTS

	8.5.1	Detailed	Description	41
	8.5.2	Member	Function Documentation	42
		8.5.2.1	construct()	42
		8.5.2.2	destruct()	42
8.6	jeod::J	eodAllocH	elperConstructDestruct< T, true, false > Class Template Reference	43
	8.6.1	Detailed	Description	43
	8.6.2	Member	Function Documentation	43
		8.6.2.1	construct()	43
		8.6.2.2	destruct()	44
8.7	jeod::J	eodMemoi	ryltem Class Reference	44
	8.7.1	Detailed	Description	45
	8.7.2	Member	Enumeration Documentation	45
		8.7.2.1	Flags	45
	8.7.3	Construc	etor & Destructor Documentation	46
		8.7.3.1	JeodMemoryItem() [1/2]	46
		8.7.3.2	JeodMemoryItem() [2/2]	46
		8.7.3.3	~JeodMemoryItem()	47
	8.7.4	Member	Function Documentation	47
		8.7.4.1	construct_flags()	47
		8.7.4.2	get_alloc_index()	47
		8.7.4.3	get_checkpointed()	48
		8.7.4.4	get_descriptor_index()	48
		8.7.4.5	get_is_array()	49
		8.7.4.6	get_is_guarded()	49
		8.7.4.7	get_is_registered()	49
		8.7.4.8	get_nelems()	50
		8.7.4.9	get_placement_new()	50
		8.7.4.10	get_unique_id()	50
		8.7.4.11	is_structured_data()	51
		8.7.4.12	set_is_registered()	51

CONTENTS

		8.7.4.13	set_unique_id()	51
	8.7.5	Field Do	cumentation	52
		8.7.5.1	alloc_info_index	52
		8.7.5.2	descriptor_index_hi	52
		8.7.5.3	descriptor_index_lo	52
		8.7.5.4	flags	53
		8.7.5.5	nelems	53
		8.7.5.6	unique_id	53
8.8	jeod::J	eodMemo	ryManager Class Reference	54
	8.8.1	Detailed	Description	57
	8.8.2	Member	Typedef Documentation	59
		8.8.2.1	AllocTable	59
		8.8.2.2	TypeTable	59
	8.8.3	Member	Enumeration Documentation	60
		8.8.3.1	DebugLevel	60
		8.8.3.2	NameType	60
	8.8.4	Construc	ctor & Destructor Documentation	60
		8.8.4.1	JeodMemoryManager() [1/3]	60
		8.8.4.2	JeodMemoryManager() [2/3]	61
		8.8.4.3	JeodMemoryManager() [3/3]	61
		8.8.4.4	~JeodMemoryManager()	61
	8.8.5	Member	Function Documentation	61
		8.8.5.1	add_allocation_atomic()	62
		8.8.5.2	add_string_atomic()	62
		8.8.5.3	allocate_memory()	63
		8.8.5.4	begin_atomic_block()	64
		8.8.5.5	check_master()	64
		8.8.5.6	create_memory()	65
		8.8.5.7	create_memory_internal()	66
		8.8.5.8	delete_oldest_alloc_entry_atomic()	66

vi

8.8.5.9	deregister_container()	67
8.8.5.10	destroy_memory()	68
8.8.5.11	destroy_memory_internal()	68
8.8.5.12	end_atomic_block()	69
8.8.5.13	find_alloc_entry_atomic()	69
8.8.5.14	free_memory()	70
8.8.5.15	generate_shutdown_report()	71
8.8.5.16	get_alloc_id_atomic()	71
8.8.5.17	get_string_atomic()	72
8.8.5.18	get_type_descriptor() [1/2]	72
8.8.5.19	get_type_descriptor() [2/2]	73
8.8.5.20	get_type_descriptor_atomic() [1/2]	74
8.8.5.21	get_type_descriptor_atomic() [2/2]	74
8.8.5.22	get_type_descriptor_nolock()	75
8.8.5.23	get_type_entry_atomic() [1/2]	75
8.8.5.24	get_type_entry_atomic() [2/2]	76
8.8.5.25	get_type_index_nolock()	76
8.8.5.26	is_allocated()	77
8.8.5.27	is_allocated_internal()	78
8.8.5.28	is_table_empty()	78
8.8.5.29	operator=()	78
8.8.5.30	register_class()	79
8.8.5.31	register_container()	79
8.8.5.32	register_memory_internal()	80
8.8.5.33	reset_alloc_id_atomic()	81
8.8.5.34	restart_clear_memory()	81
8.8.5.35	restart_reallocate()	81
8.8.5.36	set_debug_level() [1/2]	82
8.8.5.37	set_debug_level() [2/2]	82
8.8.5.38	set_guard_enabled()	83

CONTENTS vii

		8.8.5.39	set_mode()	83
		8.8.5.40	set_mode_internal()	83
	8.8.6	Friends A	and Related Function Documentation	84
		8.8.6.1	init_attrjeodJeodMemoryManager	84
		8.8.6.2	InputProcessor	84
	8.8.7	Field Doo	cumentation	84
		8.8.7.1	alloc_table	84
		8.8.7.2	allocation_number	85
		8.8.7.3	cur_data_size	85
		8.8.7.4	debug_level	85
		8.8.7.5	guard_enabled	86
		8.8.7.6	Master	86
		8.8.7.7	max_data_size	86
		8.8.7.8	max_table_size	86
		8.8.7.9	mode	87
		8.8.7.10	mutex	87
		8.8.7.11	sim_interface	87
		8.8.7.12	string_table	87
		8.8.7.13	type_table	88
8.9	jeod::Je	eodMemor	ryReflectiveTable Class Reference	88
	8.9.1	Detailed	Description	89
	8.9.2	Construc	tor & Destructor Documentation	89
		8.9.2.1	JeodMemoryReflectiveTable() [1/2]	89
		8.9.2.2	JeodMemoryReflectiveTable() [2/2]	89
	8.9.3	Member	Function Documentation	89
		8.9.3.1	add() [1/2]	89
		8.9.3.2	add() [2/2]	89
		8.9.3.3	operator=()	90
8.10	jeod::Je	eodMemor	ryTable< ValueType > Class Template Reference	90
	8.10.1	Detailed	Description	91

viii CONTENTS

	8.10.2	Member Typedef Documentation	92
		8.10.2.1 const_value_iterator	92
		8.10.2.2 NameIndex	93
		8.10.2.3 ValueList	93
	8.10.3	Constructor & Destructor Documentation	93
		8.10.3.1 JeodMemoryTable() [1/2]	93
		8.10.3.2 ~JeodMemoryTable()	93
		8.10.3.3 JeodMemoryTable() [2/2]	94
	8.10.4	Member Function Documentation	94
		8.10.4.1 add()	94
		8.10.4.2 begin()	94
		8.10.4.3 clone()	95
		8.10.4.4 del()	95
		8.10.4.5 end()	95
		8.10.4.6 find()	96
		8.10.4.7 get()	96
		8.10.4.8 operator=()	97
	8.10.5	Field Documentation	97
		8.10.5.1 string_to_index	97
		8.10.5.2 value_list	97
8.11	jeod::Je	eodMemoryTableClonable< ValueType > Class Template Reference	98
	8.11.1	Detailed Description	98
	8.11.2	Constructor & Destructor Documentation	98
		8.11.2.1 JeodMemoryTableClonable() [1/2]	99
		8.11.2.2 JeodMemoryTableClonable() [2/2]	99
	8.11.3	Member Function Documentation	99
		8.11.3.1 clone()	99
		8.11.3.2 operator=()	99
8.12	jeod::Je	eodMemoryTableCopyable< ValueType > Class Template Reference	100
	8.12.1	Detailed Description	100

CONTENTS

	8.12.2	Constructor & Destructor Documentation	 100
		8.12.2.1 JeodMemoryTableCopyable() [1/2]	 101
		8.12.2.2 JeodMemoryTableCopyable() [2/2]	 101
	8.12.3	Member Function Documentation	 101
		8.12.3.1 clone()	 101
		8.12.3.2 operator=()	 101
8.13	jeod::Je	eodMemoryTypeDescriptor Class Reference	 102
	8.13.1	Detailed Description	 104
	8.13.2	Constructor & Destructor Documentation	 104
		8.13.2.1 JeodMemoryTypeDescriptor() [1/2]	 104
		8.13.2.2 ~JeodMemoryTypeDescriptor()	 104
		8.13.2.3 JeodMemoryTypeDescriptor() [2/2]	 105
	8.13.3	Member Function Documentation	 105
		8.13.3.1 base_type()	 105
		8.13.3.2 buffer_end() [1/2]	 105
		8.13.3.3 buffer_end() [2/2]	 106
		8.13.3.4 buffer_size() [1/2]	 106
		8.13.3.5 buffer_size() [2/2]	 106
		8.13.3.6 clone()	 107
		8.13.3.7 construct_array()	 107
		8.13.3.8 delete_array()	 107
		8.13.3.9 delete_object()	 108
		8.13.3.10 destroy_memory()	 108
		8.13.3.11 destruct_array()	 109
		8.13.3.12 dimensionality()	 109
		8.13.3.13 get_attr()	 109
		8.13.3.14 get_name()	 110
		8.13.3.15 get_register_instances()	 110
		8.13.3.16 get_size()	 110
		8.13.3.17 get_typeid()	 111

CONTENTS

		8.13.3.18 initialize_type_name()
		8.13.3.19 is_structured()
		8.13.3.20 most_derived_pointer() [1/2]
		8.13.3.21 most_derived_pointer() [2/2]
		8.13.3.22 operator=()
		8.13.3.23 pointer_dimension()
		8.13.3.24 set_check_for_registration_errors()
		8.13.3.25 type_spec()
	8.13.4	Field Documentation
		8.13.4.1 check_for_registration_errors
		8.13.4.2 name
		8.13.4.3 obj_id
		8.13.4.4 register_instances
		8.13.4.5 size
8.14	jeod::Je	eodMemoryTypeDescriptorDerived< Type > Class Template Reference
	8.14.1	Detailed Description
	8.14.2	Member Typedef Documentation
		8.14.2.1 Attributes
		8.14.2.2 TypeDescriptor
	8.14.3	Constructor & Destructor Documentation
		8.14.3.1 JeodMemoryTypeDescriptorDerived() [1/2]
		8.14.3.2 JeodMemoryTypeDescriptorDerived() [2/2]
		8.14.3.3 ~JeodMemoryTypeDescriptorDerived()
	8.14.4	Member Function Documentation
		8.14.4.1 clone()
		8.14.4.2 construct_array()
		8.14.4.3 delete_array()
		8.14.4.4 delete_object()
		8.14.4.5 destruct_array()
		8.14.4.6 is_structured()

CONTENTS xi

		8.14.4.7 most_derived_pointer() [1/2]	119
		8.14.4.8 most_derived_pointer() [2/2]	120
		8.14.4.9 operator=()	120
8.15	jeod::Je	eodMemoryTypePreDescriptor Class Reference	121
	8.15.1	Detailed Description	121
	8.15.2	Constructor & Destructor Documentation	121
		8.15.2.1 ~JeodMemoryTypePreDescriptor()	121
	8.15.3	Member Function Documentation	121
		8.15.3.1 get_descriptor()	122
		8.15.3.2 get_typeid()	122
8.16	jeod::Je	eodMemoryTypePreDescriptorDerived< Type > Class Template Reference	122
	8.16.1	Detailed Description	123
	8.16.2	Member Typedef Documentation	123
		8.16.2.1 TypeDescriptor	123
	8.16.3	Constructor & Destructor Documentation	124
		8.16.3.1 JeodMemoryTypePreDescriptorDerived() [1/2]	124
		8.16.3.2 JeodMemoryTypePreDescriptorDerived() [2/2]	124
		8.16.3.3 ~JeodMemoryTypePreDescriptorDerived()	124
	8.16.4	Member Function Documentation	124
		8.16.4.1 get_descriptor()	125
		8.16.4.2 get_ref()	125
		8.16.4.3 get_typeid()	126
	8.16.5	Field Documentation	126
		8.16.5.1 descriptor	126
		8.16.5.2 is_exportable	126
8.17	jeod::Je	eodSimEngineAttributes< Type, is_class > Class Template Reference	126
	8.17.1	Detailed Description	127
	8.17.2	Member Function Documentation	127
		8.17.2.1 attributes()	127
8.18	ieod::Je	eodSimEngineAttributes< Type *, false > Class Template Reference	127

xii CONTENTS

	8.18.1	Detailed Description
	8.18.2	Member Function Documentation
		8.18.2.1 attributes()
8.19	jeod::Je	eodSimEngineAttributes< Type, true > Class Template Reference
	8.19.1	Detailed Description
	8.19.2	Member Function Documentation
		8.19.2.1 attributes()
8.20	jeod::Je	eodSimEngineAttributes< void *, false > Class Template Reference
	8.20.1	Detailed Description
	8.20.2	Member Function Documentation
		8.20.2.1 attributes()
8.21	jeod::M	emoryMessages Class Reference
	8.21.1	Detailed Description
	8.21.2	Constructor & Destructor Documentation
		8.21.2.1 MemoryMessages() [1/2]
		8.21.2.2 MemoryMessages() [2/2]
	8.21.3	Member Function Documentation
		8.21.3.1 operator=()
	8.21.4	Friends And Related Function Documentation
		8.21.4.1 init_attrjeodMemoryMessages
		8.21.4.2 InputProcessor
	8.21.5	Field Documentation
		8.21.5.1 corrupted_memory
		8.21.5.2 debug
		8.21.5.3 internal_error
		8.21.5.4 invalid_size
		8.21.5.5 lock_error
		8.21.5.6 null_pointer
		8.21.5.7 out_of_memory
		8.21.5.8 registration_error
		8.21.5.9 singleton_error
		8.21.5.10 suspect_pointer
8.22	jeod::Je	eodMemoryManager::TypeEntry Struct Reference
	8.22.1	Detailed Description
	8.22.2	Constructor & Destructor Documentation
		8.22.2.1 TypeEntry()
	8.22.3	Field Documentation
		8.22.3.1 index
		8.22.3.2 tdesc

CONTENTS xiii

9	File I	Documentation	137
	9.1	class_declarations.hh File Reference	137
		9.1.1 Detailed Description	137
	9.2	jeod_alloc.hh File Reference	137
		9.2.1 Detailed Description	139
	9.3	jeod_alloc_construct_destruct.hh File Reference	139
		9.3.1 Detailed Description	140
	9.4	jeod_alloc_get_allocated_pointer.hh File Reference	140
		9.4.1 Detailed Description	141
	9.5	memory_attributes_templates.hh File Reference	141
		9.5.1 Detailed Description	142
	9.6	memory_item.cc File Reference	142
		9.6.1 Detailed Description	142
	9.7	memory_item.hh File Reference	142
		9.7.1 Detailed Description	143
	9.8	memory_manager.cc File Reference	143
		9.8.1 Detailed Description	143
		9.8.2 Macro Definition Documentation	143
		9.8.2.1 MAKE_DESCRIPTOR	144
	9.9	memory_manager.hh File Reference	144
		9.9.1 Detailed Description	145
	9.10	memory_manager_hide_from_trick.hh File Reference	145
		9.10.1 Detailed Description	145
	9.11	memory_manager_protected.cc File Reference	145
		9.11.1 Detailed Description	146
	9.12	memory_manager_static.cc File Reference	146
		9.12.1 Detailed Description	
	9.13	memory_messages.cc File Reference	
		9.13.1 Detailed Description	147
		9.13.2 Macro Definition Documentation	147
		9.13.2.1 MAKE_MEMORY_MESSAGE_CODE	147
	9.14	memory_messages.hh File Reference	147
		9.14.1 Detailed Description	
	9.15	memory_table.hh File Reference	
		9.15.1 Detailed Description	
	9.16	memory_type.cc File Reference	
		9.16.1 Detailed Description	
	9.17	memory_type.hh File Reference	
		9.17.1 Detailed Description	149
Inc	lev		151

Chapter 1

Module Index

1.1 Modules

Here is a list of all modules:

Models	26
Utils	27
Memory	28
Externally-usable macros	11
Internal macros	21
Support classes	25

2 Module Index

Chapter 2

Namespace Index

2.1	Namespace	List

Here is a list of all namespaces with brief descriptions:	
iend	

4 Namespace Index

Chapter 3

Hierarchical Index

3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

jeod::JeodMemoryTypeDescriptor::attr
$jeod:: JeodAllocHelperAllocatedPointer < T, is_poly > \dots $
$jeod:: JeodAllocHelperAllocatedPointer < T, true > \dots $
$jeod:: JeodAllocHelperConstruct Destruct < T, is_class, is_abstract > \dots $
$jeod:: JeodAllocHelperConstruct Destruct < T, false, is_abstract > \dots $
$jeod:: JeodAllocHelperConstruct Destruct < T, true, false > \dots $
jeod::JeodMemoryItem
jeod::JeodMemoryManager
jeod::JeodMemoryTable< ValueType >
jeod::JeodMemoryTableClonable < ValueType >
jeod::JeodMemoryTableCopyable< ValueType >
$jeod:: JeodMemoryTable < JeodMemoryTypeDescriptor > \dots $
jeod::JeodMemoryTableClonable< JeodMemoryTypeDescriptor >
${\sf jeod::JeodMemoryTable} < {\sf std::string} > \dots $
jeod::JeodMemoryTableCopyable < std::string >
jeod::JeodMemoryReflectiveTable
jeod::JeodMemoryTypeDescriptor
jeod::JeodMemoryTypeDescriptorDerived< Type >
jeod:: Jeod Memory Type Pre Descriptor
jeod::JeodMemoryTypePreDescriptorDerived< Type >
${\sf jeod::JeodSimEngineAttributes} < {\sf Type, is_class} > \dots \\ {\sf 126}$
${\sf jeod::JeodSimEngineAttributes} < {\sf Type} *, {\sf false} > $
${\sf jeod::JeodSimEngineAttributes} < {\sf Type, true} > \ldots $
$jeod:: JeodSimEngineAttributes < void *, false > \dots $
jeod::MemoryMessages
ieod:.leodMemoryManager::TypeEntry 135

6 Hierarchical Index

Chapter 4

Data Structure Index

4.1 Data Structures

Here are the data structures with brief descriptions:

jeod::JeodMemoryTypeDescriptor::attr	
The simulation engine attributes that describe the type.trick_io(**)	37
jeod::JeodAllocHelperAllocatedPointer< T, is_poly >	
Class template that provides a static function $cast$ that casts a pointer to an object of type T to a	
void* pointer	37
jeod::JeodAllocHelperAllocatedPointer< T, true >	
Partial instantiation of JeodAllocHelperAllocatedPointer for polymorphic classes	38
jeod::JeodAllocHelperConstructDestruct< T, is_class, is_abstract >	
Class template that provides static functions construct and destruct that construct an array of	
objects	39
jeod::JeodAllocHelperConstructDestruct< T, false, is_abstract >	
Partial instantiation for non-classes	41
jeod::JeodAllocHelperConstructDestruct< T, true, false >	
Partial instantiation for non-abstract classes	43
jeod::JeodMemoryItem	
A JeodMemoryItem contains metadata about some chunk of allocated memory	44
jeod::JeodMemoryManager	
This class provides the interface between the macros in jeod_alloc.hh and the rest of the JEOD	
memory model	54
jeod::JeodMemoryReflectiveTable	
A JeodMemoryReflectiveTable maps strings to themselves	88
jeod::JeodMemoryTable< ValueType >	
A JeodMemoryTable maps strings to values with a coordinated map/vector pair	90
jeod::JeodMemoryTableClonable< ValueType >	
A JeodMemoryTableClonable is a JeodMemoryTable that implements the required clone() func-	
tionality by invoking the ValueType's clone() method to create a clone of the input value	98
jeod::JeodMemoryTableCopyable< ValueType >	
A JeodMemoryTableCopyable is a JeodMemoryTable that implements the required clone() func-	
tionality by invoking the ValueType's copy constructor to create a clone of the input value	100
jeod::JeodMemoryTypeDescriptor	
Abstract class for managing data allocated as some specific type	102
jeod::JeodMemoryTypeDescriptorDerived< Type >	
Extends JeodMemoryTypeDescriptor to describe a specific type	115
jeod::JeodMemoryTypePreDescriptor	
Abstract class for describing a type without necessarily needing to create a JeodMemoryTypeDesc	ripto
of that type	121

8 Data Structure Index

jeod::JeodMemoryTypePreDescriptorDerived< Type >	
A JeodMemoryTypePreDescriptorDerived describes a <i>Type</i>	122
jeod::JeodSimEngineAttributes< Type, is_class >	
Class template to construct a simulation engine attributes object that represents some type	126
jeod::JeodSimEngineAttributes< Type *, false >	
Partial template instantiation of JeodSimEngineAttributes for a pointer type	127
jeod::JeodSimEngineAttributes< Type, true >	
Partial template instantiation of JeodSimEngineAttributes for a class	128
jeod::JeodSimEngineAttributes< void *, false >	
Template specialization of JeodSimEngineAttributes for void*	129
jeod::MemoryMessages	
Declares messages associated with the integration test model	130
jeod::JeodMemoryManager::TypeEntry	
The type table is indexed by an integer and contains type descriptors	135

Chapter 5

File Index

5.1 File List

Here is a list of all files with brief descriptions:

class_decla	arations.hh	
F	orward declarations of classes defined in the utils/memory model	137
jeod_alloc.		
D	Define JEOD memory allocation macros	137
	_construct_destruct.hh	
	· · · · · · · · · · · · · · · · · · ·	139
. – –	_get_allocated_pointer.hh	
		140
	ttributes_templates.hh	
	efine the class template JeodSimEngineAttributes	141
memory_ite		
	nplement the JeodMemoryItem class	142
memory_ite		
D	efine the class JeodMemoryItem	142
memory_m		
	nplement the JeodMemoryManager class	143
memory_m		
	efine the JeodMemoryManager class, the central agent of the memory model	144
	nanager_hide_from_trick.hh	
	rick doesn't understand these	145
	nanager_protected.cc	
	mplement those JeodMemoryManager member functions that access data members that need	
	be treated with care to make the memory manager thread safe	145
	nanager_static.cc	
	nplement the static methods of the JeodMemoryManager class	146
•	nessages.cc	
	nplement the class MemoryMessages	146
-	nessages.hh	
	Define the class MemoryMessages, the class that specifies the message IDs used in the memory	
	nodel	147
memory_ta		
	Define classes for representing data types	148
memory_ty		
	nplement destructors for the classes for representing data types	148
memory_ty	•	
	befine the abstract class JeodMemoryTypeDescriptor and templates that create instantiable	4.40
C	lasses that derive from JeodMemoryTypeDescriptor	149

10 File Index

Chapter 6

Module Documentation

6.1 Externally-usable macros

The supported use of the JEOD memory model is via those macros advertised as externally-usable.

Macros

#define JEOD MEMORY DEBUG 2

Specifies the level of checking performed by the JEOD memory model.

#define JEOD_REGISTER_CLASS(type) jeod::JeodMemoryManager::register_class(jeod::JeodMemoryTypePreDescriptorDel_ref())

Register the type type with the memory manager.

• #define JEOD_REGISTER_INCOMPLETE_CLASS(type) JEOD_REGISTER_CLASS(type)

Register the incomplete class type with the memory manager.

 #define JEOD_REGISTER_NONEXPORTED_CLASS(type) jeod::JeodMemoryManager::register_class(jeod::JeodMemoryTyp _ref())

Register the type type with the memory manager, but with the class marked as not exportable to the simulation engine.

#define JEOD_REGISTER_CHECKPOINTABLE(owner, elem_name)

Register the data member elem_name of the owner as a Checkpointable object.

• #define JEOD_DEREGISTER_CHECKPOINTABLE(owner, elem_name)

Register the data member elem_name of the owner as a Checkpointable object.

#define JEOD_ALLOC_CLASS_MULTI_POINTER_ARRAY(nelem, type, asters) JEOD_ALLOC_ARRAY_INTERNAL(type asters, nelem, JEOD_ALLOC_POINTER_FILL, JEOD_REGISTER_CLASS(type asters))

Allocate an array of nelem multi-level pointers to the specified type.

#define JEOD_ALLOC_CLASS_POINTER_ARRAY(nelem, type) JEOD_ALLOC_CLASS_MULTI_POINTER_ARRAY(nelem, type, *)

Allocate an array of nelem pointers to the specified type.

• #define JEOD_ALLOC_CLASS_ARRAY(nelem, type) JEOD_ALLOC_ARRAY_INTERNAL(type, nelem, JEOD_ALLOC_OBJECT_FILL, JEOD_REGISTER_CLASS(type))

Allocate an array of nelem instances of the specified structured type.

 #define JEOD_ALLOC_PRIM_ARRAY(nelem, type) JEOD_ALLOC_ARRAY_INTERNAL(type, nelem, JEOD_ALLOC_PRIMITIVE_FILL, JEOD_REGISTER_CLASS(type))

Allocate nelem elements of the specified primitive type.

#define JEOD_ALLOC_CLASS_OBJECT(type, constr) JEOD_ALLOC_OBJECT_INTERNAL(type, JEOD_ALLOC_OBJECT_FILL, constr, JEOD_REGISTER_CLASS(type))

Allocate one instance of the specified class.

12 Module Documentation

#define JEOD_ALLOC_PRIM_OBJECT(type, initial) JEOD_ALLOC_OBJECT_INTERNAL(type, JEOD_ALLOC_PRIMITIVE_FINITIAL(type, JEOD_REGISTER_CLASS(type))

Allocate one instance of the specified type.

#define JEOD_IS_ALLOCATED(ptr) jeod::JeodMemoryManager::is_allocated(jeod::jeod_alloc_get_allocated_pointer(ptr),
 __FILE__, __LINE__)

Determine if ptr was allocated by some <code>JEOD_ALLOC_xxx_ARRAY</code> macro.

• #define JEOD_DELETE_ARRAY(ptr) JEOD_DELETE_INTERNAL(ptr, true)

Free memory at ptr that was earlier allocated with some <code>JEOD_ALLOC_xxx_ARRAY</code> macro.

• #define JEOD_DELETE_OBJECT(ptr) JEOD_DELETE_INTERNAL(ptr, false)

Free memory at ptr that was earlier allocated with some <code>JEOD_ALLOC_xxx_OBJECT</code> macro.

• #define JEOD_DELETE_2D(ptr, size, is_array)

6.1.1 Detailed Description

The supported use of the JEOD memory model is via those macros advertised as externally-usable.

These externally-usable macros expand into invocations of internal macros, which in turn expand into calls to methods of classes defined in the memory model.

6.1.2 Macro Definition Documentation

6.1.2.1 JEOD_ALLOC_CLASS_ARRAY

Allocate an array of nelem instances of the specified structured type.

The default constructor is invoked to initialize each allocated object.

Returns

Allocated array of specified type.

Parameters

Ī	nelem	Size of the array.	
	type	The underlying type, which must be a structured type.	

Example:

```
Foo ** foo_array = JEOD_ALLOC_CLASS_ARRAY(2,Foo);
```

This allocates two objects of the class Foo.

Definition at line 394 of file jeod_alloc.hh.

6.1.2.2 JEOD_ALLOC_CLASS_MULTI_POINTER_ARRAY

Allocate an array of *nelem* multi-level pointers to the specified *type*.

The asters are asterisks that specify the pointer level. The allocated memory is initialized via new.

Returns

Allocated array of specified type.

Parameters

nelem Size of the array.	
type The underlying type, which must be a structured typ	
asters	A bunch of asterisks.

Example:

```
Foo *** foo_array = JEOD_ALLOC_CLASS_MULTI_POINTER_ARRAY(2,Foo,**);
```

This allocates two pointers-to-pointers to the class Foo. Note that this does not allocate either the Foo objects or pointers to the Foo objects.

Definition at line 361 of file jeod_alloc.hh.

6.1.2.3 JEOD_ALLOC_CLASS_OBJECT

Allocate **one** instance of the specified class.

The supplied constructor arguments, *constr*, are used as arguments to new. The default constructor will be invoked if the *constr* argument is the empty list; a non-default constructor will be invoked for a non-empty list.

Returns

Pointer to allocated object.

14 Module Documentation

Parameters

type	The underlying type, which must be a structured type.
constr	Constructor arguments, enclosed in parentheses.

Example:

```
Foo * foo = JEOD_ALLOC_CLASS_OBJECT(Foo, (bar,baz));
```

This allocates a new object of type Foo, invoking the Foo::Foo(bar,baz) constructor.

Definition at line 431 of file jeod_alloc.hh.

6.1.2.4 JEOD_ALLOC_CLASS_POINTER_ARRAY

Allocate an array of *nelem* pointers to the specified *type*.

The allocated memory is initialized via new.

Returns

Allocated array of specified type.

Parameters

nelem	Size of the array.
type	The underlying type, which must be a structured type.

Example:

```
Foo ** foo_array = JEOD_ALLOC_CLASS_POINTER_ARRAY(2, Foo);
```

This allocates two pointers to the class Foo. Note that this does not allocate the Foo objects themselves.

Definition at line 378 of file jeod_alloc.hh.

6.1.2.5 JEOD_ALLOC_PRIM_ARRAY

Allocate *nelem* elements of the specified primitive *type*.

The allocated array is zero-filled.

Returns

Allocated array of specified type.

Parameters

nelem	Size of the array.
type	The underlying type, which must be a C++ primitive type.

Example:

```
double * double_array = JEOD_ALLOC_PRIM_ARRAY(2, double);
```

This allocates an array of two doubles.

Definition at line 410 of file jeod_alloc.hh.

6.1.2.6 JEOD_ALLOC_PRIM_OBJECT

Allocate one instance of the specified type.

The object is initialized with the supplied initial value.

Returns

Pointer to allocated primitive.

Parameters

type	The underlying type, which must be a C++ primitive type.
initial	Initial value.

Example:

```
double * foo = JEOD_ALLOC_PRIM_OBJECT(double, 3.14159265358979323846);
```

This allocates a double and initializes it to pi.

Definition at line 447 of file jeod_alloc.hh.

16 Module Documentation

6.1.2.7 JEOD_DELETE_2D

```
#define JEOD_DELETE_2D(
    ptr,
    size,
    is_array )
```

Value:

```
if(ptr != nullptr)
{
    for(unsigned int ii = 0; ii < size; ++ii)
    {
        if(is_array)
        {
            JEOD_DELETE_ARRAY(ptr[ii]);
        }
        else
        {
            JEOD_DELETE_OBJECT(ptr[ii]);
        }
    }
}
JEOD_DELETE_ARRAY(ptr);</pre>
```

Definition at line 501 of file jeod_alloc.hh.

6.1.2.8 JEOD_DELETE_ARRAY

Free memory at ptr that was earlier allocated with some <code>JEOD_ALLOC_xxx_ARRAY</code> macro.

Parameters

```
ptr Memory to be released.
```

Example:

```
Foo * foo_array = JEOD_ALLOC_CLASS_ARRAY(2,Foo);
...
JEOD_DELETE_ARRAY(foo_array);
```

The above allocates a chunk of memory and then frees it.

Definition at line 484 of file jeod_alloc.hh.

6.1.2.9 JEOD_DELETE_OBJECT

Free memory at *ptr* that was earlier allocated with some <code>JEOD_ALLOC_xxx_OBJECT</code> macro.

Parameters

```
ptr Memory to be released.
```

Example:

```
Foo * foo1 = JEOD_ALLOC_CLASS_OBJECT(Foo,());
...
JEOD_DELETE_OBJECT(foo1);
```

The above allocates a chunk of memory and then frees it.

Definition at line 499 of file jeod alloc.hh.

6.1.2.10 JEOD_DEREGISTER_CHECKPOINTABLE

Value:

Register the data member elem_name of the owner as a Checkpointable object.

Assumptions and Limitations:

- The *owner* must be a pointer, typically this.
- The owner class must have been registered with the memory manager via JEOD_REGISTER_CLASS.
- The *elem_name* must identify a data member of the *owner* whose type derives from Checkpointable.

18 Module Documentation

Parameters

owner	The object that contains the Checkpointable object.
elem_name	The Checkpointable object.

Definition at line 309 of file jeod_alloc.hh.

6.1.2.11 JEOD_IS_ALLOCATED

Determine if *ptr* was allocated by some <code>JEOD_ALLOC_xxx_ARRAY</code> macro.

Returns

true if ptr was allocated by this module, false otherwise.

Parameters

```
ptr Memory to be checked.
```

Example:

```
char * name;
...
if (JEOD_IS_ALLOCATED(name)) {
  JEOD_DELETE_ARRAY(name);
  name = NULL;
}
```

The above deletes the memory at name, but only if that memory was allocated by the JEOD memory management module.

Definition at line 468 of file jeod_alloc.hh.

6.1.2.12 JEOD_MEMORY_DEBUG

```
#define JEOD_MEMORY_DEBUG 2
```

Specifies the level of checking performed by the JEOD memory model.

- 0 JEOD memory management off
- 1 Error checking only
- 2 Summary checking
- 3 Blow-by-block account of allocation, deallocation.

Definition at line 134 of file jeod_alloc.hh.

6.1.2.13 JEOD_REGISTER_CHECKPOINTABLE

Value:

Register the data member *elem_name* of the *owner* as a Checkpointable object.

Assumptions and Limitations:

- The owner must be a pointer, typically this.
- The owner class must have been registered with the memory manager via JEOD_REGISTER_CLASS.
- The *elem_name* must identify a data member of the *owner* whose type derives from Checkpointable.

Parameters

owner	The object that contains the Checkpointable object.
elem_name	The Checkpointable object.

Definition at line 288 of file jeod_alloc.hh.

6.1.2.14 JEOD_REGISTER_CLASS

Register the type *type* with the memory manager.

Parameters

```
type Data type (C token, not a string).
```

Definition at line 249 of file jeod_alloc.hh.

20 Module Documentation

6.1.2.15 JEOD_REGISTER_INCOMPLETE_CLASS

Register the incomplete class *type* with the memory manager.

The type mechanism now does the "right thing" with types. This macro is deprecated.

Parameters

```
type Data type (C token, not a string).
```

Definition at line 260 of file jeod_alloc.hh.

6.1.2.16 JEOD_REGISTER_NONEXPORTED_CLASS

Register the type *type* with the memory manager, but with the class marked as not exportable to the simulation engine.

Instances of a non-exported class allocated with JEOD_ALLOC_xxx will not be registered with the simulation engine.

Parameters

type	Data type (C token, not a string).
------	------------------------------------

Definition at line 270 of file jeod alloc.hh.

6.2 Internal macros 21

6.2 Internal macros

The internal macros act as the bridge between the externally-usable memory model macros and the publicly-visible memory model class methods.

Macros

• #define JEOD ALLOC OBJECT FILL 0xdf

Fill pattern for non-primitive types.

• #define JEOD_ALLOC_PRIMITIVE_FILL 0

Fill pattern for primitive types.

• #define JEOD_ALLOC_POINTER_FILL 0

Fill pattern for pointer types.

#define JEOD_CREATE_MEMORY(is_array, nelem, fill, tentry) jeod::JeodMemoryManager::create_memory(is
 —array, nelem, fill, tentry, __FILE__, __LINE__)

Allocate and register memory to be populated via placement new.

#define JEOD_ALLOC_ARRAY_INTERNAL(type, nelem, fill, tentry) new(JEOD_CREATE_MEMORY(true, nelem, fill, tentry)) type[nelem]

Allocate nelem elements of pointers to the specified structured type.

 #define JEOD_ALLOC_OBJECT_INTERNAL(type, fill, constr, tentry) new(JEOD_CREATE_MEMORY(false, 1, fill, tentry)) type constr

Allocate an instance of the specified class using the specified constructor arguments.

#define JEOD DELETE INTERNAL(ptr, is array)

Free memory allocated with some JEOD_ALLOC macro.

6.2.1 Detailed Description

The internal macros act as the bridge between the externally-usable memory model macros and the publicly-visible memory model class methods.

6.2.2 Macro Definition Documentation

6.2.2.1 JEOD_ALLOC_ARRAY_INTERNAL

Allocate nelem elements of pointers to the specified structured type.

Parameters

type	Data type.
nelem	Size of the array.
fill	Fill pattern.
Generated b	y Doxygen Fill pattern.
tentry	JEOD type descriptor entry.

22 Module Documentation

Definition at line 193 of file jeod_alloc.hh.

6.2.2.2 JEOD_ALLOC_OBJECT_FILL

```
#define JEOD_ALLOC_OBJECT_FILL 0xdf
```

Fill pattern for non-primitive types.

This is a nasty fill pattern that forces JEOD developers to write constructors that initialize every element of a class.

Definition at line 153 of file jeod_alloc.hh.

6.2.2.3 JEOD_ALLOC_OBJECT_INTERNAL

Allocate an instance of the specified class using the specified constructor arguments.

Parameters

type	Data type.
fill	Fill pattern.
constr	Constructor arguments, enclosed in parentheses.
tentry	JEOD type descriptor entry.

Definition at line 205 of file jeod_alloc.hh.

6.2.2.4 JEOD_ALLOC_POINTER_FILL

```
#define JEOD_ALLOC_POINTER_FILL 0
```

Fill pattern for pointer types.

Pointer types are initialized to null pointers. Note that this may change in the future. JEOD developers are strongly encouraged to initialize pointer arrays after allocating them.

Definition at line 171 of file jeod_alloc.hh.

6.2 Internal macros 23

6.2.2.5 JEOD_ALLOC_PRIMITIVE_FILL

```
#define JEOD_ALLOC_PRIMITIVE_FILL 0
```

Fill pattern for primitive types.

Primitive types are initialized to all zero.

Definition at line 161 of file jeod_alloc.hh.

6.2.2.6 JEOD_CREATE_MEMORY

Allocate and register memory to be populated via placement new.

Parameters

is_array	Allocated as an array?
nelem	Size of the array.
fill	Fill pattern.
tentry	JEOD type descriptor entry.

Definition at line 181 of file jeod_alloc.hh.

6.2.2.7 JEOD_DELETE_INTERNAL

```
#define JEOD_DELETE_INTERNAL( ptr, \\ is\_array~)
```

Value:

24 Module Documentation

```
__LINE__);

ptr = nullptr;
}

while(0)
```

Free memory allocated with some JEOD_ALLOC macro.

Depends on

```
dynamic_cast<void*>(ptr)
```

yielding a pointer to the most derived object pointed to by ptr. See ISO/IEC 14882:2003 section 5.2.7.7.

Parameters

ptr	Memory to be released.
is_array	True for DELETE_ARRAY, false for DELETE_OBJECT.

Definition at line 218 of file jeod_alloc.hh.

6.3 Support classes 25

6.3 Support classes

The memory model classes are the workhorses of the JEOD memory model.

Namespaces

• jeod

Namespace jeod.

Macros

• #define __STDC_LIMIT_MACROS

6.3.1 Detailed Description

The memory model classes are the workhorses of the JEOD memory model.

6.3.2 Macro Definition Documentation

6.3.2.1 __STDC_LIMIT_MACROS

#define ___STDC_LIMIT_MACROS

Definition at line 35 of file memory_manager_protected.cc.

26 Module Documentation

6.4 Models

Modules

• Utils

6.4.1 Detailed Description

6.5 Utils 27

6.5 Utils

Modules

Memory

6.5.1 Detailed Description

28 Module Documentation

6.6 Memory

Modules

· Externally-usable macros

The supported use of the JEOD memory model is via those macros advertised as externally-usable.

· Internal macros

The internal macros act as the bridge between the externally-usable memory model macros and the publicly-visible memory model class methods.

· Support classes

The memory model classes are the workhorses of the JEOD memory model.

Files

· file class declarations.hh

Forward declarations of classes defined in the utils/memory model.

· file jeod alloc.hh

Define JEOD memory allocation macros.

· file jeod alloc construct destruct.hh

Define templates for use by jeod_alloc.hh.

· file jeod alloc get allocated pointer.hh

Define function template jeod_alloc_get_allocated_pointer.

· file memory_attributes_templates.hh

Define the class template JeodSimEngineAttributes.

· file memory_item.hh

Define the class JeodMemoryItem.

· file memory_manager.hh

Define the JeodMemoryManager class, the central agent of the memory model.

• file memory_manager_hide_from_trick.hh

Trick doesn't understand these.

· file memory_messages.hh

Define the class MemoryMessages, the class that specifies the message IDs used in the memory model.

· file memory_table.hh

Define classes for representing data types.

· file memory type.hh

Define the abstract class JeodMemoryTypeDescriptor and templates that create instantiable classes that derive from JeodMemoryTypeDescriptor.

· file memory item.cc

Implement the JeodMemoryItem class.

• file memory_manager.cc

Implement the JeodMemoryManager class.

file memory_manager_protected.cc

Implement those JeodMemoryManager member functions that access data members that need to be treated with care to make the memory manager thread safe.

· file memory manager static.cc

Implement the static methods of the JeodMemoryManager class.

file memory_messages.cc

Implement the class MemoryMessages.

file memory_type.cc

Implement destructors for the classes for representing data types.

6.6 Memory 29

Namespaces

• jeod

Namespace jeod.

6.6.1 Detailed Description

30 Module Documentation

Chapter 7

Namespace Documentation

7.1 jeod Namespace Reference

Namespace jeod.

Data Structures

class JeodAllocHelperAllocatedPointer

Class template that provides a static function cast that casts a pointer to an object of type T to a void* pointer.

class JeodAllocHelperAllocatedPointer< T, true >

Partial instantiation of JeodAllocHelperAllocatedPointer for polymorphic classes.

• class JeodAllocHelperConstructDestruct

Class template that provides static functions construct and destruct that construct an array of objects.

class JeodAllocHelperConstructDestruct
 T, false, is_abstract

Partial instantiation for non-classes.

class JeodAllocHelperConstructDestruct< T, true, false >

Partial instantiation for non-abstract classes.

class JeodMemoryItem

A JeodMemoryItem contains metadata about some chunk of allocated memory.

· class JeodMemoryManager

This class provides the interface between the macros in jeod_alloc.hh and the rest of the JEOD memory model.

class JeodMemoryReflectiveTable

A JeodMemoryReflectiveTable maps strings to themselves.

class JeodMemoryTable

A JeodMemoryTable maps strings to values with a coordinated map/vector pair.

class JeodMemoryTableClonable

A JeodMemoryTableClonable is a JeodMemoryTable that implements the required clone() functionality by invoking the ValueType's clone() method to create a clone of the input value.

class JeodMemoryTableCopyable

A JeodMemoryTableCopyable is a JeodMemoryTable that implements the required clone() functionality by invoking the ValueType's copy constructor to create a clone of the input value.

class JeodMemoryTypeDescriptor

Abstract class for managing data allocated as some specific type.

class JeodMemoryTypeDescriptorDerived

Extends JeodMemoryTypeDescriptor to describe a specific type.

· class JeodMemoryTypePreDescriptor

Abstract class for describing a type without necessarily needing to create a JeodMemoryTypeDescriptor of that type.

class JeodMemoryTypePreDescriptorDerived

A JeodMemoryTypePreDescriptorDerived describes a Type.

class JeodSimEngineAttributes

Class template to construct a simulation engine attributes object that represents some type.

class JeodSimEngineAttributes
 Type *, false >

Partial template instantiation of JeodSimEngineAttributes for a pointer type.

class JeodSimEngineAttributes
 Type, true >

Partial template instantiation of JeodSimEngineAttributes for a class.

class JeodSimEngineAttributes< void *, false >

Template specialization of JeodSimEngineAttributes for void*.

class MemoryMessages

Declares messages associated with the integration test model.

Typedefs

using AllocTable = std::map< const void *, JeodMemoryItem >

An AllocTable maps memory addresses to memory descriptions.

using TypeTable = JeodMemoryTableClonable < JeodMemoryTypeDescriptor >

The type type itself is a memory table with copy implemented by clone().

Functions

template < typename T > void * jeod_alloc_construct_array (std::size_t nelem, void *addr)

Construct an array of objects of type T.

• template<typename T >

void jeod_alloc_destruct_array (std::size_t nelem, void *addr)

Destruct an array of objects of type T.

• template<typename T >

```
void * jeod_alloc_get_allocated_pointer (T *pointer)
```

Cast a pointer to some object to a pointer to void* such that a pointer to a polymorphic object, downcast to a base class pointer, becomes a pointer to the original object, but also such that a pointer to an instance of a non-polymorphic class or a pointer to a non-class type is handled correctly.

Variables

- static constexpr uint32_t MAGIC0 = 0x2203992c
- static constexpr uint32_t MAGIC1 = 0x6c052d84

7.1.1 Detailed Description

Namespace jeod.

7.1.2 Typedef Documentation

7.1.2.1 AllocTable

```
using jeod::AllocTable = typedef std::map<const void *, JeodMemoryItem>
```

An AllocTable maps memory addresses to memory descriptions.

Definition at line 76 of file memory manager hide from trick.hh.

7.1.2.2 TypeTable

```
using jeod::TypeTable = typedef JeodMemoryTableClonable<JeodMemoryTypeDescriptor>
```

The type type itself is a memory table with copy implemented by clone().

Definition at line 81 of file memory_manager_hide_from_trick.hh.

7.1.3 Function Documentation

7.1.3.1 jeod_alloc_construct_array()

Construct an array of objects of type T.

Template Parameters

```
T Pointed-to type.
```

Parameters

nelem	Number of elements in the array
addr	Address to be constructed

Returns

Constructed array.

Definition at line 202 of file jeod_alloc_construct_destruct.hh.

7.1.3.2 jeod_alloc_destruct_array()

Destruct an array of objects of type T.

Template Parameters

T Pointed-to type	
-------------------	--

Parameters

nelem	Number of elements in the array
addr	Address to be destructed

Definition at line 214 of file jeod_alloc_construct_destruct.hh.

7.1.3.3 jeod_alloc_get_allocated_pointer()

Cast a pointer to some object to a pointer to void* such that a pointer to a polymorphic object, downcast to a base class pointer, becomes a pointer to the original object, but also such that a pointer to an instance of a non-polymorphic class or a pointer to a non-class type is handled correctly.

Template Parameters

```
T Pointed-to type.
```

Parameters

pointer	Pointer to be cast to void*.

Usage:

```
jeod_alloc_get_allocated_pointer(pointer)
```

Note that the template parameter does not need to be specified. The compiler automagically determines the type.

Assumptions and limitations:

- The function argument pointer is a pointer.
- The pointer is not *cv* qualified (i.e., neither const nor volatile).
- · Inheritance is public for polymorphic classes.
- jeod_alloc_get_allocated_pointer(&array[1]) does not return a pointer to

```
&array[0]
```

.

Definition at line 153 of file jeod_alloc_get_allocated_pointer.hh.

 $References\ jeod:: JeodAllocHelperAllocatedPointer<\ T,\ is_poly>:: cast().$

 $Referenced\ by\ jeod:: JeodMemoryTypeDescriptorDerived < Type >::most_derived_pointer().$

7.1.4 Variable Documentation

7.1.4.1 MAGIC0

```
constexpr uint32_t jeod::MAGIC0 = 0x2203992c [static]
```

Definition at line 55 of file memory_manager.cc.

Referenced by jeod::JeodMemoryManager::allocate_memory(), and jeod::JeodMemoryManager::free_memory().

7.1.4.2 MAGIC1

```
constexpr uint32_t jeod::MAGIC1 = 0x6c052d84 [static]
```

Definition at line 56 of file memory_manager.cc.

Referenced by jeod::JeodMemoryManager::allocate_memory(), and jeod::JeodMemoryManager::free_memory().

Chapter 8

Data Structure Documentation

8.1 jeod::JeodMemoryTypeDescriptor::attr Struct Reference

The simulation engine attributes that describe the type.trick_io(**)

```
#include <memory_type.hh>
```

8.1.1 Detailed Description

The simulation engine attributes that describe the type.trick_io(**)

Definition at line 348 of file memory_type.hh.

The documentation for this struct was generated from the following file:

• memory_type.hh

8.2 jeod::JeodAllocHelperAllocatedPointer< T, is_poly > Class Template Reference

Class template that provides a static function *cast* that casts a pointer to an object of type *T* to a void* pointer.

```
#include <jeod_alloc_get_allocated_pointer.hh>
```

Static Public Member Functions

static void * cast (T *pointer)
 Cast a pointer to a non-polymorphic class via an implicit cast.

8.2.1 Detailed Description

```
template<typename T, bool is_poly> class jeod::JeodAllocHelperAllocatedPointer< T, is_poly >
```

Class template that provides a static function *cast* that casts a pointer to an object of type T to a void* pointer.

Template Parameters

Т	Туре
is_poly	True if the type T is a polymorphic class.

This class template is intended for used by jeod_alloc_get_allocated_pointer. Use in any other context is caveat emptor.

This template provides a default implementation for non-polymorphic classes (is_poly == false) that uses implicit cast. The partial template instantiation that immediately follows provides n an implementation that uses dynamic_cast when is_poly is true.

Definition at line 92 of file jeod_alloc_get_allocated_pointer.hh.

8.2.2 Member Function Documentation

8.2.2.1 cast()

Cast a pointer to a non-polymorphic class via an implicit cast.

Returns

Input pointer cast to void* via implicit cast.

Parameters

pointer	Pointer

Definition at line 100 of file jeod_alloc_get_allocated_pointer.hh.

Referenced by jeod::jeod_alloc_get_allocated_pointer().

The documentation for this class was generated from the following file:

· jeod_alloc_get_allocated_pointer.hh

8.3 jeod::JeodAllocHelperAllocatedPointer< T, true > Class Template Reference

Partial instantiation of JeodAllocHelperAllocatedPointer for polymorphic classes.

```
#include <jeod_alloc_get_allocated_pointer.hh>
```

Static Public Member Functions

static void * cast (T *pointer)
 Cast a pointer to a non-class object via dynamic cast.

8.3.1 Detailed Description

```
\label{template} \mbox{typename T} > \\ \mbox{class jeod::JeodAllocHelperAllocatedPointer} < \mbox{T, true} > \\
```

Partial instantiation of JeodAllocHelperAllocatedPointer for polymorphic classes.

This class uses the fact that $dynamic_cast < void* > (ptr)$ results in a pointer to the most derived object pointed to by ptr. See ISO/IEC 14882:2003 section 5.2.7.7 for details.

Definition at line 112 of file jeod_alloc_get_allocated_pointer.hh.

8.3.2 Member Function Documentation

8.3.2.1 cast()

Cast a pointer to a non-class object via dynamic_cast.

Returns

Input pointer cast to void* via dynamic_cast.

Parameters

```
pointer Pointer
```

Definition at line 120 of file jeod_alloc_get_allocated_pointer.hh.

The documentation for this class was generated from the following file:

jeod_alloc_get_allocated_pointer.hh

8.4 jeod::JeodAllocHelperConstructDestruct < T, is_class, is_abstract > Class Template Reference

Class template that provides static functions construct and destruct that construct an array of objects.

```
#include <jeod_alloc_construct_destruct.hh>
```

Static Public Member Functions

static void * construct (std::size_t nelem, void *addr)

Construct an array of objects.

static void destruct (std::size_t nelem, void *addr)

Destruct an array of objects.

8.4.1 Detailed Description

```
template < typename\ T,\ bool\ is\_class,\ bool\ is\_abstract > \\ class\ jeod:: JeodAllocHelperConstructDestruct < T,\ is\_class,\ is\_abstract > \\
```

Class template that provides static functions construct and destruct that construct an array of objects.

Template Parameters

T	Туре
is_class	True if the type T is a class.
is_abstract	True if the type T is an abstract class.

This class template is intended for used by jeod_alloc_construct_array and jeod_alloc_destruct_array. Use in any other context is caveat emptor.

This template provides do-nothing implementations, which is about all one can do for arrays of abstract objects (which can't exist).

Definition at line 102 of file jeod_alloc_construct_destruct.hh.

8.4.2 Member Function Documentation

8.4.2.1 construct()

Construct an array of objects.

Returns

Constructed array.

Parameters

nelem	Number of elements in the array
addr	Address to be constructed

Definition at line 111 of file jeod_alloc_construct_destruct.hh.

8.4.2.2 destruct()

Destruct an array of objects.

Parameters

nelem	Number of elements in the array	
addr	Address to be destructed	

Definition at line 121 of file jeod_alloc_construct_destruct.hh.

The documentation for this class was generated from the following file:

jeod_alloc_construct_destruct.hh

8.5 jeod::JeodAllocHelperConstructDestruct< T, false, is_abstract > Class Template Reference

Partial instantiation for non-classes.

```
#include <jeod_alloc_construct_destruct.hh>
```

Static Public Member Functions

- static void * construct (std::size_t nelem, void *addr)
 Construct an array of objects.
- static void destruct (std::size_t nelem, void *addr)
 Destruct an array of objects.

8.5.1 Detailed Description

```
template<typename T, bool is_abstract>
class jeod::JeodAllocHelperConstructDestruct< T, false, is_abstract >
```

Partial instantiation for non-classes.

Definition at line 130 of file jeod_alloc_construct_destruct.hh.

8.5.2 Member Function Documentation

8.5.2.1 construct()

Construct an array of objects.

Returns

Constructed array.

Parameters

nelem	Number of elements in the array	
addr	Address to be constructed	

Definition at line 139 of file jeod_alloc_construct_destruct.hh.

8.5.2.2 destruct()

Destruct an array of objects.

Parameters

n	nelem	Number of elements in the array	
а	addr	Address to be destructed	

Definition at line 150 of file jeod_alloc_construct_destruct.hh.

The documentation for this class was generated from the following file:

• jeod_alloc_construct_destruct.hh

8.6 jeod::JeodAllocHelperConstructDestruct < T, true, false > Class Template Reference

Partial instantiation for non-abstract classes.

```
#include <jeod_alloc_construct_destruct.hh>
```

Static Public Member Functions

- static void * construct (std::size_t nelem, void *addr)
 - Construct an array of objects.
- static void destruct (std::size_t nelem, void *addr)

Destruct an array of objects.

8.6.1 Detailed Description

```
\label{template} \mbox{template} < \mbox{typename T} > \\ \mbox{class jeod::JeodAllocHelperConstructDestruct} < \mbox{T, true, false} > \\ \mbox{the template} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} < \mbox{T, true, false} > \\ \mbox{T, true, false} > \\ \mbox{T, true, false} > \\ \mbox{T, true, false} >
```

Partial instantiation for non-abstract classes.

Definition at line 159 of file jeod_alloc_construct_destruct.hh.

8.6.2 Member Function Documentation

8.6.2.1 construct()

Construct an array of objects.

Returns

Constructed array.

Parameters

nelem	Number of elements in the array	
addr	Address to be constructed	

Definition at line 168 of file jeod_alloc_construct_destruct.hh.

8.6.2.2 destruct()

Destruct an array of objects.

Parameters

nelem	Number of elements in the array	
addr	Address to be destructed	

Definition at line 178 of file jeod alloc construct destruct.hh.

The documentation for this class was generated from the following file:

· jeod alloc construct destruct.hh

8.7 jeod::JeodMemoryItem Class Reference

A JeodMemoryItem contains metadata about some chunk of allocated memory.

```
#include <memory_item.hh>
```

Public Types

```
    enum Flags {
        PlacementNew = 1, IsArray = 2, IsGuarded = 4, IsStructured = 8,
        IsRegistered = 16, CheckPointed = 32 }
```

Identifies by name the bit flags the comprise a JeodMemoryItem::flag.

Public Member Functions

- JeodMemoryItem ()=default
- JeodMemoryItem (bool placement_new, bool is_array, bool is_guarded, bool is_structured, unsigned int nelems_in, unsigned int type_idx, unsigned int alloc_idx)

Construct a JeodMemoryItem.

- ~JeodMemoryItem ()=default
- void set_unique_id (uint32_t id)

Set the unique identifier.

• void set_is_registered (bool value)

Set the is_registered flag.

• uint32_t get_nelems () const

Access the array size.

uint32_t get_alloc_index () const

Access the allocation information index.

```
• uint32_t get_unique_id () const
```

Access the unique identifier.

• uint32_t get_descriptor_index () const

Access the type descriptor index.

• bool get_is_array () const

Access the is_array flag.

bool get_is_guarded () const

Access the is_guarded flag.

· bool get placement new () const

Access the placement_new flag.

· bool is_structured_data () const

Is the associated data a structure/class?

bool get_is_registered () const

Access the checkpointed flag.

· bool get_checkpointed () const

Access the checkpointed flag.

Static Private Member Functions

• static uint8_t construct_flags (bool placement_new, bool is_array, bool is_guarded, bool is_structured)

Construct the flags for a new JeodMemoryItem.

Private Attributes

```
• uint32_t nelems {}
```

Number of elements in the allocated array.

• uint32 t alloc info index {}

Allocation information index, max of 2^{\wedge} 32-2 tracked locations.

uint32_t unique_id {}

Unique identifier, max of 2^{32-2} allocations (zero is not used).

• uint16_t descriptor_index_hi {}

High order bits of the descriptor index.

uint8_t descriptor_index_lo {}

Low order bits of the descriptor index.

uint8_t flags {}

Flags indicating whether.

8.7.1 Detailed Description

A JeodMemoryItem contains metadata about some chunk of allocated memory.

This is a simple datatype that contains POD elements only. All data members are private and are accessible only through getters; the members are essentially constant. The only way to change the values is via a wholesale copy. Definition at line 86 of file memory_item.hh.

8.7.2 Member Enumeration Documentation

8.7.2.1 Flags

```
enum jeod::JeodMemoryItem::Flags
```

Identifies by name the bit flags the comprise a JeodMemoryItem::flag.

Enumerator

PlacementNew	Was the item constructed with placement new? There is no functional placement delete in		
	C++.		
IsArray	Was the item an array constructed via new []? This addresses the delete[] versus delete		
	issue.		
IsGuarded	Is the allocated buffer surrounded by guard words? This flag is always false in regular new		
	mode.		
IsStructured	Is the item a class (versus a primitive type)? Classes add several other twists.		
IsRegistered	Has the item been registered with the simulation engine?		
CheckPointed	Reserved for future work, as are flag bits 6 ando 7 (64 and 128).		

Definition at line 93 of file memory_item.hh.

8.7.3 Constructor & Destructor Documentation

```
8.7.3.1 JeodMemoryItem() [1/2]
jeod::JeodMemoryItem::JeodMemoryItem ( ) [default]
```

8.7.3.2 JeodMemoryItem() [2/2]

Construct a JeodMemoryItem.

The data are essentially constant, so the only viable way to set elements to meaningful values is via this non-default constructor.

Parameters

in	placement_new	Constructed with placement new?
in	is_array	Constructed with new []?
in	is_guarded	Is the item an array?
in	is_structured	Is the item a structured data type?
in	nelems_in	Number of elements
in	type_idx	Type descriptor (index)
in	alloc_idx	Macro invocation info (index)

Definition at line 86 of file memory_item.cc.

8.7.3.3 ~JeodMemoryItem()

```
\verb"jeod::JeodMemoryItem":: \sim \verb"JeodMemoryItem" ( ) [default]
```

8.7.4 Member Function Documentation

8.7.4.1 construct_flags()

Construct the flags for a new JeodMemoryItem.

Returns

Constructed flags

Parameters

in	placement_new	Constructed with placement new?
in	is_array	Constructed with new []?
in	is_guarded	Is the item an array?
in	is_structured	Is the item a structured data type?

Definition at line 47 of file memory_item.cc.

References flags, IsArray, IsGuarded, IsStructured, and PlacementNew.

8.7.4.2 get_alloc_index()

```
uint32_t jeod::JeodMemoryItem::get_alloc_index ( ) const [inline]
```

Access the allocation information index.

Returns

Allocation information index

Definition at line 246 of file memory_item.hh.

References alloc info index.

```
8.7.4.3 get_checkpointed()
```

```
bool jeod::JeodMemoryItem::get_checkpointed ( ) const [inline]
```

Access the checkpointed flag.

Returns

Checkpointed?

Definition at line 309 of file memory_item.hh.

References CheckPointed, and flags.

```
8.7.4.4 get_descriptor_index()
```

```
uint32_t jeod::JeodMemoryItem::get_descriptor_index ( ) const [inline]
```

Access the type descriptor index.

Returns

Type descriptor index

Definition at line 255 of file memory_item.hh.

References descriptor_index_hi, and descriptor_index_lo.

8.7.4.5 get_is_array()

bool jeod::JeodMemoryItem::get_is_array () const [inline]

Access the is array flag.

Returns

Allocated as an array?

Definition at line 273 of file memory item.hh.

References flags, and IsArray.

Referenced by jeod::JeodMemoryManager::destroy_memory_internal(), jeod::JeodMemoryManager::restart_ \leftarrow clear_memory(), and jeod::JeodMemoryTypeDescriptor::type_spec().

8.7.4.6 get_is_guarded()

```
bool jeod::JeodMemoryItem::get_is_guarded ( ) const [inline]
```

Access the is_guarded flag.

Returns

Is allocated memory guarded?

Definition at line 282 of file memory_item.hh.

References flags, and IsGuarded.

Referenced by jeod::JeodMemoryManager::destroy_memory_internal(), and jeod::JeodMemoryManager::restart -- _ clear_memory().

8.7.4.7 get_is_registered()

```
bool jeod::JeodMemoryItem::get_is_registered ( ) const [inline]
```

Access the checkpointed flag.

Returns

Registered with sim engine?

Definition at line 300 of file memory_item.hh.

References flags, and IsRegistered.

Referenced by jeod::JeodMemoryManager::destroy_memory_internal(), jeod::JeodMemoryManager::restart_ clear_memory(), and jeod::JeodMemoryManager::~JeodMemoryManager().

8.7.4.8 get_nelems()

```
uint32_t jeod::JeodMemoryItem::get_nelems ( ) const [inline]
```

Access the array size.

Returns

Array size

Definition at line 228 of file memory_item.hh.

References nelems.

Referenced by jeod::JeodMemoryManager::add_allocation_atomic(), jeod::JeodMemoryTypeDescriptor::buffer — _end(), jeod::JeodMemoryTypeDescriptor::buffer_size(), jeod::JeodMemoryManager::destroy_memory_internal(), jeod::JeodMemoryManager::restart_clear_memory(), and jeod::JeodMemoryTypeDescriptor::type_spec().

8.7.4.9 get_placement_new()

```
bool jeod::JeodMemoryItem::get_placement_new ( ) const [inline]
```

Access the placement_new flag.

Returns

Allocated for placement new?

Definition at line 264 of file memory_item.hh.

References flags, and PlacementNew.

Referenced by jeod::JeodMemoryManager::destroy_memory_internal(), and jeod::JeodMemoryManager::restart -- _ clear_memory().

8.7.4.10 get_unique_id()

```
uint32_t jeod::JeodMemoryItem::get_unique_id ( ) const [inline]
```

Access the unique identifier.

Returns

Unique identifier

Definition at line 237 of file memory_item.hh.

References unique_id.

8.7.4.11 is_structured_data()

```
bool jeod::JeodMemoryItem::is_structured_data ( ) const [inline]
```

Is the associated data a structure/class?

Returns

True for structured data

Definition at line 291 of file memory_item.hh.

References flags, and IsStructured.

8.7.4.12 set_is_registered()

Set the is_registered flag.

Parameters

	in	value	New value of the is_registered flag
--	----	-------	-------------------------------------

Definition at line 132 of file memory_item.cc.

References flags, and IsRegistered.

8.7.4.13 set_unique_id()

Set the unique identifier.

Parameters

in	id	Unique identifier
----	----	-------------------

Definition at line 105 of file memory_item.cc.

References jeod::MemoryMessages::internal_error, and unique_id.

Referenced by jeod::JeodMemoryManager::register_memory_internal().

8.7.5 Field Documentation

8.7.5.1 alloc_info_index

```
uint32_t jeod::JeodMemoryItem::alloc_info_index {} [private]
```

Allocation information index, max of 2^{32-2} tracked locations.

The allocation information is a string of the form "file.cc:line#" that indicates where in the code the data was allocated. The underlying string is maintained in the global memory manager's string table.trick_units(–)

Definition at line 190 of file memory item.hh.

Referenced by get_alloc_index().

8.7.5.2 descriptor_index_hi

```
uint16_t jeod::JeodMemoryItem::descriptor_index_hi {} [private]
```

High order bits of the descriptor index.

The descriptor_index specifies the type descriptor that describes the data. The underlying descriptor is maintained in the global memory manager's type descriptor table.trick_units(-)

Definition at line 205 of file memory_item.hh.

Referenced by get_descriptor_index().

8.7.5.3 descriptor_index_lo

```
uint8_t jeod::JeodMemoryItem::descriptor_index_lo {} [private]
```

Low order bits of the descriptor index.

trick units(-)

Definition at line 210 of file memory_item.hh.

Referenced by get_descriptor_index().

8.7.5.4 flags

```
uint8_t jeod::JeodMemoryItem::flags {} [private]
```

Flags indicating whether.

- The data was constructed with default new or placement new
- · The data was allocated as an array or as a single object
- · The allocated are guarded
- · The data is a structured or non-structured data type
- The data has been checkpointed (future)
- Plus three more future-use spares.trick_units(-)

Definition at line 221 of file memory item.hh.

Referenced by construct_flags(), get_checkpointed(), get_is_array(), get_is_guarded(), get_is_registered(), get_checkpointed(), get_is_guarded(), get_is_registered(), get_checkpointed(), get_is_guarded(), get_is_registered(), get_checkpointed(), get_is_guarded(), get_is_registered(), get_checkpointed(), get_is_guarded(), get_is_guarde

8.7.5.5 nelems

```
uint32_t jeod::JeodMemoryItem::nelems {} [private]
```

Number of elements in the allocated array.

trick_units(-)

Definition at line 182 of file memory_item.hh.

Referenced by get_nelems().

8.7.5.6 unique_id

```
uint32_t jeod::JeodMemoryItem::unique_id {} [private]
```

Unique identifier, max of 2³²⁻² allocations (zero is not used).

The unique identifier forms the basis of the item name sent to the simulation engine for this memory item.trick_← units(−)

Definition at line 197 of file memory_item.hh.

Referenced by get_unique_id(), and set_unique_id().

The documentation for this class was generated from the following files:

- · memory_item.hh
- memory_item.cc

8.8 jeod::JeodMemoryManager Class Reference

This class provides the interface between the macros in jeod_alloc.hh and the rest of the JEOD memory model.

```
#include <memory_manager.hh>
```

Data Structures

struct TypeEntry

The type table is indexed by an integer and contains type descriptors.

Public Types

enum DebugLevel { Debug off = 0, Summary only = 1, Error details = 2, Full details = 3 }

The memory manager as a whole and individual operations have a debug level.

• enum NameType { Typeid_type_name = 0, Demangled_type_name = 1 }

The type lookup by type name needs to know whether the provided name is a typeid name or a demangled name.

Public Member Functions

- JeodMemoryManager ()=delete
- JeodMemoryManager (const JeodMemoryManager &)=delete
- JeodMemoryManager & operator= (const JeodMemoryManager &)=delete
- JeodMemoryManager (JeodMemoryInterface &)

Construct a MemoryManager object.

virtual ~JeodMemoryManager ()

Destruct a MemoryManager object.

• void restart_clear_memory ()

Wipe out all allocated memory in anticipation of restoring the memory in some previously recording checkpoint file.

 void restart_reallocate (const std::string &mangled_type_name, uint32_t unique_id, uint32_t nelements, bool is_array)

Restore one chunk of allocated memory per a checkpoint file entry.

Static Public Member Functions

static const TypeEntry register_class (JeodMemoryTypePreDescriptor &tdesc)

Register a class with the memory manager.

static const JeodMemoryTypeDescriptor * get_type_descriptor (const std::type_info &typeid_info)

Get a type descriptor from the memory manager's type table.

static const JeodMemoryTypeDescriptor * get_type_descriptor (NameType name_type, const std::string &name)

Get a type descriptor from the memory manager's type table.

 static void * create_memory (bool is_array, unsigned int nelems, int fill, const TypeEntry &tentry, const char *file, unsigned int line)

Allocate memory and register the allocated memory with JEOD.

static bool is allocated (const void *addr, const char *file, unsigned int line)

Query whether some address was allocated by JEOD.

• static void destroy_memory (void *addr, bool delete_array, const char *file, unsigned int line)

Destroy memory previously registered with JEOD.

• static void register_container (const void *container, const std::type_info &container_type, const std::string &elem_name, JeodCheckpointable &checkpointable)

Register a checkpointable object with the memory manager.

 static void deregister_container (const void *container, const std::type_info &container_type, const std::string &elem_name, JeodCheckpointable &checkpointable)

Deregister all checkpointable object contained within some object.

• static void set_mode (JeodSimulationInterface::Mode new_mode)

Set the memory manager's simulation interface mode.

static void set_debug_level (unsigned int level)

Set the debug level.

static void set_debug_level (DebugLevel level)

Set the debug level.

static void set_guard_enabled (bool value)

Set the guard_enabled flag.

static bool is_table_empty ()

Query whether all allocated memory has been freed.

Private Types

using AllocTable = std::map< const void *, JeodMemoryItem >

An AllocTable maps memory addresses to memory descriptions.

using TypeTable = JeodMemoryTableClonable < JeodMemoryTypeDescriptor >

The type type itself is a memory table with copy implemented by clone().

Private Member Functions

• void generate_shutdown_report ()

Generate a shutdown report.

• void * create_memory_internal (bool is_array, unsigned int nelems, int fill, const TypeEntry &tentry, const char *file, unsigned int line)

Allocate memory for use with placement new and register that memory with with the memory manager and with the simulation engine.

• void register_memory_internal (const void *addr, uint32_t unique_id, bool placement_new, bool is_array, unsigned int nelems, const TypeEntry &tentry, const char *file, unsigned int line)

Allocate memory if that was not already done by the caller and register the memory with JEOD and with an external agent.

• bool is_allocated_internal (const void *addr, const char *file, unsigned int line)

Query whether some address was allocated by JEOD.

• void destroy_memory_internal (void *addr, bool delete_array, const char *file, unsigned int line)

Destroy a chunk of memory and knowledge about it.

void set_mode_internal (JeodSimulationInterface::Mode new_mode)

Set the mode and perform mode transitions.

· void begin atomic block () const

Prepare for a set of operations that must be done atomically.

void end_atomic_block (bool ignore_errors) const

End an atomic set of operations.

const TypeEntry get type entry atomic (JeodMemoryTypePreDescriptor &tdesc)

Return the type entry for the input type descriptor, adding the descriptor to the type table if the type has not yet been registered.

- const TypeEntry get_type_entry_atomic (NameType name_type, const std::string &type_name) const
 Retrieve the descriptor for the specified type from the type table.
- bool get_type_index_nolock (const JeodMemoryTypeDescriptor &tdesc, uint32_t *idx)

Retrieve the index for the specified type from the type table, adding an entry if needed.

- const JeodMemoryTypeDescriptor * get_type_descriptor_atomic (const std::type_info &typeid_info) const Retrieve the descriptor for the specified type from the type table.
- const JeodMemoryTypeDescriptor & get_type_descriptor_atomic (unsigned int idx) const

Retrieve the descriptor for the specified type from the type table.

- const JeodMemoryTypeDescriptor & get_type_descriptor_nolock (const JeodMemoryItem &item) const
 - Retrieve the descriptor for the specified type from the type table.

const std::string & get_string_atomic (unsigned int idx) const
 Retrieve the specified string from the string table.

unsigned int add string atomic (const std::string &str)

ansigned int add_string_atomic (const std..string astr

Add a location identifier string to the string table.

uint32_t get_alloc_id_atomic (const char *file, unsigned int line)

Create a unique identifier for an allocation.

void reset_alloc_id_atomic (uint32_t unique_id)

Reset the unique identifier for a restart.

 void find_alloc_entry_atomic (const void *addr, bool delete_entry, const char *file, unsigned int line, void *&found_addr, JeodMemoryItem &found_item, const JeodMemoryTypeDescriptor *&found_type)

Find the allocation table entry that matches the input address, and delete it if delete_entry is true.

 void add_allocation_atomic (const void *addr, const JeodMemoryItem &item, const JeodMemoryTypeDescriptor &tdesc, const char *file, unsigned int line)

Add the specified addr/item pair to the table.

 void delete_oldest_alloc_entry_atomic (void *&addr, JeodMemoryItem &item, const JeodMemoryTypeDescriptor *&type)

Find and delete the alloc table entry with the smallest unique id, setting the provided references with info about the deleted item.

- void * allocate_memory (std::size_t nelems, std::size_t elem_size, bool guard, int fill) const Allocate memory.
- void free_memory (void *addr, std::size_t length, bool guard, unsigned int alloc_idx, const char *file, unsigned int line) const

Release memory.

Static Private Member Functions

static bool check_master (bool error_is_fatal, int line)

Many of the static methods are a pass-through to a private non-static method, with the static method testing that the pass-through is valid.

Private Attributes

· JeodMemoryInterface & sim interface

The interface to the simulation engine's memory manager.

• DebugLevel debug_level {Error_details}

Debugging level.

• size t cur data size {}

Number of allocated user bytes (excludes management overhead).

• size t max data size {}

Maximum value attained by cur_data_size.

unsigned int max_table_size {}

Maximum value attained by alloc_table.size().

unsigned int allocation_number {}

Number of allocations.

AllocTable alloc_table

Maps memory addresses to the descriptions of those addresses.

• TypeTable type_table

Maps typeid names to type descriptors.

JeodMemoryReflectiveTable string_table

Maps unique strings to themselves.

pthread_mutex_t mutex {}

Mutex that synchronizes access to the tables.

• JeodSimulationInterface::Mode mode {JeodSimulationInterface::Construction}

Simulation interface mode.

• bool guard_enabled {true}

Data can be guarded if this is set.

Static Private Attributes

• static JeodMemoryManager * Master = nullptr

The singleton instance of the JeodMemoryManager class.

Friends

- · class InputProcessor
- void init_attrjeod__JeodMemoryManager ()

8.8.1 Detailed Description

This class provides the interface between the macros in jeod_alloc.hh and the rest of the JEOD memory model.

The public interface is via the publicly visible static methods. All nonstatic member functions are private. Each public static method relays the method call to the singleton memory manager via a correspondingly named private member function.

Singleton

The class is intended to be a singleton. The private static member JeodMemoryManager::Master points to this singular instance. The constructor sets that static member if it is null. The constructor issues a non-fatal error when multiple instances of the class are created.

Thread Safety

This class contains objects that must be accessed and updated in a thread-safe manner. The member data that must be used atomically are

- JeodMemoryManager::alloc_table Maps memory addresses to memory items
- JeodMemoryManager::type_table Maps RTTI names to type descriptors
- JeodMemoryManager::string_table Maps unique strings to themselves.
- JeodMemoryManager::cur_data_size Current size of allocated data.

- JeodMemoryManager::max_data_size Maximum of the above.
- JeodMemoryManager::max_table_size Maximum allocation table size.
- JeodMemoryManager::allocation_number Number of allocations made.

To ensure the constraint is satisfied, access to the these elements is protected by means of a mutex and is limited to a small number of methods. A pair of methods, <code>JeodMemoryManager::begin_atomic_block</code> and <code>JeodMemoryManager::end_atomic_block</code> systematize the use of the mutex. The methods that operate on the protected data are

- · Constructor and destructor.
 - The constructor operates on the protected data before it creates the mutex and marks the JeodMemoryManager object as usable. The destructor marks the object as unusable and destroys the mutex before operating on the protected data.
- JeodMemoryManager::generate_shutdown_report, which is called by the destructor after it has destroyed the mutex.
- Methods whose names end with _atomic. These methods use the begin_atomic_block / end_atomic_
 block paradigm to ensure that the operations are carried out atomically.
- Methods whose names end with _nolock. These methods operate on protected data but do so without atomic protection. These methods are called only by _atomic methods from within their atomic protection block.

Forbidden Word - Mutable

The data member JeodMemoryManager::mutex is mutable, a forbidden word per the JEOD coding standards. The coding standards allow for waivers to the standards if the exception is justified. This section provides the explanation needed to enable the use of that word in this case.

The *mutable* keyword tells the compiler to ignore modifications to mutable elements in an otherwise *const* method. The *mutex* is mutable because, athough its value does change with a successful lock, it is restored to its prelock value with an unlock. A method that could otherwise qualify as a const method can still be a const method by marking the mutex as mutable. Mutexes are one of the well-accepted types of data that typically marked as mutable.

Assumptions and Constraints on the Simulation Developer

This class places restrictions on the simulation developer.

- The simulation's MessageHandler object must be constructed prior to constructing the simulation's JeodMemoryManager object.
- The simulation's MessageHandler object must not be destroyed prior to constructing the simulation's JeodMemoryManager object.
- The simulation's JeodMemoryManager object must be constructed prior to invoking any of the JEOD_←
 ALLOC_xxx macros in other models.
- The simulation's JeodMemoryManager object must not be destroyed before other models release their allocated memory.

The recommended solution is to create an instance of a compliant SimulationInterface before creating any other models and to destroy that SimulationInterface object after destroying all other models. A simple way to achieve this in a Trick-07 simulation is to define a Trick sim object that contains a TrickSimulationInterface element and to place this sim object immediately after the sys sim object.

Assumptions and Constraints on the Simulation Engine

This class makes certain assumptions of the behavior of the simulation engine.

- The simulation engine will not spawn threads that use the JEOD memory model to allocate memory until after the SimulationInterface object has been constructed.
- The simulation engine will join all threads that use the JEOD memory model prior to destroying the SimulationInterface object.

The Trick-07 and Trick-10 simulation engines satisfies these constraints.

Assumptions and Constraints on the Simulation Developer

This class places certain limitations on the architecture of a JEOD-based simulation.

- The JeodMemoryManager destructor uses the simulation's message handler to report errors discovered during destruction and may eventually use the simulation's simulation engine memory interface to revoke the registration of memory allocated by JEOD that has not been freed. This in turn means that: The simulation's message handler and simulation engine memory interface must be destructed after destructing the memory manager. The destructors for those objects cannot use the memory manager.
- The JEOD memory allocation and deallocation macros expand into calls to memory manager methods.
 The memory manager must be viable (post construction, pre destruction) for these calls to function properly.
 This in turn means that the memory manager must be constructed very early in the overall construction process and destructed very late in in the overall destruction process.
- The supported solution to both of these issues is to use a compliant derived class of the JeodSimulation
 —
 Interface class and to ensure that this composite object created early and destroyed late. In a Trick-07
 simulation, this can be accomplished simply by placing a declaration of an object of type JeodTrickSim
 —
 Interface near the top of an S_define file. The recommended placement is just after the Trick system sim
 object.

Definition at line 212 of file memory_manager.hh.

8.8.2 Member Typedef Documentation

8.8.2.1 AllocTable

```
using jeod::JeodMemoryManager::AllocTable = std::map<const void *, JeodMemoryItem> [private]
```

An AllocTable maps memory addresses to memory descriptions.

Definition at line 350 of file memory_manager.hh.

8.8.2.2 TypeTable

using jeod::JeodMemoryManager::TypeTable = JeodMemoryTableClonable<JeodMemoryTypeDescriptor>
[private]

The type type itself is a memory table with copy implemented by clone().

Definition at line 355 of file memory_manager.hh.

8.8.3 Member Enumeration Documentation

8.8.3.1 DebugLevel

enum jeod::JeodMemoryManager::DebugLevel

The memory manager as a whole and individual operations have a debug level.

The debug levels and the message handler must be set to a sufficiently high level to enable and see the debugging output.

Enumerator

Debug_off	Debugging is off.	
Summary_only	only Summary information; Allocation data are not stored.	
Error_details	Allocation data stored and used with error messages.	
Full_details Blow-by-blow accounting of all transactions.		

Definition at line 226 of file memory_manager.hh.

8.8.3.2 NameType

enum jeod::JeodMemoryManager::NameType

The type lookup by type name needs to know whether the provided name is a typeid name or a demangled name.

Enumerator

Typeid_type_name	Name is from a std::type_info.name()
Demangled_type_name	Name is what people might use.

Definition at line 238 of file memory_manager.hh.

8.8.4 Constructor & Destructor Documentation

8.8.4.1 JeodMemoryManager() [1/3]

jeod::JeodMemoryManager::JeodMemoryManager () [delete]

8.8.4.2 JeodMemoryManager() [2/3]

8.8.4.3 JeodMemoryManager() [3/3]

Construct a MemoryManager object.

Parameters

	in,out	interface	The memory interface with the simulation engine
--	--------	-----------	---

Definition at line 62 of file memory_manager.cc.

References MAKE_DESCRIPTOR, Master, mutex, and jeod::MemoryMessages::singleton_error.

8.8.4.4 ∼JeodMemoryManager()

```
jeod::JeodMemoryManager::~JeodMemoryManager ( ) [virtual]
```

Destruct a MemoryManager object.

Assumptions and Limitations

- · In a multi-threaded environment,
 - This destructor shall be called once and once only to destroy the singleton JeodMemoryManager object.
 - The thread that calls this destructor shall wait until all other threads that access JEOD memory have finished, either by default or by force.

Note that this is a constraint on the simulation engine, not on JEOD.

Definition at line 136 of file memory_manager.cc.

 $References\ alloc_table,\ generate_shutdown_report(),\ jeod:: JeodMemoryItem:: get_is_registered(),\ get_type_ {\leftarrow}\ descriptor_nolock(),\ Master,\ mutex,\ and\ sim_interface.$

8.8.5 Member Function Documentation

8.8.5.1 add_allocation_atomic()

Add the specified addr/item pair to the table.

Assumptions and Limitations

- Operations on the map must be atomic. This method satisfies that requirement.
- The specified address must not already be in the table.

Parameters

in	addr	Newly allocated memory	
in	item	item Description of that memory	
in	tdesc	tdesc Description of the type	
in	file	Source file containing JEOD_ALLOC	
in	line Line number containing JEOD_ALLOC		

Definition at line 700 of file memory_manager_protected.cc.

References alloc_table, begin_atomic_block(), jeod::JeodMemoryTypeDescriptor::buffer_end(), jeod::Jeod MemoryTypeDescriptor::buffer_size(), jeod::MemoryMessages::corrupted_memory, cur_data_size, end_atomic_ block(), jeod::JeodMemoryItem::get_nelems(), get_type_descriptor_nolock(), max_data_size, and max_table_size.

Referenced by register_memory_internal().

8.8.5.2 add_string_atomic()

Add a location identifier string to the string table.

Assumptions and Limitations

• Operations on the map must be atomic. This method satisfies that requirement.

Returns

String table index

Parameters

Definition at line 188 of file memory_manager_protected.cc.

References jeod::JeodMemoryReflectiveTable::add(), begin_atomic_block(), end_atomic_block(), and string_table.

Referenced by register_memory_internal().

8.8.5.3 allocate_memory()

Allocate memory.

Assumptions and Limitations

- This is a low-level allocation function. It does not
 - Register the allocated memory with JEOD or with an external agent.
 - Construct the newly-allocated memory.
- The returned address should not be released using the C free function or C++ delete operator. Failure to obey this restriction will result in big problems.

Returns

Allocated memory

Parameters

in	nelems	Number of elements
in	elem_size	Size of each element
in	guard	Allocate guard bytes if set
in	fill	Fill pattern (ref. memset)

Definition at line 700 of file memory_manager.cc.

 $References\ jeod:: MAGIC0,\ jeod:: MAGIC1,\ and\ jeod:: Memory Messages:: out_of_memory.$

Referenced by create_memory_internal(), and restart_reallocate().

8.8.5.4 begin_atomic_block()

```
void jeod::JeodMemoryManager::begin_atomic_block ( ) const [private]
```

Prepare for a set of operations that must be done atomically.

Assumptions and Limitations

• This method must be used in conjunction with end atomic block.

```
try {
  begin_atomic_block ();
  operate_on_protected_members();
  end_atomic_block (false);
}
catch (...) {
  end_atomic_block (true);
  throw;
}
```

 See the class header for a detailed description. Purpose: (Prepare for a set of operations that must be done atomically.) Assumptions and limitations: This method must be used in conjunction with end_← atomic block.

```
try {
   begin_atomic_block ();
   operate_on_protected_members();
   end_atomic_block (false);
}
catch (...) {
   end_atomic_block (true);
   throw;
}
```

(See the class header for a detailed description.))

Definition at line 97 of file memory_manager_protected.cc.

References jeod::MemoryMessages::lock error, and mutex.

Referenced by add_allocation_atomic(), add_string_atomic(), delete_oldest_alloc_entry_atomic(), find_alloc_centry_atomic(), get_alloc_id_atomic(), get_string_atomic(), get_type_descriptor_atomic(), get_type_entry_atomic(), and reset_alloc_id_atomic().

8.8.5.5 check_master()

Many of the static methods are a pass-through to a private non-static method, with the static method testing that the pass-through is valid.

This method performs that test and handles the failure response.

Returns

True if Master is not null

Parameters

in	error_is_fatal	True $=>$ call fail
in	line	LINE

Definition at line 59 of file memory_manager_static.cc.

References Master, and jeod::MemoryMessages::singleton_error.

Referenced by create_memory(), deregister_container(), destroy_memory(), get_type_descriptor(), is_allocated(), is_table_empty(), register_class(), register_container(), set_debug_level(), set_guard_enabled(), and set_mode().

8.8.5.6 create_memory()

Allocate memory and register the allocated memory with JEOD.

Assumptions and Limitations

- This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.
- The allocated memory is not constructed by this method. The calling routine should initialize the memory with placement new.
- Access to this method is through the JEOD memory allocation macros. Use in any other context is caveat emptor.

Returns

Allocated memory

Parameters

in	is_array	Memory constructed by new[] if set
in	nelems Number of elements to be allocated	
in	fill	Byte fill pattern
in	tentry	Type entry
in	file	Source file containing JEOD_ALLOC
in	line	Line number containing JEOD_ALLOC

Definition at line 243 of file memory_manager_static.cc.

References check_master(), create_memory_internal(), and Master.

8.8.5.7 create_memory_internal()

Allocate memory for use with placement new and register that memory with with the memory manager and with the simulation engine.

Assumptions and Limitations

- This method will be invoked via the JEOD memory allocation macros. Use in any other context is a case of caveat emptor.
- The type descriptor index must index the type descriptor that describes the type to be created.
- The memory is allocated but not constructed. Construction is the responsibility of the caller. The JEOD memory allocation macros construct the allocated memory via placement new.

Returns

Allocated memory

Parameters

in	is_array	Memory constructed by new[] if set	
in	nelems	ems Number of elements to be allocated	
in	fill	Byte fill pattern	
in	tentry	Type entry	
in	file	Source file containing JEOD_ALLOC	
in	line	Line number containing JEOD_ALLOC	

Definition at line 387 of file memory_manager.cc.

References allocate_memory(), jeod::JeodMemoryTypeDescriptor::get_size(), guard_enabled, register_memory ← _internal(), and jeod::JeodMemoryManager::TypeEntry::tdesc.

Referenced by create_memory().

8.8.5.8 delete_oldest_alloc_entry_atomic()

```
JeodMemoryItem & item,
const JeodMemoryTypeDescriptor *& type ) [private]
```

Find and delete the alloc table entry with the smallest unique id, setting the provided references with info about the deleted item.

The addr and type are set to NULL if the table is empty.

Assumptions and Limitations

- Operations on the map must be atomic. This method satisfies that requirement.
- If the restore doesn't work the sim will be knee deep in alligators.

Parameters

out	addr	Address found in table
out	item	Descriptor for above
out	type	Type descriptor

Definition at line 802 of file memory_manager_protected.cc.

References alloc_table, allocation_number, begin_atomic_block(), jeod::JeodMemoryTypeDescriptor::buffer_size(), cur_data_size, end_atomic_block(), and get_type_descriptor_nolock().

Referenced by restart_clear_memory().

8.8.5.9 deregister_container()

Deregister all checkpointable object contained within some object.

Assumptions and Limitations

• This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.

Parameters

in	container	Object container
in	container_type	Container type info
in	elem_name	Element name
in,out	checkpointable	Checkpointable object

Definition at line 368 of file memory_manager_static.cc.

References check_master(), get_type_descriptor_atomic(), Master, jeod::MemoryMessages::null_pointer, and sim_interface.

8.8.5.10 destroy_memory()

Destroy memory previously registered with JEOD.

Assumptions and Limitations

- This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.
- The provided memory shall not be used in any way after calling this method. This method destructs and frees that memory.
- Access to this method is through the JEOD memory allocation macros. Use in any other context is caveat emptor.

Parameters

in,out	addr	Memory to be destroyed
in	delete_array	DELETE_ARRAY (true) vs. DELETE_OBJECT
in	file	Source file containing delete
in	line	Line number containing delete

Definition at line 300 of file memory_manager_static.cc.

References check_master(), destroy_memory_internal(), and Master.

8.8.5.11 destroy_memory_internal()

Destroy a chunk of memory and knowledge about it.

This includes

- · De-registering the memory with JEOD and with an external agent.
- · Invoking the destructor in the case of a structured type.
- · Releasing the memory to the system.

Parameters

in,out	addr	Memory to be destroyed
in	delete_array	DELETE_ARRAY (true) vs. DELETE_OBJECT
in	file	Source file containing delete
in	line	Line number containing delete

Definition at line 549 of file memory_manager.cc.

References jeod::JeodMemoryTypeDescriptor::buffer_size(), jeod::MemoryMessages::debug, debug_level, jeod \hookleftarrow ::JeodMemoryTypeDescriptor::destroy_memory(), find_alloc_entry_atomic(), free_memory(), jeod::JeodMemory \hookleftarrow Item::get_alloc_index(), jeod::JeodMemoryItem::get_is_array(), jeod::JeodMemoryItem::get_is_guarded(), jeod \hookleftarrow ::JeodMemoryItem::get_is_registered(), jeod::JeodMemoryItem::get_relems(), jeod::JeodMemoryItem::get_ \hookleftarrow placement_new(), get_string_atomic(), jeod::MemoryMessages::null_pointer, sim_interface, jeod::Memory \hookleftarrow Messages::suspect_pointer, and jeod::JeodMemoryTypeDescriptor::type_spec().

Referenced by destroy_memory().

8.8.5.12 end_atomic_block()

End an atomic set of operations.

Parameters

in	ignore_errors	Ignore errors from unlock?

Definition at line 117 of file memory_manager_protected.cc.

References jeod::MemoryMessages::lock_error, and mutex.

Referenced by add_allocation_atomic(), add_string_atomic(), delete_oldest_alloc_entry_atomic(), find_alloc_entry_atomic(), get_alloc_id_atomic(), get_string_atomic(), get_type_descriptor_atomic(), get_type_entry_atomic(), and reset_alloc_id_atomic().

8.8.5.13 find_alloc_entry_atomic()

Find the allocation table entry that matches the input address, and delete it if delete_entry is true.

The matching is strict. A match occurs only if the input address is a key in the allocation table. An error is reported if the input address is inside the allocated space corresponding to one of the allocation table entries.

Output values:

- · Entry not found:
 - The found addr and found type are set to NULL.
 - The found item is not touched.
- · Entry found:
 - The found_addr is set to the key of the found entry.
 - The found_item is copied from the value of the found entry.
 - The *found_type* points to the type_descriptor entry for the found item's type.

Assumptions and Limitations

• Operations on the map must be atomic. This method satisfies that requirement.

Parameters

in	addr	Address
in	delete_entry	Indicates entry is to be deleted
in	file	Source file containing JEOD_XXX
in	line Line number containing JEOD_	
out	found_addr	Address found in table
out	found_item	Descriptor for above
out	found_type	Type descriptor

Definition at line 587 of file memory manager protected.cc.

References alloc_table, begin_atomic_block(), jeod::JeodMemoryTypeDescriptor::buffer_size(), cur_data_size, end_atomic_block(), jeod::JeodMemoryTypeDescriptor::get_name(), get_type_descriptor_nolock(), and jeod:: \leftarrow MemoryMessages::suspect_pointer.

Referenced by destroy_memory_internal(), and is_allocated_internal().

8.8.5.14 free_memory()

Release memory.

Assumptions and Limitations

- · This is a low-level de-allocation function. It does not
 - De-register the memory with JEOD or with an external agent.
 - Destruct the memory.

Parameters

in,out	addr	Memory to be freed
in	length	Buffer size
in	guard	Memory was guarded if set
in	alloc_idx	Allocation index
in	file	Source file containing delete
in	line	Line number containing delete

Definition at line 775 of file memory_manager.cc.

References jeod::MemoryMessages::corrupted_memory, get_string_atomic(), jeod::MAGIC0, and jeod::MAGIC1.

Referenced by destroy_memory_internal(), and restart_clear_memory().

8.8.5.15 generate_shutdown_report()

```
void jeod::JeodMemoryManager::generate_shutdown_report ( ) [private]
```

Generate a shutdown report.

Assumptions and Limitations

• This method is to be called by the destructor only. It freely accesses tabular data, the assumption being that the mutex and flags that protect that data are now gone.

Definition at line 180 of file memory_manager.cc.

References alloc_table, jeod::MemoryMessages::corrupted_memory, jeod::MemoryMessages::debug, debug level, jeod::JeodMemoryTable valueType >::get(), jeod::JeodMemoryItem::get_alloc_index(), get_type_descriptor_nolock(), max_data_size, max_table_size, string_table, and jeod::JeodMemoryTypeDescriptor::type_descriptor::type_spec().

Referenced by ~JeodMemoryManager().

8.8.5.16 get_alloc_id_atomic()

Create a unique identifier for an allocation.

Assumptions and Limitations

• Operations on the map must be atomic. This method satisfies that requirement.

Returns

Allocation ID

Parameters

	in	file	Source file containing JEOD_ALLOC
ſ	in	line	Line number containing JEOD_ALLOC

Definition at line 490 of file memory_manager_protected.cc.

References allocation_number, begin_atomic_block(), jeod::MemoryMessages::corrupted_memory, and end_ \leftarrow atomic_block().

Referenced by register_memory_internal().

8.8.5.17 get_string_atomic()

```
const std::string & jeod::JeodMemoryManager::get_string_atomic ( unsigned int idx ) const [private]
```

Retrieve the specified string from the string table.

Assumptions and Limitations

• Operations on the map must be atomic. This method satisfies that requirement.

Returns

String table index

Parameters

in <i>idx</i>	Class index
---------------	-------------

Definition at line 154 of file memory_manager_protected.cc.

References begin_atomic_block(), end_atomic_block(), jeod::JeodMemoryTable< ValueType >::get(), jeod:: \leftarrow MemoryMessages::internal_error, and string_table.

Referenced by destroy_memory_internal(), and free_memory().

8.8.5.18 get_type_descriptor() [1/2]

Get a type descriptor from the memory manager's type table.

Assumptions and Limitations

• This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.

Returns

Type descriptor

Parameters

in	typeid_info	C++ type descriptor
----	-------------	---------------------

Definition at line 184 of file memory_manager_static.cc.

References check_master(), get_type_descriptor_atomic(), and Master.

Referenced by jeod::JeodMemoryTypeDescriptor::base_type().

```
8.8.5.19 get_type_descriptor() [2/2]
```

Get a type descriptor from the memory manager's type table.

Assumptions and Limitations

• This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.

Returns

Type descriptor

Parameters

in	name_type	Typeid or demangled name
in	type_name	Type name

Definition at line 209 of file memory_manager_static.cc.

References check_master(), get_type_entry_atomic(), Master, and jeod::JeodMemoryManager::TypeEntry::tdesc.

Retrieve the descriptor for the specified type from the type table.

Assumptions and Limitations

· Operations on the map must be atomic. This method satisfies that requirement.

Returns

Type descriptor

Parameters

in	typeid_info	Type info
----	-------------	-----------

Definition at line 333 of file memory_manager_protected.cc.

Referenced by deregister_container(), get_type_descriptor(), and register_container().

Retrieve the descriptor for the specified type from the type table.


Assumptions and Limitations

- The input index is non-zero. This assumption is enforced.
- Operations on the map must be atomic. This method satisfies that requirement.

Returns

Type descriptor

Parameters



Definition at line 442 of file memory_manager_protected.cc.

References begin_atomic_block(), end_atomic_block(), jeod::JeodMemoryTable < ValueType >::get(), jeod:: \leftarrow MemoryMessages::internal_error, and type_table.

8.8.5.22 get_type_descriptor_nolock()

Retrieve the descriptor for the specified type from the type table.

Assumptions and Limitations

- The type is in the table. A core dump will result if it is not.
- · Operations on the type table must be atomic. This method does not satisfy that requirement.

Returns

Type descriptor

Parameters

in	item	Memory descriptor
----	------	-------------------

Definition at line 561 of file memory_manager.hh.

Referenced by add_allocation_atomic(), delete_oldest_alloc_entry_atomic(), find_alloc_entry_atomic(), generate \leftarrow _shutdown_report(), and \sim JeodMemoryManager().

```
8.8.5.23 get_type_entry_atomic() [1/2]
```

Return the type entry for the input type descriptor, adding the descriptor to the type table if the type has not yet been registered.

Assumptions and Limitations

- The mangled name returned by the std::type_info name method is unique across all allocatable types and is invariant.
- Operations on the map must be atomic. This method satisfies that requirement.

Returns

Type descriptor index

Parameters

in	tdesc	Type pre-descriptor
----	-------	---------------------

Definition at line 273 of file memory manager protected.cc.

References jeod::JeodMemoryTable< ValueType >::add(), begin_atomic_block(), jeod::MemoryMessages::debug, debug_level, end_atomic_block(), jeod::JeodMemoryTable< ValueType >::find(), jeod::JeodMemoryTable< ValueType >::get(), jeod::JeodMemoryTypePreDescriptor::get_descriptor(), jeod::JeodMemoryTypeDescriptor::get_name(), jeod::JeodMemoryTypePreDescriptor::get_typeid(), and type table.

Referenced by get_type_descriptor(), register_class(), and restart_reallocate().

Retrieve the descriptor for the specified type from the type table.

Assumptions and Limitations

· Operations on the map must be atomic. This method satisfies that requirement.

Returns

Type entry

Parameters

in	name_type	Name type spec
in	type_name	Type name

Definition at line 373 of file memory_manager_protected.cc.

References jeod::JeodMemoryTable< ValueType >::begin(), begin_atomic_block(), jeod::JeodMemoryTable< ValueType >::end(), end_atomic_block(), jeod::JeodMemoryTable< ValueType >::find(), jeod::JeodMemoryTypeDescriptor::get_name(), type_table, and Typeid_type_name.

8.8.5.25 get_type_index_nolock()

Retrieve the index for the specified type from the type table, adding an entry if needed.

Assumptions and Limitations

• Operations on the type table must be atomic. This method does not satisfy that requirement.

Returns

True => table updated

Parameters

in	tdesc	Descriptor
out	idx	Type descriptor index

Definition at line 235 of file memory_manager_protected.cc.

References jeod::JeodMemoryTable< ValueType >::add(), jeod::JeodMemoryTable< ValueType >::find(), jeod::

JeodMemoryTypeDescriptor::get_typeid(), and type_table.

8.8.5.26 is_allocated()

Query whether some address was allocated by JEOD.

Assumptions and Limitations

• This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.

Returns

True if allocated by JEOD

Parameters

in	addr	Memory to be queried
in	file	Source file containing query
in	line	Line number containing query

Definition at line 270 of file memory_manager_static.cc.

References check_master(), is_allocated_internal(), and Master.

8.8.5.27 is_allocated_internal()

Query whether some address was allocated by JEOD.

Returns

True if the address in question was allocated by JEOD

Parameters

	in	addr	Memory to be queried	
	in	file	Source file containing query	
Ī	in	line	Line number containing query	

Definition at line 519 of file memory_manager.cc.

References find_alloc_entry_atomic().

Referenced by is_allocated().

```
8.8.5.28 is_table_empty()
```

```
bool jeod::JeodMemoryManager::is_table_empty ( ) [static]
```

Query whether all allocated memory has been freed.

Assumptions and Limitations

• Intended for testing use only. This method does not use a thread-safe query.

Returns

Has all memory been freed?

Definition at line 132 of file memory_manager_static.cc.

References alloc_table, check_master(), and Master.

8.8.5.29 operator=()

8.8.5.30 register_class()

```
\label{lem:const_JeodMemoryManager::register_class} \begin{small} \beg
```

Register a class with the memory manager.

Assumptions and Limitations

- This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.
- Access to this method is through the JEOD memory allocation macros. Use in any other context is caveat emptor.

Returns

Type entry for the class

Parameters

in tdesc Type pre-descriptor	or .
------------------------------	------

Definition at line 158 of file memory_manager_static.cc.

References check_master(), get_type_entry_atomic(), and Master.

8.8.5.31 register_container()

Register a checkpointable object with the memory manager.

Assumptions and Limitations

• This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.

Parameters

in	container	Object container
in	container_type	Container type info
in	elem_name	Element name
in,out	checkpointable	Checkpointable object

Definition at line 322 of file memory_manager_static.cc.

References check_master(), get_type_descriptor_atomic(), Master, jeod::MemoryMessages::null_pointer, and sim_interface.

8.8.5.32 register_memory_internal()

Allocate memory if that was not already done by the caller and register the memory with JEOD and with an external agent.

Assumptions and Limitations

- This method will be invoked via the JEOD memory allocation macros. Use in any other context is caveat emptor.
- The corresponding delete macro will be used to delete the memory. Using the C free function or the C++ delete operator can cause *big* problems.
- The delete macro will be expanded with the same placement new option as was used in the allocation macro that resulted in this call.
- The memory is not constructed. That is the job of the expansion of the JEOD_ALLOC macro.

Parameters

in	addr	Memory to be registered
in	unique_id	Unique id
in	placement_new	Was memory allocated by this model?
in	is_array	Was memory allocated as an array?
in	nelems	Array size
in	tentry	Type entry
in	file	Source file containing JEOD_ALLOC
in	line	Line number containing JEOD_ALLOC

Definition at line 421 of file memory_manager.cc.

References add_allocation_atomic(), add_string_atomic(), jeod::JeodMemoryTypeDescriptor::buffer_size(), jeod \hookleftarrow ::MemoryMessages::debug, debug_level, get_alloc_id_atomic(), jeod::JeodMemoryTypeDescriptor::get_register \hookleftarrow _instances(), jeod::JeodMemoryManager::TypeEntry::index, jeod::MemoryMessages::invalid_size, jeod::Jeod \hookleftarrow MemoryTypeDescriptor::is_structured(), reset_alloc_id_atomic(), jeod::JeodMemoryTypeDescriptor::type_spec().

Referenced by create memory internal(), and restart reallocate().

8.8.5.33 reset_alloc_id_atomic()

Reset the unique identifier for a restart.

Assumptions and Limitations

· Operations on the map must be atomic. This method satisfies that requirement.

Parameters

in	unique↔	Unique id of a restored allocation
	_id	

Definition at line 537 of file memory_manager_protected.cc.

References allocation_number, begin_atomic_block(), and end_atomic_block().

Referenced by register_memory_internal().

8.8.5.34 restart_clear_memory()

```
void jeod::JeodMemoryManager::restart_clear_memory ( )
```

Wipe out all allocated memory in anticipation of restoring the memory in some previously recording checkpoint file.

Assumptions and Limitations

• If the restore doesn't work the sim will be knee deep in alligators.

Definition at line 272 of file memory_manager.cc.

References allocation_number, jeod::JeodMemoryTypeDescriptor::buffer_size(), cur_data_size, delete_oldest_ \leftarrow alloc_entry_atomic(), jeod::JeodMemoryTypeDescriptor::destroy_memory(), free_memory(), jeod::JeodMemory \leftarrow Item::get_alloc_index(), jeod::JeodMemoryItem::get_is_array(), jeod::JeodMemoryItem::get_is_guarded(), jeod::JeodMemoryItem::get_odMemo

8.8.5.35 restart_reallocate()

Restore one chunk of allocated memory per a checkpoint file entry.

Assumptions and Limitations

• This restores the allocation, but not the contents. The contents will soon be restored by the simulation engine.

Parameters

in	mangled_type_name	Mangled type name
in	unique_id	Unique id
in	nelements	Number of elements
in	is_array	True => an array

Definition at line 320 of file memory_manager.cc.

References allocate_memory(), jeod::JeodMemoryTypeDescriptor::construct_array(), jeod::JeodMemoryType Descriptor::get_size(), get_type_entry_atomic(), guard_enabled, register_memory_internal(), jeod::Memory Messages::suspect_pointer, jeod::JeodMemoryManager::TypeEntry::tdesc, and Typeid_type_name.

```
8.8.5.36 set_debug_level() [1/2]
```

Set the debug level.

Parameters

in	level	New debug level
----	-------	-----------------

Definition at line 98 of file memory_manager_static.cc.

References Full_details.

```
8.8.5.37 set_debug_level() [2/2]
```

Set the debug level.

Parameters

in	level	New debug level

Definition at line 84 of file memory_manager_static.cc.

References check_master(), debug_level, and Master.

8.8.5.38 set_guard_enabled()

```
void jeod::JeodMemoryManager::set_guard_enabled ( bool\ value\ ) \quad [static]
```

Set the guard_enabled flag.

Parameters

```
in value New value
```

Definition at line 114 of file memory_manager_static.cc.

References check_master(), guard_enabled, and Master.

8.8.5.39 set_mode()

Set the memory manager's simulation interface mode.

Assumptions and Limitations

• This method must not be called before the singleton memory manager has been created or after it has been destroyed. A fatal error results when this is not true.

Parameters

in	new_mode	New mode

Definition at line 411 of file memory_manager_static.cc.

References check_master(), Master, and set_mode_internal().

8.8.5.40 set_mode_internal()

Set the mode and perform mode transitions.

Parameters

in <i>new_mode</i>	New mode
--------------------	----------

Definition at line 665 of file memory_manager.cc.

References mode.

Referenced by set_mode().

8.8.6 Friends And Related Function Documentation

8.8.6.1 init_attrjeod__JeodMemoryManager

```
void init_attrjeod__JeodMemoryManager ( ) [friend]
```

8.8.6.2 InputProcessor

```
friend class InputProcessor [friend]
```

Definition at line 214 of file memory_manager.hh.

8.8.7 Field Documentation

8.8.7.1 alloc_table

```
AllocTable jeod::JeodMemoryManager::alloc_table [private]
```

Maps memory addresses to the descriptions of those addresses.

trick_io(**)

Definition at line 522 of file memory_manager.hh.

Referenced by add_allocation_atomic(), delete_oldest_alloc_entry_atomic(), find_alloc_entry_atomic(), generate __shutdown_report(), is_table_empty(), and ~JeodMemoryManager().

8.8.7.2 allocation_number

```
unsigned int jeod::JeodMemoryManager::allocation_number {} [private]
```

Number of allocations.

This always increments and can be adjusted upward on restarts.trick_io(*o) trick_units(-)

Definition at line 513 of file memory_manager.hh.

Referenced by delete_oldest_alloc_entry_atomic(), get_alloc_id_atomic(), reset_alloc_id_atomic(), and restart_collear memory().

8.8.7.3 cur data size

```
size_t jeod::JeodMemoryManager::cur_data_size {} [private]
```

Number of allocated user bytes (excludes management overhead).

```
trick_io(*o) trick_units(-)
```

Definition at line 497 of file memory_manager.hh.

Referenced by add_allocation_atomic(), delete_oldest_alloc_entry_atomic(), find_alloc_entry_atomic(), and restart_clear_memory().

8.8.7.4 debug_level

```
DebugLevel jeod::JeodMemoryManager::debug_level {Error_details} [private]
```

Debugging level.

- 0 = Minimal output, errors only.
- 1 = Summary report, generated just before exit(0).
- 2 = Report unfreed memory as well.
- 3 = Blow-by-blow report of each allocation and deallocation.trick_units(-)

Definition at line 492 of file memory_manager.hh.

Referenced by destroy_memory_internal(), generate_shutdown_report(), get_type_entry_atomic(), register_ \leftarrow memory_internal(), and set_debug_level().

8.8.7.5 guard_enabled

```
bool jeod::JeodMemoryManager::guard_enabled {true} [private]
```

Data can be guarded if this is set.

If not set, guards will never be established.trick_units(-)

Definition at line 548 of file memory_manager.hh.

Referenced by create_memory_internal(), restart_reallocate(), and set_guard_enabled().

8.8.7.6 Master

```
JeodMemoryManager * jeod::JeodMemoryManager::Master = nullptr [static], [private]
```

The singleton instance of the JeodMemoryManager class.

The constructor sets this pointer.trick_io(*o) trick_units(-)

Definition at line 368 of file memory manager.hh.

Referenced by check_master(), create_memory(), deregister_container(), destroy_memory(), get_type_ \leftarrow descriptor(), is_allocated(), is_table_empty(), JeodMemoryManager(), register_class(), register_container(), set_ \leftarrow debug_level(), set_guard_enabled(), set_mode(), and \sim JeodMemoryManager().

8.8.7.7 max_data_size

```
size_t jeod::JeodMemoryManager::max_data_size {} [private]
```

Maximum value attained by cur_data_size.

```
trick_io(*o) trick_units(-)
```

Definition at line 502 of file memory_manager.hh.

Referenced by add_allocation_atomic(), generate_shutdown_report(), and restart_clear_memory().

8.8.7.8 max table size

```
unsigned int jeod::JeodMemoryManager::max_table_size {} [private]
```

Maximum value attained by alloc_table.size().

```
trick_io(*o) trick_units(-)
```

Definition at line 507 of file memory_manager.hh.

Referenced by add_allocation_atomic(), generate_shutdown_report(), and restart_clear_memory().

8.8.7.9 mode

JeodSimulationInterface::Mode jeod::JeodMemoryManager::mode {JeodSimulationInterface::Construction}
[private]

Simulation interface mode.

trick_units(-)

Definition at line 542 of file memory manager.hh.

Referenced by set_mode_internal().

8.8.7.10 mutex

```
pthread_mutex_t jeod::JeodMemoryManager::mutex {} [mutable], [private]
```

Mutex that synchronizes access to the tables.

trick_io(**)

Definition at line 537 of file memory_manager.hh.

Referenced by begin_atomic_block(), end_atomic_block(), JeodMemoryManager(), and ~JeodMemoryManager().

8.8.7.11 sim_interface

```
JeodMemoryInterface& jeod::JeodMemoryManager::sim_interface [private]
```

The interface to the simulation engine's memory manager.

trick_io(*o) trick_units(-)

Definition at line 483 of file memory_manager.hh.

Referenced by deregister_container(), destroy_memory_internal(), register_container(), register_memory_ \hookleftarrow internal(), restart_clear_memory(), and \sim JeodMemoryManager().

8.8.7.12 string_table

JeodMemoryReflectiveTable jeod::JeodMemoryManager::string_table [private]

Maps unique strings to themselves.

trick_io(**)

Definition at line 532 of file memory_manager.hh.

Referenced by add_string_atomic(), generate_shutdown_report(), and get_string_atomic().

8.8.7.13 type_table

```
TypeTable jeod::JeodMemoryManager::type_table [private]
```

Maps typeid names to type descriptors.

```
trick_io(**)
```

Definition at line 527 of file memory manager.hh.

Referenced by get_type_descriptor_atomic(), get_type_entry_atomic(), and get_type_index_nolock().

The documentation for this class was generated from the following files:


- memory_manager.hh
- memory_manager.cc
- memory_manager_protected.cc
- memory_manager_static.cc

8.9 jeod::JeodMemoryReflectiveTable Class Reference

A JeodMemoryReflectiveTable maps strings to themselves.

```
#include <memory_table.hh>
```

Inheritance diagram for jeod::JeodMemoryReflectiveTable:



Public Member Functions

• JeodMemoryReflectiveTable ()

Default constructor.

- JeodMemoryReflectiveTable (const JeodMemoryReflectiveTable &)=delete
- JeodMemoryReflectiveTable & operator= (const JeodMemoryReflectiveTable &)=delete
- unsigned int add (const std::string &keyval)

Add a key to the table.

Private Member Functions

unsigned int add (const std::string &key, const std::string &val)
 Not implemented.

Additional Inherited Members

8.9.1 Detailed Description

A JeodMemoryReflectiveTable maps strings to themselves.

Definition at line 413 of file memory_table.hh.

8.9.2 Constructor & Destructor Documentation

```
8.9.2.1 JeodMemoryReflectiveTable() [1/2]
```

```
jeod::JeodMemoryReflectiveTable::JeodMemoryReflectiveTable ( ) [inline]
```

Default constructor.

Definition at line 420 of file memory_table.hh.

8.9.2.2 JeodMemoryReflectiveTable() [2/2]

8.9.3 Member Function Documentation

```
8.9.3.1 add() [1/2]
```

Not implemented.

Referenced by jeod::JeodMemoryManager::add_string_atomic().

```
8.9.3.2 add() [2/2]
```

Add a key to the table.

A reflective table has values equal to keys.

Returns

Index number mapped by the key.

Parameters

in	keyval	Key (and value) to be added to the table.
----	--------	---

Definition at line 442 of file memory_table.hh.

References jeod::JeodMemoryTable< ValueType >::add().

8.9.3.3 operator=()

The documentation for this class was generated from the following file:


· memory_table.hh

8.10 jeod::JeodMemoryTable< ValueType > Class Template Reference

A JeodMemoryTable maps strings to values with a coordinated map/vector pair.

```
#include <memory_table.hh>
```

Inheritance diagram for jeod::JeodMemoryTable < ValueType >:



Public Types

- using NameIndex = std::map< const std::string, unsigned int >
 Maps strings to an index number.
- using ValueList = std::vector< const ValueType * >

Maps index numbers to key values.

• using const_value_iterator = typename ValueList::const_iterator

Const iterator over values.

Public Member Functions

• JeodMemoryTable ()

Default constructor.

virtual ~JeodMemoryTable ()

Destructor.

- JeodMemoryTable (const JeodMemoryTable &)=delete
- JeodMemoryTable & operator= (const JeodMemoryTable &)=delete
- · unsigned int find (const std::string &key) const

Find the index number at which key/value pair is stored in the table.

• const_value_iterator begin () const

Returns a const iterator that points to the first element of the list.

const_value_iterator end () const

Returns a const iterator that points past the last element of the list.

unsigned int add (const std::string &key, const ValueType &val)

Add a key/value pair to the table.

• void del (const std::string &key)

Delete the key and associated data from the table.

const ValueType * get (unsigned int idx) const

Retrieve the value for the specified index from the list.

Protected Member Functions

virtual const ValueType * clone (const ValueType &value) const =0
 (Somehow) clone the input value.

Private Attributes

• NameIndex string_to_index

Maps keys to indices in the value_list.

ValueList value_list

Vector of values.

8.10.1 Detailed Description

 $\label{lem:lemplate} \begin{tabular}{ll} template < typename \ ValueType > \\ class \ jeod::JeodMemoryTable < ValueType > \\ \end{tabular}$

A JeodMemoryTable maps strings to values with a coordinated map/vector pair.

Template Parameters

ValueType	The underlying type of the values maintained in the table. The stored values are pointers to this
	underlying type.

A JeodMemoryTable contains two data members: a std::map and a std::vector. The map data member maps keys to integers. The integer mapped by a key is the index into the vector where the value associated with the key is stored.

So why not just use a map? The reason is that storing an integer requires less memory than storing a string or a pointer to a string, particularly on 64 bit machines. In the application at hand, keeping track of memory allocations, the number of data types is relatively small compared to the to the number of allocated chunks of data. The extra overhead of maintaining a map and a vector is small compared to the savings that results from storing thousands of integers rather than pointers or strings.

Principal Operations

add()

Returns the integer value associated with a key in the table's map. In the case of a new key/value pair, a new key/vector size entry is added to the map and the value is added to the end of the vector. Note well: The value is ignored when the key is already in the map.

del()

Deletes the key from the table's map and deletes the cloned value at the corresponding index. The vector itself is modified (truncated) only in the special case of deleting the last-added entry. This ensures that stored indices will remain valid.

get()

Returns the value in the table's vector at the specified index.

Assumptions and Limitations

- The value is ignored for duplicate key entries. The underlying assumption is that all of the values for those duplicate entries are somehow equal to one another.
- As-is, the table is not thread-safe. Calls to add() and get() made in a multi-threaded environment should be protected by a mutex. This protection is the responsibility of the (programmatic) users.
- JEOD reserves index 0 for internal use. Valid indices are positive.
- The del() method should be used only if the (programmatic) user *knows* that no other references to the to-be-deleted entry exist.

Definition at line 123 of file memory_table.hh.

8.10.2 Member Typedef Documentation

8.10.2.1 const_value_iterator

```
template<typename ValueType>
using jeod::JeodMemoryTable< ValueType >::const_value_iterator = typename ValueList::const_↔
iterator
```

Const iterator over values.

Definition at line 140 of file memory_table.hh.

8.10.2.2 NameIndex

```
template<typename ValueType>
using jeod::JeodMemoryTable< ValueType >::NameIndex = std::map<const std::string, unsigned
int>
```

Maps strings to an index number.

Definition at line 130 of file memory_table.hh.

8.10.2.3 ValueList

```
template<typename ValueType>
using jeod::JeodMemoryTable< ValueType >::ValueList = std::vector<const ValueType *>
```

Maps index numbers to key values.

Definition at line 135 of file memory table.hh.

8.10.3 Constructor & Destructor Documentation

8.10.3.1 JeodMemoryTable() [1/2]

```
template<typename ValueType>
jeod::JeodMemoryTable< ValueType >::JeodMemoryTable ( ) [inline]
```

Default constructor.

Note that JEOD reserves table index 0 as meaning nothing.

Definition at line 148 of file memory_table.hh.

8.10.3.2 ~JeodMemoryTable()

```
template<typename ValueType>
virtual jeod::JeodMemoryTable< ValueType >::~JeodMemoryTable ( ) [inline], [virtual]
```

Destructor.

The contents of the vector are clones created by add() and hence must be deleted to avoid a leak.

Definition at line 161 of file memory_table.hh.

8.10.3.3 JeodMemoryTable() [2/2]

8.10.4 Member Function Documentation

8.10.4.1 add()

Add a key/value pair to the table.

Returns

Index number mapped by the key

Parameters

in	key	Key	
in	val	Value	

Definition at line 231 of file memory_table.hh.

8.10.4.2 begin()

```
template<typename ValueType>
const_value_iterator jeod::JeodMemoryTable< ValueType >::begin ( ) const [inline]
```

Returns a const iterator that points to the first element of the list.

Definition at line 212 of file memory_table.hh.

Referenced by jeod::JeodMemoryManager::get_type_entry_atomic().

8.10.4.3 clone()

(Somehow) clone the input value.

Returns

Clone of input value.

Parameters

in value Value to be cloned.

 $Implemented\ in\ jeod:: JeodMemoryTableCopyable < \ valueType >,\ jeod:: JeodMemoryTableCopyable < \ std:: string >, \\ jeod:: JeodMemoryTableClonable < \ valueType >,\ and\ jeod:: JeodMemoryTableClonable < \ JeodMemoryTypeDescriptor >. \\$

 $Referenced \ by \ jeod:: JeodMemoryTable < JeodMemoryTypeDescriptor > :: add().$

8.10.4.4 del()

Delete the key and associated data from the table.

Use with care.

Parameters

```
in key Key
```

Exceptions

```
std::invalid_argument on attempting to delete an element that is not in the table.
```

Definition at line 262 of file memory table.hh.

8.10.4.5 end()

```
template<typename ValueType>
const_value_iterator jeod::JeodMemoryTable< ValueType >::end ( ) const [inline]
```

Returns a const iterator that points past the last element of the list.

Definition at line 220 of file memory_table.hh.

Referenced by jeod::JeodMemoryManager::get_type_entry_atomic().


8.10.4.6 find()

Find the index number at which key/value pair is stored in the table.

Returns

Index number mapped by the key

Parameters



Definition at line 186 of file memory_table.hh.

8.10.4.7 get()

Retrieve the value for the specified index from the list.

Returns

Value for specified index.

Parameters

in	idx	Table index whose value is to be retrieved.

Exceptions

std::out_of_range	for an index of zero or for an index beyond the range of the vector.

Exceptions

std::invalid_argument	when the index is in range but the value is null. This only happens when the item in	
	question has previously been deleted.	

Definition at line 301 of file memory_table.hh.

Referenced by jeod::JeodMemoryManager::generate_shutdown_report(), jeod::JeodMemoryManager::get_ \leftarrow string_atomic(), jeod::JeodMemoryManager::get_type_descriptor_atomic(), and jeod::JeodMemoryManager \leftarrow ::get_type_entry_atomic().

8.10.4.8 operator=()

8.10.5 Field Documentation

8.10.5.1 string to index

```
template<typename ValueType>
NameIndex jeod::JeodMemoryTable< ValueType >::string_to_index [private]
```

Maps keys to indices in the value_list.

trick_io(**)

Definition at line 334 of file memory_table.hh.

Referenced by jeod::JeodMemoryTable < JeodMemoryTypeDescriptor >::add(), jeod::JeodMemoryTable < JeodMemoryTypeDescriptor >::find(), and jeod::JeodMemoryTypeDescriptor >::find(), and jeod::JeodMemoryTable < JeodMemoryTypeDescriptor >:: \sim JeodMemoryTable().

8.10.5.2 value_list

```
template<typename ValueType>
ValueList jeod::JeodMemoryTable< ValueType >::value_list [private]
```

Vector of values.

trick io(**)

Definition at line 339 of file memory_table.hh.

Referenced by jeod::JeodMemoryTable< JeodMemoryTypeDescriptor >::add(), jeod::JeodMemoryTable< Jeod \leftarrow MemoryTypeDescriptor >::begin(), jeod::JeodMemoryTable< JeodMemoryTypeDescriptor >::del(), jeod::JeodMemoryTypeDescriptor >::del(), jeod::JeodMemoryTypeDescriptor >::get(), jeod::JeodMemoryTypeDescriptor >::JeodMemoryTable(), and jeod::JeodMemory \leftarrow Table< JeodMemoryTypeDescriptor >:: \leftarrow JeodMemoryTable().

The documentation for this class was generated from the following file:


• memory_table.hh

8.11 jeod::JeodMemoryTableClonable < ValueType > Class Template Reference

A JeodMemoryTableClonable is a JeodMemoryTable that implements the required clone() functionality by invoking the *ValueType's* clone() method to create a clone of the input value.

```
#include <memory_table.hh>
```

Inheritance diagram for jeod::JeodMemoryTableClonable< ValueType >:



Public Member Functions

- JeodMemoryTableClonable ()
 - Default constructor.
- JeodMemoryTableClonable (const JeodMemoryTableClonable &)=delete
- JeodMemoryTableClonable & operator= (const JeodMemoryTableClonable &)=delete

Protected Member Functions

const ValueType * clone (const ValueType &value) const override
 Creates a copy of the input value by invoking its clone method.

Additional Inherited Members

8.11.1 Detailed Description

```
\label{template} \mbox{template} < \mbox{typename ValueType} > \\ \mbox{class jeod::JeodMemoryTableClonable} < \mbox{ValueType} > \\ \mbox{}
```

A JeodMemoryTableClonable is a JeodMemoryTable that implements the required clone() functionality by invoking the *ValueType's* clone() method to create a clone of the input value.

Definition at line 347 of file memory table.hh.

8.11.2 Constructor & Destructor Documentation

```
8.11.2.1 JeodMemoryTableClonable() [1/2]
```

```
template<typename ValueType>
jeod::JeodMemoryTableClonable< ValueType >::JeodMemoryTableClonable ( ) [inline]
```

Default constructor.

Definition at line 354 of file memory table.hh.

8.11.2.2 JeodMemoryTableClonable() [2/2]

8.11.3 Member Function Documentation

8.11.3.1 clone()

Creates a copy of the input value by invoking its clone method.

Returns

Duplicate of input value.

Parameters

```
in value Value to be cloned.
```

Implements jeod::JeodMemoryTable< ValueType >.

Definition at line 370 of file memory_table.hh.

8.11.3.2 operator=()

The documentation for this class was generated from the following file:


· memory_table.hh

8.12 jeod::JeodMemoryTableCopyable < ValueType > Class Template Reference

A JeodMemoryTableCopyable is a JeodMemoryTable that implements the required clone() functionality by invoking the *ValueType's* copy constructor to create a clone of the input value.

```
#include <memory_table.hh>
```

Inheritance diagram for jeod::JeodMemoryTableCopyable < ValueType >:



Public Member Functions

- JeodMemoryTableCopyable ()
 - Default constructor.
- JeodMemoryTableCopyable (const JeodMemoryTableCopyable &)=delete
- JeodMemoryTableCopyable & operator= (const JeodMemoryTableCopyable &)=delete

Protected Member Functions

const ValueType * clone (const ValueType &value) const override
 Creates a copy of the input value by invoking its copy constructor.

Additional Inherited Members

8.12.1 Detailed Description

```
template<typename ValueType>
class jeod::JeodMemoryTableCopyable< ValueType >
```

A JeodMemoryTableCopyable is a JeodMemoryTable that implements the required clone() functionality by invoking the *ValueType's* copy constructor to create a clone of the input value.

Definition at line 381 of file memory_table.hh.

8.12.2 Constructor & Destructor Documentation

8.12.2.1 JeodMemoryTableCopyable() [1/2]

```
template<typename ValueType>
jeod::JeodMemoryTableCopyable< ValueType >::JeodMemoryTableCopyable ( ) [inline]
```

Default constructor.

Definition at line 388 of file memory table.hh.

8.12.2.2 JeodMemoryTableCopyable() [2/2]

8.12.3 Member Function Documentation

8.12.3.1 clone()

Creates a copy of the input value by invoking its copy constructor.

Returns

Duplicate of input value.

Parameters

```
in value Value to be cloned.
```

Implements jeod::JeodMemoryTable< ValueType >.

Definition at line 404 of file memory_table.hh.

8.12.3.2 operator=()

The documentation for this class was generated from the following file:


· memory_table.hh

8.13 jeod::JeodMemoryTypeDescriptor Class Reference

Abstract class for managing data allocated as some specific type.

```
#include <memory_type.hh>
```

Inheritance diagram for jeod::JeodMemoryTypeDescriptor:



Data Structures

struct attr

The simulation engine attributes that describe the type.trick_io(**)

Public Member Functions

• JeodMemoryTypeDescriptor (const std::type_info &obj_typeid, const struct ATTRIBUTES_tag &type_attr, std::size_t type_size, bool is_exportable=true)

Non-default constructor.

- virtual ~JeodMemoryTypeDescriptor ()=default
- JeodMemoryTypeDescriptor (const JeodMemoryTypeDescriptor &)=default
- JeodMemoryTypeDescriptor & operator= (const JeodMemoryTypeDescriptor &)=delete
- const std::type_info & get_typeid () const

Get the type info for the type.

const std::string & get_name () const

Get the name of the type.

• std::size_t get_size () const

Get the size of the type.

const struct ATTRIBUTES_tag & get_attr () const

Get the simulation engine attributes for the type.

• bool get_register_instances () const

Get the simulation engine attributes for the type.

• std::size_t dimensionality () const

Determine the dimensionality of the type.

• std::size t buffer size (unsigned int nelems) const

Compute the size of a buffer.

std::size_t buffer_size (const JeodMemoryItem &item) const

Compute the size of a buffer.

const void * buffer end (const void *addr, unsigned int nelems) const

Compute the address of the byte just past the end a buffer.

const void * buffer_end (const void *addr, const JeodMemoryItem &item) const

Compute the address of the byte just past the end a buffer.

const std::string type_spec (const JeodMemoryItem &item) const

Construct a type specification string.

- void destroy_memory (bool placement_new, bool is_array, unsigned int nelem, void *addr) const
 Destroy memory.
- virtual JeodMemoryTypeDescriptor * clone () const =0

Create a copy of the descriptor.

virtual bool is structured () const =0

Indicate whether the type associated with the descriptor is a structured (non-primitive, non-pointer) type.

virtual void * construct_array (std::size_t nelem, void *addr) const =0

Construct an array of objects of the type.

virtual const void * most_derived_pointer (const void *addr) const =0

Find the most-derived object corresponding to the input pointer.

virtual void * most_derived_pointer (void *addr) const =0

Find the most-derived object corresponding to the input pointer.

Static Public Member Functions

static void set check for registration errors (bool val)

Enable/disable registration error messages.

Protected Member Functions

virtual void delete_array (void *addr) const =0

Delete an array of instances of the type associated with the descriptor.

virtual void delete_object (void *addr) const =0

Delete a single instance of the type associated with the descriptor.

• virtual void destruct_array (std::size_t nelem, void *addr) const =0

Destruct (but do not delete) an array of nelem instances of the type associated with the descriptor.

Static Protected Member Functions

• static std::string initialize_type_name (const std::string &type_name)

The jeod_alloc.hh macros insert a space between the type name and the asterisks.

• static std::size_t pointer_dimension (const std::string &demangled_name)

Get the pointer dimensionality of the type.

static const JeodMemoryTypeDescriptor * base_type (const std::string &demangled_name)

Get the descriptor for the base (non-pointer) of some pointer type.

Protected Attributes

· const std::type_info & obj_id

The RTTI descriptor of the type.

· const std::string name

The name of the type in code.

• const std::size_t size {}

The size of an instance of the type.

• bool register_instances {}

Should instances be registered with the simulation engine? If true (default value), instances of the type will be registered with the simulation engine; the simulation engine is responsible for checkpointing and restoring the contents of such instances.

Static Protected Attributes

• static bool check_for_registration_errors = false

When set, suspect memory interface results will be reported as a warnings.

8.13.1 Detailed Description

Abstract class for managing data allocated as some specific type.

A JeodMemoryTypeDescriptor is a clonable object that contains the name and size of a specific data type. Instantiable subclasses of this class are created by the class templates that derive from this base class.

Definition at line 97 of file memory_type.hh.

8.13.2 Constructor & Destructor Documentation

8.13.2.1 JeodMemoryTypeDescriptor() [1/2]

Non-default constructor.

Note that construction is via a char* as that is what the C preprocessor creates when it stringifies a token.

Parameters

in	obj_typeid	Type ID for type
in	type_attr	Type attributes
in	type_size	Type size
in	is_exportable	Register instances?

Definition at line 173 of file memory_type.cc.

8.13.2.2 ~JeodMemoryTypeDescriptor()

```
virtual jeod::JeodMemoryTypeDescriptor::~JeodMemoryTypeDescriptor ( ) [virtual], [default]
```

8.13.2.3 JeodMemoryTypeDescriptor() [2/2]

8.13.3 Member Function Documentation

8.13.3.1 base_type()

Get the descriptor for the base (non-pointer) of some pointer type.

Note

Assumes GNU c++ name mangling, where 'const' is always preceded by a space.

Definition at line 98 of file memory_type.cc.

References jeod::JeodMemoryManager::Demangled_type_name, and jeod::JeodMemoryManager::get_type_ \hookleftarrow descriptor().

```
8.13.3.2 buffer_end() [1/2]
```

Compute the address of the byte just past the end a buffer.

Parameters

in	addr	Start of buffer
in	nelems	Size of the array

Definition at line 217 of file memory_type.hh.

References buffer_size().

Referenced by jeod::JeodMemoryManager::add_allocation_atomic(), and buffer_end().

8.13.3.3 buffer_end() [2/2]

Compute the address of the byte just past the end a buffer.

Parameters

in	addr	Start of buffer
in	item	Buffer descriptor

Definition at line 227 of file memory_type.hh.

References buffer_end(), and jeod::JeodMemoryItem::get_nelems().

```
8.13.3.4 buffer_size() [1/2]
```

Compute the size of a buffer.

Parameters

in	nelems	Size of the array
----	--------	-------------------

Returns

: Buffer size

Definition at line 197 of file memory_type.hh.

References size.

Referenced by jeod::JeodMemoryManager::add_allocation_atomic(), buffer_end(), buffer_size(), jeod::Jeod HemoryManager::delete_oldest_alloc_entry_atomic(), jeod::JeodMemoryManager::destroy_memory_internal(), jeod::JeodMemoryManager::register_memory_internal(), and jeod::JeodMemoryManager::restart_clear_memory().

```
8.13.3.5 buffer_size() [2/2]
```

Compute the size of a buffer.

Parameters

in <i>item</i> Buffer descriptor

Returns

: Buffer size

Definition at line 207 of file memory_type.hh.

References buffer_size(), and jeod::JeodMemoryItem::get_nelems().

8.13.3.6 clone()

```
virtual JeodMemoryTypeDescriptor* jeod::JeodMemoryTypeDescriptor::clone ( ) const [pure virtual]
```

Create a copy of the descriptor.

Returns

Copy.

Implemented in jeod::JeodMemoryTypeDescriptorDerived< Type >.

Referenced by jeod::JeodMemoryTableClonable < JeodMemoryTypeDescriptor >::clone().

8.13.3.7 construct_array()

Construct an array of objects of the type.

The default implementation does nothing, which is the right thing to do for primitive types, pointers, and abstract classes.

Implemented in jeod::JeodMemoryTypeDescriptorDerived< Type >.

Referenced by jeod::JeodMemoryManager::restart_reallocate().

8.13.3.8 delete_array()

Delete an array of instances of the type associated with the descriptor.

In other words, delete[] addr.

Parameters

in, out addr Address to be deleted
--

Implemented in jeod::JeodMemoryTypeDescriptorDerived< Type >.

Referenced by destroy_memory().

8.13.3.9 delete_object()

Delete a single instance of the type associated with the descriptor.

In other words, delete addr.

Parameters

in,out	addr	Address to be deleted
--------	------	-----------------------

Implemented in jeod::JeodMemoryTypeDescriptorDerived< Type >.

Referenced by destroy_memory().

8.13.3.10 destroy_memory()

```
void jeod::JeodMemoryTypeDescriptor::destroy_memory (
          bool placement_new,
          bool is_array,
          unsigned int nelem,
          void * addr ) const [inline]
```

Destroy memory.

Parameters

in	placement_new	Constructed with placement new?
in	is_array	Allocated as an array?
in	nelem	Number of elements
in,out	addr	Address to destroy

Definition at line 242 of file memory_type.hh.

References delete_array(), delete_object(), and destruct_array().

Referenced by jeod::JeodMemoryManager::destroy_memory_internal(), and jeod::JeodMemoryManager::restart ← __clear_memory().

8.13.3.11 destruct_array()

Destruct (but do not delete) an array of *nelem* instances of the type associated with the descriptor.

Parameters

in	nelem	Number of elements in addr
in,out	addr	Address to be destructed

 $Implemented \ in \ jeod:: JeodMemoryTypeDescriptorDerived < \ Type >.$

Referenced by destroy_memory().

8.13.3.12 dimensionality()

```
std::size_t jeod::JeodMemoryTypeDescriptor::dimensionality ( ) const [inline]
```

Determine the dimensionality of the type.

Returns

: Type dimensionality

Definition at line 187 of file memory_type.hh.

References name, and pointer_dimension().

```
8.13.3.13 get_attr()
```

```
const struct ATTRIBUTES_tag& jeod::JeodMemoryTypeDescriptor::get_attr ( ) const [inline]
```

Get the simulation engine attributes for the type.

Returns

Type attributes

Definition at line 167 of file memory_type.hh.

```
8.13.3.14 get_name()
```

```
const std::string& jeod::JeodMemoryTypeDescriptor::get_name ( ) const [inline]
```

Get the name of the type.

Returns

Type name

Definition at line 149 of file memory_type.hh.

References name.

Referenced by jeod::JeodMemoryManager::find_alloc_entry_atomic(), and jeod::JeodMemoryManager::get_type — entry_atomic().

8.13.3.15 get_register_instances()

```
bool jeod::JeodMemoryTypeDescriptor::get_register_instances ( ) const [inline]
```

Get the simulation engine attributes for the type.

Returns

Type attributes

Definition at line 176 of file memory_type.hh.

References register_instances.

Referenced by jeod::JeodMemoryManager::register_memory_internal().

8.13.3.16 get_size()

```
std::size_t jeod::JeodMemoryTypeDescriptor::get_size ( ) const [inline]
```

Get the size of the type.

Returns

Type size

Definition at line 158 of file memory_type.hh.

References size.

Referenced by jeod::JeodMemoryManager::create_memory_internal(), and jeod::JeodMemoryManager::restart_← reallocate().

```
8.13.3.17 get_typeid()
```

```
const std::type_info& jeod::JeodMemoryTypeDescriptor::get_typeid ( ) const [inline]
```

Get the type info for the type.

Returns

Type info

Definition at line 140 of file memory_type.hh.

References obj_id.

Referenced by jeod::JeodMemoryManager::get_type_index_nolock().

8.13.3.18 initialize_type_name()

The jeod_alloc.hh macros insert a space between the type name and the asterisks.

Delete that space.

Returns

Name, as c++ string

Parameters

in	type_name	Name, as C string
----	-----------	-------------------

Definition at line 57 of file memory_type.cc.

8.13.3.19 is_structured()

```
virtual bool jeod::JeodMemoryTypeDescriptor::is_structured ( ) const [pure virtual]
```

Indicate whether the type associated with the descriptor is a structured (non-primitive, non-pointer) type.

 $Implemented \ in \ jeod:: JeodMemoryTypeDescriptorDerived < \ Type >.$

Referenced by jeod::JeodMemoryManager::register_memory_internal().

```
8.13.3.20 most_derived_pointer() [1/2]
virtual const void* jeod::JeodMemoryTypeDescriptor::most_derived_pointer (
              const void * addr ) const [pure virtual]
Find the most-derived object corresponding to the input pointer.
Implemented in jeod::JeodMemoryTypeDescriptorDerived< Type >.
8.13.3.21 most_derived_pointer() [2/2]
virtual void* jeod::JeodMemoryTypeDescriptor::most_derived_pointer (
              void * addr ) const [pure virtual]
Find the most-derived object corresponding to the input pointer.
Implemented in jeod::JeodMemoryTypeDescriptorDerived< Type >.
8.13.3.22 operator=()
JeodMemoryTypeDescriptor& jeod::JeodMemoryTypeDescriptor::operator= (
              const JeodMemoryTypeDescriptor & ) [delete]
8.13.3.23 pointer_dimension()
\verb|size_t| \verb|jeod::JeodMemoryTypeDescriptor::pointer_dimension| (
              const std::string & demangled_name ) [static], [protected]
Get the pointer dimensionality of the type.
Definition at line 74 of file memory_type.cc.
Referenced by dimensionality().
8.13.3.24 set_check_for_registration_errors()
static void jeod::JeodMemoryTypeDescriptor::set_check_for_registration_errors (
              bool val ) [inline], [static]
```

Enable/disable registration error messages.

Parameters

in	val	New value for check_for_registration_errors	1
----	-----	---	---

Definition at line 106 of file memory_type.hh.

References check_for_registration_errors.

8.13.3.25 type_spec()

Construct a type specification string.

Returns

Type string

Parameters

in	item	Item descriptor
----	------	-----------------

Definition at line 190 of file memory_type.cc.

References jeod::JeodMemoryItem::get_is_array(), jeod::JeodMemoryItem::get_nelems(), and obj_id.

Referenced by jeod::JeodMemoryManager::destroy_memory_internal(), jeod::JeodMemoryManager::generate_ shutdown_report(), and jeod::JeodMemoryManager::register_memory_internal().

8.13.4 Field Documentation

8.13.4.1 check_for_registration_errors

```
bool jeod::JeodMemoryTypeDescriptor::check_for_registration_errors = false [static], [protected]
```

When set, suspect memory interface results will be reported as a warnings.

No messages are issued when this flag is clear.trick_units(-)

Definition at line 330 of file memory_type.hh.

Referenced by set_check_for_registration_errors().

8.13.4.2 name

```
const std::string jeod::JeodMemoryTypeDescriptor::name [protected]
```

The name of the type in code.

```
trick_io(**)
```

Definition at line 342 of file memory_type.hh.

Referenced by dimensionality(), and get name().

8.13.4.3 obj_id

```
const std::type_info& jeod::JeodMemoryTypeDescriptor::obj_id [protected]
```

The RTTI descriptor of the type.

```
trick_io(**)
```

Definition at line 337 of file memory type.hh.

Referenced by get_typeid(), and type_spec().

8.13.4.4 register_instances

```
bool jeod::JeodMemoryTypeDescriptor::register_instances {} [protected]
```

Should instances be registered with the simulation engine? If true (default value), instances of the type will be registered with the simulation engine; the simulation engine is responsible for checkpointing and restoring the contents of such instances.

If false, instances will not be registered with the simulation engine; the simulation engine is not responsible for checkpointing/restarting such instances.trick_io(**)

Definition at line 365 of file memory_type.hh.

Referenced by get_register_instances().

8.13.4.5 size

```
const std::size_t jeod::JeodMemoryTypeDescriptor::size {} [protected]
```

The size of an instance of the type.

```
trick_io(**)
```

Definition at line 353 of file memory_type.hh.

Referenced by buffer_size(), and get_size().

The documentation for this class was generated from the following files:


- memory_type.hh
- memory_type.cc

8.14 jeod::JeodMemoryTypeDescriptorDerived < Type > Class Template Reference

Extends JeodMemoryTypeDescriptor to describe a specific type.

```
#include <memory_type.hh>
```

Inheritance diagram for jeod::JeodMemoryTypeDescriptorDerived< Type >:



Public Types

- using TypeDescriptor = JeodMemoryTypeDescriptorDerived < Type >
 This class.
- using Attributes = JeodSimEngineAttributes < Type, std::is_class < Type >::value >
 Attributes for the Type.

Public Member Functions

JeodMemoryTypeDescriptorDerived (bool is exportable=true)

Default constructor.

• JeodMemoryTypeDescriptorDerived (const JeodMemoryTypeDescriptorDerived &src)

Copy constructor; pass-through to the parent class equivalent.

- ~JeodMemoryTypeDescriptorDerived () override=default
- JeodMemoryTypeDescriptorDerived & operator= (const JeodMemoryTypeDescriptorDerived &)=delete
- JeodMemoryTypeDescriptor * clone () const override

Create a copy of the descriptor.

• bool is_structured () const override

Indicate whether the type associated with the descriptor is a structured (non-primitive, non-pointer) type.

- void * construct_array (std::size_t nelem, void *addr) const override
 - Construct an array of objects of the type.
- const void * most_derived_pointer (const void *addr) const override

Find the most-derived object corresponding to the input pointer.

void * most_derived_pointer (void *addr) const override

Find the most-derived object corresponding to the input pointer.

Protected Member Functions

void delete_array (void *addr) const override

Delete an array of instances of type Type.

void delete_object (void *addr) const override

Delete a single instance of type Type.

void destruct_array (std::size_t nelem, void *addr) const override

Destroy an array of nelem instances of type Type.

Additional Inherited Members

8.14.1 Detailed Description

```
\label{template} \mbox{typename Type} $>$ \mbox{class jeod::JeodMemoryTypeDescriptorDerived} < \mbox{Type} > $
```

Extends JeodMemoryTypeDescriptor to describe a specific type.

tparam Type The type to be described.

Definition at line 372 of file memory_type.hh.

8.14.2 Member Typedef Documentation

8.14.2.1 Attributes

```
template<typename Type >
using jeod::JeodMemoryTypeDescriptorDerived< Type >::Attributes = JeodSimEngineAttributes<Type,
std::is_class<Type>::value>
```

Attributes for the Type.

Definition at line 385 of file memory_type.hh.

8.14.2.2 TypeDescriptor

```
template<typename Type >
using jeod::JeodMemoryTypeDescriptorDerived< Type >::TypeDescriptor = JeodMemoryTypeDescriptorDerived<Type>
```

This class.

Definition at line 380 of file memory_type.hh.

8.14.3 Constructor & Destructor Documentation

8.14.3.1 JeodMemoryTypeDescriptorDerived() [1/2]

Default constructor.

Invoke the parent class non-default constructor with type, attributes, and size information.

Definition at line 394 of file memory_type.hh.

Referenced by jeod::JeodMemoryTypeDescriptorDerived < Type >::clone().

8.14.3.2 JeodMemoryTypeDescriptorDerived() [2/2]

Copy constructor; pass-through to the parent class equivalent.

Parameters

```
in src Item to be copied
```

Definition at line 403 of file memory_type.hh.

8.14.3.3 ∼JeodMemoryTypeDescriptorDerived()

```
template<typename Type >
jeod::JeodMemoryTypeDescriptorDerived< Type >::~JeodMemoryTypeDescriptorDerived ( ) [override],
[default]
```

8.14.4 Member Function Documentation

8.14.4.1 clone()

```
template<typename Type >
JeodMemoryTypeDescriptor* jeod::JeodMemoryTypeDescriptorDerived< Type >::clone ( ) const [inline],
[override], [virtual]
```

Create a copy of the descriptor.

Returns

Copy.

Implements jeod::JeodMemoryTypeDescriptor.

Definition at line 418 of file memory_type.hh.

References jeod::JeodMemoryTypeDescriptorDerived< Type >::JeodMemoryTypeDescriptorDerived().

8.14.4.2 construct_array()

Construct an array of objects of the type.

Implements jeod::JeodMemoryTypeDescriptor.

Definition at line 436 of file memory_type.hh.

8.14.4.3 delete_array()

Delete an array of instances of type Type.

In other words, delete[] addr.

Parameters

```
in, out | addr | Address to be deleted
```

Implements jeod::JeodMemoryTypeDescriptor.

Definition at line 468 of file memory_type.hh.

8.14.4.4 delete_object()

Delete a single instance of type Type.

In other words, delete addr.

Parameters

```
in, out | addr | Address to be deleted
```

Implements jeod::JeodMemoryTypeDescriptor.

Definition at line 479 of file memory_type.hh.

8.14.4.5 destruct_array()

Destroy an array of *nelem* instances of type *Type*.

Implements jeod::JeodMemoryTypeDescriptor.

Definition at line 488 of file memory_type.hh.

8.14.4.6 is_structured()

```
template<typename Type >
bool jeod::JeodMemoryTypeDescriptorDerived< Type >::is_structured ( ) const [inline], [override],
[virtual]
```

Indicate whether the type associated with the descriptor is a structured (non-primitive, non-pointer) type.

Implements jeod::JeodMemoryTypeDescriptor.

Definition at line 428 of file memory_type.hh.

8.14.4.7 most_derived_pointer() [1/2]

Find the most-derived object corresponding to the input pointer.

Parameters

in	addr	Pointer to be examined
----	------	------------------------

Returns

Pointer to most-derived object.

Implements jeod::JeodMemoryTypeDescriptor.

Definition at line 446 of file memory_type.hh.

8.14.4.8 most_derived_pointer() [2/2]

Find the most-derived object corresponding to the input pointer.

Parameters

in	addr	Pointer to be examined
----	------	------------------------

Returns

Pointer to most-derived object.

Implements jeod::JeodMemoryTypeDescriptor.

Definition at line 456 of file memory_type.hh.

References jeod::jeod_alloc_get_allocated_pointer().

8.14.4.9 operator=()

The documentation for this class was generated from the following file:


memory_type.hh

8.15 jeod::JeodMemoryTypePreDescriptor Class Reference

Abstract class for describing a type without necessarily needing to create a JeodMemoryTypeDescriptor of that type.

```
#include <memory_type.hh>
```

Inheritance diagram for jeod::JeodMemoryTypePreDescriptor:



Public Member Functions

- virtual ~JeodMemoryTypePreDescriptor ()=default
- virtual const std::type_info & get_typeid () const =0
 Get the type info for the type.
- virtual const JeodMemoryTypeDescriptor & get_descriptor ()=0
 Get a type descriptor for the type.

8.15.1 Detailed Description

Abstract class for describing a type without necessarily needing to create a JeodMemoryTypeDescriptor of that type.

The intent is to avoid creating a type descriptor for a type if the type is already represented in the type table.

Usage of a JeodMemoryTypePreDescriptor is highly constrained. There are two simple rules:

- Never cache a pointer or reference to a JeodMemoryTypeDescriptor in long-term memory.
- Never cache a pointer or reference to a JeodMemoryTypeDescriptor obtained by calling the JeodMemoryTypeDescriptor's get_descriptor method.

Definition at line 507 of file memory_type.hh.

8.15.2 Constructor & Destructor Documentation

8.15.2.1 ~JeodMemoryTypePreDescriptor()

```
virtual jeod::JeodMemoryTypePreDescriptor::~JeodMemoryTypePreDescriptor ( ) [virtual], [default]
```

8.15.3 Member Function Documentation

8.15.3.1 get_descriptor()

virtual const JeodMemoryTypeDescriptor& jeod::JeodMemoryTypePreDescriptor::get_descriptor ()
[pure virtual]

Get a type descriptor for the type.

The returned value should not be cached in a permanent store. The reference has a lifespan limited to that of the JeodMemoryTypePreDescriptor object.

Returns

Type descriptor.

 $Implemented\ in\ jeod:: JeodMemoryTypePreDescriptorDerived < Type >.$

Referenced by jeod::JeodMemoryManager::get_type_entry_atomic().

8.15.3.2 get_typeid()

virtual const std::type_info@ jeod::JeodMemoryTypePreDescriptor::get_typeid () const [pure virtual]

Get the type info for the type.

Returns

Type info

Implemented in jeod::JeodMemoryTypePreDescriptorDerived< Type >.

Referenced by jeod::JeodMemoryManager::get_type_entry_atomic().

The documentation for this class was generated from the following file:

• memory_type.hh

8.16 jeod::JeodMemoryTypePreDescriptorDerived < Type > Class Template Reference

A JeodMemoryTypePreDescriptorDerived describes a *Type*.

```
#include <memory_type.hh>
```

Inheritance diagram for jeod::JeodMemoryTypePreDescriptorDerived< Type >:

jeod::JeodMemoryTypePreDescriptor

jeod::JeodMemoryTypePreDescriptorDerived < Type >

Public Types

using TypeDescriptor = JeodMemoryTypeDescriptorDerived < Type >

The type descriptor this class describes.

Public Member Functions

• JeodMemoryTypePreDescriptorDerived (bool exportable=true)

Default constructor.

• JeodMemoryTypePreDescriptorDerived (const JeodMemoryTypePreDescriptorDerived &src)

Copy constructor.

• ~JeodMemoryTypePreDescriptorDerived () override

Destructor.

JeodMemoryTypePreDescriptor & get_ref ()

Get a reference to this object.

const std::type_info & get_typeid () const override

Get the type info for the type.

• const JeodMemoryTypeDescriptor & get_descriptor () override

Get a type descriptor for the type.

Private Attributes

- TypeDescriptor * descriptor {}
- bool is_exportable {true}

8.16.1 Detailed Description

```
\label{template} \mbox{typename Type} $$ \mbox{class jeod::JeodMemoryTypePreDescriptorDerived} < \mbox{Type} > $$ \mbox{typ
```

A JeodMemoryTypePreDescriptorDerived describes a *Type*.

Definition at line 531 of file memory_type.hh.

8.16.2 Member Typedef Documentation

8.16.2.1 TypeDescriptor

```
template<typename Type >
using jeod::JeodMemoryTypePreDescriptorDerived< Type >::TypeDescriptor = JeodMemoryTypeDescriptorDerived<Type</pre>
```

The type descriptor this class describes.

Definition at line 539 of file memory_type.hh.

8.16.3 Constructor & Destructor Documentation

8.16.3.1 JeodMemoryTypePreDescriptorDerived() [1/2]

Default constructor.

Definition at line 544 of file memory_type.hh.

8.16.3.2 JeodMemoryTypePreDescriptorDerived() [2/2]

Copy constructor.

Definition at line 552 of file memory_type.hh.

 $References\ jeod:: JeodMemoryTypePreDescriptorDerived < Type > :: descriptor.$

8.16.3.3 ~JeodMemoryTypePreDescriptorDerived()

```
template<typename Type >
jeod::JeodMemoryTypePreDescriptorDerived< Type >::~JeodMemoryTypePreDescriptorDerived ( )
[inline], [override]
```

Destructor.

Definition at line 564 of file memory_type.hh.

References jeod::JeodMemoryTypePreDescriptorDerived < Type >::descriptor.

8.16.4 Member Function Documentation

8.16.4.1 get_descriptor()

```
template<typename Type >
const JeodMemoryTypeDescriptor& jeod::JeodMemoryTypePreDescriptorDerived< Type >::get_descriptor
( ) [inline], [override], [virtual]
```

Get a type descriptor for the type.

Note well: The referenced value has a lifespan limited to that of this object. The returned value must not be cached in a permanent store. Use new in conjunction with the copy constructor instead.

Returns

Type descriptor.

Implements jeod::JeodMemoryTypePreDescriptor.

Definition at line 606 of file memory_type.hh.

References jeod::JeodMemoryTypePreDescriptorDerived< Type >::descriptor, and jeod::JeodMemoryTypePre \leftarrow DescriptorDerived< Type >::is_exportable.

8.16.4.2 get_ref()

```
template<typename Type >
JeodMemoryTypePreDescriptor& jeod::JeodMemoryTypePreDescriptorDerived< Type >::get_ref ( )
[inline]
```

Get a reference to this object.

This is an utter hack. Because the descriptor is created after the fact, a function that receives a JeodMemoryTypePreDescriptor must either take a copy or a non-const reference as input. A reference is preferred. The problem: Non-const references cannot be bound to rvalues. They can however be bound to other references, and hence this method.

Note well: The returned reference has a lifespan limited to that of this object. Use with great care. This is not intended for general consumption.

Returns

Reference to this object.

Definition at line 583 of file memory_type.hh.

8.16.4.3 get_typeid()

```
template<typename Type >
const std::type_info& jeod::JeodMemoryTypePreDescriptorDerived< Type >::get_typeid ( ) const
[inline], [override], [virtual]
```

Get the type info for the type.

Returns

Type info

Implements jeod::JeodMemoryTypePreDescriptor.

Definition at line 592 of file memory_type.hh.

8.16.5 Field Documentation

8.16.5.1 descriptor

```
template<typename Type >
TypeDescriptor* jeod::JeodMemoryTypePreDescriptorDerived< Type >::descriptor {} [private]
```

Definition at line 616 of file memory_type.hh.

Referenced by jeod::JeodMemoryTypePreDescriptorDerived< Type >::get_descriptor(), jeod::JeodMemory \leftarrow TypePreDescriptorDerived< Type >::JeodMemoryTypePreDescriptorDerived(), and jeod::JeodMemoryTypePre \leftarrow DescriptorDerived< Type >:: \sim JeodMemoryTypePreDescriptorDerived().

8.16.5.2 is_exportable

```
template<typename Type >
bool jeod::JeodMemoryTypePreDescriptorDerived< Type >::is_exportable {true} [private]
```

Definition at line 617 of file memory_type.hh.

 $Referenced \ by \ jeod:: JeodMemoryTypePreDescriptorDerived < Type > :: get_descriptor().$

The documentation for this class was generated from the following file:

· memory_type.hh

8.17 jeod::JeodSimEngineAttributes < Type, is_class > Class Template Reference

Class template to construct a simulation engine attributes object that represents some type.

```
#include <memory_attributes_templates.hh>
```

Static Public Member Functions

static struct ATTRIBUTES_tag attributes (bool)
 Construct a JEOD ATTRIBUTES TYPE that represents a primitive type.

8.17.1 Detailed Description

```
\label{template} \begin{tabular}{ll} template < typename Type, bool is\_class > \\ class jeod::JeodSimEngineAttributes < Type, is\_class > \\ \end{tabular}
```

Class template to construct a simulation engine attributes object that represents some type.

All partial template instantiations of this template define a class with a single static function named attributes. This default implementation is for a primitive type. Subsequent partial instantiations will address other types.

Template Parameters

Туре	The type for which an attributes is to be constructed.
is_class	True if the type is a class, false otherwise.

Definition at line 91 of file memory_attributes_templates.hh.

8.17.2 Member Function Documentation

8.17.2.1 attributes()

Construct a JEOD_ATTRIBUTES_TYPE that represents a primitive type.

Returns

Constructed attributes object.

Definition at line 98 of file memory_attributes_templates.hh.

The documentation for this class was generated from the following file:

• memory_attributes_templates.hh

8.18 jeod::JeodSimEngineAttributes< Type *, false > Class Template Reference

Partial template instantiation of JeodSimEngineAttributes for a pointer type.

```
#include <memory_attributes_templates.hh>
```

Static Public Member Functions

static struct ATTRIBUTES_tag attributes (bool is_exportable=true)
 Construct a JEOD ATTRIBUTES TYPE that represents a pointer type.

8.18.1 Detailed Description

```
template<typename Type>class jeod::JeodSimEngineAttributes< Type *, false >
```

Partial template instantiation of JeodSimEngineAttributes for a pointer type.

Template Parameters

```
Type The pointed-to type.
```

Definition at line 110 of file memory_attributes_templates.hh.

8.18.2 Member Function Documentation

8.18.2.1 attributes()

Construct a JEOD_ATTRIBUTES_TYPE that represents a pointer type.

Parameters

```
is_exportable True => type is exportable.
```

Returns

Constructed attributes object.

Definition at line 118 of file memory_attributes_templates.hh.

The documentation for this class was generated from the following file:

· memory_attributes_templates.hh

8.19 jeod::JeodSimEngineAttributes < Type, true > Class Template Reference

Partial template instantiation of JeodSimEngineAttributes for a class.

```
#include <memory_attributes_templates.hh>
```

Static Public Member Functions

static struct ATTRIBUTES_tag attributes (bool is_exportable=true)
 Construct a JEOD ATTRIBUTES TYPE that represents a structured type.

8.19.1 Detailed Description

```
\label{template} \mbox{typename Type} > \\ \mbox{class jeod::JeodSimEngineAttributes} < \mbox{Type, true} > \\
```

Partial template instantiation of JeodSimEngineAttributes for a class.

Template Parameters

```
Type The class.
```

Definition at line 148 of file memory_attributes_templates.hh.

8.19.2 Member Function Documentation

8.19.2.1 attributes()

Construct a JEOD_ATTRIBUTES_TYPE that represents a structured type.

Parameters

```
is_exportable | True => type is exportable.
```

Returns

Constructed attributes object.

Definition at line 156 of file memory_attributes_templates.hh.

The documentation for this class was generated from the following file:

· memory_attributes_templates.hh

8.20 jeod::JeodSimEngineAttributes < void *, false > Class Template Reference

Template specialization of JeodSimEngineAttributes for void*.

```
#include <memory_attributes_templates.hh>
```

Static Public Member Functions

static struct ATTRIBUTES_tag attributes (bool)
 Construct a JEOD_ATTRIBUTES_TYPE that represents a void pointer.

8.20.1 Detailed Description

```
\label{lem:lemplate} \mbox{template} <> \mbox{class jeod::JeodSimEngineAttributes} < \mbox{void} \ *, \mbox{false} >
```

Template specialization of JeodSimEngineAttributes for void*.

Definition at line 130 of file memory_attributes_templates.hh.

8.20.2 Member Function Documentation

```
8.20.2.1 attributes()
```

Construct a JEOD_ATTRIBUTES_TYPE that represents a void pointer.

Returns

Constructed attributes object.

Definition at line 137 of file memory_attributes_templates.hh.

The documentation for this class was generated from the following file:

· memory_attributes_templates.hh

8.21 jeod::MemoryMessages Class Reference

Declares messages associated with the integration test model.

```
#include <memory_messages.hh>
```

Public Member Functions

- MemoryMessages ()=delete
- MemoryMessages (const MemoryMessages &)=delete
- MemoryMessages & operator= (const MemoryMessages &)=delete

Static Public Attributes

• static const char * singleton_error = "utils/memory/" "singleton_error"

Error issued when multiple instance of a class that should be a singleton are created or when no such instance exists (but should).

static const char * out_of_memory = "utils/memory/" "out_of_memory"

Issued when malloc returns NULL.

static const char * lock_error = "utils/memory/" "lock_error"

Issued when problems arise with in protection for atomic operations.

• static const char * null_pointer = "utils/memory/" "null_pointer"

Issued when the caller attempts to do something with a null pointer such as registering or freeing.

static const char * suspect_pointer = "utils/memory/" "suspect_pointer"

Issued when the caller attempts to register memory that overlaps with previously recording allocations or attempts to destroy memory that was not previously registered.

• static const char * invalid size = "utils/memory/" "invalid size"

Issued when the caller attempts to allocate zero bytes.

• static const char * corrupted_memory = "utils/memory/" "corrupted_memory"

Issued when guard bytes have been overwritten.

• static const char * registration_error = "utils/memory/" "registration_error"

Issued when a model programmer messed up.

• static const char * internal_error = "utils/memory/" "internal_error"

Issued when the memory model programmer messed up.

static const char * debug = "utils/memory/" "debug"

Used to identify debug output.

Friends

- · class InputProcessor
- void init_attrjeod__MemoryMessages ()

8.21.1 Detailed Description

Declares messages associated with the integration test model.

Definition at line 85 of file memory messages.hh.

8.21.2 Constructor & Destructor Documentation

8.21.2.1 MemoryMessages() [1/2]

```
jeod::MemoryMessages::MemoryMessages ( ) [delete]
```

8.21.2.2 MemoryMessages() [2/2]

8.21.3 Member Function Documentation

8.21.3.1 operator=()

8.21.4 Friends And Related Function Documentation

8.21.4.1 init_attrjeod__MemoryMessages

```
void init_attrjeod__MemoryMessages ( ) [friend]
```

8.21.4.2 InputProcessor

```
friend class InputProcessor [friend]
```

Definition at line 87 of file memory messages.hh.

8.21.5 Field Documentation

8.21.5.1 corrupted_memory

```
char const * jeod::MemoryMessages::corrupted_memory = "utils/memory/" "corrupted_memory" [static]
```

Issued when guard bytes have been overwritten.

```
trick_units(-)
```

Definition at line 126 of file memory_messages.hh.

Referenced by jeod::JeodMemoryManager::add_allocation_atomic(), jeod::JeodMemoryManager::free_memory(), jeod::JeodMemoryManager::generate_shutdown_report(), and jeod::JeodMemoryManager::get_alloc_id_atomic().

8.21.5.2 debug

```
char const * jeod::MemoryMessages::debug = "utils/memory/" "debug" [static]
```

Used to identify debug output.

trick_units(-)

Definition at line 141 of file memory_messages.hh.

Referenced by jeod::JeodMemoryManager::destroy_memory_internal(), jeod::JeodMemoryManager::generate --_shutdown_report(), jeod::JeodMemoryManager::get_type_entry_atomic(), and jeod::JeodMemoryManager --::register_memory_internal().

8.21.5.3 internal_error

```
char const * jeod::MemoryMessages::internal_error = "utils/memory/" "internal_error" [static]
```

Issued when the memory model programmer messed up.

trick_units(-)

Definition at line 136 of file memory_messages.hh.

Referenced by jeod::JeodMemoryManager::get_string_atomic(), jeod::JeodMemoryManager::get_type_ descriptor_atomic(), and jeod::JeodMemoryItem::set_unique_id().

8.21.5.4 invalid_size

```
char const * jeod::MemoryMessages::invalid_size = "utils/memory/" "invalid_size" [static]
```

Issued when the caller attempts to allocate zero bytes.

trick_units(-)

Definition at line 121 of file memory messages.hh.

Referenced by jeod::JeodMemoryManager::register_memory_internal().

8.21.5.5 lock_error

```
char const * jeod::MemoryMessages::lock_error = "utils/memory/" "lock_error" [static]
```

Issued when problems arise with in protection for atomic operations.

trick_units(-)

Definition at line 103 of file memory_messages.hh.

Referenced by jeod::JeodMemoryManager::begin_atomic_block(), and jeod::JeodMemoryManager::end_atomic __block().

8.21.5.6 null_pointer

```
char const * jeod::MemoryMessages::null_pointer = "utils/memory/" "null_pointer" [static]
```

Issued when the caller attempts to do something with a null pointer such as registering or freeing.

trick units(-)

Definition at line 109 of file memory_messages.hh.

Referenced by jeod::JeodMemoryManager::deregister_container(), jeod::JeodMemoryManager::destroy_ memory_internal(), and jeod::JeodMemoryManager::register_container().

8.21.5.7 out_of_memory

```
char const * jeod::MemoryMessages::out_of_memory = "utils/memory/" "out_of_memory" [static]
```

Issued when malloc returns NULL.

trick_units(-)

Definition at line 98 of file memory_messages.hh.

Referenced by jeod::JeodMemoryManager::allocate memory().

8.21.5.8 registration_error

```
char const * jeod::MemoryMessages::registration_error = "utils/memory/" "registration_error"
[static]
```

Issued when a model programmer messed up.

trick_units(-)

Definition at line 131 of file memory messages.hh.

8.21.5.9 singleton_error

```
char const * jeod::MemoryMessages::singleton_error = "utils/memory/" "singleton_error" [static]
```

Error issued when multiple instance of a class that should be a singleton are created or when no such instance exists (but should).

trick_units(-)

Definition at line 93 of file memory_messages.hh.

Referenced by jeod::JeodMemoryManager::check_master(), and jeod::JeodMemoryManager::JeodMemory ← Manager().

8.21.5.10 suspect_pointer

```
char const * jeod::MemoryMessages::suspect_pointer = "utils/memory/" "suspect_pointer" [static]
```

Issued when the caller attempts to register memory that overlaps with previously recording allocations or attempts to destroy memory that was not previously registered.

```
trick_units(-)
```

Definition at line 116 of file memory_messages.hh.

Referenced by jeod::JeodMemoryManager::destroy_memory_internal(), jeod::JeodMemoryManager::find_alloc_centry_atomic(), and jeod::JeodMemoryManager::restart_reallocate().

The documentation for this class was generated from the following files:

- · memory_messages.hh
- · memory_messages.cc

8.22 jeod::JeodMemoryManager::TypeEntry Struct Reference

The type table is indexed by an integer and contains type descriptors.

```
#include <memory_manager.hh>
```

Public Member Functions

• TypeEntry (uint32_t num, const JeodMemoryTypeDescriptor *desc)

Pair constructor.

Data Fields

• uint32_t index

Type table index number.

const JeodMemoryTypeDescriptor * tdesc

Type descriptor.

8.22.1 Detailed Description

The type table is indexed by an integer and contains type descriptors.

This class bundles the two together.

Definition at line 248 of file memory_manager.hh.

8.22.2 Constructor & Destructor Documentation

8.22.2.1 TypeEntry()

Pair constructor.

Definition at line 263 of file memory_manager.hh.

8.22.3 Field Documentation

8.22.3.1 index

```
uint32_t jeod::JeodMemoryManager::TypeEntry::index
```

Type table index number.

```
trick_io(**)
```

Definition at line 253 of file memory_manager.hh.

Referenced by jeod::JeodMemoryManager::register_memory_internal().

8.22.3.2 tdesc

```
\verb|const| JeodMemoryTypeDescriptor*| jeod:: JeodMemoryManager:: TypeEntry:: tdesc| for the const of the constant of the const
```

Type descriptor.

trick_io(**)

Definition at line 258 of file memory_manager.hh.

Referenced by jeod::JeodMemoryManager::create_memory_internal(), jeod::JeodMemoryManager::get_type_ \leftarrow descriptor(), jeod::JeodMemoryManager::register_memory_internal(), and jeod::JeodMemoryManager::restart_ \leftarrow reallocate().

The documentation for this struct was generated from the following file:

• memory_manager.hh

Chapter 9

File Documentation

9.1 class_declarations.hh File Reference

Forward declarations of classes defined in the utils/memory model.

Namespaces

• jeod

Namespace jeod.

9.1.1 Detailed Description

Forward declarations of classes defined in the utils/memory model.

9.2 jeod_alloc.hh File Reference

Define JEOD memory allocation macros.

```
#include <cstddef>
#include <new>
#include "utils/sim_interface/include/memory_attributes.hh"
#include "jeod_alloc_get_allocated_pointer.hh"
#include "memory_manager.hh"
```

Macros

#define JEOD MEMORY DEBUG 2

Specifies the level of checking performed by the JEOD memory model.

#define JEOD_ALLOC_OBJECT_FILL 0xdf

Fill pattern for non-primitive types.

#define JEOD ALLOC PRIMITIVE FILL 0

Fill pattern for primitive types.

• #define JEOD ALLOC POINTER FILL 0

Fill pattern for pointer types.

#define JEOD_CREATE_MEMORY(is_array, nelem, fill, tentry) jeod::JeodMemoryManager::create_memory(is
 —array, nelem, fill, tentry, __FILE__, __LINE__)

Allocate and register memory to be populated via placement new.

#define JEOD_ALLOC_ARRAY_INTERNAL(type, nelem, fill, tentry) new(JEOD_CREATE_MEMORY(true, nelem, fill, tentry)) type[nelem]

Allocate nelem elements of pointers to the specified structured type.

 #define JEOD_ALLOC_OBJECT_INTERNAL(type, fill, constr, tentry) new(JEOD_CREATE_MEMORY(false, 1, fill, tentry)) type constr

Allocate an instance of the specified class using the specified constructor arguments.

• #define JEOD_DELETE_INTERNAL(ptr, is_array)

Free memory allocated with some JEOD_ALLOC macro.

#define JEOD_REGISTER_CLASS(type) jeod::JeodMemoryManager::register_class(jeod::JeodMemoryTypePreDescriptorDelerref())

Register the type type with the memory manager.

• #define JEOD_REGISTER_INCOMPLETE_CLASS(type) JEOD_REGISTER_CLASS(type)

Register the incomplete class type with the memory manager.

 #define JEOD_REGISTER_NONEXPORTED_CLASS(type) jeod::JeodMemoryManager::register_class(jeod::JeodMemoryTyp _ref())

Register the type type with the memory manager, but with the class marked as not exportable to the simulation engine.

• #define JEOD_REGISTER_CHECKPOINTABLE(owner, elem_name)

Register the data member elem_name of the owner as a Checkpointable object.

• #define JEOD DEREGISTER CHECKPOINTABLE(owner, elem name)

Register the data member elem_name of the owner as a Checkpointable object.

#define JEOD_ALLOC_CLASS_MULTI_POINTER_ARRAY(nelem, type, asters) JEOD_ALLOC_ARRAY_INTERNAL(type asters, nelem, JEOD_ALLOC_POINTER_FILL, JEOD_REGISTER_CLASS(type asters))

Allocate an array of nelem multi-level pointers to the specified type.

#define JEOD_ALLOC_CLASS_POINTER_ARRAY(nelem, type) JEOD_ALLOC_CLASS_MULTI_POINTER_ARRAY(nelem, type, *)

Allocate an array of nelem pointers to the specified type.

 #define JEOD_ALLOC_CLASS_ARRAY(nelem, type) JEOD_ALLOC_ARRAY_INTERNAL(type, nelem, JEOD_ALLOC_OBJECT_FILL, JEOD_REGISTER_CLASS(type))

Allocate an array of nelem instances of the specified structured type.

 #define JEOD_ALLOC_PRIM_ARRAY(nelem, type) JEOD_ALLOC_ARRAY_INTERNAL(type, nelem, JEOD_ALLOC_PRIMITIVE_FILL, JEOD_REGISTER_CLASS(type))

Allocate nelem elements of the specified primitive type.

#define JEOD_ALLOC_CLASS_OBJECT(type, constr) JEOD_ALLOC_OBJECT_INTERNAL(type, JEOD_ALLOC_OBJECT_FILL, constr, JEOD_REGISTER_CLASS(type))

Allocate one instance of the specified class.

• #define JEOD_ALLOC_PRIM_OBJECT(type, initial) JEOD_ALLOC_OBJECT_INTERNAL(type, JEOD_ALLOC_PRIMITIVE_F (initial), JEOD_REGISTER_CLASS(type))

Allocate one instance of the specified type.

#define JEOD_IS_ALLOCATED(ptr) jeod::JeodMemoryManager::is_allocated(jeod::jeod_alloc_get_allocated_pointer(ptr),
 __FILE__, __LINE__)

Determine if ptr was allocated by some JEOD_ALLOC_xxx_ARRAY macro.

#define JEOD_DELETE_ARRAY(ptr) JEOD_DELETE_INTERNAL(ptr, true)

Free memory at ptr that was earlier allocated with some <code>JEOD_ALLOC_xxx_ARRAY</code> macro.

• #define JEOD_DELETE_OBJECT(ptr) JEOD_DELETE_INTERNAL(ptr, false)

Free memory at ptr that was earlier allocated with some JEOD_ALLOC_xxx_OBJECT macro.

#define JEOD_DELETE_2D(ptr, size, is_array)

9.2.1 Detailed Description

Define JEOD memory allocation macros.

The jeod_alloc.hh memory macros can be viewed as

- Being externally-usable or for internal use only.
 The supported use of the JEOD memory model is via those macros advertised as externally-usable. These externally-usable macros expand into invocations of internal macros, which in turn expand into calls to methods of classes defined in the memory model. Those macros marked as internal are for internal use only by this file.
- Supporting allocation versus deletion.
 Some of the jeod_alloc.hh memory macros allocate memory while others delete it. With one exception, the allocation/delete nature of a macro is explicit in the macro name. Allocation macros start with JEOD_ALLOC. Macros that address deleting memory start with JEOD_DELETE.
- Operating on objects versus arrays.
 The memory management macros come in two basic forms: ARRAY and OBJECT. Memory allocated with an ARRAY allocator macro must be freed with JEOD_DELETE_ARRAY. Memory allocated with an OBJECT allocator macro must be freed with JEOD_DELETE_OBJECT. This corresponds to the C++ distiction between operator new[], delete[], new, and delete.
- Operating on structured versus non-structured data.
 The JEOD memory model registers allocated memory with the underlying simulation engine (e.g., Trick). To make the data in a structured type visible to the engine, the user must declare an external reference to the engine's description of the type. For example, to allocate an instance of some class Foo using the default constructor use

```
JEOD_DECLARE_ATTRIBUTES (Foo)
...
Foo * foo_obj = JEOD_ALLOC_CLASS (Foo, ());
```

See JEOD DECLARE ATTRIBUTES.

Two compile -D options affect the behavior of these macros. These are

- JEOD_MEMORY_DEBUG The memory model debugging level. The debugging level ranges from 0 (off) to 3 (all transactions). If this is not set in the compile flags the value is set to 0 (off).
- JEOD_MEMORY_GUARD Guards will be added around allocated memory if this option is defined and has a non-zero value.

9.3 jeod_alloc_construct_destruct.hh File Reference

Define templates for use by jeod alloc.hh.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include <cstddef>
#include <cstring>
#include <type_traits>
```

Data Structures

class jeod::JeodAllocHelperConstructDestruct
 T, is_class, is_abstract

Class template that provides static functions construct and destruct that construct an array of objects.

class jeod::JeodAllocHelperConstructDestruct
 T, false, is_abstract

Partial instantiation for non-classes.

class jeod::JeodAllocHelperConstructDestruct
 T, true, false >

Partial instantiation for non-abstract classes.

Namespaces

jeod

Namespace jeod.

Functions

```
    template<typename T >
        void * jeod::jeod_alloc_construct_array (std::size_t nelem, void *addr)
        Construct an array of objects of type T.
    template<typename T >
        void jeod::jeod_alloc_destruct_array (std::size_t nelem, void *addr)
        Destruct an array of objects of type T.
```

9.3.1 Detailed Description

Define templates for use by jeod_alloc.hh.

These are isolated from jeod_alloc.hh because

- They are templates; everything in jeod_alloc.hh is a macro.
- · Some of the templates might have wider interest than JEOD.
- Some of this stuff can go away with C++11.

The externally-usable items defined in this file are

- · Function template jeod alloc construct array, and
- Function template jeod_alloc_destruct_array.

9.4 jeod_alloc_get_allocated_pointer.hh File Reference

Define function template jeod_alloc_get_allocated_pointer.

```
#include <cstddef>
#include <cstring>
#include <type_traits>
```

Data Structures

class jeod::JeodAllocHelperAllocatedPointer< T, is_poly >

Class template that provides a static function cast that casts a pointer to an object of type T to a void* pointer.

class jeod::JeodAllocHelperAllocatedPointer< T, true >

Partial instantiation of JeodAllocHelperAllocatedPointer for polymorphic classes.

Namespaces

jeod

Namespace jeod.

Functions

template < typename T >
 void * jeod::jeod_alloc_get_allocated_pointer (T *pointer)

Cast a pointer to some object to a pointer to void* such that a pointer to a polymorphic object, downcast to a base class pointer, becomes a pointer to the original object, but also such that a pointer to an instance of a non-polymorphic class or a pointer to a non-class type is handled correctly.

9.4.1 Detailed Description

Define function template jeod_alloc_get_allocated_pointer.

9.5 memory_attributes_templates.hh File Reference

Define the class template JeodSimEngineAttributes.

```
#include "utils/sim_interface/include/memory_attributes.hh"
#include "utils/sim_interface/include/memory_interface.hh"
#include "utils/sim_interface/include/simulation_interface.hh"
#include <type_traits>
#include <typeinfo>
```

Data Structures

class jeod::JeodSimEngineAttributes
 Type, is_class >

Class template to construct a simulation engine attributes object that represents some type.

- class jeod::JeodSimEngineAttributes< Type *, false >

Partial template instantiation of JeodSimEngineAttributes for a pointer type.

class jeod::JeodSimEngineAttributes< void *, false >

Template specialization of JeodSimEngineAttributes for void*.

class jeod::JeodSimEngineAttributes
 Type, true >

Partial template instantiation of JeodSimEngineAttributes for a class.

Namespaces

· jeod

Namespace jeod.

9.5.1 Detailed Description

Define the class template JeodSimEngineAttributes.

9.6 memory_item.cc File Reference

Implement the JeodMemoryItem class.

```
#include "utils/message/include/message_handler.hh"
#include "../include/memory_item.hh"
#include "../include/memory_messages.hh"
```

Namespaces

jeod

Namespace jeod.

9.6.1 Detailed Description

Implement the JeodMemoryItem class.

9.7 memory_item.hh File Reference

Define the class JeodMemoryItem.

```
#include <cstdint>
#include "utils/sim_interface/include/jeod_class.hh"
```

Data Structures

· class jeod::JeodMemoryItem

A JeodMemoryItem contains metadata about some chunk of allocated memory.

Namespaces

• jeod

Namespace jeod.

9.7.1 Detailed Description

Define the class JeodMemoryItem.

9.8 memory_manager.cc File Reference

Implement the JeodMemoryManager class.

```
#include <cstddef>
#include <cstdint>
#include <cstdlib>
#include <iomanip>
#include <iostream>
#include <map>
#include <pthread.h>
#include <sstream>
#include <typeinfo>
#include "utils/message/include/message_handler.hh"
#include "../include/memory_item.hh"
#include "../include/memory_manager.hh"
#include "../include/memory_messages.hh"
```

Namespaces

• jeod

Namespace jeod.

Macros

• #define MAKE_DESCRIPTOR(type)

Variables

- static constexpr uint32_t jeod::MAGIC0 = 0x2203992c
- static constexpr uint32_t jeod::MAGIC1 = 0x6c052d84

9.8.1 Detailed Description

Implement the JeodMemoryManager class.

9.8.2 Macro Definition Documentation

9.8.2.1 MAKE_DESCRIPTOR

Value:

```
do

{
    JeodMemoryTypeDescriptorDerived<type> tdesc;
    type_table.add(tdesc.get_typeid().name(), tdesc);
} while(0)
```

Referenced by jeod::JeodMemoryManager::JeodMemoryManager().

9.9 memory_manager.hh File Reference

Define the JeodMemoryManager class, the central agent of the memory model.

```
#include <cstddef>
#include <list>
#include <map>
#include <ostream>
#include <pthread.h>
#include <string>
#include <typeinfo>
#include "utils/container/include/checkpointable.hh"
#include "utils/sim_interface/include/config.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/sim_interface/include/memory_interface.hh"
#include "utils/sim_interface/include/simulation_interface.hh"
#include "memory_item.hh"
#include "memory_type.hh"
```

Data Structures

• class jeod::JeodMemoryManager

This class provides the interface between the macros in jeod_alloc.hh and the rest of the JEOD memory model.

• struct jeod::JeodMemoryManager::TypeEntry

The type table is indexed by an integer and contains type descriptors.

Namespaces

• jeod

Namespace jeod.

9.9.1 Detailed Description

Define the JeodMemoryManager class, the central agent of the memory model.

9.10 memory_manager_hide_from_trick.hh File Reference

Trick doesn't understand these.

```
#include "memory_item.hh"
#include "memory_table.hh"
#include "memory_type.hh"
#include <map>
```

Namespaces

jeod

Namespace jeod.

Typedefs

```
    using jeod::AllocTable = std::map< const void *, JeodMemoryItem >
        An AllocTable maps memory addresses to memory descriptions.
    using jeod::TypeTable = JeodMemoryTableClonable
    JeodMemoryTypeDescriptor >
        The type type itself is a memory table with copy implemented by clone().
```

9.10.1 Detailed Description

Trick doesn't understand these.

This file is included from the private part of memory_manager.hh. The types are private and the corresponding members hidden from Trick. These will be folded into memory_manager.hh when Trick ICG, both Trick 7 and Trick 10, understands these or provides a common mechanism for telling ICG to ignore content.

9.11 memory_manager_protected.cc File Reference

Implement those JeodMemoryManager member functions that access data members that need to be treated with care to make the memory manager thread safe.

```
#include <cstddef>
#include <cstdint>
#include <cstdlib>
#include <iomanip>
#include <iostream>
#include <map>
#include <pthread.h>
#include <sstream>
#include <typeinfo>
#include "utils/message/include/message_handler.hh"
#include "../include/memory_item.hh"
#include "../include/memory_manager.hh"
#include "../include/memory_messages.hh"
```

Namespaces

· jeod

Namespace jeod.

Macros

```
• #define __STDC_LIMIT_MACROS
```

9.11.1 Detailed Description

Implement those JeodMemoryManager member functions that access data members that need to be treated with care to make the memory manager thread safe.

9.12 memory_manager_static.cc File Reference

Implement the static methods of the JeodMemoryManager class.

```
#include <string>
#include "utils/message/include/message_handler.hh"
#include "utils/named_item/include/named_item.hh"
#include "../include/memory_manager.hh"
#include "../include/memory_messages.hh"
```

Namespaces

jeod

Namespace jeod.

9.12.1 Detailed Description

Implement the static methods of the JeodMemoryManager class.

9.13 memory_messages.cc File Reference

Implement the class MemoryMessages.

```
#include "utils/message/include/make_message_code.hh"
#include "../include/memory_messages.hh"
```

Namespaces

• jeod

Namespace jeod.

Macros

• #define MAKE_MEMORY_MESSAGE_CODE(id) JEOD_MAKE_MESSAGE_CODE(MemoryMessages, "utils/memory/", id)

9.13.1 Detailed Description

Implement the class MemoryMessages.

9.13.2 Macro Definition Documentation

9.13.2.1 MAKE_MEMORY_MESSAGE_CODE

```
\label{eq:define_make_memory_message_code} $$id$ ) $$ JEOD_MAKE_MESSAGE_CODE(MemoryMessages, "utils/memory/", id) $$
```

Definition at line 43 of file memory_messages.cc.

9.14 memory_messages.hh File Reference

Define the class MemoryMessages, the class that specifies the message IDs used in the memory model.

```
#include "utils/sim_interface/include/jeod_class.hh"
```

Data Structures

· class jeod::MemoryMessages

Declares messages associated with the integration test model.

Namespaces

• jeod

Namespace jeod.

9.14.1 Detailed Description

Define the class MemoryMessages, the class that specifies the message IDs used in the memory model.

9.15 memory_table.hh File Reference

Define classes for representing data types.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include <cstddef>
#include <map>
#include <stdexcept>
#include <string>
#include <vector>
```

Data Structures

class jeod::JeodMemoryTable< ValueType >

A JeodMemoryTable maps strings to values with a coordinated map/vector pair.

class jeod::JeodMemoryTableClonable
 ValueType >

A JeodMemoryTableClonable is a JeodMemoryTable that implements the required clone() functionality by invoking the ValueType's clone() method to create a clone of the input value.

class jeod::JeodMemoryTableCopyable
 ValueType >

A JeodMemoryTableCopyable is a JeodMemoryTable that implements the required clone() functionality by invoking the ValueType's copy constructor to create a clone of the input value.

class jeod::JeodMemoryReflectiveTable

A JeodMemoryReflectiveTable maps strings to themselves.

Namespaces

jeod

Namespace jeod.

9.15.1 Detailed Description

Define classes for representing data types.

9.16 memory_type.cc File Reference

Implement destructors for the classes for representing data types.

```
#include <cstddef>
#include <sstream>
#include <string>
#include "utils/named_item/include/named_item.hh"
#include "utils/sim_interface/include/simulation_interface.hh"
#include "../include/memory_item.hh"
#include "../include/memory_manager.hh"
#include "../include/memory_type.hh"
```

Namespaces

jeod

Namespace jeod.

9.16.1 Detailed Description

Implement destructors for the classes for representing data types.

9.17 memory_type.hh File Reference

Define the abstract class JeodMemoryTypeDescriptor and templates that create instantiable classes that derive from JeodMemoryTypeDescriptor.

```
#include "jeod_alloc_construct_destruct.hh"
#include "jeod_alloc_get_allocated_pointer.hh"
#include "memory_attributes_templates.hh"
#include "memory_item.hh"
#include "memory_messages.hh"
#include "utils/message/include/message_handler.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/sim_interface/include/memory_attributes.hh"
#include <cstddef>
#include <cstring>
#include <string>
#include <type_traits>
#include <typeinfo>
```

Data Structures

· class jeod::JeodMemoryTypeDescriptor

Abstract class for managing data allocated as some specific type.

struct jeod::JeodMemoryTypeDescriptor::attr

The simulation engine attributes that describe the type.trick_io(**)

class jeod::JeodMemoryTypeDescriptorDerived< Type >

Extends JeodMemoryTypeDescriptor to describe a specific type.

class jeod::JeodMemoryTypePreDescriptor

Abstract class for describing a type without necessarily needing to create a JeodMemoryTypeDescriptor of that type.

class jeod::JeodMemoryTypePreDescriptorDerived< Type >

A JeodMemoryTypePreDescriptorDerived describes a Type.

Namespaces

jeod

Namespace jeod.

9.17.1 Detailed Description

Define the abstract class JeodMemoryTypeDescriptor and templates that create instantiable classes that derive from JeodMemoryTypeDescriptor.

Index

STDC_LIMIT_MACROS	jeod::JeodMemoryManager, 63
Support classes, 25	buffer_end
~JeodMemoryItem	jeod::JeodMemoryTypeDescriptor, 105
jeod::JeodMemoryItem, 47	buffer_size
~JeodMemoryManager	jeod::JeodMemoryTypeDescriptor, 106
jeod::JeodMemoryManager, 61	
~JeodMemoryTable	cast
jeod::JeodMemoryTable, 93	jeod::JeodAllocHelperAllocatedPointer, 38
~JeodMemoryTypeDescriptor	jeod::JeodAllocHelperAllocatedPointer< T, true >
jeod::JeodMemoryTypeDescriptor, 104	39
~JeodMemoryTypeDescriptorDerived	check_for_registration_errors
jeod::JeodMemoryTypeDescriptorDerived, 117	jeod::JeodMemoryTypeDescriptor, 113
~JeodMemoryTypePreDescriptor	check_master
jeod::JeodMemoryTypePreDescriptor, 121	jeod::JeodMemoryManager, 64
~JeodMemoryTypePreDescriptorDerived	class_declarations.hh, 137
jeod::JeodMemoryTypePreDescriptorDerived, 124	clone
	jeod::JeodMemoryTable, 94
add	jeod::JeodMemoryTableClonable, 99
jeod::JeodMemoryReflectiveTable, 89	jeod::JeodMemoryTableCopyable, 101
jeod::JeodMemoryTable, 94	jeod::JeodMemoryTypeDescriptor, 107
add_allocation_atomic	jeod::JeodMemoryTypeDescriptorDerived, 117
jeod::JeodMemoryManager, 61	const_value_iterator
add_string_atomic	jeod::JeodMemoryTable, 92
jeod::JeodMemoryManager, 62	construct
alloc_info_index	jeod::JeodAllocHelperConstructDestruct, 40
jeod::JeodMemoryItem, 52	jeod::JeodAllocHelperConstructDestruct< T, false,
alloc_table	is_abstract >, 42
jeod::JeodMemoryManager, 84	jeod::JeodAllocHelperConstructDestruct< T, true
AllocTable	false $>$, 43
jeod, 32	construct_array
jeod::JeodMemoryManager, 59	jeod::JeodMemoryTypeDescriptor, 107
allocate_memory	jeod::JeodMemoryTypeDescriptorDerived, 118
jeod::JeodMemoryManager, 63	construct_flags
allocation_number	jeod::JeodMemoryItem, 47
jeod::JeodMemoryManager, 84	corrupted_memory
Attributes	jeod::MemoryMessages, 132
jeod::JeodMemoryTypeDescriptorDerived, 116	create_memory
attributes	jeod::JeodMemoryManager, 65
jeod::JeodSimEngineAttributes, 127	create_memory_internal
jeod::JeodSimEngineAttributes< Type *, false >,	jeod::JeodMemoryManager, 66
128	cur_data_size
jeod::JeodSimEngineAttributes< Type, true >, 129	jeod::JeodMemoryManager, 85
jeod::JeodSimEngineAttributes< void *, false >,	
130	debug
	jeod::MemoryMessages, 132
base_type	debug_level
jeod::JeodMemoryTypeDescriptor, 105	jeod::JeodMemoryManager, 85
begin	DebugLevel
jeod::JeodMemoryTable, 94	jeod::JeodMemoryManager, 60
begin atomic block	del

jeod::JeodMemoryTable, 95	find_alloc_entry_atomic
delete_array	jeod::JeodMemoryManager, 69
jeod::JeodMemoryTypeDescriptor, 107	Flags
jeod::JeodMemoryTypeDescriptorDerived, 118	jeod::JeodMemoryItem, 45
delete_object	flags
jeod::JeodMemoryTypeDescriptor, 108	jeod::JeodMemoryItem, 52
jeod::JeodMemoryTypeDescriptorDerived, 118	free_memory
delete_oldest_alloc_entry_atomic	jeod::JeodMemoryManager, 70
jeod::JeodMemoryManager, 66	jeodeodiwemorywanager, 70
deregister container	generate_shutdown_report
jeod::JeodMemoryManager, 67	jeod::JeodMemoryManager, 71
descriptor	get
jeod::JeodMemoryTypePreDescriptorDerived, 126	jeod::JeodMemoryTable, 96
descriptor_index_hi	get_alloc_id_atomic
jeod::JeodMemoryItem, 52	jeod::JeodMemoryManager, 71
descriptor_index_lo	get_alloc_index
jeod::JeodMemoryItem, 52	jeod::JeodMemoryItem, 47
destroy_memory	get_attr
jeod::JeodMemoryManager, 68	jeod::JeodMemoryTypeDescriptor, 109
jeod::JeodMemoryTypeDescriptor, 108	get_checkpointed
destroy_memory_internal	jeod::JeodMemoryItem, 48
jeod::JeodMemoryManager, 68	get_descriptor
destruct	jeod::JeodMemoryTypePreDescriptor, 121
jeod::JeodAllocHelperConstructDestruct, 41	jeod::JeodMemoryTypePreDescriptorDerived, 124
jeod::JeodAllocHelperConstructDestruct< T, false,	get_descriptor_index
is_abstract >, 42	jeod::JeodMemoryItem, 48
jeod::JeodAllocHelperConstructDestruct< T, true,	get_is_array
false >, 43	jeod::JeodMemoryItem, 48
destruct_array	get_is_guarded
jeod::JeodMemoryTypeDescriptor, 109	jeod::JeodMemoryItem, 49
jeod::JeodMemoryTypeDescriptorDerived, 119	get_is_registered
dimensionality	jeod::JeodMemoryItem, 49
jeod::JeodMemoryTypeDescriptor, 109	get_name
, , , , ,	jeod::JeodMemoryTypeDescriptor, 109
end	get_nelems
jeod::JeodMemoryTable, 95	jeod::JeodMemoryItem, 49
end_atomic_block	get_placement_new
jeod::JeodMemoryManager, 69	jeod::JeodMemoryItem, 50
Externally-usable macros, 11	get_ref
JEOD_ALLOC_CLASS_ARRAY, 12	jeod::JeodMemoryTypePreDescriptorDerived, 125
JEOD_ALLOC_CLASS_MULTI_POINTER_AR \leftrightarrow	get_register_instances
RAY, 13	jeod::JeodMemoryTypeDescriptor, 110
JEOD_ALLOC_CLASS_OBJECT, 13	get_size
JEOD_ALLOC_CLASS_POINTER_ARRAY, 14	jeod::JeodMemoryTypeDescriptor, 110
JEOD_ALLOC_PRIM_ARRAY, 14	get_string_atomic
JEOD_ALLOC_PRIM_OBJECT, 15	jeod::JeodMemoryManager, 72
JEOD_DELETE_2D, 15	get_type_descriptor
JEOD_DELETE_ARRAY, 16	jeod::JeodMemoryManager, 72, 73
JEOD_DELETE_OBJECT, 17	get_type_descriptor_atomic
JEOD_DEREGISTER_CHECKPOINTABLE, 17	jeod::JeodMemoryManager, 73, 74
JEOD_IS_ALLOCATED, 18	get_type_descriptor_nolock
JEOD_MEMORY_DEBUG, 18	jeod::JeodMemoryManager, 75
JEOD_REGISTER_CHECKPOINTABLE, 18	get_type_entry_atomic
JEOD_REGISTER_CLASS, 19	jeod::JeodMemoryManager, 75, 76
JEOD_REGISTER_INCOMPLETE_CLASS, 19	get_type_index_nolock
JEOD_REGISTER_NONEXPORTED_CLASS, 20	jeod::JeodMemoryManager, 76
	get_typeid
find	jeod::JeodMemoryTypeDescriptor, 110
jeod::JeodMemoryTable, 96	jeod::JeodMemoryTypePreDescriptor, 122

jeod::JeodMemoryTypePreDescriptorDerived, 125	JEOD_ALLOC_PRIM_ARRAY
get_unique_id	Externally-usable macros, 14
jeod::JeodMemoryItem, 50	JEOD_ALLOC_PRIM_OBJECT
guard_enabled	Externally-usable macros, 15
jeod::JeodMemoryManager, 85	JEOD_ALLOC_PRIMITIVE_FILL
index	Internal macros, 22
jeod::JeodMemoryManager::TypeEntry, 136	JEOD_CREATE_MEMORY
init_attrjeodJeodMemoryManager	Internal macros, 23
jeod::JeodMemoryManager, 84	JEOD_DELETE_2D
init_attrjeodMemoryMessages	Externally-usable macros, 15
jeod::MemoryMessages, 132	JEOD_DELETE_ARRAY
initialize_type_name	Externally-usable macros, 16
jeod::JeodMemoryTypeDescriptor, 111	JEOD_DELETE_INTERNAL
InputProcessor	Internal macros, 23
jeod::JeodMemoryManager, 84	JEOD_DELETE_OBJECT
jeod::MemoryMessages, 132	Externally-usable macros, 17 JEOD_DEREGISTER_CHECKPOINTABLE
Internal macros, 21	Externally-usable macros, 17
JEOD_ALLOC_ARRAY_INTERNAL, 21	JEOD IS ALLOCATED
JEOD_ALLOC_OBJECT_FILL, 22	_ _
JEOD_ALLOC_OBJECT_INTERNAL, 22	Externally-usable macros, 18 JEOD_MEMORY_DEBUG
JEOD_ALLOC_POINTER_FILL, 22	Externally-usable macros, 18
JEOD_ALLOC_PRIMITIVE_FILL, 22	JEOD_REGISTER_CHECKPOINTABLE
JEOD_CREATE_MEMORY, 23	Externally-usable macros, 18
JEOD_DELETE_INTERNAL, 23	JEOD_REGISTER_CLASS
internal_error	Externally-usable macros, 19
jeod::MemoryMessages, 133	JEOD_REGISTER_INCOMPLETE_CLASS
invalid_size	Externally-usable macros, 19
jeod::MemoryMessages, 133	JEOD_REGISTER_NONEXPORTED_CLASS
is_allocated	Externally-usable macros, 20
jeod::JeodMemoryManager, 77	jeod, 31
is_allocated_internal	AllocTable, 32
jeod::JeodMemoryManager, 77	jeod_alloc_construct_array, 33
is_exportable	jeod_alloc_destruct_array, 33
jeod::JeodMemoryTypePreDescriptorDerived, 126	jeod_alloc_get_allocated_pointer, 34
is_structured	MAGIC0, 35
jeod::JeodMemoryTypeDescriptor, 111	MAGIC1, 35
jeod::JeodMemoryTypeDescriptorDerived, 119	TypeTable, 33
is_structured_data	jeod::JeodAllocHelperAllocatedPointer
jeod::JeodMemoryItem, 50	cast, 38
is_table_empty jeod:.JeodMemoryManager, 78	jeod::JeodAllocHelperAllocatedPointer< T, is_poly >
jeodJeodiviemorywanager, 78	37
JEOD_ALLOC_ARRAY_INTERNAL	jeod::JeodAllocHelperAllocatedPointer< T, true >, 38
Internal macros, 21	cast, 39
JEOD ALLOC CLASS ARRAY	jeod::JeodAllocHelperConstructDestruct
Externally-usable macros, 12	construct, 40
JEOD_ALLOC_CLASS_MULTI_POINTER_ARRAY	destruct, 41
Externally-usable macros, 13	jeod::JeodAllocHelperConstructDestruct< T, false, is_ <-
JEOD_ALLOC_CLASS_OBJECT	abstract >, 41
Externally-usable macros, 13	construct, 42
JEOD_ALLOC_CLASS_POINTER_ARRAY	destruct, 42
Externally-usable macros, 14	jeod::JeodAllocHelperConstructDestruct< T, is_class
JEOD_ALLOC_OBJECT_FILL	is_abstract >, 39
Internal macros, 22	jeod::JeodAllocHelperConstructDestruct< T, true, false
JEOD_ALLOC_OBJECT_INTERNAL	>, 43
Internal macros, 22	construct, 43
JEOD_ALLOC_POINTER_FILL	destruct, 43
Internal macros, 22	jeod::JeodMemoryItem, 44

\sim JeodMemoryItem, 47	JeodMemoryManager, 60, 61
alloc_info_index, 52	Master, 86
construct_flags, 47	max_data_size, 86
descriptor_index_hi, 52	max_table_size, 86
descriptor_index_lo, 52	mode, 86
Flags, 45	mutex, 87
flags, 52	NameType, 60
get_alloc_index, 47	operator=, 78
get_checkpointed, 48	register_class, 78
get_descriptor_index, 48	register_container, 79
get_is_array, 48	register_memory_internal, 80
get_is_guarded, 49	reset_alloc_id_atomic, 80
get_is_registered, 49	restart_clear_memory, 81
get_nelems, 49	restart_reallocate, 81
get_placement_new, 50	set_debug_level, 82
get_unique_id, 50	set_guard_enabled, 82
is_structured_data, 50	set_mode, 83
JeodMemoryItem, 46	set_mode_internal, 83
nelems, 53	sim_interface, 87
set_is_registered, 51	string_table, 87
set_unique_id, 51	type_table, 87
unique_id, 53	TypeTable, 59
jeod::JeodMemoryManager, 54	jeod::JeodMemoryManager::TypeEntry, 135
~JeodMemoryManager, 61	index, 136
add_allocation_atomic, 61	tdesc, 136
add_string_atomic, 62	TypeEntry, 135
alloc_table, 84	jeod::JeodMemoryReflectiveTable, 88
AllocTable, 59	add, 89
allocate_memory, 63	JeodMemoryReflectiveTable, 89
allocation_number, 84	operator=, 90
begin_atomic_block, 63	jeod::JeodMemoryTable
check_master, 64	~JeodMemoryTable, 93
create_memory, 65	add, 94
create_memory_internal, 66	begin, 94
cur data size, 85	clone, 94
debug_level, 85	const value iterator, 92
DebugLevel, 60	del, 95
delete_oldest_alloc_entry_atomic, 66	end, 95
deregister_container, 67	find, 96
destroy_memory, 68	get, 96
destroy_memory_internal, 68	JeodMemoryTable, 93
end_atomic_block, 69	NameIndex, 92
find_alloc_entry_atomic, 69	operator=, 97
free_memory, 70	string_to_index, 97
generate_shutdown_report, 71	value list, 97
get_alloc_id_atomic, 71	ValueList, 93
get string atomic, 72	jeod::JeodMemoryTable< ValueType >, 90
get_type_descriptor, 72, 73	jeod::JeodMemoryTableClonable
get_type_descriptor_atomic, 73, 74	clone, 99
get_type_descriptor_nolock, 75	JeodMemoryTableClonable, 98, 99
get_type_entry_atomic, 75, 76	operator=, 99
get_type_index_nolock, 76	jeod::JeodMemoryTableClonable< ValueType >, 98
guard_enabled, 85	jeod::JeodMemoryTableCopyable
init_attrjeodJeodMemoryManager, 84	clone, 101
InputProcessor, 84	JeodMemoryTableCopyable, 100, 101
is_allocated, 77	operator=, 101
is_allocated_internal, 77	jeod::JeodMemoryTableCopyable< ValueType >, 100
is_allocated_internal, // is_table_empty, 78	jeod::JeodMemoryTypeDescriptor, 102
is_lable_ellipty, 10	JeouJeouwiemory rypeDescriptor, 102

\sim JeodMemoryTypeDescriptor, 104	${\sf jeod::JeodMemoryTypePreDescriptorDerived} < {\sf Type} >,$
base_type, 105	122
buffer_end, 105	jeod::JeodSimEngineAttributes
buffer_size, 106	attributes, 127
check_for_registration_errors, 113	jeod::JeodSimEngineAttributes< Type *, false >, 127
clone, 107	attributes, 128
construct_array, 107	jeod::JeodSimEngineAttributes< Type, is_class >, 126
delete_array, 107	jeod::JeodSimEngineAttributes< Type, true >, 128
delete_object, 108	attributes, 129
destroy_memory, 108	jeod::JeodSimEngineAttributes< void *, false >, 129
destruct array, 109	attributes, 130
dimensionality, 109	jeod::MemoryMessages, 130
get_attr, 109	corrupted_memory, 132
get_name, 109	debug, 132
get_register_instances, 110	init_attrjeodMemoryMessages, 132
get_size, 110	InputProcessor, 132
get typeid, 110	internal_error, 133
initialize_type_name, 111	invalid_size, 133
is_structured, 111	lock_error, 133
JeodMemoryTypeDescriptor, 104	MemoryMessages, 131
most_derived_pointer, 111, 112	null_pointer, 133
name, 113	operator=, 132
obj_id, 114	out_of_memory, 134
	registration_error, 134
operator=, 112 pointer_dimension, 112	singleton_error, 134
register_instances, 114	suspect_pointer, 134
set_check_for_registration_errors, 112	jeod_alloc.hh, 137
size, 114	jeod_alloc_construct_array
type_spec, 113	jeod, 33
jeod::JeodMemoryTypeDescriptor::attr, 37	jeod_alloc_construct_destruct.hh, 139
jeod::JeodMemoryTypeDescriptoratti, 37	jeod_alloc_destruct_array
~JeodMemoryTypeDescriptorDerived, 117	jeod, 33
Attributes, 116	jeod_alloc_get_allocated_pointer
clone, 117	jeod, 34
construct_array, 118	jeod_alloc_get_allocated_pointer.hh, 140
delete_array, 118	JeodMemoryItem
delete_diray, 118	jeod::JeodMemoryItem, 46
destruct_array, 119	JeodMemoryManager
is structured, 119	jeod::JeodMemoryManager, 60, 61
JeodMemoryTypeDescriptorDerived, 116, 117	JeodMemoryReflectiveTable
most_derived_pointer, 119, 120	jeod::JeodMemoryReflectiveTable, 89
operator=, 120	JeodMemoryTable
TypeDescriptor, 116	jeod::JeodMemoryTable, 93
jeod::JeodMemoryTypeDescriptorDerived< Type >,	JeodMemoryTableClonable
115	jeod::JeodMemoryTableClonable, 98, 99
jeod::JeodMemoryTypePreDescriptor, 121	JeodMemoryTableCopyable
~JeodMemoryTypePreDescriptor, 121	jeod::JeodMemoryTableCopyable, 100, 101
get_descriptor, 121	JeodMemoryTypeDescriptor
get_typeid, 122	jeod::JeodMemoryTypeDescriptor, 104
jeod::JeodMemoryTypePreDescriptorDerived	JeodMemoryTypeDescriptorDerived
~JeodMemoryTypePreDescriptorDerived, 124	jeod::JeodMemoryTypeDescriptorDerived, 116,
descriptor, 126	117
get_descriptor, 124	JeodMemoryTypePreDescriptorDerived
get_ref, 125	jeod::JeodMemoryTypePreDescriptorDerived, 124
get_typeid, 125	lock_error
is_exportable, 126	jeod::MemoryMessages, 133
JeodMemoryTypePreDescriptorDerived, 124	journal fill outgood for
TypeDescriptor, 123	MAGIC0
••	

icad 25	icad:: laadMamaryTablaCanyabla 101
jeod, 35 MAGIC1	jeod::JeodMemoryTableCopyable, 101
	jeod::JeodMemoryTypeDescriptor, 112
jeod, 35	jeod::JeodMemoryTypeDescriptorDerived, 120
MAKE_DESCRIPTOR	jeod::MemoryMessages, 132
memory_manager.cc, 143	out_of_memory
MAKE_MEMORY_MESSAGE_CODE	jeod::MemoryMessages, 134
memory_messages.cc, 147	naintar dimanaian
Master	pointer_dimension
jeod::JeodMemoryManager, 86	jeod::JeodMemoryTypeDescriptor, 112
max_data_size	register_class
jeod::JeodMemoryManager, 86	jeod::JeodMemoryManager, 78
max_table_size	
jeod::JeodMemoryManager, 86	register_container
Memory, 28	jeod::JeodMemoryManager, 79
memory_attributes_templates.hh, 141	register_instances
memory_item.cc, 142	jeod::JeodMemoryTypeDescriptor, 114
memory_item.hh, 142	register_memory_internal
memory_manager.cc, 143	jeod::JeodMemoryManager, 80
MAKE_DESCRIPTOR, 143	registration_error
memory_manager.hh, 144	jeod::MemoryMessages, 134
memory_manager_hide_from_trick.hh, 145	reset_alloc_id_atomic
memory_manager_protected.cc, 145	jeod::JeodMemoryManager, 80
memory_manager_static.cc, 146	restart_clear_memory
memory_messages.cc, 146	jeod::JeodMemoryManager, 81
MAKE_MEMORY_MESSAGE_CODE, 147	restart_reallocate
memory_messages.hh, 147	jeod::JeodMemoryManager, 81
memory_table.hh, 148	
memory_type.cc, 148	set_check_for_registration_errors
memory_type.hh, 149	jeod::JeodMemoryTypeDescriptor, 112
MemoryMessages	set_debug_level
jeod::MemoryMessages, 131	jeod::JeodMemoryManager, 82
mode	set_guard_enabled
jeod::JeodMemoryManager, 86	jeod::JeodMemoryManager, 82
Models, 26	set_is_registered
most_derived_pointer	jeod::JeodMemoryItem, 51
jeod::JeodMemoryTypeDescriptor, 111, 112	set_mode
jeod::JeodMemoryTypeDescriptorDerived, 119,	jeod::JeodMemoryManager, 83
120	set_mode_internal
mutex	jeod::JeodMemoryManager, 83
jeod::JeodMemoryManager, 87	set_unique_id
joodinoodiiioiioi jiiidiidgoi, o	jeod::JeodMemoryItem, 51
name	sim interface
jeod::JeodMemoryTypeDescriptor, 113	jeod::JeodMemoryManager, 87
NameIndex	singleton_error
jeod::JeodMemoryTable, 92	jeod::MemoryMessages, 134
NameType	size
jeod::JeodMemoryManager, 60	jeod::JeodMemoryTypeDescriptor, 114
nelems	string_table
jeod::JeodMemoryItem, 53	jeod::JeodMemoryManager, 87
null pointer	string_to_index
jeod::MemoryMessages, 133	jeod::JeodMemoryTable, 97
joodiviemoi yiviessayes, 100	Support classes, 25
obj_id	STDC_LIMIT_MACROS, 25
jeod::JeodMemoryTypeDescriptor, 114	suspect_pointer
operator=	jeod::MemoryMessages, 134
jeod::JeodMemoryManager, 78	jeouwemorywessayes, 134
jeod::JeodMemoryReflectiveTable, 90	tdesc
jeod::JeodMemoryTable, 97	jeod::JeodMemoryManager::TypeEntry, 136
jeod::JeodMemoryTableClonable, 99	type_spec
jedadedalvietnoi y rabie Glotiable, 33	ryhe_sher

```
jeod::JeodMemoryTypeDescriptor, 113
type_table
    jeod::JeodMemoryManager, 87
TypeDescriptor
    jeod::JeodMemoryTypeDescriptorDerived, 116
    jeod::JeodMemoryTypePreDescriptorDerived, 123
TypeEntry
    jeod::JeodMemoryManager::TypeEntry, 135
TypeTable
    jeod, 33
    jeod::JeodMemoryManager, 59
unique_id
    jeod::JeodMemoryItem, 53
Utils, 27
value_list
    jeod::JeodMemoryTable, 97
ValueList
    jeod::JeodMemoryTable, 93
```