3 Check the shooting mode. Confirm that **P** appears in the display.



4 Ready the camera.

 Hold the camera steady with both hands and brace your elbows against your sides. Shaking or unsteady hands can blur your shots.



 To prevent pictures that are out of focus or too dark (underexposed), keep your fingers and other objects away from the lens and AF-assist illuminator.



5 Frame the picture.



The bright frame in the OVF shows the area that will appear in the final photograph.