Setting	Description
② Flash compensation/output	The options available vary with flash control mode. • **TTL**: Adjust flash compensation (the full value may not be applied if the limits of the flash control system are exceeded). In the cases of the EF-X20, EF-20, and EF-42, the selected value is added to the value selected with the flash unit. • **M/MULTI**: Adjust flash output (compatible units only). Choose from values expressed as fractions of full power, from ⅓ (mode **M**) or ¼ (**MULTI**) down to ⅟₅₁₂ in increments equivalent to ⅓ EV. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results.
③ Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode (**P**, **S**, **A**, or **M**) selected. • **$\frac{4TL}{AUTO}$ (FLASH AUTO)**: The flash fires only as required; flash level is adjusted according to subject brightness. A 🔅 icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken. • **4TL (STANDARD)**: The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released. • **$\frac{4TL}{SLOW}$ (SLOW SYNC.)**: Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.

Peripherals and Optional Accessories

11

347