

7 Maintenance

Target groups O, E, M, C



Definition of the target groups:

Operating Instructions General,
 Chapter Introduction/target groups.



Observe the following information:

- Operating Instructions General,
 Chapter Safety,
 Chapter Maintenance,
- Subsuppliers' Operating Instructions,
- Electrical Equipment Operating Instructions.

7.1 Maintenance schedule

Area	Inspection	Action	ОС	TI
General	Fastening	Fasten		Υ
	Damage	 Replace 	Р	М
	(condition)	■ Repair		
	Function	Repair	Ν	S
	 Unusual noises 	Eliminate the cause	Ν	М
	• Wear	Replace	Р	М
		■ Repair		
	Contamination	- Clean	Р	М
Cylinder	Function	- Replace	Ν	S
		■ Repair		
		Set speed		
	 Bearing assembly 	Fasten	Р	Υ
		- Replace		
		 Repair 		
	Sealing	Replace	S	M
		Repair		

AISHA-CCM Version: A - 2018-10-22 11



Backup roll changing device

Maintenance

Area	Inspection	Action	ОС	TI
Rails and wheels	• Wear	■ Repair	S	3M
	 Contamination 	■ Replace		
		■ Clean		
Fluid line,	- Leaks	 Replace 	Р	М
fluid connection		■ Repair		
	Volumetric flow rate	Set volumetric flow rate	N	М

Operating condition (OC)		Time interval (TI)		
N	Normal operation (production)	s	every shift (8 hours)	
S	Special operating mode	**)M	every month	
Р	Stop (maintenance, troubleshooting)	**)Y	every year	
		**) Intervals combined with numbers denote e.g.:		
		3M= every three months		

NOTICE

In the first three months after commissioning, the pipework must be inspected every two weeks. This allows leaks to be detected at an early stage.

12 Version: A - 2018-10-22 AISHA-CCM