

EEN452 - Control and Operation of Electric Power Systems

Part 3: Frequency control


https://sps.cut.ac.cy/courses/een452/

Dr Petros Aristidou

Department of Electrical Engineering, Computer Engineering & Informatics Last updated: March 17, 2025

Demand response for ancillary services





Source: Gómez-Expósito, A., Conejo, A. J., & Cañizares, C. A. (2018). Electric Energy Systems Analysis and Operation. CRC Press.

Today's learning objectives



After this part of the lecture and additional reading, you should be able to ...

- 1 ... understand the fundamentals of frequency and power control;
- 2 ... perform calculations concerning primary and secondary frequency control.

1 Outline



- 1 Fundamentals
- 2 Inertia response
- 3 Primary frequency control
- 4 Secondary frequency control

1 Introduction



Frequency must remain close to its nominal value:


- for the correct operation of loads (rotating machines)
- because it is an indication that the (active) power production balances the (active) power consumption (including network losses).


What is the link between frequency and active power balance?


- Electrical energy cannot be stored; it is produced when it is requested
- in the very first instants after a disturbance: the missing (resp. excess) amount of energy is taken from (resp. stored into) the rotating masses of the synchronous machines (see previous chapter)
- this causes a variation of their speed of rotation, and hence of frequency

1 Introduction









1 Introduction






https://extranet.nationalgrid.com/RealTime (Data last updated on : 06/02/2021 19:37:00)

1 Frequency services





2 Outline



- 1 Fundamentals
- 2 Inertia response
- 3 Primary frequency control
- 4 Secondary frequency control

2 Kinetic energy of rotor



The kinetic energy of the rotor is given by:

$$W_c = \frac{1}{2}J\omega_r^2 \cdot 10^{-6} \quad \text{MJ}$$

where

J: moment of inertia of all the rotating masses in kg-m² ω_r : synchronous speed of rotor in rad-mech/s

Converting to electrical speed with $\omega_s = (P/2)\omega_r$, gives:

$$\textit{W}_{c} = \frac{1}{2} \left(\textit{J}(2/P)^{2} \omega_{s} \cdot 10^{-6} \right) \omega_{s} \approxeq \frac{1}{2} \left(\textit{J}(2/P)^{2} \omega_{N} \cdot 10^{-6} \right) \omega_{s} = \frac{1}{2} \textit{M} \omega_{s}$$

where

 $M = J(2/P)^2 \omega_N \cdot 10^{-6}$: moment of inertia in MJ-s/rad-elec

P: the number of poles

 ω_s : the rotor speed in rad-elec/s

 ω_N : the synchronous speed in rad-elec/s



The inertia constant of the machine, is defined as:

$$S_N H = W_c = \frac{1}{2} M \omega_s$$
 MJ

where

 S_N : the machine rating in MVA

 $H = W_c/S_N$: the inertia constant in MJ/MVA or MW-s/MVA or pu-s

It follows:

$$M = \frac{2S_N H}{\omega_s}$$
 MJ-s/rad-elec

Setting $S_B = S_N$ (S_B the base power for the per-unit system):

$$M_{pu} = \frac{2H}{\omega_s} s^2/\text{rad-elec} \approx \frac{2H}{\omega_N} s^2/\text{rad-elec}$$



Example constants for various synchronous machines:

Table 12.1 Typical inertia constants of synchronous machines*

Type of Machine	Intertia Constant H Stored Energy in MW Sec per MVA**		
Turbine Generator			
Condensing	1,800 rpm	9-6	
	3,000 rpm	7-4	
Non-Condensing	3,000 rpm	4-3	
Water wheel Generator			
Slow-speed (< 200 rpm)		2-3	
High-speed (> 200 rpm)		2-4	
Synchronous Condenser***			
Large		1.25	
Small		1.00	
Synchronous Motor with load	varying from		
1.0 to 5.0 and higher for heavy flywheels		2.00	

2 Synchronous machine motion equation



From previous chapter, we know:

$$\frac{dW_c}{dt} = P_m - P_e$$

where

 P_m : mechanical power applied to the rotor by the turbine P_e : electrical power output of the stator (ignoring losses)

This leads to:

$$P_m - P_e = \frac{dW_c}{dt} = J\omega_r \frac{d^2\theta_r}{dt^2} = \left(J(2/P)^2\omega_N \cdot 10^{-6}\right) \frac{d^2\theta_e}{dt^2} = M \frac{d^2\theta_e}{dt^2}$$

where

 θ_e : rotor angle in rad-elec

2 Synchronous machine motion equation



Or, in per-unit:

$$P_m^{pu} - P_e^{pu} = M_{pu} \frac{d^2 \theta_e}{dt^2} = M_{pu} \frac{d^2 \delta}{dt^2} = M_{pu} \frac{d\omega_s}{dt} = \frac{2H}{\omega_N} \frac{d\omega_s}{dt}$$

where

$$\frac{d\delta}{dt} = \omega_s(t) - \omega_N$$

To account for mechanical rotational loss due to windage and friction, we usually add a frequency-dependent term *D*:

$$P_{m}^{pu} - P^{pu} - \frac{D}{\omega_{N}} \omega_{s} = M_{pu} \frac{d\omega_{s}}{dt} = \frac{2H}{\omega_{N}} \frac{d\omega_{s}}{dt}$$

The value of D/ω_N has typical values [0, 2]. The units of D are per unit power.




The Rate of Change of Frequency (ROCOF) defines the initial slope of the frequency after a power imbalance (ΔP_{pu}). Considering a generator connected to a load with D=0:

$$\mathsf{RoCoF} = \frac{\mathit{d}\omega_{\mathsf{s}}}{\mathit{d}t} = \frac{\omega_{\mathit{N}}}{2H} \left(P_{\mathit{m}}^{\mathit{pu}} - P_{\mathsf{e}}^{\mathit{pu}} \right) = \frac{\omega_{\mathit{N}}}{2H} \Delta P^{\mathit{pu}}$$

2 Multi-machine system



When we have multiple synchronous machines in the system, each one will have its own speed dictated by its own swing equation and parameters $(H_i, S_{N,i}, \omega_{s,i})$.



Which one do we use?

We can compute the inertia constant of a single machine referred to the common system as:

$$H_i' = \frac{H_i S_{N,i}}{\sum_{i=1}^n S_{N,i}}$$

Then, we can define the "center of inertia" (COI) frequency as a representative average frequency of the system:

$$\omega_{coi} = \frac{\sum_{i=1}^{n} H_i' \cdot \omega_{s,i}}{\sum_{i=1}^{n} H_i'}$$

2 Multi-machine system



The total system inertia is computed as:

$$H_{sys} = rac{\sum_{i=1}^{n} H_i S_{N,i}}{S_{sys}}$$
 $S_{sys} = \sum_{i=1}^{n} S_{N,i}$

This leads to the COI swing equation:


$$\mathsf{RoCoF} = rac{d\omega_{coi}}{dt} = rac{\omega_{\mathit{N}}}{2H_{\mathit{sys}}}\Delta P_{\mathit{sys}}^{\mathit{pu}}$$

With the frequency at time ΔT after the power imbalance (assuming the imbalance remains constant):


$$\omega_{coi}(t_0 + \Delta T) = \frac{\omega_N}{2H_{\rm sys}} \Delta P_{\rm sys}^{\rm pu} \cdot \Delta T + \omega_{coi}(t_0)$$



- System inertia is crucial to retain the frequency initially after a power mismatch. It represents an energy storage buffer that stabilizes the system.
- Conventional units (synchronous-machine-based) are gradually displaced or switched off in favour of renewable generation units (power-electronic interfaced) with lower marginal costs.
- Power-electronic-interfaced generators do not inherently contribute to the system inertia as they lack kinetic inertia.







- Lower system inertia leads to higher RoCoF (see slide 17) and higher frequency nadir.
- This can trigger frequency-based protections of generators and loads, damage generators due to vibrations, lead to motor disconnections, lead to sub-optimal operation of components, etc.


We need to add inertia to the system!




Solutions?

- Add power sources or energy buffers that can provide kinetic inertia inherently (flywheels, synchronous condensers, etc.).
- Program power-electronic interfaced generators and storage devices to emulate inertial response. This behaviour is called virtual or synthetic inertia.
- The power-electronic interfaced resources need to have enough energy stored (W_V) to provide virtual inertia (H_V) and they need to release energy in response to the RoCoF of energy.


$$\begin{aligned} H_{sys} &= \frac{\sum_{i=1}^{n_c} W_{c,i} + \sum_{i=1}^{n_V} W_{V,i}}{S_{sys}} \\ &= \frac{\sum_{i=1}^{n_c} H_{c,i} S_{c,i} + \sum_{i=1}^{n_V} H_{V,i} S_{V,i}}{S_{sys}} \end{aligned}$$







(a) Schematic representation of (kinetic) energy exchange



Tielens, P. (2017). "Operation and control of power systems with low synchronous inertia", Doctoral thesis, KU Leuven.


3 Outline



- 1 Fundamentals
- 2 Inertia response
- 3 Primary frequency control
 - The speed governor
 - Frequency response
- Secondary frequency control

3 Frequency services





3 Mechanisms



What will happen to the frequency if the imbalance is not "fixed"?

$$\frac{d\omega_s}{dt} = \frac{\omega_N}{2H} \left(P_m^{pu} - P_e^{pu} \right)$$


 \rightarrow The frequency will keep decreasing (or increasing) until it reaches the protection limits and the system will go into emergency mode (or blackout).


How do we "fix" the imbalance?

- ① We can modify the mechanical power input P_m^{pu} by changing the setpoints of the prime mover (e.g., adjust the steam/water/gas flow in the turbines). This is automatically done by devices called **speed governors** (ρυθμιστές ταχύτητας).
- We can modify the electrical power output P_e^{pu} by disconnecting (e.g., under-frequency load shedding schemes) or adjusting (e.g., flexible loads) electrical loads.
- ightarrow Unscheduled disconnection of loads is not desirable because it affects the power quality of consumers and it's used only as a last resort for protection purposes.
- \rightarrow The main solution mechanism are the speed governors in combination with flexible loads.

3.1 The speed governor: overview








3.1 The speed governor: block diagram





where

 ω_r : speed of rotation

z: fraction of opening of the turbine control valves (0 < z < 1)


 P_m : mechanical power produced by the turbine

G(s): transfer function between z and P_m

F(s): transfer function between ω_r and z

3.1 The speed governor: the isochronous regulator





where

 $\omega_s = p\omega_m$: electrical speed

p: number of pairs of poles

 ω_N : nominal frequency


Servomotor: represented by the gain K > 0 and the integrator

In steady state $\omega = p\omega_r = \omega_N \longrightarrow$ no frequency error

- a single generator can be equipped with an isochronous regulator
- frequently used in gen-sets for backup generators supplying the entire system in case of islanding.

3.1 The speed governor: the droop-based regulator






where

 Z_0 : valve opening setpoint (to modify the power production of the generator)

3.1 The speed governor: the droop-based regulator



Equivalently:



where

$$T_{sm} = \frac{1}{K\sigma}$$
: time constant of the servomotor

$$z = \frac{1}{1 + sT_{sm}} \left(Z_0 - \frac{\omega_s - \omega_N}{\sigma \omega_N} \right)$$

What is the value of z in steady-state?


3.1 Steady-state characteristic of a turbine-governor set



 Steady-state characteristic of turbine-governor

$$P_m = P^0 - \frac{P_N}{\sigma} \frac{f - f_N}{f_N}$$

- P⁰ is the power setpoint of generator
- \bullet P_N is the generator nominal power
- f_N is the system nominal frequency
- f is the measured frequency



 σ is the droop of the speed governor. It defines the ratio between the relative frequency deviation and the relative power deviation

$$\left| \frac{\Delta \omega / \omega_N}{\Delta P_m / P_N} \right| = \left| \frac{\Delta f / f_N}{\Delta P_m / P_N} \right| = \sigma$$

(Typical values: 4-5%)

3.1 Steady-state characteristic of a turbine-governor set



- A frequency deviation $\Delta f = \sigma f_N = 0.04 \cdot 50 = 2$ Hz would result in a variation of mechanical power $\Delta P_m = P_N$
- Infinite speed droop: the machine operates at constant power, and does not participate in frequency control
- Frequency regulation parameter: Gives the power output change of the generator to a frequency change

$$R_f = \frac{\sigma f_N}{P_N} [Hz/MW]$$

- The speed controller is of the proportional type
 - it leaves a steady-state frequency error, but . . .
 - this is precisely the signal allowing to share the effort over the various generators.

3.2 Modelling assumptions



- system has come back to steady state \Rightarrow all machines have the same electrical speed = $2\pi f$
- the network is lossless
- the mechanical power produced by the turbines is completely converted into electrical power
- load is sensitive to frequency:

$$P_c = P_c^o p(f) \quad \text{with } p(f_N) = 1$$

$$= P_c^o \left(p(f_N) + \frac{dp}{df} \Big|_{f = f_N} (f - f_N) \right) = P_c^o (1 + D(f - f_N))$$

D: sensitivity of load to frequency (1/Hz)

• the system initially operates at the nominal frequency ($f = f_N$ for simplicity

3.2 Share of power variation among the generators



The steady-state characteristics of the various generators can be combined into

$$P_{m} = \sum_{i=1}^{n} P_{mi} = \sum_{i=1}^{n} P_{i}^{0} - \frac{f - f_{N}}{f_{N}} \sum_{i=1}^{n} \frac{P_{Ni}}{\sigma_{i}}$$

Expressing that load is balanced by generation:

$$\sum_{i=1}^{n} P_{i}^{o} - \frac{f - f_{N}}{f_{N}} \sum_{i=1}^{n} \frac{P_{Ni}}{\sigma_{i}} = P_{c}^{o} (1 + D(f - f_{N}))$$

In particular, at the initial operating point: $\sum_{i=1}^{n} P_i^o = P_c^o$

Disturbance: increase ΔP_c of consumption, *the setpoints* P_i^o *being unchanged*

$$\sum_{i=1}^{n} P_{i}^{o} - \frac{f - f_{N}}{f_{N}} \sum_{i=1}^{n} \frac{P_{Ni}}{\sigma_{i}} = P_{c}^{o} \left(1 + D\left(f - f_{N}\right)\right) + \frac{\Delta P_{c}}{\Delta P_{c}}$$

$$\Longrightarrow -\frac{f - f_{N}}{f_{N}} \sum_{i=1}^{n} \frac{P_{Ni}}{\sigma_{i}} = P_{c}^{o} D\left(f - f_{N}\right) + \Delta P_{c}$$

3.2 Share of power variation among the generators



$$\Delta f = f - f_N = -\frac{\Delta P_c}{\beta}$$
 with $\beta = DP_c^o + \frac{1}{f_N} \sum_{i=1}^n \frac{P_{Ni}}{\sigma_i}$

- β is the composite frequency response characteristic (MW/Hz). It characterizes the accuracy of primary frequency control. Also called "network power frequency characteristic" or "stiffness of system"
- Variation of power of j-th generator: $\Delta P_{mj} = -\frac{\Delta f}{f_N} \frac{P_{Nj}}{\sigma_j} = \frac{\Delta P_c}{f_N} \frac{P_{Nj}}{\sigma_j}$
- The steady-state frequency error allows a predictable and adjustable sharing of the power variation over the various (participating) generators
- all speed droops being fixed, the larger the nominal power of a generator, the larger its participation
- all nominal powers being fixed, the smaller the speed droop of a generator, the larger its participation
- the larger the number of generators participating in frequency control, the smaller the frequency deviation

3.2 Primary reserve




- only a fraction of the total number of generators participate in primary frequency control
- to participate, the generator must have a primary reserve, i.e. it must produce less than its maximum power
- this is not desirable:
 - \bullet for generators using a renewable energy source \to Can only provide downward regulation (decrease active power output)
 - for units whose power cannot (easily) be varied: e.g. nuclear units
- primary reserve = service offered by the producer on the corresponding dedicated market
- if it is selected, the generator is paid:
 - for making the reserve available (even if it is not activated)
 - as well as for the activation of the reserve:
 - amount paid to the producer for an increase of power
 - ≠ amount paid to the producer for a decrease of power.

3.2 The "50.2 Hz problem"




- Inverters were set to halt production and disconnect from the grid if the grid frequency drifted above 50.2 Hz
- All were programmed to behave the same way!
 - \bullet collective shutdown would cause many gigawatts of generating capacity to leave the grid at the same time \to lower frequency
 - $\hbox{ Reconnection would cause frequency ramp up} \\ \longrightarrow \hbox{ yo-yo effect}$
- Solution?



3.2 The duck curve





- In 2020 the grid operator were required to spin up 13 gigawatts of production in three hours time – an enormous change in capacity
- Solution?


4 Outline



- Fundamentals
- 2 Inertia response
- 3 Primary frequency control
- Secondary frequency control

4 Frequency services





4 Objectives and principle of secondary frequency control ...



What?


- eliminate the frequency error inherent to primary frequency control
- bring the power exchange between networks to the desired value (contracts)
- restore the generator primary reserves

How?

- Split the interconnected system into multiple areas (corresponding to a country, to the network managed by a transmission operator, etc.)
- gather measurements in each control area:
 - frequency
 - 2 sum of power flows in the tie-lines linking the area to the rest of the system
- sends set-point corrections ΔP_i^o are sent to dedicated generators in each area.

4 Primary frequency control of an interconnection





With the same modelling assumptions:

• generators of network 1:
$$P_{m1} = \sum_{i \in A1} P_i^o - \frac{f - f_N}{f_N} \sum_{i \in A1} \frac{P_{Ni}}{\sigma_i}$$

- load of network 1: $P_{c1} = P_{c1}^o + D_1 P_{c1}^o (f f_N)$
- power balance in network 1: $P_{m1} = P_{c1} + P_{12}$

• generators of network 2:
$$P_{m2} = \sum_{i \in A2} P_i^o - \frac{f - f_N}{f_N} \sum_{i \in A2} \frac{P_{Ni}}{\sigma_i}$$

- load of network 2: $P_{c2} = P_{c2}^o + D_2 P_{c2}^o (f f_N)$
- power balance in network 2: $P_{m2} = P_{c2} + P_{21} = P_{c2} P_{12}$
- power balance of whole system : $P_{m1} + P_{m2} = P_{c1} + P_{c2}$

4 Primary frequency control of an interconnection



Scenario:

- ullet the whole system operates initially at frequency f_N
- the load power in network 1 increases by ΔP_{c1} .

Applying the relations of primary frequency control:

to network 1:
$$-\beta_1 \Delta f = \Delta P_{c1} + \Delta P_{12}$$

to network 2: $-\beta_2 \Delta f = -\Delta P_{12}$


where β_1,β_2 : composite frequency response characteristics of networks 1 and 2

Hence the frequency changes by : $\Delta f = -\frac{\Delta P_{c1}}{\beta_1 + \beta_2}$ the tie-line power changes by:

$$\Delta P_{12} = -\frac{\beta_2}{\beta_1 + \beta_2} \Delta P_{c1} < 0$$

- the power flow from network 1 to network 2 decreases, due to the support provided to network 1 by the generators of network 2
- the larger β_2 with respect to β_1 , the more pronounced this effect.





Control distributed in the various areas:

- measurements from one area gathered by the control center of that area
- no exchange of real-time measurements between areas



Area Control Error (ACE):

in area 1:
$$ACE_1 = P_{12} - P_{12}^o + \lambda_1 (f - f_N) = \Delta P_{12} + \lambda_1 \Delta f$$

in area 2: $ACE_2 = P_{21} - P_{21}^o + \lambda_2 (f - f_N) = -\Delta P_{12} + \lambda_2 \Delta f$
 λ_1, λ_2 : bias factors

Generator power correction (output of Proportional-Integral controller):

in area 1:
$$\Delta P_1^o = -K_{p1}ACE_1 - K_{i1} \int ACE_1 dt \quad K_{i1}, K_{p1} > 0$$

in area 2: $\Delta P_2^o = -K_{p2}ACE_2 - K_{i2} \int ACE_2 dt \quad K_{i2}, K_{p2} > 0$

Distribution over the generators participating in secondary frequency control:

for the *i*-th generator of area 1:
$$P_i^o + \rho_i \Delta P_1^o$$
 with $\sum_i \rho_i = 1$ for the *j*-th generator of area 2: $P_j^0 + \rho_j \Delta P_2^o$ with $\sum_i \rho_j = 1$



When the system comes back to steady state, the integral control imposes:

$$ACE_1 = 0 \Rightarrow \Delta P_{12} + \lambda_1 \Delta f = 0$$

$$ACE_2 = 0 \Rightarrow -\Delta P_{12} + \lambda_2 \Delta f = 0$$

whose solution is: $\Delta f = 0$ and $\Delta P_{12} = 0$

→ both objectives of secondary frequency control are met!

Choosing the bias factors λ_i :

- They do not impact the final system state but the dynamics to reach it
- It is appropriate to choose: $\lambda_1 = \beta_1$ $\lambda_2 = \beta_2$ Indeed, in the above example:

$$ACE_2|_{\lambda_2=\beta_2}=-\Delta P_{12}+\beta_2\Delta f=0\Rightarrow\Delta P_2^0=0$$

no adjustment of the generators in zone 2 ← *that's what we wanted!*

• the more λ_2 differs from β_2 , the more the generators in zone 2 are *uselessly* adjusted by the secondary frequency controller.



Choosing the K_i and K_p gains of the PI controllers:

- They influence the dynamics, in particular the speed of action of secondary frequency control
- secondary frequency control must not act too promptly, in order not interfere with primary frequency control (which is the "first line of defense")
- quite often, $K_p = 0$ (integral control only).

Choosing the participation factors ρ_i :

- ρ_i coefficients: distribute the correction signal ΔP_1^o (or ΔP_2°) on the participating generators, which must have secondary reserve
- for both primary and secondary frequency controls, the power variation that a participating unit commits to provide, in a given time interval, must be compatible with its maximum rate of change:

 \simeq a few % P_N / min for thermal units


 $\simeq P_N$ / min for hydro units

4 Extension to three or more areas



Three-area example:

- 1 wants to sell 1000 MW to 3
- 2 does not want to sell nor to buy power.



Settings of the secondary frequency controllers:

$$P_{12}^{o} + P_{13}^{o} = 1000 \text{MW}$$
 $P_{21}^{o} + P_{23}^{\circ} = 0 \text{MW}$ $P_{31}^{o} + P_{32}^{\circ} = -1000 \text{MW}$

After all secondary frequency controllers have acted:

$$\begin{aligned} ACE_1 &= 0 \Rightarrow (P_{12} + P_{13}) - (P_{12}^{\circ} + P_{13}^{\circ}) + \lambda_1 \Delta f = P_{12} + P_{13} - 1000 + \lambda_1 \Delta f = 0 \\ ACE_2 &= 0 \Rightarrow (P_{21} + P_{23}) - (P_{21}^{\circ} + P_{23}^{0}) + \lambda_2 \Delta f = -P_{12} + P_{23} + \lambda_2 \Delta f = 0 \\ ACE_3 &= 0 \Rightarrow (P_{31} + P_{32}) - (P_{31}^{o} + P_{32}^{o}) + \lambda_3 \Delta f = -P_{13} - P_{23} + 1000 + \lambda_3 \Delta f = 0 \\ &\Rightarrow \Delta f = 0 \qquad P_{12} + P_{13} = 1000 \qquad P_{12} = P_{23} \qquad P_{13} + P_{23} = 1000 \end{aligned}$$

Secondary frequency control does not control individual power flows!