XEN₁₀

device> in family write max10 and in name write name assignments>pinplanner assign pins to leds/switches SW1—8 are 38 to 47 (-42) LED1—8 are 50 to 60 (-51 53 55)

prpcessing>start io analsis' then compile full

tools>assignments>programmer>file>

add files>. add the .sof file

file> create svf file

click on jtag.exe cable ft2232 detect svf <filename>.svf progress

close the terminal

now u can check w xen10 boards:)

SCANCHAIN

scanchainfiles: synthesis ke 2 + toplevel change toplevel and set as toplevelentity compile tools>assignments>programmer>file>create svf file copy this svf file into URvjtag click on jtag.exe cable ft2232 detect svf <filename>.svf progress

close the terminal

copypaste the tracefile.txt in scanchainfiles write cmd in address bar scan_vjtag.exe TRACEFILE.txt output123.txt

name and create output123.