EAE 298 Aeroacoustics, Fall Quarter 2016

Homework #1: Computation of Sound Pressure Level and Octave Band Spectrum for a Sonic Boom using Matlab (Due Date: 10/18/2016)

[Prob. 1, 50 pts] The wav file, 'Boom_F1B2_6.wav', is a recording of a sonic boom. The time history of the pressure is shown in a figure below.



Play the file. You can set up a player object using Matlab audioplayer. Please use a sample code below for audioplayer to play and listen to the sound

% Audioplayer in Matlab fs=44100; pvolts=yy/max(abs(yy)); pvolts=[pvolts]; ppobj=audioplayer(pvolts,fs); play(ppobj);

The values in the wav file are in volts. B&K measurement microphones invert the pressure – a negative voltage from the microphone corresponds to a positive pressure. When you apply the calibration constant, account for this sign reversal. For this problem, the pre-calculated constant calibration factor is – 116 pascals/volt. Convert the time series in voltage to pascals. (Assume that all of the power in the boom waveform is within the range of flat response of the microphone).

- 1. Plot the waveform in pascals as a function of time. What is the peak pressure in the time domain? Notice the shape of the first arrival it has the classic "N" wave shape of a sonic boom. Notice the duration in time from the positive-pressure peak to the negative-pressure peak. [10 pts]
- 2. Calculate and plot the single-sided power spectral density function (G_{xx}). Use a single record for the boom waveform (and don't bother using a window there isn't much power at either end of the waveform). [30 pts]
- In acoustics it is common (for better or worse) to convert levels to decibels. Convert and plot the standard narrowband sound pressure level with the reference pressure of 20 micro-Pascal. [10 pts]

[Prob. 2, 50 Pts] Write a computer program to convert the narrow band spectra to one-third octave and octave band spectra.

- 1. Convert the narrowband spectrum to one-third octave band spectrum and make a plot [20 pts]
- 2. Convert the one-third octave band spectrum to octave band spectrum and make a plot [20 pts]
- 3. Convert the octave band spectrum to the overall sound pressure level [10 pts]

Please submit the report and upload the source codes on Canvas.