Experiment Name: DC Motor Speed Control Using PWM and Microcontroller.

<u>PWM:</u> PWM stands for Pulse Width Modulation. A modulation technique that generates variablewidth pulses to represent the amplitude of an analog input signal.


To understand PWM as a type of signal which can be produced from a digital IC such as microcontroller or 555 timer. The signal thus produced will have a train of pulses and these pulses will be in form of a square wave. That is, at any given instance of time the wave will either be high or will be low. For the ease of understanding let us consider a 5V PWM signal, in this case the PWM signal will either be 5V (high) or at ground level 0V (low). The duration at which the signals stays high is called the "on time" and the duration at which the signal stays low is called as the "off time".

Duty cycle of the PWM:

As told earlier, a PWM signal stays on for a particular time and then stays off for the rest of the period. The percentage of time in which the PWM signal remains HIGH (on time) is called as duty cycle. If the signal is always ON it is in 100% duty cycle and if it is always off it is 0% duty cycle. The formulae to calculate the duty cycle is shown below.

Duty Cycle =Turn ON time/ (Turn ON time + Turn OFF time)

The following image represents a PWM signal with 50% duty cycle. As you can see, considering an entire time period (on time + off time) the PWM signal stays on only for 50% of the time period.



By controlling the Duty cycle from 0% to 100% we can control the "on time" of PWM signal and thus the width of signal. Since we can modulate the width of the pulse, it got its iconic name "Pulse width Modulation"

Frequency of a PWM:

The frequency of a PWM signal determines how fast a PWM completes one period. One Period is the complete ON and OFF time of a PWM signal as shown in the above figure. The formulae to calculate the Frequency is given below

Frequency = 1/Time Period Time Period = On time + Off time

Normally the PWM signals generated by microcontroller will be around 500 Hz, such high frequencies will be used in high speed switching devices like inverters or converters. But not all applications require high frequency. For example to control a servo motor we need to produce PWM signals with 50Hz frequency, so the frequency of a PWM signal is also controllable by program for all microcontrollers.

Features of L293D:

- Wide Supply-Voltage Range: 4.5 V to 36 V
- Separate Input-Logic Supply
- Internal ESD Protection
- High-Noise-Immunity Inputs
- Output Current 1 A Per Channel (600 mA for L293D)

- Peak Output Current 2 A Per Channel (1.2 A for L293D)
- Output Clamp Diodes for Inductive Transient Suppression (L293D)

The Pin diagram of the L293D is given below:





Figure: Pin diagram of L293D

Circuit Diagram:



```
Miller Code
was maini
direct duty = 0, l'initial value for duty
TRINID = No. 19. (POJRTID as imput
TRUE = Udity / PORTE as subject
Than motor in antichesk wise
THE STEELER
PLANTS ET STANTE
PWW0_init(M00); //initialize PWW0
PWMI Start(): //start PWMI
PWW) Set Dury(buty): /Set cuttent buty for PWW.
white (f) // endless loop
 if (ROV) bit && duty (250) (if button on ROV presser
   Dear no M:
   TOO bit && day (250)
      duty = duty + Mt; //increment current_duty
      PWW) Set Duny(buty): (Change the buty cycle
  if (RD) hit && duty >1) fourtin in RD pressed
   Dear ms III:
   音(RDI_bit&&dimy>0)
     duty = duty - Mr. //decrement duty
     PWWI Set Duty buty t
```

I show down change pace a little

Dear no 10: