## **Embedded Systems**

Week 5


## Serial Buses in our project

 UART serial bus for sending debug messages to your development host


• I2C serial bus for communicating with sensors (e.g., the accelerometer)


 SPI serial bus for communicating with the Bluetooth Low Energy radio

#### Serial Interfaces




#### Parallel Bus VS Serial Bus





# Simplistic View of Serial Port Operation Transmitter Receiver



Interrupt raised when Transmitter (Tx) is empty

⇒ Byte has been transmitted and next byte ready for loading

Interrupt raised when Receiver (Rx) is full

⇒ Byte has been received and is ready for reading

#### Serial Bus Interface Motivations

#### Motivation

- Without using a lot of I/O lines
  - I/O lines require I/O pads which cost \$\$\$ and size
  - I/O lines require PCB area which costs \$\$\$ and size
- Connect different systems together
  - Two embedded systems
  - A desktop and an embedded system
- Connect different chips together in the same embedded system
  - MCU to peripheral
  - MCU to MCU
- Often at relatively low data rates
- But sometimes at higher data rates
- So, what are our options?
  - Universal Synchronous/Asynchronous Receiver Transmitter
  - Also known as USART (pronounced: "you-sart")

## Serial Bus Design Space

- Number of wires required?
- Asynchronous or synchronous?
- How fast can it transfer data?
- Can it support more than two endpoints?
- Can it support more than one master (i.e. txn initiator)?
- How do we support flow control?
- How does it handle errors/noise?
- How far can signals travel?

## Serial Bus Examples

	S/A	Туре	Duplex	#Device s	Speed (kbps)	Distanc e (ft)	Wires
RS232	А	Peer	Full	2	20	30	2+
RS422	Α	Multi- drop	Half	10	10000	4000	1+
RS485	А	Multi- point	Half	32	10000	4000	2
I2C	S	Multi- master	Half	Ś	3400	<10	2
SPI	S	Multi- master	Full	?	>1000	<10	3+
Microwi re	S	Master/ slave	Full	?	>625	<10	3+
1-Wire	Α	Master/ slave	half	?	16	1000	1+

#### **UART Uses**

- PC serial port is a UART!
- Serializes data to be sent over serial cable
  - De-serializes received data



#### **UART Uses**

Used to be commonly used for internet access



#### **UART**

- Universal Asynchronous Receiver/Transmitter
- Hardware that translates between parallel and serial forms
- Commonly used in conjunction with communication standards such as EIA, RS-232, RS-422 or RS-485

#### Protocol

- Each character is sent as
  - a logic low start bit
  - a configurable number of data bits (usually 7 or 8, sometimes 5)
  - an optional parity bit
  - one or more logic high stop bits
  - with a particular bit timing ("baud")


Start	Data 0 1	Data Data 2 3	Data Dat	a Data 6	Data 7	Stop
-------	-------------	------------------	----------	-------------	-----------	------

## **UART Example**

Send the ASCII letter 'W' (1010111)




#### **UART Hardware Connection**









- Receiver also verifies that stop bit is '1'
  - If not, reports "framing error" to host system

- New start bit can appear immediately after stop bit
  - Receiver will resynchronize on each start bit

## Let us design a UART transmitter



## Transmitter/System Handshaking

- System asserts Send and holds it high when it wants to send a byte
- UART asserts Busy signal in response
- When UART has finished transfer, UART deasserts Busy signal
- System de-asserts Send signal



## Transmitter Block Diagram



## **Discussion Questions**


- How fast can we run a UART?
- What are the limitations?
- Why do we need start/stop bits?
- How many data bits can be sent?
  - 19200 baud rate, no parity, 8 data bits, 1 stop bit

## Serial Peripheral Interconnect (SPI)

- Another kind of serial protocol in embedded systems (proposed by Motorola)
- Four-wire protocol
  - SCLK Serial Clock
  - MOSI/SIMO Master Output, Slave Input
  - MISO/SOMI Master Input, Slave Output
  - SS Slave Select
- Single master device and with one or more slave devices
- Higher throughput than I2C and can do "stream transfers"
- No arbitration required
- But
  - Requires more pins
  - Has no hardware flow control
  - No slave acknowledgment (master could be talking to thin air and not even know it)

### What is SPI?

- Serial Bus protocol
- Fast, Easy to use, Simple
- Everyone supports it



#### **SPI Basics**

- A communication protocol using 4 wires
  - Also known as a 4 wire bus
- Used to communicate across small distances

Multiple Slaves, Single Master


Synchronized

## **SPI Capabilities**

- Always Full Duplex
  - Communicating in two directions at the same time
  - Transmission need not be meaningful
- Multiple Mbps transmission speed
- Transfers data in 4 to 16 bit characters
- Multiple slaves
  - Daisy-chaining possible

#### **SPI Protocol**


- Wires:
  - Master Out Slave In (MOSI)
  - Master In Slave Out (MISO)
  - System Clock (SCLK)
  - Slave Select 1...N
- Master Set Slave Select low
- Master Generates Clock
- Shift registers shift in and out data




#### **SPI** Wires in Detail

MOSI – Carries data out of Master to Slave

- MISO Carries data from Slave to Master
  - Both signals happen for every transmission
- SS\_BAR Unique line to select a slave
- SCLK Master produced clock to synchronize data transfer




# SPI uses a "shift register" model of communications



Master shifts out data to Slave, and shifts in data from Slave http://upload.wikimedia.org/wikipedia/commons/thumb/b/bb/SPI 8-bit circular transfer.svg/400px-SPI 8-bit circular transfer.svg/400px-SPI 8-bit circular transfer.svg.png

#### **SPI Communication**






## SPI clocking: there is no "standard way"

- Four clocking "modes"
  - Two phases
  - Two polarities
- Master and selected slave must be in the same mode
- During transfers with slaves A and B, Master must
  - Configure clock to Slave A's clock mode
  - Select Slave A
  - Do transfer
  - Deselect Slave A
  - Configure clock to Slave B's clock mode
  - Select Slave B
  - Do transfer
  - Deselect Slave B
- Master reconfigures clock mode on-the-fly!

# SPI timing diagram



Timing Diagram – Showing Clock polarities and phases http://www.maxim-ic.com.cn/images/appnotes/3078/3078Fig02.gif

#### **SPI Pros and Cons**

#### • Pros:

- Fast and easy
  - Fast for point-to-point connections
  - Easily allows streaming/Constant data inflow
  - No addressing/Simple to implement
- Everyone supports it


#### • Cons:

- SS makes multiple slaves very complicated
- No acknowledgement ability
- No inherent arbitration
- No flow control

## 12C bus in our projects

- Communication with the accelerometer
  - Read from the accelerometer
- Pros
  - Simple wire connection
  - Two wires bus that can connect multiple peripherals with the MCU
- Cons
  - Complexity is significantly higher

## How to operate the camera?




https://www.youtube.com/watch?v=eqZgxR6eRjo

#### **12C** Details

- Two lines
  - Serial data line (SDA)
  - Serial clock line (SCL)

Only two wires for connecting multiple

devices




#### **12C** Details

- Each I2C device recognized by a unique address
- Each I2C device can be either a transmitter or receiver
- I2C devices can be masters or slaves for a data transfer
  - Master (usually a microcontroller): Initiates a data transfer on the bus, generates the clock signals to permit that transfer, and terminates the transfer
  - Slave: Any device addressed by the master at that time


#### Bit Transfer on the I<sup>2</sup>C Bus

 In normal data transfer, the data line only changes state when the clock is low



## Start and Stop Conditions


- A transition of the data line while the clock line is high is defined as either a start or a stop condition.
- Both start and stop conditions are generated by the bus master
- The bus is considered busy after a start condition, until a stop condition occurs



## I<sup>2</sup>C Addressing

- Each node has a unique 7 (or 10) bit address
- Peripherals often have fixed and programmable address portions
- Addresses starting with 0000 or 1111 have special functions:-
  - 0000000 Is a General Call Address
  - 0000001 Is a Null (CBUS) Address
  - 1111XXX Address Extension
  - 1111111 Address Extension Next Bytes are the Actual Address

## **I2C-Connected System**




Example I2C-connected system with two microcontrollers


(Source: I2C Specification, Philips)

## Master-Slave Relationships

- Who is the master?
  - master-transmitters
  - master-receivers
- Suppose microcontroller A wants to send information to microcontroller B
  - A (master) addresses B (slave)
  - A (master-transmitter), sends data to B (slave-receiver)
  - A terminates the transfer.
- If microcontroller A wants to receive information from microcontroller B
  - A (master) addresses microcontroller B (slave)
  - A (master-receiver) receives data from B (slave-transmitter)
  - A terminates the transfer
- In both cases, the master (microcontroller A) generates the timing and terminates the transfer

#### Exercise: How fast can I2C run?





- How fast can you run it?
- Assumptions
  - 0's are driven
  - 1's are "pulled up"
- Some working figures
  - $R_p = 10 k\Omega$
  - $C_{cap} = 100 pF$
  - $V_{DD} = 5 V$
  - $V_{in\_high} = 3.5 \text{ V}$
- Recall for RC circuit
  - $V_{cap}(t) = V_{DD}(1-e^{-t/\tau})$
  - Where  $\tau = RC$

#### Exercise: Bus bit rate vs Useful data rate

- An I2C "transactions" involves the following bits
  - <S><A6:A0><R/W><A><D7:D0><A><F>
- Which of these actually carries useful data?
  - <S><A6:A0><R/W><A><D7:D0><A><F>
- So, if a bus runs at 400 kHz
  - What is the clock period?
  - What is the data throughput (i.e. data-bits/second)?
  - What is the bus "efficiency"?