```
char val; // Variable to store the data received from the serial port
int ledPin = 13; // LED Pin of Arduino
// The setup function runs once when you press reset or power the board:
void setup()
pinMode(ledPin, OUTPUT); // Set pin 13 (RED-LED) as output
Serial.begin(9600); // Start serial communications at 9,600 bits per second
// The loop function runs over and over again forever:
void loop()
 if (Serial.available())
   // ID data is available to read now:
   val = Serial.read(); // Read the value and store it in a variable "val"
 if (val == '0')
   digitalWrite(ledPin, LOW); // Turn OFF Arduino Led
 else
   digitalWrite(ledPin, HIGH); // Turn ON Arduino Led
 delay(10); // Delay in between reads for stability
```