

#### COMPUTER ORGANIZATION AND DESIGN

The Hardware/Software Interface



# **Chapter 1**

# Computer Abstractions and Technology

### **The Computer Revolution**

- Progress in computer technology
  - Underpinned by <u>Moore's Law</u>
- Makes novel applications feasible
  - Computers in automobiles
  - Cell phones
  - Human genome project
  - World Wide Web
  - Search Engines
- Computers are pervasive



## **Classes of Computers**

- Personal computers
  - General purpose, variety of software
  - Subject to cost/performance tradeoff
- Server computers
  - Network based
  - High capacity, performance, reliability
  - Range from small servers to building sized

## **Classes of Computers**

- Supercomputers
  - High-end scientific and engineering calculations
  - Highest capability but represent a small fraction of the overall computer market
- Embedded computers
  - Hidden as components of systems
  - Stringent power/performance/cost constraints

#### The PostPC Era

- Personal Mobile Device (PMD)
  - Battery operated
  - Connects to the Internet
  - Hundreds of dollars
  - Smart phones, tablets, electronic glasses
- Cloud computing
  - Warehouse Scale Computers (WSC)
  - Software as a Service (SaaS)
  - Portion of software run on a PMD and a portion run in the Cloud
  - Amazon and Google



#### What You Will Learn

- How programs are translated into the machine language
  - And how the hardware executes them
- The hardware/software interface
- What determines program performance
  - And how it can be improved
- How hardware designers improve performance
- What is parallel processing



# **Understanding Performance**

- Algorithm
  - Determines number of operations executed
- Programming language, compiler, architecture
  - Determine number of machine instructions executed per operation
- Processor and memory system
  - Determine how fast instructions are executed
- I/O system (including OS)
  - Determines how fast I/O operations are executed



# **Levels of Program Code**

- High-level language
  - Level of abstraction closer to problem domain
  - Provides for productivity and portability
- Assembly language
  - Textual representation of instructions
- Hardware representation
  - Binary digits (bits)
  - Encoded instructions and data

High-level language program (in C)

Assembly language program (for MIPS)

```
swap(int v[], int k)
{int temp;
    temp = v[k];
    v[k] = v[k+1];
    v[k+1] = temp;
}

Compiler


swap:
    muli $2, $5,4
    add $2, $4,$2
```

\$15, 0(\$2)

\$16, 4(\$2) \$16, 0(\$2)

\$15. 4(\$2)


\$31




Binary machine language program (for MIPS) 

## Components of a Computer

#### **The BIG Picture**







- Same components for all kinds of computer
  - Desktop, server, embedded
- Input/output includes
  - User-interface devices
    - Display, keyboard, mouse
  - Storage devices
    - Hard disk, CD/DVD, flash
  - Network adapters
    - For communicating with other computers



## Inside the Processor (CPU)

- Datapath: performs operations on data
- Control: sequences datapath, memory, ...
- Cache memory
  - Small fast SRAM memory for immediate access to data

#### Response Time and Throughput

- Response time
  - How long it takes to do a task
- Throughput
  - Total work done per unit time
    - e.g., tasks/transactions/... per hour
- How are response time and throughput affected by
  - Replacing the processor with a faster version?
  - Adding more processors?
- We'll focus on response time for now...

#### **Relative Performance**

- Define Performance = 1/Execution Time
- "X is n time faster than Y"

Performance<sub>x</sub>/Performance<sub>y</sub>

- = Execution time $_{Y}$  /Execution time $_{X} = n$
- Example: time taken to run a program
  - 10s on A, 15s on B
  - Execution Time<sub>B</sub> / Execution Time<sub>A</sub>
     = 15s / 10s = 1.5
  - So A is 1.5 times faster than B



## **Measuring Execution Time**

- Elapsed time
  - Total response time, including all aspects
    - Processing, I/O, OS overhead, idle time
  - Determines system performance
- CPU time
  - Time spent processing a given job
    - Discounts I/O time, other jobs' shares
  - Comprises user CPU time and system CPU time
  - Different programs are affected differently by CPU and system performance



## **CPU Clocking**

- Operation of digital hardware governed by a constant-rate clock
- Clock period: duration of a clock cycle
  - e.g.,  $250ps = 0.25ns = 250 \times 10^{-12}s$
- Clock frequency (rate): cycles per second
  - e.g.,  $4.0GHz = 4000MHz = 4.0 \times 10^9Hz$

#### **CPU Time**

CPU Time = CPU Clock Cycles × Clock Cycle Time

= CPU Clock Cycles

Clock Rate

- Performance improved by
  - Reducing number of clock cycles
  - Increasing clock rate
  - Hardware designer must often trade off clock rate against cycle count

#### **CPU Time Example**

- Computer A: 2GHz clock, 10s CPU time
- Designing Computer B
  - Aim for 6s CPU time
  - Can do faster clock, but causes 1.2 x clock cycles
- How fast must Computer B clock be?

$$Clock Rate_{B} = \frac{Clock Cycles_{B}}{CPU Time_{B}} = \frac{1.2 \times Clock Cycles_{A}}{6s}$$

$$Clock\ Cycles_A = CPU\ Time_A \times Clock\ Rate_A$$

$$= 10s \times 2GHz = 20 \times 10^9$$

Clock Rate<sub>B</sub> = 
$$\frac{1.2 \times 20 \times 10^9}{6s} = \frac{24 \times 10^9}{6s} = 4GHz$$



#### Instruction Count and CPI

Clock Cycles = Instruction Count × Cycles per Instruction

CPU Time = Instruction Count × CPI × Clock Cycle Time

$$= \frac{Instruction Count \times CPI}{Clock Rate}$$

- Instruction Count for a program
  - Determined by program, ISA and compiler
- Average cycles per instruction
  - Determined by CPU hardware
  - If different instructions have different CPI
    - Average CPI affected by instruction mix



#### **CPI Example**

- Computer A: Cycle Time = 250ps, CPI = 2.0
- Computer B: Cycle Time = 500ps, CPI = 1.2
- Same ISA
- Which is faster, and by how much?

$$\begin{aligned} \text{CPUTime}_{A} &= \text{Instruction Count} \times \text{CPI}_{A} \times \text{Cycle Time}_{A} \\ &= I \times 2.0 \times 250 \text{ps} = I \times 500 \text{ps} & \text{A is faster...} \end{aligned}$$
 
$$\begin{aligned} \text{CPUTime}_{B} &= \text{Instruction Count} \times \text{CPI}_{B} \times \text{Cycle Time}_{B} \\ &= I \times 1.2 \times 500 \text{ps} = I \times 600 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 1.2 \times 500 \text{ps} \\ &= I \times 500 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 600 \text{ps} \\ &= I \times 500 \text{ps} \end{aligned}$$
 ...by this much

#### **CPI in More Detail**

 If different instruction classes take different numbers of cycles

Clock Cycles = 
$$\sum_{i=1}^{n} (CPI_i \times Instruction Count_i)$$

Weighted average CPI

$$CPI = \frac{Clock \ Cycles}{Instruction \ Count} = \sum_{i=1}^{n} \left( CPI_i \times \frac{Instruction \ Count_i}{Instruction \ Count} \right)$$

Relative frequency

## **CPI Example**

 Alternative compiled code sequences using instructions in classes A, B, C

Class	А	В	С
CPI for class	1	2	3
IC in sequence 1	2	1	2
IC in sequence 2	4	1	1

- Sequence 1: IC = 5
  - Clock Cycles= 2x1 + 1x2 + 2x3= 10
  - Avg. CPI = 10/5 = 2.0

- Sequence 2: IC = 6
  - Clock Cycles= 4×1 + 1×2 + 1×3= 9
  - Avg. CPI = 9/6 = 1.5

### **Performance Summary**

#### **The BIG Picture**

$$CPUTime = \frac{Instructions}{Program} \times \frac{Clock\ cycles}{Instruction} \times \frac{Seconds}{Clock\ cycle}$$

- Performance depends on
  - Algorithm: affects IC, possibly CPI
  - Programming language: affects IC, CPI
  - Compiler: affects IC, CPI
  - Instruction set architecture: affects IC, CPI, T<sub>c</sub>



#### Pitfall: Amdahl's Law

 Improving an aspect of a computer and expecting a proportional improvement in overall performance

$$T_{\text{improved}} = \frac{T_{\text{affected}}}{\text{improvement factor}} + T_{\text{unaffected}}$$

- Example: multiply accounts for 80s/100s
  - How much improvement in multiply performance to get 5x overall?

$$20 = \frac{80}{n} + 20$$
 • Can't be done!

Corollary: make the common case fast



#### Pitfall: MIPS as a Performance Metric

- MIPS: Millions of Instructions Per Second
  - Doesn't account for
    - Differences in ISAs between computers
    - Differences in complexity between instructions

$$\begin{split} \text{MIPS} &= \frac{Instruction \, count}{Execution \, time \times 10^6} \\ &= \frac{Instruction \, count}{\frac{Instruction \, count \times CPI}{Clock \, rate}} = \frac{Clock \, rate}{CPI \times 10^6} \end{split}$$

CPI varies between programs on a given CPU



## **Concluding Remarks**

- Cost/performance is improving
  - Due to underlying technology development
- Hierarchical layers of abstraction
  - In both hardware and software
- Instruction set architecture
  - The hardware/software interface
- Execution time: the best performance measure
- Power is a limiting factor
  - Use parallelism to improve performance



#### **Sections to Read from the Book**

- 5<sup>th</sup> Edition sections to read
  - **1.1**
  - **1.3**
  - **1.4**
  - **1.6**
  - **1.10**
  - **1.11**