



LVDS (Tx/Rx) Design With 5V Devices in Sky130nm Process

Nov, 2023
Revision 0.0

PO Box 9276
San Jose, CA 95157
www.lewiz.com
Email: support@lewiz.com

Transceiver Netlist

```
** sch_path: /home/saumeeek/xschem_test/Transciever_Netlist.sch
**.subckt Transciever_Netlist Vinp Vinn Vout VCC INN INP BGR Vref Vss
VCC_1v8 Vinplv8 Vinnlv8

*.ipin Vinp
*.ipin Vinn
*.opin Vout
*.iopin VCC
*.opin INN
*.opin INP
*.ipin BGR
*.ipin Vref
*.iopin Vss
*.iopin VCC_1v8
*.ipin Vinplv8
*.ipin Vinnlv8

XM1 OP B Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=30 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM2 B B Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=30 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM3 ON B Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=30 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM9 OP A VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
```

```

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM10 A A VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM11 ON A VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

I0_ref VCC net1 500u

I1_ref VCC net2 500u

R3 C B 0.5k m=1

R4 A C 0.5k m=1

R5 OP INP 0.5k m=1

R6 ON INN 0.5k m=1

XM7 C C Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=2.5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM4 Vss OP net1 VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM5 C net3 net1 VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

```

```

XM6 C net3 net2 VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM8 Vss ON net2 VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

V1 net3 Vss 2.5

.save i(v1)

XM12 BGR BGR Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM13 net4 BGR Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM14 F F Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM15 net7 F Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM16 N1 net8 Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

```

```

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM17 net8 net8 Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'

+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM18 net4 net4 VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'

+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM19 net6 net4 VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=50 nf=2
ad='int((nf+1)/2) * W/nf * 0.29'

+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM20 net7 net7 VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'

+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM21 N1 net7 VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM22 H net5 VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=67 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM23 net5 net5 VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=67 nf=2
ad='int((nf+1)/2) * W/nf * 0.29'

```

```

+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM24 E E VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM25 N1 E VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=67 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM26 net8 OP net6 VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=50 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM27 F ON net6 VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=50 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM28 net5 ON D Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM29 E OP D Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM30 Vinv N1 VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=30 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

```

```

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM31 Vinv N1 Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=35 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM32 Vout Vinv VCC VCC sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=50 nf=2
ad='int((nf+1)/2) * W/nf * 0.29'

+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM33 Vout Vinv Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'

+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM34 D BGR Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=83 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM35 H H Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=83 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM36 N1 H Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=83 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

x1 VCC_1v8 Vss VCC Vinn1v8 Vinp1v8 Vref BGR Vinp Vinn INP INN
OutputDriverNetlist_5v

```

```

**.ends

* expanding    symbol: OutputDriverNetlist_5v.sym # of pins=11
** sym_path: /home/saumeek/xschem_test/OutputDriverNetlist_5v.sym
** sch_path: /home/saumeek/xschem_test/OutputDriverNetlist_5v.sch
.subckt OutputDriverNetlist_5v VCC_1v8 Vss VCC5 Vinn1v8 Vinp1v8 Vref
BGR Vinp Vinn Vop Von

*.ipin Vinp
*.ipin Vinn
*.opin Vop
*.opin Von
*.iopin VCC5
*.iopin Vss
*.iopin VCC_1v8
*.ipin BGR
*.ipin Vref
*.ipin Vinp1v8
*.ipin Vinn1v8

R1 Vcm Vop 1.5k m=1
R2 Von Vcm 1.5k m=1
C5 C Vss 1p m=1
C6 net5 Vss 1p m=1
R11 Vcm net5 100 m=1

XM27 net6 H Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=25 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM8 net1 H Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=25 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

```

```

+ sa=0 sb=0 sd=0 mult=1 m=1

XM25 Vop pu net6 Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM7 Von pd net1 Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=15 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM6 B C Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=80 nf=6
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM11 H H Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=88 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM13 C C Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=68 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM15 K Vcm F Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=50 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM19 F BGR Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=55 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

```

```

+ sa=0 sb=0 sd=0 mult=1 m=1

XM16 E Vref F Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=50 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM23 net3 BGR Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM24 D BGR Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=20 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM26 BGR BGR Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=5.88 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM21 D net3 net4 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM20 net4 D VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=30 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM22 net3 net3 VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'
```

```

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM17 E E VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=50 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM18 K K VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=50 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM14 C K VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=68 nf=3
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM12 H D VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=85 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM1 Vop Vinn5 A VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=50 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM4 Von Vinp5 A VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=50 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM3 B Vinn5 Von VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=40 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

```

```

+ sa=0 sb=0 sd=0 mult=1 m=1

XM2 B Vinp5 Vop VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=40 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM5 A E VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=80 nf=6
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM10 net2 D VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM9 Vop pu net2 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=30 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM28 Von pd net7 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=30 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM29 net7 D VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

x2 pd pu dnl dpl Vinp1v8 Vinn1v8 VCC_1v8 Vss VCC5
LevelShifterNetlist_5v

x3 Vinp5 Vss VCC5 Vinn1_5Netlist

x1 Vinn5 Vss VCC5 Vinp_5Netlist

```

```

.ends

* expanding symbol: LevelShifterNetlist_5v.sym # of pins=9
** sym_path: /home/saumeeek/xschem_test/LevelShifterNetlist_5v.sym
** sch_path: /home/saumeeek/xschem_test/LevelShifterNetlist_5v.sch
.subckt LevelShifterNetlist_5v Dn_H Dp_H Dn_L Dp_L vinp vinn VCC_1v8
VSS VCC5

*.opin Dp_H
*.opin Dn_H
*.ipin vinp
*.ipin vinn
*.opin Dp_L
*.opin Dn_L
*.iopin VCC5
*.iopin VSS
*.iopin VCC_1v8

XM1 Dn_H Dp_H VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=15 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM2 Dp_H Dn_H VCC5 VCC5 sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=15 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM5 Dn_H Dp_L VSS VSS sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=50 nf=10
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

```

```

XM3 Dp_H Dn_L VSS VSS sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=50 nf=10
ad='int((nf+1)/2) * W/nf * 0.29'

+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

x2 Dp_L VSS VCC_1v8 VCC5 vinp PreEmphasisDriverNetlist_1v8_3v3
x3 Dn_L VSS VCC_1v8 VCC5 vinn PreEmphasisDriverNetlist_1v8_3v3
.ends

```

```

* expanding symbol: Vinn1_5Netlist.sym # of pins=3
** sym_path: /home/saumeeek/xschem_test/Vinn1_5Netlist.sym
** sch_path: /home/saumeeek/xschem_test/Vinn1_5Netlist.sch
.subckt Vinn1_5Netlist Vinn VSS VCC5

*.opin Vinn
*.iopin VCC5
*.iopin VSS

x3 net2 net3 VCC5 VSS inv_0_5_3v3
x1 Vinn net1 VCC5 VSS inv_0_5_3v3
x5 net5 net4 VCC5 VSS inv_0_5_3v3
x8 net1 net2 VCC5 VSS inv_1_5_3v3
x2 net3 net5 VCC5 VSS inv_1_5_3v3
x7 net4 Vinn VCC5 VSS inv_0_5_3v3
.ends

```

```

* expanding symbol: Vinp_5Netlist.sym # of pins=3
** sym_path: /home/saumeeek/xschem_test/Vinp_5Netlist.sym
** sch_path: /home/saumeeek/xschem_test/Vinp_5Netlist.sch
.subckt Vinp_5Netlist Vinp VSS VCC5

*.opin Vinp

```

```

*.iopin VCC5
*.iopin VSS
x9 Vinp net1 VCC5 VSS inv_0_5_3v3
x1 net4 net2 VCC5 VSS inv_0_5_3v3
x5 net5 net3 VCC5 VSS inv_0_5_3v3
x7 net1 net4 VCC5 VSS inv_1_5_3v3
x2 net2 net5 VCC5 VSS inv_1_5_3v3
x6 net3 Vinp VCC5 VSS inv_0_5_3v3
.ends

* expanding symbol: PreEmphasisDriverNetlist_1v8_3v3.sym # of
pins=5
** sym_path:
/home/saumeek/xschem_test/PreEmphasisDriverNetlist_1v8_3v3.sym
** sch_path:
/home/saumeek/xschem_test/PreEmphasisDriverNetlist_1v8_3v3.sch
.subckt PreEmphasisDriverNetlist_1v8_3v3 dn VSS Vcc VCC5 DpH
*.ipin DpH
*.opin dn
*.iopin VSS
*.iopin Vcc
*.iopin VCC5
x1 VSS DpH xor_out Buf_out Vcc xor
x10 Vcc DpH xor_out net2 VSS and
x2 VSS net1 Buf_out Vcc buf2
x3 VSS DpH net1 Vcc buf1
x6 VSS net2 dn VCC5 buf2_3v3
.ends

```

```

* expanding symbol:
/home/saumeeek/simulation_library/inv_0_5_3v3.sym # of pins=4
** sym_path: /home/saumeeek/simulation_library/inv_0_5_3v3.sym
** sch_path: /home/saumeeek/simulation_library/inv_0_5_3v3.sch
.subckt inv_0_5_3v3 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss

XM3 Vout Vin Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM1 Vout Vin Vcc Vcc sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=20 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

.ends

```

```

* expanding symbol:
/home/saumeeek/simulation_library/inv_1_5_3v3.sym # of pins=4
** sym_path: /home/saumeeek/simulation_library/inv_1_5_3v3.sym
** sch_path: /home/saumeeek/simulation_library/inv_1_5_3v3.sch
.subckt inv_1_5_3v3 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss

XM3 Vout Vin Vcc Vcc sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=80 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

```

```

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM4 Vout Vin Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

.ends

* expanding symbol: /home/saumeeek/simulation_library/xor.sym # of
pins=5

** sym_path: /home/saumeeek/simulation_library/xor.sym
** sch_path: /home/saumeeek/simulation_library/xor.sch

.subckt xor Vss A Vo B Vcc

*.iopin Vcc
*.iopin Vss
*.ipin A
*.opin Vo
*.ipin B

XM1 net3 Ab Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.15 W=35 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM2 net4 A Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.15 W=35 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM3 Vo Ab net1 Vss Vss sky130_fd_pr_nfet_01v8 L=0.15 W=17 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

```

```

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM4 net1 Bb Vss Vss sky130_fd_pr_nfet_01v8 L=0.15 W=17 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM5 Vo A net2 Vss Vss sky130_fd_pr_nfet_01v8 L=0.15 W=17 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM6 net2 B Vss Vss sky130_fd_pr_nfet_01v8 L=0.15 W=17 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

x1 A Ab Vcc Vss inv111

x2 B Bb Vcc Vss inv111

XM7 Vo B net3 Vcc sky130_fd_pr_pfet_01v8 L=0.15 W=35 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM8 Vo Bb net4 Vcc sky130_fd_pr_pfet_01v8 L=0.15 W=35 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'

+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

.ends

```

* expanding symbol: /home/saumeeek/simulation_library/and.sym # of pins=5

```

** sym_path: /home/saumeeek/simulation_library/and.sym
** sch_path: /home/saumeeek/simulation_library/and.sch
.subckt and Vcc B A C VSS
*.opin C
*.iopin Vcc
*.iopin VSS
*.ipin A
*.ipin B

XM1 net1 A Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.15 W=45 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM2 net1 B Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.15 W=45 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM3 net1 A net2 VSS sky130_fd_pr_nfet_01v8 L=0.15 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM4 net2 B VSS VSS sky130_fd_pr_nfet_01v8 L=0.15 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM5 C net1 Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.15 W=65 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

```

```

XM6 C net1 VSS VSS sky130_fd_pr_nfet_01v8 L=0.15 W=25 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
.ends

```

```

* expanding symbol: buf2.sym # of pins=4
** sym_path: /home/saumeeek/xschem_test/buf2.sym
** sch_path: /home/saumeeek/xschem_test/buf2.sch
.subckt buf2 Vss Vin Buf_out Vcc
*.iopin Vcc
*.iopin Vss
*.ipin Vin
*.opin Buf_out
x1 Vin net1 Vcc Vss inv2
x2 net1 Buf_out Vcc Vss inv22
.ends

```

```

* expanding symbol: buf1.sym # of pins=4
** sym_path: /home/saumeeek/xschem_test/buf1.sym
** sch_path: /home/saumeeek/xschem_test/buf1.sch
.subckt buf1 Vss Vin Buf_out Vcc
*.iopin Vcc
*.iopin Vss
*.ipin Vin
*.opin Buf_out
x1 Vin net1 Vcc Vss inv1
x2 net1 Buf_out Vcc Vss inv11

```

```

.ends

* expanding symbol: buf2_3v3.sym # of pins=4
** sym_path: /home/saumeeek/xschem_test/buf2_3v3.sym
** sch_path: /home/saumeeek/xschem_test/buf2_3v3.sch
.subckt buf2_3v3 Vss Vin Buf_out Vcc
*.iopin Vcc
*.iopin Vss
*.ipin Vin
*.opin Buf_out
x1 Vin net1 Vcc Vss inv2_3v3
x3 net1 Buf_out Vcc Vss inv22_3v3
.ends

* expanding symbol: /home/saumeeek/simulation_library/inv111.sym #
of pins=4
** sym_path: /home/saumeeek/simulation_library/inv111.sym
** sch_path: /home/saumeeek/simulation_library/inv111.sch
.subckt inv111 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM2 Vout Vin Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.15 W=6 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

```

```

XM1 Vout Vin Vss Vss sky130_fd_pr_nfet_01v8 L=0.15 W=3 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
.ends

* expanding symbol: /home/saumeeek/simulation_library/inv2.sym # of
pins=4

** sym_path: /home/saumeeek/simulation_library/inv2.sym
** sch_path: /home/saumeeek/simulation_library/inv2.sch
.subckt inv2 Vin Vout Vcc Vss

*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss

XM1 Vout Vin Vss Vss sky130_fd_pr_nfet_01v8 L=0.17 W=2 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM2 Vout Vin Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.17 W=16 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
.ends

* expanding symbol: /home/saumeeek/simulation_library/inv22.sym # of
pins=4

** sym_path: /home/saumeeek/simulation_library/inv22.sym

```

```

** sch_path: /home/saumeeek/simulation_library/inv22.sch
.subckt inv22 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss

XM1 Vout Vin Vss Vss sky130_fd_pr_nfet_01v8 L=0.17 W=20 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM2 Vout Vin Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.17 W=5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

.ends

```

```

* expanding symbol: /home/saumeeek/simulation_library/inv1.sym # of
pins=4

** sym_path: /home/saumeeek/simulation_library/inv1.sym
** sch_path: /home/saumeeek/simulation_library/inv1.sch
.subckt inv1 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss

XM1 Vout Vin Vss Vss sky130_fd_pr_nfet_01v8 L=0.17 W=1.7 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

```

```

XM2 Vout Vin Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.17 W=3 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
.ends

* expanding symbol: /home/saumeeek/simulation_library/inv11.sym # of
pins=4
** sym_path: /home/saumeeek/simulation_library/inv11.sym
** sch_path: /home/saumeeek/simulation_library/inv11.sch
.subckt inv11 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss

XM1 Vout Vin Vss Vss sky130_fd_pr_nfet_01v8 L=0.17 W=3 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM2 Vout Vin Vcc Vcc sky130_fd_pr_pfet_01v8 L=0.17 W=6.5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
.ends

* expanding symbol: /home/saumeeek/simulation_library/inv2_3v3.sym #
of pins=4
** sym_path: /home/saumeeek/simulation_library/inv2_3v3.sym

```

```

** sch_path: /home/saumeeek/simulation_library/inv2_3v3.sch
.subckt inv2_3v3 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss

XM3 Vout Vin Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=15 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

XM1 Vout Vin Vcc Vcc sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=3 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

.ends

* expanding symbol: /home/saumeeek/simulation_library/inv22_3v3.sym
# of pins=4

** sym_path: /home/saumeeek/simulation_library/inv22_3v3.sym
** sch_path: /home/saumeeek/simulation_library/inv22_3v3.sch
.subckt inv22_3v3 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss

XM3 Vout Vin Vcc Vcc sky130_fd_pr_pfet_g5v0d10v5 L=0.5 W=20 nf=5
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1

```

```
XM4 Vout Vin Vss Vss sky130_fd_pr_nfet_g5v0d10v5 L=0.5 W=5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
.ends

.end
```