

# Table of Contents

- [1. A gentle introduction](#)
  - 1.1 Writing Python code
  - 1.2 Manipulating FreeCAD objects
  - 1.3 Vectors and Placements
- [2. All workbenches at a glance](#)
- [3. BIM modeling](#)
- [4. Creating FEM analyses](#)
- [5. Creating and manipulating geometry](#)
- [6. Creating interface tools](#)
- [7. Creating parametric objects](#)
- [8. Creating renderings](#)
- [9. Generating 2D drawings](#)
- [10. Import and export to other filetypes](#)
- [11. Installing](#)
  - 11.1 installing on Windows
  - 11.2 Installing on Linux
  - 11.3 Installing on Mac OS
  - 11.4 Uninstalling
  - 11.5 Setting basic preferences
  - 11.6 Installing additional content
- [12. Introduction](#)
- [14. Navigating in the 3D View](#)
  - 14.1 A word about the 3D space
  - 14.2 The FreeCAD 3D view
  - 14.3 Selecting objects
- [15. Parametric objects](#)
- [16. Preparing models for 3D printing](#)
  - 16.1 Exporting to slicers
  - 16.2 Converting objects to meshes
  - 16.3 Using Slic3r
  - 16.4 Using the Cura addon
  - 16.5 Generating G-code
- [17. The Community](#)
- [18. The FreeCAD Interface](#)
  - 18.1 Workbenches
  - 18.2 The interface
  - 18.3 Customizing the interface
- [19. The FreeCAD document](#)
- [20. Traditional 2D drafting](#)
- [21. Traditional modeling, the CSG way](#)
- [22. Using spreadsheets](#)
  - 22.1 Reading properties
  - 22.2 Writing properties
- [23. What is FreeCAD](#)