
Used by default after reset	Not used by default; must be explicitly set
Used in Handler mode (during exception handling)	Used in Thread mode (when not handling exceptions)
CONTROL[1] = 0	CONTROL[1] = 1
Default visible stack pointer	Only visible when explicitly selected
Loaded from the first 32-bit word of the vector table	Undefined; must be initialized by software
Used in many simple applications and by the OS kernel	Typically used by application processes in an OS environment
Accessed using "R13" or "SP"	Accessed using special register names "PSP"



R14 is the Link Register (LR). It stores the return address of a subroutine or function call. At the end of the subroutine or function, the return address stored in LR is loaded into the program counter (PC) to resume execution of the calling program. In some cases, such as exceptions. LR provides a special code value for the exception return mechanism.

What are R13, SP, MSP, and PSP?

- R13: Acts as the stack pointer.
- SP: Alias for R13, the stack pointer.
- MSP (Main Stack Pointer): Default stack pointer after reset and used during exception handling.
- PSP (Process Stack Pointer): Used in Thread mode: its stack pointer selection is controlled by the CONTROL register.

What are the types of memory regions defined in Cortex-M0 memory map?

- CODE: Mainly used for program code and exception vector table.
- SRAM: Mainly used for data memory (e.g., static RAM).
- External RAM: Used for external memory.
- External Device: Mainly used for peripherals.
- Peripherals: Mainly used for external peripherals.
- System: Private peripherals including built-in interrupt controller (NVIC) and debug components.
- Private Peripheral Bus (PPB) and System Control Space (SCS): Include specific control components.

List and explain the APSR flags in the Cortex-M0 processor with examples.

The Application Program Status Register (APSR) has four flags:

- Negative (N): Indicates a negative ALU result.
- Zero (Z): Indicates an ALU result of zero.
- Carry (C): Indicates a carried out or borrowed value in addition/subtraction.
- Overflow (V): Indicates an overflow in arithmetic operations.

Example ALU flag results:

Operation	Result	Flags
Add 1 + 0	1	Z=0, N=0, C=0, V=0
Subtract 1 - 1	0	Z=1, N=0, C=1, V=0






Figure 3.8: Memory map.

List the possible results and flags for the ALU operations given in the examples.

```
    0x70000000 + 0x70000000 = Result: 0xE00000000, N = 1, Z = 0, C = 0, V = 1
    0x90000000 + 0x90000000 = Result: 0x20000000, N= 0, Z = 0, C = 1, V = 1
```

- 0x80000000 + 0x80000000 = Result: 0x00000000, N = 0, Z = 1, C = 1, V = 1
- 0x00001234 0x00001000 = Result: 0x00000234, N = 0, Z = 0, C = 1, V = 0
- 0x00000004 0x00000005 = Result: 0xFFFFFFFF, N = 1, Z = 0, C = 0, V = 0
- 0xFFFFFFF 0xFFFFFFC = Result: 0x00000003, N = 0, Z = 0, C = 1, V = 0
- 0x80000005 0x80000004 = Result: 0x00000001, N = 0, Z = 0, C = 1, V = 0
- 0x70000000 0xF0000000 = Result: 0x80000000, N = 1, Z = 0, C = 0, V = 1
- 0xA0000000 0xA0000000 = Result: 0x00000000, N = 0, Z = 1, C = 1, V = 0

List the pros and cons of using assembly language for programming.
Pros:
Allows direct control to each instruction step and all memory operations

- Allows direct access to instructions that cannot be generated with C

Cons:


- Takes longer time to learn
- Difficult to manage data structure
- Less portable (syntax of assembly language in different tool chains can be different)


what is the primary purpose or the Cortex-M0 processor Debug state? Halting the processor stops instruction execution and enters the Debug state. This allows the debugger to access or change processor register values. The debugger can also access system memory locations.



- Application PSR (APSR)
- Interrupt PSR (IPSR)
- · Execution PSR (EPSR)

APSR contains ALU flags: N (negative flag), Z (zero flag), C (carry or borrow flag), and V (overflow flag). IPSR contains the current executing interrupt service routine (ISR) number. EPSR contains the T-bit indicating the processor's Thumb state. These registers provide essential program execution information and ALU flags for controlling conditional branches and debugging.





Explain the Cortex-M0 processor modes and states.
The Cortex-M0 processor has two operation modes and two states:
• Operation Modes:
1. Thread Mode: Executes normal code.
2. Handler Mode: Executes exception handler.
• States:
 Thumb State: The normal state for running Thumb/Thumb-2 instructions.
2. Debug State: For debugging purposes, where instruction execution can be halted to allow debugger access to processor registers and system memory.

By default, the processor runs in Thumb state and Thread mode upon power-up.




- 2. core_cm0.h: Contains definitions of processor peripherals like NVIC, System Tick Timer, and SCB, along with core access functions. In CMSIS v2, it is split into multiple files.
- 3. core_cm0.c: Provides intrinsic, compiler-independent functions.
- 4. Startup Code: Tools-specific, includes vector table and dummy definitions for system exception handlers. From CMSIS v1.30, it executes SystemInit() before branching to C startup code.
- 5. system_.h: Header file for functions implemented in system_.c.
- 6. system_.c: Implements system initialization, defines SystemCoreClock variable and SystemCoreClockUpdate() function.
- 7. Additional Files: Provides peripheral control code and other helper functions.


Differentiate between APB protocol and AHB protocol.

APB Protocol (Advanced Peripheral Bus)	AHB Protocol (Advanced High-performance Bus)
Handles all transfers as 32-bit words.	Supports various transfer sizes.
Commonly used for connecting peripherals.	Can be used for connecting different types of devices to the processor bus.

- APB Protocol (Advanced Peripheral Bus): The APB protocol is specialized for interfacing with low-bandwidth and low-power peripherals. It uses a simpler signal interface which is optimized for minimal communication overhead. All data transfers are performed using 32-bit words.
- AHB Protocol (Advanced High-performance Bus): The AHB protocol is designed for higher performance requirements, accommodating a wider range of data transfer sizes. It provides more complex operations for burst transfer, split transactions, and supports multiple masters which makes it better for connecting high-speed, high-throughput devices.



Scanned with CamScanner



Main Stack Pointer (MSP)	Process Stack Pointer (PSP)
Used by default after reset	Not used by default; must be explicitly se
Used in Handler mode (during exception handling)	Used in Thread mode (when not handling exceptions)
CONTROL[1] = 0	CONTROL[1] = 1
Default visible stack pointer	Only visible when explicitly selected
Loaded from the first 32-bit word of the vector table	Undefined; must be initialized by software
Used in many simple applications and by the OS kernel	Typically used by application processes in an OS environment
Accessed using "R13" or "SP"	Accessed using special register names "PSP"

What are the key system features of the ARM Cortex-M0 processor? Thumb instruction set offering high efficiency and code density

- High performance, achieving up to 0.9 DMIPS/MHz
- Built-in Nested Vectored Interrupt Controller (NVIC)
- Interrupts with four different programmable priority levels
- Deterministic exception response timing
- Nonmaskable interrupt (NMI) input
- Architectural predefined memory map
- Easy to use and C-friendly