Touchscreen Interfacing

ECE 3710

I used to have an open mind but my brains kept falling out.

- Steven Wright


assuming:

if given V_x:

can we deduce where on resistive chain the measurement is made?

$$R_1 = R_2 = R_3 = R_4$$

assuming:




if given V_x:

we can deduce where on resistive chain the measurement is made


$$R_1 = R_2 = R_3 = R_4$$

if we embed resistors in a screen overlay:




resistive coating: resistance per unit length

resistive coating: resistance per unit length



when the screen is touched:



given:

I.Y+=Vcc &Y-=GND

2.V = voltage at point

of contact


3. smaller V means

closer to Y- edge; larger


V means closer to Y+

edge

can determine position if we can measure voltage at point




to determine x coordinate:




need x,y coords: two measurements

to determine y coordinate:



need x,y coords: two measurements

to determine x coordinate:



touchscreen controller controls these switches


measures voltage; converts to proportional binary number

you, on theory operation:




Q: how do we actually use this?

generic touchscreen controller



XPT2046 touchscreen

interface via SPI



Tuesday, October 29, 13

p13 & p9

XPT2046 touchscreen

very simple:

1. tx: get x,y, or z/t (control byte)

2. rx: requested coord

note: the control byte also contains configuration options

XPT2046 touchscreen: control byte *

what is sent to touchscreen controller

coordinate:

x: 101

y: 001

conversion

resolution:

1:8-bits

0:12-bits

BIT7(MSB)	BIT 6	BIT 5	BIT 4	BIT 3	BIT2	BIT 1	BIT 0(LSB)
S	A2	A1	A0	MODE	SER/DFR	PD1	PD0

always 1

conversion reference type:


1: single

0:differential

power/interrupt pin: 00: unit off between conversions but /

PENIRQ active

XPT2046 touchscreen: A [2 : 0]






	A2	A1	Α0	+REF	-REF	YN	XP	YP	Y-POSITION	X-POSITION	Z ₁ -POSITION	Z ₂ -POSITION	DRIVERS
\longrightarrow	0	0	1	ΥP	YN		+IN		M				YP, YN
	0	1	1	YP	XN		+IN				М		YP,
	1	0	0	YP	XN	+IN						M	YP,
	1	0	1	XP	XN			+IN		M			XP,

XPT2046 touchscreen: control byte


CB[6:4] depend on if you want x or y

recommended configuration (CB[3:0]):

- I. differential reference
 - 2. I2-bit conversion
- 3. power-down between conversions



XPT2046 touchscreen: SPI (12 bit)



XPT2046 touchscreen: SPI

note: not all of these pins are connected on your board




fig 12, p23

response?



to receive coordinate

```
use RX queue in SPI module:

I. init conversion

2. wait

3. read DR

(AII--I)

4. read DR


(A0)

5. concatenate
```

XPT2046 touchscreen: approach

basic approach: (triggered flag is /PENIRQ)

I. don't update until screen is released




2. data is noisy: average or take median of coords while pressed

LCD Adapter

ECE 3710


better adapter would save 2 more

LCD adapter: 16 to 11 pins




more components

ah, more complexity:




latch




Funtion Table


Output	Ena		
control	LE	D	Output
L	Н	Н	Н
L	Н	L	L
L	L	Χ	Q0
Н	X	Х	Z



transceiver

(16-bit mode)





transceiver


(LCD adapter)

A to B

B to A

A to B

B to A



to write data: first step


(lower byte)

uC does:

1. outputs lower byte: IB[7:0]

a.
$$/OE=0$$

$$c./LE=1$$



uC does:

1. outputs upper byte: IB[15:8]

a./OE=0

 \rightarrow b. DIR=1

to write data: second step

(upper byte)

unchanged from step one

