Wi-Fi Training Program Assignment Questions -Module 3

Q1. What are the different 802.11 PHY layer standards? Compare their characteristics.

Standard	Frequency	Max	Modulation	Channel	Key Features
	Band	Data	Туре	Width	
		Rate			
802.11a	5 GHz	54 Mbps	OFDM	20 MHz	Less interference, shorter
					range
802.11b	2.4 GHz	11 Mbps	DSSS	22 MHz	Longer range, high
					interference
802.11g	2.4 GHz	54 Mbps	OFDM + DSSS	20 MHz	Backward compatible with
					802.11b
802.11n	2.4/5 GHz	600	OFDM +	20/40 MHz	Introduction of MIMO,
		Mbps	MIMO		better throughput
802.11ac	5 GHz	6.9	OFDM + MU-	20/40/80/1	Beamforming, multi-user
		Gbps	MIMO	60 MHz	support
802.11ax	2.4/5 GHz	~9.6	OFDMA +	20/40/80/1	Higher efficiency, dense
(Wi-Fi 6)		Gbps	MU-MIMO +	60 MHz	environments
			1024-QAM		
802.11be	2.4/5/6	>30	OFDMA +	Up to 320	Multi-link operation, very
(Wi-Fi 7)	GHz	Gbps	MIMO +	MHz	high throughput
		(est.)	4096-QAM		

Q2. What are DSSS and FHSS? How do they work?

DSSS (Direct Sequence Spread Spectrum)

Definition: DSSS is a spread spectrum technique where the data signal is multiplied by a pseudorandom noise (PN) code at a much higher rate than the original signal. This spreads the data over a wider frequency band.

How It Works:

- Each data bit is replaced with a sequence of bits (called "chips") using a spreading code.
- The signal occupies a wider bandwidth, reducing the effects of interference and improving signal robustness.
- At the receiver end, the same PN code is used to decode the signal and retrieve the original data.

Advantages:

- Resistance to narrowband interference
- · Higher data integrity and reduced signal fading
- Lower probability of interception

Use Case:

• Used in IEEE 802.11b standard (2.4 GHz, up to 11 Mbps)

•

FHSS (Frequency Hopping Spread Spectrum)

Definition: FHSS is another spread spectrum technique where the signal rapidly switches ("hops") between different frequencies within a wider band in a pseudorandom sequence.

How It Works:

- The transmitter and receiver hop between predefined frequencies in sync.
- Each transmission occurs over a short period on a given frequency before hopping to the next.
- It minimizes the chance of interference on any single frequency.

Advantages:

- Strong resistance to interference and eavesdropping
- Enhanced security due to unpredictable frequency hops
- · Better coexistence with other wireless systems

Use Case:

 Early 802.11 wireless systems (legacy), Bluetooth, and some military communication systems

Q3. How do modulation schemes work in the PHY layer? Compare different modulation schemes and their performance across various Wi-Fi standards.

Modulation Schemes in the PHY Layer

The Physical (PHY) layer in Wi-Fi is responsible for converting digital data into electromagnetic signals for wireless transmission. **Modulation schemes** are used to encode

data onto carrier signals by varying certain signal characteristics such as amplitude, frequency, or phase.

These modulation techniques allow multiple bits to be transmitted per symbol, improving data rate and spectral efficiency.

Common Modulation Schemes in Wi-Fi

Modulation	Description	Bits per	Wi-Fi Standards	Performance
Туре		Symbol		
BPSK (Binary	Varies the phase of	1	802.11a/b/g/n	High reliability,
Phase Shift	the carrier by 180° to			low data rate
Keying)	represent binary data			
QPSK	Uses 4 phase shifts to	2	802.11a/b/g/n/ac	Good balance
(Quadrature	encode 2 bits per			of speed and
Phase Shift	symbol			robustness
Keying)				
16-QAM	Modifies both	4	802.11a/g/n/ac	Higher
(Quadrature	amplitude and			throughput,
Amplitude	phase; encodes 4 bits			moderate noise
Modulation)	per symbol			resistance
64-QAM	Encodes 6 bits per	6	802.11n/ac	High data rates,
	symbol			lower noise
				immunity
256-QAM	Encodes 8 bits per	8	802.11ac/ax	Very high
	symbol			throughput,
				requires high
				signal quality
1024-QAM	Encodes 10 bits per	10	802.11ax	Ultra-high
	symbol			throughput,
				very sensitive
				to noise

Performance Across Wi-Fi Standards

Wi-Fi Standard	Max Modulation Used	Max Data Rate	Remarks
802.11b	DSSS with QPSK	11 Mbps	Robust, low-speed
802.11g	64-QAM	54 Mbps	Good performance for
			2.4 GHz
802.11n	64-QAM	600 Mbps (with	Introduced MIMO and
		MIMO)	channel bonding
802.11ac	256-QAM	1 Gbps+	High throughput in 5
			GHz

802.11ax (Wi-	1024-QAM	9.6 Gbps	Optimized for dense
Fi 6)			environments, better
			efficiency

Q4. What is the significance of OFDM in WLAN? How does it improve performance?

OFDM (Orthogonal Frequency Division Multiplexing) is a digital modulation technique used in modern WLAN standards (e.g., IEEE 802.11a/g/n/ac/ax) to efficiently transmit high-speed data over wireless channels. It divides a wideband signal into multiple narrowband subcarriers that are transmitted in parallel.

Each subcarrier is modulated independently using techniques like BPSK, QPSK, or QAM, and they are orthogonal to each other—meaning they do not interfere despite being closely spaced.

Significance of OFDM in WLAN

1. Efficient Use of Spectrum

OFDM allows multiple subcarriers to be packed closely together, maximizing the utilization of available bandwidth and increasing throughput.

2. High Data Rates

By transmitting data in parallel across multiple subcarriers, OFDM supports high data rates, suitable for applications like video streaming and large file transfers.

3. Resilience to Multipath Fading

Wireless environments suffer from multipath propagation, where signals reflect and arrive at the receiver at different times. OFDM mitigates this by using **longer symbol durations** and **cyclic prefixes**, reducing inter-symbol interference (ISI).

4. Adaptive Modulation

Each subcarrier in OFDM can be modulated individually based on channel conditions, enabling **dynamic modulation schemes** (e.g., using 64-QAM for strong signals, BPSK for weak signals), which improves reliability and performance.

5. Simplified Equalization

Since each subcarrier occupies a narrow bandwidth, **equalization becomes easier**, as flat fading can be assumed per subcarrier.

6. Supports MIMO

OFDM works efficiently with **Multiple-Input Multiple-Output (MIMO)** systems, further enhancing spectral efficiency and throughput.

Performance Benefits in WLAN

Aspect	Improvement with OFDM	
Throughput	Increases due to parallel transmission	
Latency	Lower latency in environments with multipath	
Efficiency	Better use of spectrum and adaptive modulation	
Reliability	Resilient to fading and interference	
Scalability	Works well in both low and high-density environments	

Q5. How are frequency bands divided for Wi-Fi? Explain different bands and their channels.

Wi-Fi operates primarily within unlicensed radio frequency bands defined by regulatory authorities such as the **FCC (USA)**, **ETSI (Europe)**, and **IEEE**. The most commonly used bands for Wi-Fi are:

- 2.4 GHz Band
- 5 GHz Band
- 6 GHz Band (introduced in Wi-Fi 6E)

Each band is divided into multiple **channels**, with specific characteristics and regulatory constraints.

1. 2.4 GHz Band

• Frequency Range: 2.400 – 2.4835 GHz

• **Total Channels:** 14 (though availability varies by region)

• Channel Width: 20 MHz

• Common Channels (Non-Overlapping): 1, 6, 11 (in the US)

2. 5 GHz Band

• Frequency Range: 5.150 – 5.850 GHz (varies slightly by country)

• Channel Widths: 20 MHz, 40 MHz, 80 MHz, 160 MHz (bonded channels)

• Non-Overlapping Channels: Many, such as 36, 40, 44, 48, etc.

3. 6 GHz Band (Wi-Fi 6E)

• Frequency Range: 5.925 – 7.125 GHz (depending on country regulations)

• Channel Widths: 20 MHz to 160 MHz

• Number of Channels: Over 50 additional non-overlapping channels

Q6. What is MIMO? How does it enhance WLAN performance?

MIMO (Multiple Input Multiple Output) is a wireless communication technology used in modern WLAN standards (such as 802.11n, 802.11ac, and 802.11ax) that employs multiple antennas at both the transmitter and receiver ends to transmit multiple data streams simultaneously over the same frequency band.

Instead of sending one data stream per frequency channel (as in traditional systems), MIMO increases throughput and reliability by taking advantage of multipath propagation.

- MIMO systems use multiple transmit and receive antennas .
- It divides a high-speed data stream into **multiple substreams** and transmits them **in** parallel.
- Each substream follows a different spatial path in the environment.
- The receiver uses advanced signal processing algorithms to reconstruct the original data by **combining signals** received from different antennas.

Benefits of MIMO in WLAN

Feature	Enhancement by MIMO	
Higher Throughput	Transmits multiple data streams simultaneously increased data	
	rate	
Improved Range	Utilizes multipath reflections constructively better signal	
	reception	
Better Reliability	Reduces packet loss and enhances signal quality	
Higher Spectral Efficiency	More data transmitted over the same bandwidth efficient use of	
	radio spectrum	
Supports Beamforming	Focuses signal in the direction of the receiver improves	
	performance and reduces interference	

Q7: Describe the structure of an 802.11 PHY layer frame. What are its key components?

The **802.11 PHY (Physical) layer frame** is responsible for the transmission and reception of raw data bits over a physical medium (like radio waves). The structure of a PHY layer frame consists of several parts that help in synchronization, decoding, and data delivery.

Key Components of an 802.11 PHY Layer Frame:

1. Preamble:

- Helps receivers detect the signal, synchronize, and prepare for data reception.
- Contains:
 - **Short Training Field (STF):** For signal detection and coarse frequency offset estimation.

- Long Training Field (LTF): For channel estimation and fine frequency correction.
- **Signal Field (SIG):** Carries information about the modulation rate, length of the data, and other transmission parameters.

2. Header (PLCP - Physical Layer Convergence Protocol Header):

- Provides metadata about the frame such as:
 - Data rate
 - Frame length
 - Service field
 - Parity or CRC
- o Ensures the MAC layer knows how to interpret the data.

3. Data (PSDU - PLCP Service Data Unit):

- o Contains the actual MAC layer data payload.
- Encapsulates:
 - MAC header
 - MAC payload (user data)
 - Frame Check Sequence (FCS)

Q8: What is the difference between OFDM and OFDMA?

Aspect	OFDM	OFDMA
Full Form	Orthogonal Frequency Division	Orthogonal Frequency Division
	Multiplexing	Multiple Access
Resource	All subcarriers are assigned to a	Subcarriers are divided among multiple
Allocation	single user at a time	users simultaneously
User Access	Single-user system	Multi-user system
Efficiency	Less efficient for small or bursty	Highly efficient, especially for multiple
	data packets	users or IoT
Latency	Higher latency due to sequential	Lower latency with parallel user access
	user access	
Usage	Used in Wi-Fi 5 (802.11ac)	Used in Wi-Fi 6 (802.11ax)

Q9: What is the difference between MIMO and MU-MIMO?

Aspect	MIMO	MU-MIMO
Full Form	Multiple Input Multiple Output	Multi-User Multiple Input Multiple
		Output
User Support	Communicates with one	Communicates with multiple devices
	device at a time	simultaneously
Antenna Usage	Uses multiple antennas for one	Uses multiple antennas to serve
	data stream at a time	several streams to different users
Efficiency	Good for single high-	Better for networks with many users
	bandwidth users	
Technology	Introduced in Wi-Fi 4 (802.11n)	Introduced in Wi-Fi 5 (802.11ac) and
Generation		enhanced in Wi-Fi 6
Latency	Higher, as users wait for their	Lower, due to parallel transmission
	turn	

Q10: What are PPDU, PLCP, and PMD in the PHY layer?

1. PPDU (PLCP Protocol Data Unit):

- It's the **final frame** that gets transmitted over the air.
- It includes all physical layer information like preamble, header, and payload.
- Formed by adding the PLCP header and preamble to the PSDU (which contains MAC layer data).

2. PLCP (Physical Layer Convergence Procedure):

- A **sublayer** in the PHY layer that prepares data from the MAC layer for transmission.
- Adds necessary headers and control information.
- Helps the receiver synchronize and decode the signal properly.
- Key Tasks:
 - Frame formatting
 - Timing synchronization
 - Error checking

3. PMD (Physical Medium Dependent):

- The **lowest sublayer** in the PHY layer.
- Responsible for the actual transmission and reception of bits over the physical medium (radio waves).
- Deals with modulation, signal generation, and frequency translation.

Q11: What are the types of PPDU? Explain the PPDU frame format across different Wi-Fi generations.

Types of PPDU and Their Formats:

- 1. Legacy PPDU (802.11a/g):
 - **Used in:** Wi-Fi 3 and earlier standards
 - Structure:
 - Legacy Short Training Field (L-STF)
 - Legacy Long Training Field (L-LTF)
 - Legacy Signal Field (L-SIG)
 - Data (Payload)
 - **Features:** Basic single-user support with limited modulation schemes and bandwidth (20 MHz)
- 2. High Throughput (HT) PPDU (802.11n):
 - Used in: Wi-Fi 4
 - Structure:
 - Legacy Fields (L-STF, L-LTF, L-SIG)
 - o HT-SIG
 - HT Short Training Field (HT-STF)
 - HT Long Training Fields (HT-LTFs)
 - o HT Data
 - **Features:** Supports MIMO, 40 MHz bandwidth, and aggregation, offering improved throughput over legacy PPDU.
- 3. Very High Throughput (VHT) PPDU (802.11ac):
 - Used in: Wi-Fi 5
 - Structure:
 - Legacy Fields (L-STF, L-LTF, L-SIG)
 - VHT-SIG A
 - VHT Short Training Field (VHT-STF)
 - VHT Long Training Fields (VHT-LTFs)

- VHT-SIG B
- o VHT Data
- **Features:** Supports MU-MIMO (downlink), 80/160 MHz channel bandwidths, and 256-QAM modulation for higher data rates.

4. High Efficiency (HE) PPDU (802.11ax):

- Used in: Wi-Fi 6
- Types of HE PPDUs:
 - HE SU (Single User)
 - HE MU (Multi-User)
 - HE Trigger-Based
 - HE Extended Range (HE ER)
- Structure (Example: HE SU):
 - Legacy Fields (L-STF, L-LTF, L-SIG)
 - HE-SIG-A
 - HE-STF
 - o HE-LTFs
 - HE-SIG-B (only for MU PPDU)
 - o HE Data
- **Features:** Introduces OFDMA, MU-MIMO (uplink and downlink), BSS coloring, Target Wake Time (TWT), and 1024-QAM modulation. These enhancements significantly improve spectral efficiency and network capacity.

Q12: How is the data rate calculated?

The data rate, often referred to as the bitrate or bandwidth, is the amount of data transmitted over a communication channel in a given time period. It is typically expressed in bits per second (bps), kilobits per second (kbps), megabits per second (Mbps), etc.

To calculate the data rate, you need to consider the following factors:

Bit Depth (or Data Width): The number of bits used to represent one unit of data.
 For example, if you're transmitting 8 bits (1 byte) of data per sample, the bit depth is 8.

- 2. **Sample Rate**: The number of samples transmitted per second. For example, if you're sampling data from a sensor 1000 times per second, your sample rate is 1000 Hz (samples per second).
- 3. **Number of Channels**: If you're transmitting data from multiple channels (for example, a multi-sensor system), you multiply the data rate by the number of channels.

Formula

The general formula to calculate the data rate is:

Data Rate=Bit Depth×Sample Rate×Number of Channels