Microcontrollers the Hard Way

Blink Like a Pro







Why?

NOTE: Please install AVR toolchain and AVRDUDE while I blab.

- Arduino, Python, MicroPython, CircuitPython are much easier! (Calculator without math)
- For product development...
 - C is usually faster and more space efficient
 - Need to understand architecture
- But AVR is old! 32-bit is the new hotness
 - Registers
 - Interrupts
 - Timers
 - Peripherals




Hardware Hookup





Hints



- Lots of information
- Type in exercises (at least open them from the repo)
- Try the challenges
- Have the datasheet open in another window







10.3 Register Description


From datasheet


10.3.1 MCUCR – MCU Control Register

Bit	7	6	5	4	3	2	1	0	_
0x35 (0x55)	BODS	PUD	SE	SM1	SM0	BODSE	ISC01	ISC00	MCUCR
Read/Write	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	•
Initial Value	0	0	0	0	0	0	0	0	

Bit 6 – PUD: Pull-up Disable

When this bit is written to one, the pull-ups in the I/O ports are disabled even if the DDxn and PORTxn Registers are configured to enable the pull-ups ({DDxn, PORTxn} = 0b01). See "Configuring the Pin" on page 54 for more details about this feature.





Exercise 01 - Blinky!

- Create AVR Projects folder somewhere on your computer
- In it, create blinky.c
- In blinky.c, enter the code on the right
- Save
- Open new terminal, enter commands:

```
avr-gcc -Os -mmcu=attiny84 -o blinky.elf blinky.c
avr-objcopy -j .text -j .data -O ihex blinky.elf blinky.hex
avrdude -c usbtiny -p t84 -U flash:w:blinky.hex
```

Or from wenk-sao main directory: python upload.py <path/to/blinky.c>

Hint: Up arrow is your friend in the terminal to replay commands


Challenge: Only flash the green LED instead of all 3

```
#ifndef F CPU
#define F CPU 1000000UL // 1 MHz clock speed
#endif
#include <avr/io.h>
#include <util/delay.h>
int main(void) {
    // Make Ports A and B all output
   DDRA = 0b111111111;
   DDRB = 0b11111111;
   // Infinite loop
    while(1) {
        // Turn on all LEDs
        PORTA = 0x00;
        PORTB = 0 \times 00;
        // Wait 1 second
        delay ms(1000);
        // Turn off all LEDs
        PORTA = 0xFF;
        PORTB = 0xFF;
        // Wait 1 second
        delay ms(1000);
```


Setting/Clearing Bits

PORTA = 0xFF;	Sets all bits in register PORTA to 1	
PORTA = 0b10000000;	Sets bit 7 to 1 and all others to 0	
PORTA = (1 << 7);	Sets bit 7 to 1 while keeping rest $(1 << 7) = b10000000$	PORTA - 00011010 OR 10000000
PORTA &= ~(1 << 7);	Clears bit 7 to 0 while keeping rest ~ (1 << 7) = b01111111	10011010 PORTA - 10111010 AND 01111111
		00111010
PORTA ^= (1 << 7);	Toggles just bit 7 $(1 << 7) = b10000000$	PORTA → 10011010 XOR 10000000

Intro to Interrupts




Program Memory



Intro to Timers

- Always counting, regardless of code
- Can be connected to pins, clocked by pins, used to trigger interrupts
- Timer 0: 8 bits, Timer 1: 16 bits



Timer Calculations

Period:
$$T = \frac{1}{f} = \frac{1}{1MHz} = 1\mu s$$

Prescaler $\frac{8}{1MHz} = 8\mu s$

12.11.2 TCCR1B – Timer/Counter1 Control Register B

Bit	7	6	5	4	3	2	1	0
0x2E (0x4E)	ICNC1	ICES1	-	WGM13	WGM12	CS12	CS11	CS10
Read/Write	R/W	R/W	R	R/W	R/W	R/W	R/W	R/W
Initial Value	0	0	0	0	0	0	0	0

Table 12-6. Clock Select Bit Description

The state of the s										
CS12	CS11	CS10	Description							
0	0	0	No clock source (Timer/Count	No clock source (Timer/Counter stopped).						
0	0	1	clk _{I/O} /1 (No prescaling)	Descible						
0	1	0	clk _{I/O} /8 (From prescaler)	Possible						
0	1	1	clk _{I/O} /64 (From prescaler)	prescaler						
1	0	0	clk _{I/O} /256 (From prescaler)	values						
1	0	1	clk _{I/O} /1024 (From prescaler)	values						
1	1	0	External clock source on T1 p	external clock source on T1 pin. Clock on falling edge.						
1	1	1	External clock source on T1 p	in. Clock on rising edge.						

Try different prescaler values

Timer 1 (16 bit) max value: 65,535

$$\frac{1s \cdot 1MHz}{1} = 1,000,000$$

$$\frac{1s \cdot 1MHz}{8} = 125,000$$

$$\frac{1s \cdot 1MHz}{64} = 15,625$$

$$\frac{1s \cdot 1MHz}{256} = 3906.25$$

$$\frac{1s \cdot 1MHz}{1024} = 976.5625$$

How to Set Up Timer 1

- Set WGM1 bits to choose Normal mode in TCCR1A
- 2. Set CCS1 bits to choose prescaler in TCCR1B
- 3. Load reset value (0) into TCNT1 (Timer 1)
- 4. Load target value (15625) into OCR1A
- 5. Set OCIE1A bit in TIMSK1 to enable Timer 1 compare interrupt
- 6. Enable global interrupts

Important sections in the datasheet:

- 9.1 Interrupt Vectors
- 10.3 Register Descriptions for I/O Ports
- 12.11 Register Descriptions for Timer/Counter 1

12.11.1 TCCR1A - Timer/Counter1 Control Register A

Bit	7	6	5	4	3	2	1	0	
0x2F (0x4F)	COM1A1	COM1A0	COM1B1	COM1B0	_	-	WGM11	WGM10	TCCR1A
Read/Write	R/W	R/W	R/W	R/W	R	R	R/W	R/W	•
Initial Value	0	0	0	0	0	0	0	0	

Table 12-5. Waveform Generation Modes

Mode	WGM1 [3:0]	Mode of Operation	ТОР	Update of OCR1x at	TOV1 Flag Set on
0	0000	Normal	0xFFFF	Immediate	MAX
1	0001	PWM, Phase Correct, 8-bit	0x00FF	TOP	ВОТТОМ
2	0010	PWM, Phase Correct, 9-bit	0x01FF	TOP	воттом
3	0011	PWM, Phase Correct, 10-bit	0x03FF	TOP	ВОТТОМ
4	0100	CTC (Cloar Timer on Compare)	OCD1A	Immodiata	MANY

12.11.2 TCCR1B – Timer/Counter1 Control Register B

Bit	7	6	5	4	3	2	1	0	
0x2E (0x4E)	ICNC1	ICES1	· -	WGM13	WGM12	CS12	CS11	CS10	TCCR1B
Read/Write	R/W	R/W	R	RW	R/W	R/W	R/W	R/W	-
Initial Value	0	0	0	0	0	0	0	0	

Table 12-6. Clock Select Bit Description

CS12	CS11	CS10	Description	
0	0	0	No clock source (Timer/Counter stopped).	
0	0	1	clk _{I/O} /1 (No prescaling)	
0	1	0	clk _{I/O} /8 (From prescaler)	
0	1	1	clk _{I/O} /64 (From prescaler)	
1	0	0	clk _{I/O} /256 (From prescaler)	
1	0	1	clk _{I/O} /1024 (From prescaler)	
1	1	0	External alask source on T1 nin Clask on folling adas	

12.11.5 OCR1AH and OCR1AL - Output Compare Register 1 A

t	7	6	5	4	3	2	1	0	
2B (0x4B)				OCR1	A[15:8]				OCR1
2A (0x4A)				OCR1	A[7:0]				OCR
ead/Write	R/W	R/W	R/W	R/W	R/W	R/W	R/W	R/W	-
tial Value	0	0	0	0	0	0	0	0	

12.11.8 TIMSK1 - Timer/Counter Interrupt Mask Register 1

Bit	7	6	5	4	3	2	1	0	
0x0C (0x2C)	-	-	ICIE1	-	8-	OCIE1B	OCIE1A	TOIE1	TIMSK1
Read/Write	R	R	R/W	R	R	R/W	R/W	R/W	•
Initial Value	0	0	0	0	0	0	0	0	

Exercise 02 - Blinky with Timer 1

DDRA = (1 << 7);


DDRB = (1 << 2);

Create timer-blinky.c with code below


```
$ avr-gcc -Os -mmcu=attiny84 -o timer-blinky.elf timer-blinky.c
 $ avr-objcopy -j .text -j .data -O ihex timer-blinky.elf
 timer-blinky.hex
 $ avrdude -c usbtiny -p t84 -U flash:w:timer-blinky.hex
 Or:
 $ python upload.py <path/to/timer-blinky.c>
 Challenge: Flash green LED with a delay of 500 ms
 instead of 1 second.
#include <avr/io.h>
#include <avr/interrupt.h>
// Timer values (1 sec with prescaler of 64)
const uint16 t t1 load = 0;
const uint16 t t1 comp = 15625;
int main (void) {
    // Make only red LED pins output (PA7, PB2)
```

```
DDRB = (1 << 2);
   // Set Timer 1 to normal operation
   TCCR1A = 0;
   TCCR1B = 0;
   // Set prescaler to 64
   TCCR1B = (1 << CS11) + (1 << CS10);
   // Reset Timer 1 and set compare values
   TCNT1 = t1 load;
   OCR1A = t1 comp;
   // Enable Timer 1 compare interrupt
   TIMSK1 = (1 << OCIE1A);
   // Enable global interrupts
   sei();
   // Infinite loop
   while(1) {
       // Do nothing
// Interrupt service routine
ISR (TIM1 COMPA vect) {
   // Reset Timer 1
   TCNT1 = t1 load;
   // Toggle red LEDs
   PORTA ^= (1 << 7);
    PORTB ^= (1 << 2);
}
```

Intro to Pulse Width Modulation



Intro to Hardware PWM (Output Compare)



How to Set Up PWM

- Set WGM0 bits in TCCR0A and TCCR0B
- 2. Set COM0A and COM0B bits in TCCR0A
- 3. Set CCS0 bits in TCCR0B for prescaler of 1
- 4. Set OCRA with desired duty cycle (0..255)

Important sections in the datasheet:

- 10.3 Register Descriptions for I/O Ports
- 11.9 Register Descriptions for Timer/Counter 0

11.9.1 TCCR0A - Timer/Counter Control Register A

Bit	7	6	5	4	3	2	1	0	
0x30 (0x50)	COM0A1	COM0A0	COM0B1	COM0B0	-	02	WGM01	WGM00	TCCR0
Read/Write	R/W	R/W	R/W	R/W	R	R	R/W	R/W	
Initial Value	0	0	0	0	0	0	0	0	

 Table 11-8.
 Waveform Generation Mode Bit Description

Mode	WGM02	WGM01	WGM00	Timer/Counter Mode of Operation	ТОР	Update of OCRx at	TOV Flag Set on ⁽¹⁾
0	0	0	0	Normal	0xFF	Immediate	MAX
1	0	0	1	PWM, Phase Correct	0xFF	ТОР	воттом
2	0	1	0	СТС	OCRA	Immediate	MAX
3	0	1	1	Fast PWM	0xFF	воттом	MAX
4	1	0	0	Reserved	-	-	-
5	1	0	1	PWM, Phase Correct	OCRA	TOP	воттом
6	1	1	0	Reserved		-	-
7	1	1	1	Fast PWM	OCRA	воттом	TOP

Table 11-3. Compare Output Mode, Fast PWM Mode⁽¹⁾

COM0A1	COM0A0	Description
0	0	Normal port operation, OC0A disconnected
0	1	WGM02 = 0: Normal Port Operation, OC0A Disconnected WGM02 = 1: Toggle OC0A on Compare Match
1	0	Clear OC0A on Compare Match Set OC0A at BOTTOM (non-inverting mode)
1	1	Set OC0A on Compare Match Clear OC0A at BOTTOM (inverting mode)

Exercise 03 - Hardware PWM

Create hardware-pwm.c with code to the right

```
$ avr-gcc -Os -mmcu=attiny84 -o hardware-pwm.elf hardware-pwm.c
$ avr-objcopy -j .text -j .data -O ihex hardware-pwm.elf
hardware-pwm.hex
$ avrdude -c usbtiny -p t84 -U flash:w:hardware-pwm.hex
```

Or:

```
$ python upload.py <path/to/hardware-pwm.c>
```


Challenge: Notice that a duty cycle of 0% does not completely turn off LED. This is because in Fast PWM mode, at least 1 clock cycle happens while pin is low (LED on). Fix this by using Phase Correct PWM.

Hint: Read about the WGM0 bits in the TCCR0A register (datasheet section 11.9.1)

```
// Need to define clock speed for delay functions
#define F CPU 1000000UL // 1 MHz clock speed
#endif
#include <avr/io.h>
#include <util/delay.h>
int main (void) {
   // Make only red LED pins output (PA7, PB2)
   DDRA = (1 << 7);
   DDRB = (1 << 2);
    // Set Timer 0 to fast PWM
   TCCR0A = (1 << WGM01) | (1 << WGM00);
   // Set Compare Output modes for A and B to inverting PWM
   TCCR0A = (1 << COM0A1) | (1 << COM0A0);
   TCCR0A = (1 << COM0B1) | (1 << COM0B0);
   // Set prescaler to 1 (no prescaling)
   TCCROB = (1 \ll CSOO);
   // Infinite loop
    while(1) {
       int16 t d;
        // Increase left eye, decrease right eye
        for (d = 0; d \le 255; d++) {
            OCROA = (uint8 t)d;
                                        // Left eye
            OCROB = (uint8 t)255 - d; // Right eye
            delay ms(2);
        // Decrease left eye, increase right eye
        for (d = 255; d >= 0; d--) {
            OCROA = (uint8 t)d;
                                        // Left eye
           OCROB = (uint8 t)255 - d; // Right eye
            delay ms(2);
```

Software PWM

- Configure Timer 0 in normal mode
- Whenever Timer 0 reaches OCR0A, ticks++
- ticks is unsigned8-bit
- Let ticks roll over from 255 to 0
- Continually compare ticks to desired value



PWM Frequency

CPU clock: 1 MHz

Timer 0 prescaler: 1

OCR0A (comp): ???

Ticks counting from 0 to 255 is one period

50 Hz LED refresh looks decent (and it's the best we can do)

$$\frac{1,000,000Hz}{255 \cdot comp} = 50Hz$$

 $comp \approx 78$

Exercise 04 - Software PWM

Open wenk-sao/Firmware/ 04-software-pwm/software-pwm.c

Compile and upload it to the microcontroller.

Challenge: Have fun! Make some fun color patterns with the eyes. Check out rainbow-pattern.c to see how to remove LED flicker.



Twitter: ShawnHymel



Instagram: shawn_hymel



LinkedIn: linkedin.com/ShawnHymel



```
#include <avr/io.h>
                                                                 // Set left eve: orange
#include <avr/interrupt.h>
                                                                 left r = 255;
                                                                 left g = 30;
// Timer values
                                                                 left b = 0;
const uint8 t t0 load = 0;
const uint8 t t0 comp = 78; // ~50 Hz PWM
                                                                 // Set right eye: teal
                                                                 right r = 0;
// LED pins (left = PORTB, right = PORTA)
                                                                 right g = 128;
                                                                 right b = 128;
const uint8 t p lr = 2;
const uint8 t p lq = 0;
const uint8 t p lb = 1;
const uint8 t p rr = 7;
                                                         // Interrupt service routine
const uint8 t p rg = 2;
                                                         ISR (TIMO COMPA vect) {
const uint8 t p rb = 3;
                                                             // Reset Timer 0
// Tick counter
                                                             TCNT0 = t0 load;
volatile uint8 t ticks = 0;
                                                             // Increment counter (just let roll over)
// Duty cycle per color
                                                             ticks++;
volatile uint8 t left r = 0;
volatile uint8 t left q = 0;
                                                             // Set left LED based on duty cycle
volatile uint8 t left b = 0;
                                                             if ( ticks < left r ) {</pre>
volatile uint8 t right r = 0;
                                                                 PORTB &= ~(1 << p lr); // LED on
volatile uint8 t right g = 0;
volatile uint8 t right b = 0;
                                                                 PORTB |= (1 << p lr); // LED off
// Program entry point
                                                             if (ticks < left q) {
int main (void) {
                                                                 PORTB &= ~(1 << p lg); // LED on
                                                              else {
    // Make LED pins output
                                                                 PORTB |= (1 << p lg); // LED off
    DDRA = (1 << p rr) | (1 << p rq) | (1 << p rb);
    DDRB = (1 << p lr) | (1 << p lg) | (1 << p lb);
                                                             if ( ticks < left b ) {
                                                                 PORTB &= ~(1 << p lb); // LED on
    // Set Timer 0 to normal operation
                                                             } else {
   TCCR0A = 0;
                                                                 PORTB |= (1 << p lb); // LED off
    TCCR0B = 0;
    // Set prescaler to 1
                                                             // Set right LED based on duty cycle
   TCCR0B \mid = (1 << CS00);
                                                             if ( ticks < right r ) {
                                                                 PORTA &= ~(1 << p rr); // LED on
    // Reset Timer 0 and set compare values
    TCNT0 = t0 load;
                                                                 PORTA |= (1 << p rr); // LED off
   OCROA = t0 comp;
                                                             if ( ticks < right q ) {
    // Enable Timer 0 compare interrupt
                                                                 PORTA &= ~(1 << p rg); // LED on
   TIMSK0 = (1 << OCIE0A);
                                                             } else {
                                                                 PORTA |= (1 << p rg); // LED off
   // Enable global interrupts
   sei();
                                                             if (ticks < right b) {
                                                                 PORTA &= ~(1 << p rb); // LED on
   // Infinite loop
    while(1) {
                                                                 PORTA |= (1 << p rb); // LED off
```