Link layer, LANs: roadmap

- introduction
- multiple access protocols
  - Channel partitioning
  - Random Access protocols
    - Slotted ALOHA, CSMA/CD, CSMA/CA
- LANs
  - Ethernet
  - MAC addresses, ARP
  - Switches
  - Routing between subnets
  - VLANs

Multiple access links, protocols

two types of “links”:

- point-to-point
  - point-to-point link between Ethernet switch, host
  - PPP for dial-up access
- broadcast (shared wire or medium)
  - old-school Ethernet
  - upstream HFC in cable-based access network
  - 802.11 wireless LAN, 4G/4G. satellite

shared wire (e.g., cabled Ethernet)

shared radio: 4G/5G

shared radio: WiFi



shared radio: satellite

humans at a cocktail party (shared air, acoustical)

Multiple access protocols

- single shared broadcast channel
  - Shared wire (ethernet), shared radio (WiFi, 5G, Satellite)
- two or more simultaneous transmissions by nodes: interference
  - *collision* if node receives two or more signals at the same time

multiple access protocol

- distributed algorithm that determines how nodes share channel, i.e., determine when node can transmit
- communication about channel sharing must use channel itself!
  - no out-of-band channel for coordination

An ideal multiple access protocol

given: multiple access channel (MAC) of rate *R* bps

desiderata:

1. when one node wants to transmit, it can send at rate *R*.
2. when *M* nodes want to transmit, each can send at average rate *R/M*
3. fully decentralized:
   - no special node to coordinate transmissions
   - no synchronization of clocks, slots
4. simple

MAC protocols: taxonomy

three broad classes:

- channel partitioning
  - divide channel into smaller “pieces” (time slots, frequency, code)
  - allocate piece to node for exclusive use
- random access
  - channel not divided, allow collisions
  - “recover” from collisions
- “taking turns”
  - nodes take turns, but nodes with more to send can take longer turns

Link layer, LANs: roadmap

- introduction
- multiple access protocols
  - Channel partitioning
  - Random Access protocols
    - Slotted ALOHA, CSMA/CD, CSMA/CA
- LANs
  - Ethernet
  - Switches
  - addressing, ARP
  - VLANs

Channel partitioning MAC protocols: TDMA

TDMA: time division multiple access

- access to channel in “rounds”
- each station gets fixed length slot (length = packet transmission time) in each round
- unused slots go idle
- example: 6-station LAN, 1,3,4 have packets to send, slots 2,5,6 idle



Channel partitioning MAC protocols: FDMA

FDMA: frequency division multiple access

- channel spectrum divided into frequency bands
- each station assigned fixed frequency band
- unused transmission time in frequency bands go idle
- example: 6-station LAN, 1,3,4 have packet to send, frequency bands 2,5,6 idle



Link layer, LANs: roadmap

- introduction
- multiple access protocols
  - Channel partitioning
  - Random Access protocols
    - Slotted ALOHA, CSMA/CD, CSMA/CA
- LANs
  - Ethernet
  - MAC addresses, ARP
  - Switches
  - Routing between subnets
  - VLANs

Random access protocols

- when node has packet to send
  - transmit at full channel data rate R
  - no *a priori* coordination among nodes
- two or more transmitting nodes: "collision"
- random access protocol specifies:
  - how to detect collisions
  - how to recover from collisions (e.g., via delayed retransmissions)
- examples of random access MAC protocols:
  - ALOHA, slotted ALOHA
  - CSMA, CSMA/CD, CSMA/CA

Slotted ALOHA



assumptions:

- all frames same size
- time divided into equal size slots (time to transmit 1 frame)
- nodes start to transmit only slot beginning
- nodes are synchronized
- if 2 or more nodes transmit in a slot, all nodes detect collision

operation:

- when node obtains fresh frame, transmits in next slot
  - *if no collision:* node can send new frame in next slot
  - *if collision:* node retransmits frame in each subsequent slot with probability *p* until success

randomization – *why*?

Slotted ALOHA



C: collision
S: success
E: empty

Pros:

- single active node can continuously transmit at full rate of channel
- highly decentralized: only slots in nodes need to be in sync
- simple

Cons:

- collisions, wasting slots
- idle slots
- nodes may be able to detect collision in less than time to transmit packet
- clock synchronization

Slotted ALOHA: efficiency

efficiency: long-run fraction of successful slots (many nodes, all with many frames to send)

- *suppose: N* nodes with many frames to send, each transmits in slot with probability *p*
  - prob that given node has success in a slot = $p(1-p)^{N-1}$
  - prob that *any* node has a success = $Np(1-p)^{N-1}$
  - max efficiency: find p^* that maximizes $Np(1-p)^{N-1}$
  - for many nodes, take limit of $Np^*(1-p^*)^{N-1}$ as *N* goes to infinity, gives:

max efficiency = 1/e = .37

- *at best:* channel used for useful transmissions 37% of time!

Pure ALOHA

- unslotted Aloha: simpler, no synchronization
  - when frame first arrives: transmit immediately
- collision probability increases with no synchronization:
  - frame sent at t_0 collides with other frames sent in $[t_0-1,t_0+1]$



- pure Aloha efficiency: 18% !

CSMA (carrier sense multiple access)

simple CSMA: listen before transmit:

- if channel sensed idle: transmit entire frame
- if channel sensed busy: defer transmission

- human analogy: don't interrupt others!

p-persistent CSMA

- if channel sensed idle: transmit with probability *p*
- if channel sensed busy: defer transmission

CSMA: collisions

- collisions can *still* occur with carrier sensing:
  - propagation delay means two nodes may not hear each other's just-started transmission
- collision: entire packet transmission time wasted
  - distance & propagation delay play role in determining collision probability



CSMA/CD:

- CSMA/CD reduces the amount of time wasted in collisions
  - transmission aborted on collision detection



Ethernet CSMA/CD algorithm

1. Ethernet receives datagram from network layer, creates frame
2. If Ethernet senses channel:
   if idle: start frame transmission.
   if busy: wait until channel idle, then transmit
3. If entire frame transmitted without collision - done!
4. If another transmission detected while sending: abort, send jam signal
5. After aborting, enter *binary (exponential) backoff:*
   - after *m*th collision, chooses *K* at random from $\{0,1,2, \ldots, 2^m-1\}$. Ethernet waits $K \cdot 512$ bit times, returns to Step 2
   - more collisions: longer backoff interval

CSMA/CD efficiency

- T_{prop} = max prop delay between 2 nodes in LAN
- t_{trans} = time to transmit max-size frame

$$efficiency = \frac{1}{1 + 5t_{prop}/t_{trans}}$$

- efficiency goes to 1
  - as t_{prop} goes to 0
  - as t_{trans} goes to infinity
- better performance than ALOHA: and simple, cheap, decentralized!

(WiFi) 802.11 MAC Protocol: CSMA/CA

- avoid collisions: two or more nodes transmitting at same time
- 802.11: CSMA - sense before transmitting
  - don't collide with detected ongoing transmission by another node
- 802.11: *no* collision detection!
  - difficult to sense collisions: high transmitting signal, weak received signal due to fading
  - can't sense all collisions in any case: hidden terminal, fading
  - goal: *avoid collisions:* CSMA/CollisionAvoidance





(WiFi) 802.11 MAC Protocol: CSMA/CA

802.11 sender

1 if sense channel idle for **DIFS** then
transmit entire frame (no CD)

2 if sense channel busy then
- start random backoff timer
- If timer expires and channel busy: sense channel
- If timer expires and channel idle: transmit

3 if no ACK for tx frame, increase random backoff interval

802.11 receiver

if frame received OK
return ACK after **SIFS** (ACK needed due to hidden terminal problem)



Avoiding collisions (more)

idea: sender "reserves" channel use for data frames using small reservation packets

- sender first transmits *small request-to-send* (RTS) packet to BS using CSMA
  - RTSs may still collide with each other (but they're short)
- BS broadcasts *clear-to-send* CTS in response to RTS
- CTS heard by all nodes
  - sender transmits data frame
  - other stations defer transmissions

Collision Avoidance: RTS-CTS exchange



Check: https://www.tkn.tu-berlin.de/teaching/rn/animations/csma/

Link layer, LANs: roadmap

- introduction
- multiple access protocols
  - Channel partitioning
  - Random Access protocols
    - Slotted ALOHA, CSMA/CD, CSMA/CA
- LANs
  - Ethernet
  - MAC addresses, ARP
  - Switches
  - Routing between subnets
  - VLANs

Ethernet

"dominant" wired LAN technology:

- first widely used LAN technology
- simpler, cheap
- kept up with speed race: 10 Mbps – 400 Gbps
- single chip, multiple speeds (e.g., Broadcom BCM5761)

Metcalfe's Ethernet sketch



Bob Metcalfe: Ethernet co-inventor, 2022 ACM Turing Award recipient



https://www.uspto.gov/learning-and-resources/journeys-innovation/audio-stories/defying-doubters

Ethernet: physical topology

- bus: popular through mid 90s
  - all nodes in same collision domain (can collide with each other)
- switched: prevails today
  - active link-layer 2 *switch* in center
  - each “spoke” runs a (separate) Ethernet protocol (nodes do not collide with each other)

bus: coaxial cable





switched

Ethernet frame structure

sending interface encapsulates IP datagram (or other network layer protocol packet) in Ethernet frame

preamble:

- used to synchronize receiver, sender clock rates
- 7 bytes of 10101010 followed by one byte of 10101011

Ethernet frame structure (more)



- addresses: 6 byte source, destination MAC addresses
  - if adapter receives frame with matching destination address, or with broadcast address (e.g., ARP packet), it passes data in frame to network layer protocol
  - otherwise, adapter discards frame
- type: indicates higher layer protocol
  - mostly IP but others possible, e.g., Novell IPX, AppleTalk
  - used to demultiplex up at receiver
- CRC: cyclic redundancy check at receiver
  - error detected: frame is dropped

Ethernet: unreliable, connectionless

- connectionless: no handshaking between sending and receiving NICs
- unreliable: receiving NIC doesn't send ACKs or NAKs to sending NIC
  - data in dropped frames recovered only if initial sender uses higher layer rdt (e.g., TCP), otherwise dropped data lost
- Ethernet's MAC protocol: unslotted CSMA/CD with binary backoff

Link layer, LANs: roadmap

- introduction
- multiple access protocols
  - Channel partitioning
  - Random Access protocols
    - Slotted ALOHA, CSMA/CD, CSMA/CA
- LANs
  - Ethernet
  - MAC addresses, ARP
  - Switches
  - Routing between subnets
  - VLANs

MAC addresses

each interface on LAN

- has unique 48-bit MAC address
- has a locally unique 32-bit IP address (as we've seen)

MAC address: used "locally" to get frame from one interface to another physically-connected interface (same subnet, in IP-addressing sense)



ARP: address resolution protocol

Question: how to determine interface's MAC address, knowing its IP address?



ARP table: each IP node (host, router) on LAN has table

- IP/MAC address mappings for some LAN nodes:

  < IP address; MAC address; TTL>
- TTL (Time To Live): time after which address mapping will be forgotten (typically 20 min)

ARP protocol in action

example: A wants to send datagram to B

- B's MAC address not in A's ARP table, so A uses ARP to find B's MAC address

A broadcasts ARP query, containing B's IP addr

1
- destination MAC address = FF-FF-FF-FF-FF-FF
- all nodes on LAN receive ARP query

ARP table in A

IP addr	MAC addr	TTL



ARP protocol in action

example: A wants to send datagram to B

- B's MAC address not in A's ARP table, so A uses ARP to find B's MAC address



ARP protocol in action

example: A wants to send datagram to B

- B's MAC address not in A's ARP table, so A uses ARP to find B's MAC address

ARP table in A

IP addr	MAC addr	TTL
137.196.7.14	58-23-D7-FA-20-B0	500



③ A receives B's reply, adds B entry into its local ARP table

Link layer, LANs: roadmap

- introduction
- multiple access protocols
  - Channel partitioning
  - Random Access protocols
    - Slotted ALOHA, CSMA/CD, CSMA/CA
- LANs
  - Ethernet
  - MAC addresses, ARP
  - Switches
  - Routing between subnets
  - VLANs

Switched Ethernet LAN



Ethernet switch

- Switch is a link-layer device: takes an *active* role
  - store, forward Ethernet (or other type of) frames
  - examine incoming frame's MAC address, *selectively* forward frame to one-or-more outgoing links
  - when frame is to be forwarded on a segment, uses CSMA/CD to access segment
- transparent: hosts *unaware* of presence of switches
  - Switching function does not require MAC address of the switch
- plug-and-play, self-learning
  - switches do not need to be configured

Switch: multiple simultaneous transmissions

- hosts have dedicated, direct connection to switch
- switches buffer packets
- Ethernet protocol used on *each* incoming link, so:
  - no collisions; full duplex
  - each link is its own collision domain
- switching: A-to-A' and B-to-B' can transmit simultaneously, without collisions



switch with six interfaces (1,2,3,4,5,6)

Switch forwarding table

Q: how does switch know A' reachable via interface 4, B' reachable via interface 5?

A: each switch has a switch table, each entry:

- (MAC address of host, interface to reach host, time stamp)
- looks like a routing table!

Q: how are entries created, maintained in switch table?

- something like a routing protocol?



Self-learning, forwarding: example

- frame destination, A’, location unknown: flood
- destination A location known: selectively send on just one link
- Record the interface of A’



MAC addr	interface	TTL
A	*1*	*60*
A ’	*4*	*60*

switch table (initially empty)

Switch vs Router?

Link layer, LANs: roadmap

- introduction
- multiple access protocols
  - Channel partitioning
  - Random Access protocols
    - Slotted ALOHA, CSMA/CD, CSMA/CA
- LANs
  - Ethernet
  - MAC addresses, ARP
  - Switches
  - Routing between subnets
  - VLANs

Routing to another subnet: addressing

walkthrough: sending a datagram from *A* to *B* via *R*

- focus on addressing – at IP (datagram) and MAC layer (frame) levels
- assume that:
  - A knows B's IP address
  - A knows IP address of first hop router, R (how?)
  - A knows R's MAC address (how?)



Routing to another subnet: addressing

- A creates IP datagram with IP source A, destination B
- A creates link-layer frame containing A-to-B IP datagram
  - R's MAC address is frame's destination



Routing to another subnet: addressing

- frame sent from A to R
- frame received at R, datagram removed, passed up to IP



Routing to another subnet: addressing

- R determines outgoing interface, passes datagram with IP source A, destination B to link layer
- R creates link-layer frame containing A-to-B IP datagram. Frame destination address: B's MAC address



Routing to another subnet: addressing

- R determines outgoing interface, passes datagram with IP source A, destination B to link layer
- R creates link-layer frame containing A-to-B IP datagram. Frame destination address: B's MAC address
- transmits link-layer frame



Routing to another subnet: addressing

- B receives frame, extracts IP datagram destination B
- B passes datagram up protocol stack to IP



Identify Src/Dst MAC addresses for A to C