

Comparison of IC Implementation Technologies




Outline

- Full-Custom Design
- Cell-based Design
- Gate Array
- Structured ASIC
- FPLD


Introduction to Integrated Circuits

small size ic


- *Integrated circuits* combine dozens (SSI) to millions (VLSI) of transistors into a single chip.
- The locations and connections of the transistors are defined by several *masks* in the *fabrication* process.




Simplified View of IC Fabrication



IC Implementation Options



Full-Custom Layout Example



Intel 4004 ('71)

Full-Custom Design

- Designers determine and draw all device geometries.
- All mask layers are customized.
- E.g. microprocessor, memory
- Pros: complete design flexibility, high degree of optimization in performance and area.
- Cons: large amount of design effort and time, expensive to design and manufacture.
- For applications that require high volume, cost can be amortized over the high volume.

攤平



How can we shorten the time from design to a physical IC?

Cell-Based Design

- Reuse!
- Large complex cells/blocks e.g. marcos, IPs.
- Small cells e.g. standard cells.

ex : Intel CPU會放
ARM的micro processor

Standard Cell-Based Design Example




Standard-Cell-Based Design

- Use predesigned, pretested and precharacterized logic cells from standard-cell library as building blocks.
- Standard cells are of the same height.
- Cells are laid out in rows.
- Chip layout (placement and routing) are much easier than in full-custom design.
- All masks need to be customized to fabricate a new chip.
- Pros: save design time and money, reduce risk compared to full-custom ICs.
cell based是減少design的時間 而非製造的時間 那些mask還是要重新設計
- Cons: somewhat less efficient in size and performance than full-custom ICs.

How about half-made chips?

Mask Programmable Gate-Array



Source: NEC Corp.

transistor都已經放好了 只要接metal那些的 減少製造的成本和時間

Mask Programmable Gate-Array

- A gate-array is partly pre-fabricated.
- Identical base cells are pre-fabricated in the form of a 2-D array
- Wires between transistors inside the cells or across the cells are custom fabricated for each customer.
- So custom masks are made for wiring only.
- **Pros:** cost saving (fabrication cost of a large number of identical template wafers is amortized over different customers), shorter manufacture lead time.
- **Cons:** performance not as good as full-custom or standard-cell-based ICs.

Structured ASIC

- Like gate-array, an array of tiles is pre-fabricated.
- Unlike gate-array, the majority of the metal layers are also pre-fabricated to form local and global interconnect.
- Power, clock and test structures are predefined in most structured ASICs.
- Structured ASICs may also have “built-in” macros common for certain applications.
- Customize only upper metal layers for customers.

只能設計高層的metal

Structured ASIC Example




Figure 1: Structured ASIC Block Diagram





Figure 2: Structured ASIC Metal Utilization

Field Programmable Logic Device (FPLD)

- Off-the-shelf
- Contains programmable logic blocks + programmable interconnect network



Field Programmable Logic Device

- General-purpose chip for implementing logic circuitry.
- Logic cells and interconnect can be programmed by end-user to implement specific circuitry.
- Transistors and wires are already prefabricated on a PLD.
- Already packaged and fully tested.
- No need to create custom masks for each customer.
- **Pros:** low non-recurring-engineering cost (ideal for low-volume production), fast turnaround time.
- **Cons:** lower performance and larger chip size.


IC Economics

- Total cost = Variable cost per unit * Volume
+ Fixed cost
- Fixed cost: independent of volume produced e.g.
costs of design and simulation, masks,
equipments, etc.
- Variable cost: dependent on volume e.g. cost of
the parts, assembly costs, other manufacturing
costs, testing costs, etc.

(material cost per IC + testing cost per IC + packaging cost + ...) / Yield * Volume

良率高就不用浪費cost做一堆

Cost vs Design Volume Example



variable cost
每一個花多少
低的量多就能把價格壓下來

Comparison of Technologies

	Full-custom	Standard cell-based	Gate array	FPLD
Cell size	variable	fixed height	fixed	fixed
Cell type	variable	variable	fixed	programmable
Cell placement	variable	in row	fixed	fixed
Inter-connections	variable	variable	variable	programmable
Custom layers	all layers	all layers	routing layers only	none

Comparison of Technologies

	Full-custom	Standard cell-based	Gate array	FPLD
Performance	+++	++	+	-
Area	+++ <small>smallest</small>	++	+	--
High-volume cost	++	++	+	+
Low-volume cost	---	--	+	+++
Fabrication time	---	--	-	+++
Time to market	---	--	++	+++
Risk reduction	---	--	-	+++
Design modification	---	--	-	+++

Summary

- Different implementation options cater for different needs and concerns.
- IC design trend: going more regular to cope with increasing design complexity.
- Going more cell-based/array-based.