Telegraf Integration into Kepler


Introduction

Kepler (Kubernetes-based Efficient Power Level Exporter) is a Prometheus exporter. It uses eBPF to probe CPU performance counters and Linux kernel tracepoints [1] whereas Telegraf is an agent for collecting, processing, aggregating, and writing metrics. [2] This document covers the steps for integrating Telegraf with Kepler.

Benefits of Integrating Telegraf with Kepler:

Integrating Telegraf with Kepler helps user to gather additional platform level metrics on top of Kepler metrics. Kepler provide useful container and Node metrics. On the other hand, through Telegraf, metrics like Power Supply Current output (%) can be gathered using IPMI Sensor plugin. Also, it can help to gather DPDK related metrics which is currently not possible through Kepler. By correlating power, CPU usage metrics from Kepler and DPDK metrics from Telegraf, user might better understand about power usage of their packet processing application and can used them as inputs to identify opportunities for power optimization. Hence, Kepler and Telegraf metrics together can serve use cases that help end users to understand and optimize power usage by their various networking applications.

Setup



Setup Details:

The Control plane server details are as follows:

Model	Intel(R) Xeon(R) Gold 6230N CPU @
	2.30GHz
Sockets	2
Cores per sockets	20

Total Cores	80
Software	Ubuntu 22.04.1 LTS

Download and Install kepler:

There are various ways Kepler can be downloaded and installed. For more details on each steps please refer to the <u>Kepler documents</u>.

```
root@:~# git clone https://github.com/sustainable-computing-io/kepler.git
root@:~# cd kepler/
root@:~# make build-manifest OPTS="BM_DEPLOY PROMETHEUS_DEPLOY"
root@:~# cd _output/generated-manifest/
root@:~# vi deployment.yaml
root@:~# kubectl apply -f output/generated-manifest/deployment.yaml
```

Installation of Kepler can be confirmed through following commands:

```
root@:~# docker ps -a | grep 'kepler'
   530a71f0067f
                       quay.io/sustainable_computing_io/kepler
                                                                             "/bin/sh -
   c '/usr/bi..." 33 seconds ago
                                       Up 31 seconds
   k8s_kepler-exporter_kepler-exporter-bzj9b_kepler_827ee818-9f5a-460c-a368-
   fc90fde5d378 0
   decae0dc60e2
                        k8s.gcr.io/pause:3.3
                                                                             "/pause"
   38 seconds ago Up 35 seconds
   k8s POD kepler-exporter-bzj9b kepler 827ee818-9f5a-460c-a368-fc90fde5d378 0
root@:~# kubectl get pod -n kepler
NAME READY STATUS RESkepler-exporter-8h8x7 1/1 Running 0 kepler-exporter-bzj9b 1/1 Running 0
                                            RESTARTS AGE
                                          0
                                                       635
                                                       63s
root@:~# kubectl port-forward kepler-exporter-jdklk 9102:9102 -n kepler --
address='0.0.0.0'
```

Download and start the Telegraf:

Telegraf can be installed on the system in various ways. Here it has been done by downloading and building it from source.

Telegraf requires Go version >=1.22 which can be installed : <u>Install Go</u> and the Makefile requires GNU make.

Telegraf shares the same minimum requirements as Go:

- Linux kernel version 2.6.32 or later
- Windows 10 or later
- FreeBSD 12 or later
- macOS 10.15 Catalina or later

Clone the Telegraf repository:

```
root@:~# git clone https://github.com/influxdata/telegraf.git
```

```
Run make build from the source directory
```

```
root@:~# cd telegraf
root@:~# make build
```

Generate a Telegraf config file

Edit the generated config file to enable required plugins. For this integration activity following plugins should be enabled:

Input Plugins: Intel PowerStat plugin, Intel PMU plugin, and IPMI sensor input

Output Plugin: Prometheus output plugin must be enabled in Telegraf config in order to store the metrics in Prometheus database.

Below is the sample config that have been used to enable all the above-mentioned plugins. Although, user can enable any other desired plugin by commenting out the respective section.

```
root@:~# vi telegraf.conf
# Global tags can be specified here in key="value" format.
[global_tags]
 # dc = "us-east-1" # will tag all metrics with dc=us-east-1
  # rack = "1a"
 ## Environment variables can be used as tags, and throughout the config file
  # user = "$USER"
# Configuration for telegraf agent
 ## Default data collection interval for all inputs
 interval = "10s"
  ## Rounds collection interval to 'interval'
  ## ie, if interval="10s" then always collect on :00, :10, :20, etc.
 round interval = true
  ## Telegraf will send metrics to outputs in batches of at most
  ## metric batch size metrics.
  ## This controls the size of writes that Telegraf sends to output plugins.
 metric batch size = 1000
  \#\# Maximum number of unwritten metrics per output. Increasing this value
  ## allows for longer periods of output downtime without dropping metrics at the
  ## cost of higher maximum memory usage.
 metric buffer limit = 10000
  ## Collection jitter is used to jitter the collection by a random amount.
  ## Each plugin will sleep for a random time within jitter before collecting.
  ## This can be used to avoid many plugins querying things like sysfs at the
  ## same time, which can have a measurable effect on the system.
 collection jitter = "0s"
  ## Default flushing interval for all outputs. Maximum flush_interval will be
  ## flush interval + flush jitter
  flush_interval = "10s"
  ## Jitter the flush interval by a random amount. This is primarily to avoid
  ## large write spikes for users running a large number of telegraf instances.
  ## ie, a jitter of 5s and interval 10s means flushes will happen every 10-15s
 flush jitter = "0s"
  \#\# By default or when set to "0s", precision will be set to the same
  ## timestamp order as the collection interval, with the maximum being 1s.
     ie, when interval = "10s", precision will be "1s"
  ##
          when interval = "250ms", precision will be "1ms"
  ## Precision will NOT be used for service inputs. It is up to each individual
  ## service input to set the timestamp at the appropriate precision.
  ## Valid time units are "ns", "us" (or "\u00fcs"), "ms", "s".
 precision = ""
  ## Log at debug level.
  # debug = false
```

```
## Log only error level messages.
  # quiet = false
 ## Log target controls the destination for logs and can be one of "file",
 ## "stderr" or, on Windows, "eventlog". When set to "file", the output file
 ## is determined by the "logfile" setting.
 # logtarget = "file"
 ## Name of the file to be logged to when using the "file" logtarget. If set to
 ## the empty string then logs are written to stderr.
 # logfile = ""
 ## The logfile will be rotated after the time interval specified. When set
 \#\# to 0 no time based rotation is performed. Logs are rotated only when
 \ensuremath{\#\#} written to, if there is no log activity rotation may be delayed.
 # logfile_rotation_interval = "0d"
 ## The logfile will be rotated when it becomes larger than the specified
 ## size. When set to 0 no size based rotation is performed.
 # logfile_rotation_max_size = "OMB"
 ## Maximum number of rotated archives to keep, any older logs are deleted.
 ## If set to -1, no archives are removed.
 # logfile_rotation_max_archives = 5
 ## Pick a timezone to use when logging or type 'local' for local time.
 ## Example: America/Chicago
 # log_with_timezone = ""
 ## Override default hostname, if empty use os. Hostname()
 hostname = ""
 ## If set to true, do no set the "host" tag in the telegraf agent.
 omit hostname = false
OUTPUT PLUGINS
# # Configuration for the Prometheus client to spawn
[[outputs.prometheus client]]
 ## Address to listen on
 listen = ":9273"
 ## Metric version controls the mapping from Telegraf metrics into
 ## Prometheus format. When using the prometheus input, use the same value in
 ## both plugins to ensure metrics are round-tripped without modification.
 ##
 ##
     example: metric_version = 1;
 ##
              metric version = 2; recommended version
 # metric version = 1
INPUT PLUGINS
# # Intel PowerStat plugin enables monitoring of platform metrics (power, TDP) and
Core metrics like temperature, power and utilization.
[[inputs.intel_powerstat]]
 ## All global metrics are always collected by Intel PowerStat plugin.
 ## User can choose which per-CPU metrics are monitored by the plugin in
cpu metrics array.
 ## Empty array means no per-CPU specific metrics will be collected by the plugin
 in this case only platform level
 ## telemetry will be exposed by Intel PowerStat plugin.
 #the package metrics setting:
```

```
package metrics = ["current power consumption", "current dram power consumption",
"thermal design power", "max turbo frequency", "uncore frequency",
"cpu base_frequency"]
  ## Supported options:
## "cpu_frequency", "cpu_busy_frequency", "cpu_temperature",
"cpu_c1_state_residency", "cpu_c6_state_residency", "cpu_busy_cycles"
    cpu_metrics = ["cpu_frequency", "cpu_busy_frequency", "cpu_temperature",
"cpu_c1_state_residency", "cpu_c6_state_residency", "cpu_busy_cycles"]
# Intel Performance Monitoring Unit plugin exposes Intel PMU metrics available
through Linux Perf subsystem
# This plugin ONLY supports Linux on amd64
[[inputs.intel pmu]]
  ## List of filesystem locations of JSON files that contain PMU event definitions.
 event_definitions = ["/root/.cache/pmu-events/GenuineIntel-6-55-7-core.json",
"/root/.cache/pmu-events/GenuineIntel-6-55-7-uncore.json"]
  ## List of core events measurement entities. There can be more than one
core events sections.
  [[inputs.intel pmu.core events]]
    ## List of events to be counted. Event names shall match names from
event definitions files.
    \#\overline{\#} Single entry can contain name of the event (case insensitive) augmented with
config options and perf modifiers.
    ## If absent, all core events from provided event_definitions are counted
skipping unresolvable ones.
    events = ["INST RETIRED.ANY",
"CPU_CLK_UNHALTED.THREAD_ANY:config1=0x4043200000000k"]
    ## Limits the counting of events to core numbers specified.
    ## If absent, events are counted on all cores.
    ## Single "0", multiple "0,1,2" and range "0-2" notation is supported for each
array element.
    ## example: cores = ["0,2", "4", "12-16"]
    cores = ["0"]
    ## Indicator that plugin shall attempt to run core events.events as a single
perf group.
    ## If absent or set to false, each event is counted individually. Defaults to
    ## This limits the number of events that can be measured to a maximum of
available hardware counters per core.
    ## Could vary depending on type of event, use of fixed counters.
    # perf group = false
    ## Optionally set a custom tag value that will be added to every measurement
within this events group.
    ## Can be applied to any group of events, unrelated to perf group setting.
    # events tag = ""
  ## List of uncore event measurement entities. There can be more than one
uncore events sections.
  [[inputs.intel pmu.uncore events]]
    ## List of events to be counted. Event names shall match names from
event definitions files.
    ## Single entry can contain name of the event (case insensitive) augmented with
config options and perf modifiers.
    ## If absent, all uncore events from provided event definitions are counted
skipping unresolvable ones.
    events = ["UNC CHA CLOCKTICKS", "UNC CHA TOR OCCUPANCY.IA MISS"]
    ## Limits the counting of events to specified sockets.
    ## If absent, events are counted on all sockets.
    \#\# Single "0", multiple "0,1" and range "0-1" notation is supported for each
array element.
    ## example: sockets = ["0-2"]
    sockets = ["0"]
```

```
## Indicator that plugin shall provide an aggregated value for multiple units
of same type distributed in an uncore.
   ## If absent or set to false, events for each unit are exposed as separate
metric. Defaults to false.
    # aggregate uncore units = false
    ## Optionally set a custom tag value that will be added to every measurement
within this events group.
   # events_tag = ""
^{\sharp} Read metrics from the bare metal servers via IPMI
[[inputs.ipmi sensor]]
  ## optionally specify the path to the ipmitool executable
  # path = "/usr/bin/ipmitool"
 ##
 ## Setting 'use_sudo' to true will make use of sudo to run ipmitool.
 ## Sudo must be configured to allow the telegraf user to run ipmitool
 ## without a password.
 use sudo = true
 ##
 ## optionally force session privilege level. Can be CALLBACK, USER, OPERATOR,
ADMINISTRATOR
 # privilege = "ADMINISTRATOR"
 ## optionally specify one or more servers via a url matching
 ## [username[:password]@][protocol[(address)]]
 ##
 ##
       root:passwd@lan(127.0.0.1)
  ##
 ## if no servers are specified, local machine sensor stats will be queried
 # servers = ["USERID:PASSWORD@lan(192.168.1.1)"]
  ## Recommended: use metric 'interval' that is a multiple of 'timeout' to avoid
  ## gaps or overlap in pulled data
 interval = "30s"
  ## Timeout for the ipmitool command to complete. Default is 20 seconds.
 timeout = "20s"
 ## Schema Version: (Optional, defaults to version 1)
 metric version = 2
  ## Optionally provide the hex key for the IMPI connection.
  # hex_key = ""
 ## If ipmitool should use a cache
 \#\# for me ipmitool runs about 2 to 10 times faster with cache enabled on HP G10
servers (when using ubuntu20.04)
  ## the cache file may not work well for you if some sensors come up late
  # use_cache = false
 ## Path to the ipmitools cache file (defaults to OS temp dir)
 ## The provided path must exist and must be writable
 # cache path = ""
```

Run Telegraf with the plugins defined in config file:

```
root@:~#./telegraf --config telegraf.conf
```

Download and start the Prometheus container:

Prometheus can be installed on a system in various ways. Here it is downloaded and installed as a container.

Create a Prometheus configuration file that is scrapping from both Kepler and Telegraf instance:


Sample Prometheus configuration file is as follows:

```
# my global config
global:
                        15s # Set the scrape interval to every 15 seconds.
  scrape interval:
Default is every 1 minute.
  evaluation interval: 15s # Evaluate rules every 15 seconds. The default
is every 1 minute.
# scrape timeout is set to the global default (10s).
# A scrape configuration containing exactly one endpoint to scrape:
# Here it's Prometheus itself.
scrape configs:
# The job name is added as a label `job=<job name>` to any timeseries
scraped from this config.
      - job_name: 'kepler'
        static configs:
            - targets: ['192.168.1.50:9102']
      - job_name: 'telegraf'
        static configs:
            - targets: ['10.243.23.142:9273']
```

Run the Prometheus container with the created Prometheus configuration file:

```
root@:~# docker run -d -p 9090:9090 -v $PWD/prometheus.yaml:/etc/prometheus/prometheus.yml prom/prometheus
```

On the Prometheus GUI at localhost:9090, it can be confirmed that Prometheus is scrapping from Kepler and Telegraf.



Download and Start Grafana container

Like, Prometheus, Grafana can be installed on the system in various ways. Here, we are installing Grafana's container image.

root@:~# docker run -d --network host --name grafana grafana/grafana

Once Grafana container is running access the Grafana GUI at localhost:3000. Login with default credentials. After login, The Prometheus database needs to be added as a data source into Grafana GUI. Click on "DATA SOURCES" -> "Add your first data source"

Dashboard

Once Prometheus has been added as a data source, create a dashboard by exporting <u>Kepler-Exporter.json</u>, a default Grafana dashboard for Kepler.

This default Kepler dashboard can be edited in order to display Telegraf metric along with Kepler metrics.

For example in below shown example, right hand shows Power related metrics collected by Telegraf whereas left hand shows Power related metrics by Kepler per namespace:



On Kepler side:

PKG → Represents kepler_container_package_joules_total metrics which measures the cumulative energy consumed by the CPU socket, including all cores and uncore components (e.g. last-level cache, integrated GPU and memory controller).

DRAM → Represents kepler_container_dram_joules_total metric which describes the total energy spent in DRAM by a container.

Other → Represents kepler_container_other_joules_total metric measures the cumulative energy consumption on other host components besides the CPU and DRAM. Generally, this metric is the host energy consumption (from acpi) less the RAPL Package and DRAM.

On Telegraf side:

Total PKG current Power → Represents powerstat_package_current_power_consumptions metrics which showcase Current power consumption of processor package. On Grafana it is the sum of the metrics on both the sockets i.e. powerstat_package_current_power_consumptions of socket 0 + powerstat_package_current_power_consumptions of socket 1.

Total DRAM power -> Represents powerstat_package_current_dram_power_consumptions metrics which describes the total energy spent in DRAM of both the sockets.

Total Thermal design Power - > Represents


powerstat_package_current_thermal_power_consumptions metrics which describes maximum Thermal Design Power (TDP) available for processor package. On Grafana it is the sum of the metrics on both the sockets i.e. powerstat_package_current_thermal _power_consumptions of socket 0 + powerstat_package_current_thermal_power_consumptions of

_power_consumptions of socket 0 + powerstat_package_current_thermal_power_consumptions of socket 1.

Total DRAM Power metrics number on Kepler side and Telegraf side aligns with each other(approximately).

Telegraf- IPMI metric

On Kepler dashboard, we are also pulling IPMI metrics which show Power Supply Current out %.



References:

- [1] https://sustainable-computing.io/
- [2] https://github.com/influxdata/telegraf