
#### **EEE2001B Professional Core**



# Computer Organization & Operating Systems (COOS)





Course Code	EEE2001B			
Course Category	Professional Core			
Course Title	Computer Organization and Operating Systems			
Weekly Teaching Hrs. and	L	T	Laboratory	Credits
Credits	2	-	-	2 + 0 + 0

**Pre-requisites**: Fundamentals of Computers, Data Structures, Computer Organization


#### Course Objectives:

- To discuss a basic structure of computers.
- To understand the I/O ports and memory system of the computers.
- To acknowledge the concepts of operating systems and process management.
- 4. To explain the concepts of Memory Management and I/O management

#### Course Outcomes: After completion of this course students will be able to

- Understand the basics of computer organization.
- Learn about I/O ports and memory system of the computer.
- Comprehend key mechanisms of the Operating System functions.
- Assess memory management issues.

### **Text and Reference Books**




#### Text Books:

- Carl Hamacher, Zvonko Vranesic, Safwat Zaky: Computer Organization, 5th Edition, Tata McGraw Hill, 2002.
- Carl Hamacher, Zvonko Vranesic, Safwat Zaky, Naraig Manjikian: Computer Organization and Embedded Systems, 6<sup>th</sup> Edition, Tata McGraw Hill, 2012.

### Reference Books:

 William Stallings: Computer Organization & Architecture, 9<sup>th</sup> Edition, Pearson, 2015.

# Unit-1 (Part 1) Basic Structure of Computers




### **Syllabus Points**

- Basic operational concepts
- Bus structures
- Performance processor clock, basic performance equation, clock rate
- Performance measurement
- Memory location and addresses
- Memory operations
- Instructions and instruction sequencing
- Addressing modes
- Assembly language
- Basic input and output operations
- Stacks and queues
- Subroutines
- Additional instructions
- Encoding of machine instructions







- Progress in computer technology
  - Underpinned by Moore's Law
- Makes novel applications feasible
  - Computers in automobiles
  - Cell phones
  - Human genome project
  - World Wide Web
  - Search Engines
- Computers are universal

### **Classes of Computers**


- Desktop/laptop computers
  - General purpose, variety of software
  - Subject to cost/performance tradeoff
- Workstations
  - More computing power used in engg. applications, graphics etc.
- Enterprise System/ Mainframes
  - Used for business data processing
- Server computers (Low End Range)
  - Network based
  - High capacity, performance, reliability
  - Range from small servers to building sized
- Supercomputer (High End Range)
  - Large scale numerical calculation such as weather forecasting, aircraft design
- Embedded computers
  - Hidden as components of systems

7

12/15/2 Stringent power/performance/cost-constraintse





### **Functional Units**



### **Functional Units**










Figure 1.1. Basic functional units of a computer.

### Information Handled by a Computer




- Instructions/machine instructions
- Govern the transfer of information within a computer as well as between the computer and its I/O devices
- the arithmetic and logic to be Specify operations performed
- Program
- Data
- Used as operands by the instructions
- Source program
- Encoded in binary code 0 and 1

### **Memory Unit**



- Store programs and data
- Two classes of storage
- Primary storage
- Fast
- Programs must be stored in memory while they are being executed
- Large number of semiconductor storage cells
- Processed in words
- Address
- RAM and memory access time
- Memory hierarchy cache, main memory
- Secondary storage larger and cheaper

### **Data Representation**



Bit – 1 bit 0 or 1

4 bit = nibble

1Byte – 8 bits

2 byte − 16 bits ☐ 1 word

32 bits ☐ 2 words ☐ double word

64 bit 

4 words 

quad word

# **Arithmetic and Logic Unit** (ALU)



- Most computer operations are executed in ALU of the processor.
  - Load the operands into memory
  - bring them to the processor
  - perform operation in ALU
  - store the result back to memory or retain in the processor.
- Registers
- Fast control of ALU

### **Control Unit**



- All computer operations are controlled by the control unit.
- The timing signals that govern the I/O transfers are also generated by the control unit.
- Control unit is usually distributed throughout the machine instead of standing alone.
- Operations of a computer:
- Accept information in the form of programs and data through an input unit and store it in the memory
- Fetch the information stored in the memory, under program control, into an ALU, where the information is processed
- Output the processed information through an output unit
- Control all activities inside the machine through a control unit





- The computer accepts information in the form of programs and data through an input unit and stores it in the memory.
- Information stored in the memory is fetched under program control into an arithmetic and logic unit, where it is processed.
- Processed information leaves the computer through an output unit.
- All activities in the computer are directed by the control unit.



# **Basic Operational Concepts**



### Review



- Activity in a computer is governed by instructions.
- To perform a task, an appropriate program consisting of a list of instructions is stored in the memory.
- Individual instructions are brought from the memory into the processor, which executes the specified operations.
- Data to be used as operands are also stored in the memory.



#### Instruction:

1START 100

```
[Label]: Opcode operand1, operand2
     READ A
     MOV RO, A
     READ B
       MOV R1, B
    ADD Ro, R1
     MOVE C, R0
     PRINT C
    STOP
```

18





- Add LOC A, R0
- Add the operand at memory location LOCA to the operand in a register R0 in the processor.
- Place the sum into register R0.
- The original contents of LOCA are preserved.
- The original contents of R0 is overwritten.
- Instruction is fetched from the memory into the processor – the operand at LOCA is fetched and added to the contents of R0 – the resulting sum is stored in register R0.


# Separate Memory Access and ALU Operation



- Load LOC A, R1
- Add R1, R0
- Whose contents will be overwritten?

## Connection Between the Processor and the Memory





Connections between the processor and the memory.





- Instruction register (IR)
- Program counter (PC)
- General-purpose register  $(R_0 R_{n-1})$
- Memory address register (MAR)
- Memory data register (MDR)





- Programs reside in the memory through input devices
- PC is set to point to the first instruction
- The contents of PC are transferred to MAR
- A Read signal is sent to the memory
- The first instruction is read out and loaded into MDR
- The contents of MDR are transferred to IR
- Decode and execute the instruction

# Typical Operating Steps (Cont')



- Get operands for ALU
  - General-purpose register
  - Memory (address to MAR Read MDR to ALU)
- Perform operation in ALU
- Store the result back
  - To general-purpose register
  - To memory (address to MAR, result to MDR Write)
- During the execution, PC is incremented to the next instruction





- Normal execution of programs may be preempted if some device requires urgent servicing.
- The normal execution of the current program must be interrupted – the device raises an interrupt signal.
- Interrupt-service routine
- Current system information backup and restore (PC, general-purpose registers, control information, specific information)





- There are many ways to connect different parts inside a computer together.
- A group of lines that serves as a connecting path for several devices is called a bus.
- Address/data/control

#### **Bus Structure**



Single-bus




Figure 1.3. Single-bus structure.

Multiple Buses






- Different devices have different transfer/operate speed.
- If the speed of bus is bounded by the slowest device connected to it, the efficiency will be very low.
- How to solve this?
- A common approach use buffers.
   e.g.- Printing the characters



### **Performance**



#### **Performance**



- The most important measure of a computer is how quickly it can execute programs.
- Three factors affect performance:
  - Hardware design
  - Instruction set
  - Compiler





 Processor time to execute a program depends on the hardware involved in the execution of individual machine instructions.




Figure 1.5. The processor cache.





- The processor and a relatively small membery can be on a fabricated integrated circuit single chip.
  - Speed
  - Cost
  - Memory management





- Clock, clock cycle (P), and clock rate (R=1/P)
- The execution of each instruction is divided into several steps (Basic Steps), each of which completes in one clock cycle.
- Hertz cycles per second





- T processor time required to execute a program that has been prepared in high-level language
- N number of actual machine language instructions needed to complete the execution (note: loop)
- S average number of basic steps needed to execute one machine instruction. Each step completes in one clock cycle
- R clock rate
- Note: these are not independent to each other

$$_{T}=N\times S$$

R


• How to improve T?


Reduce N and S, Increase R, but these affect

# Pipeline and Superscalar Operation



- Instructions are not necessarily executed one after another.
- The value of S doesn't have to be the number of clock cycles to execute one instruction.
- Pipelining overlapping the execution of successive instructions.
- Add R1, R2, R3 at the same time processor reads next





### 1 clk cyle per phase

- 2 = Fetch and execute
- 3 instruction

NP = No. of instruction \* no. of phases = 3\*2 = 6 clk cycle

Pipelines = 1 Instruction \* 2 +(2) remaining instruction\*1

$$= 1 * 2 + 2$$

# Pipeline and Superscalar Operation



- Superscalar operation multiple instruction pipelines are implemented in the processor.
- Goal reduce S (could become <1!)</li>

## **Clock Rate**



- Increase clock rate
- Improve the integrated-circuit (IC) technology to make the circuits faster
- Reduce the amount of processing done in one basic step (however, this may increase the number of basic steps needed)
- Increases in R that are entirely caused by improvements in IC technology affect all aspects of the processor's operation equally except the time to access the main memory.





- A compiler translates a high-level language program into a sequence of machine instructions.
- To reduce N, we need a suitable machine instruction set and a compiler that makes good use of it.
- Goal reduce N×S
- A compiler may not be designed for a specific processor; however, a high-quality compiler is usually designed for, and with, a specific processor.

# **Performance Measurement**




- T is difficult to compute.
- Measure computer performance using benchmark programs.
- System Performance Evaluation Corporation (SPEC) selects and publishes representative application programs for different application domains, together with test results for many commercially available computers.
- Compile and run (no simulation)
- Reference computer

 $SPEC\ rating = \begin{array}{c} \text{Running time on the} \\ \text{referencecomputer} & \text{Running time on} \\ SPEC\ rating = \text{the computer under test} \end{array}$ 

n is the number of program in the suite

# Multiprocessors and Multicomputers




- Multiprocessor computer
- Execute a number of different application tasks in parallel
- Execute subtasks of a single large task in parallel
- All processors have access to all of the memory shared-memory multiprocessor
- Cost processors, memory units, complex interconnection networks
- Multicomputers
- Each computer only have access to its own memory
- Exchange message via a communication network messagepassing multicomputers

# Unit 1 Part –II Machine Instructions & Programs

#### **Outline**

- Numbers, Arithmetic Operations, and Characters
- Memory Locations and Addresses
- Memory Operation
- Instructions and Instruction Sequencing
- Addressing Modes
- Assembly Language
- Basic Input / Output Operations
- Stacks and Queues
- Subroutines
- Linked List
- Encoding of Machine Instructions

#### **Computer System**



3

## **Number Representation**

- Consider an n-bit vector  $B = b_{n-1} \mathsf{K} b_1 b_0$ , where  $b_i = 0$  or 1 for  $0 \le i \le n-1$
- The vector B can represent unsigned integer values V in

•here 
$$b \times 2^n - 1$$
 where  $b \times 2 + b_0 \times 1$ 

- ➤ We≺n≱ed to represent positive and negative numbers for most applications
- Three systems are used for representing such numbers
  - Sign-and-magnitude
  - ♦ 1's-complement
  - 2's-complement

- 0000 0
- 0001 1
- 0010 2
- (+12)
- (-5)
- Sign + Magnitude
- $\bullet$  + = 0
- -= 1
- 0 0101
- 1's complement [
- 10001101
- 01110010
- 2's complement
- 10001101 (Given no.)
- 01110010 (1's complement)
- 1 (add 1)
- -----
- 0111001 1

#### **Number Systems**


- In sign-and-magnitude system
  - Negative values are represented by changing the most significant bit from 0 to 1
- In 1's-complement system
  - Negative values are obtained by complementing each bit of the corresponding positive number
  - The operation of forming the 1's-complement of a given number is equivalent to subtracting that number from 2 n-1
- In 2's-complement system
  - ◆ The operation of forming the 2's-complement of a given number is done by subtracting that number from 2 <sup>n</sup>
- The 2's-complement of a number is obtained by adding 1 to 1's-complement of that number


# An Example of Number Representations

$b_{\scriptscriptstyle 3} b_{\scriptscriptstyle 2} b_{\scriptscriptstyle 1} b_{\scriptscriptstyle 0}$	sign and magnitude	1's-complement	2's-complement
0 1 1 1	+7	+7	+7
0 1 1 0	+6	+6	+6
0 1 0 1	+5	+5	+5
0 1 0 0	+4	+4	+4
0 0 1 1	+3	+3	+3
0 0 1 0	+2	+2	+2
0 0 0 1	+1	+1	+1
0 0 0 0	+0	+0	+0
1 0 0 0	-0	-7	-8
1 0 0 1	-1	-6	-7
1 0 1 0	-2	-5	-6
1 0 1 1	-3	-4	-5
1 1 0 0	-4	-3	-4
1 1 0 1	-5	-2	-3
1 1 1 0	-6	-1	-2
1 1 1 1	-7	-0	-1

#### 2's-Complement System

+7+(-3)






# Addition of Numbers in 2's Complement

$   \begin{array}{rcl}     1001 &=& -7 \\     + \underline{0101} &=& 5 \\     1110 &=& -2 \\     & (a) (-7) + (+5)   \end{array} $	1100 = -4  +0100 = 4  10000 = 0  (b) (-4) + (+4)
0011 = 3 + 0100 = 4 0111 = 7 (c) (+3) + (+4)	1100 = -4  +1111 = -1  11011 = -5  (d) (-4) + (-1)
0101 = 5 + $0100 = 4$ 1001 = Overflow (e) (+5) + (+4)	1001 = -7  +1010 = -6  10011 = Overflow  (f) (-7) + (-6)

# Sign Extension of 2's Complement

- Sign extension
  - To represent a signed number in 2's complement form using a larger number of bits, repeat the sign bit as many times as needed to the left



#### **Memory Locations**

- A memory consists of cells, each of which can store a bit of binary information (0 or 1)
- Because a single bit represents a very small amount of information
  - Bits are seldom handled individually
- The memory usually is organized so that a group of bits can be stored or retrieved in a single, basic operation
  - Each group of n bits is referred to as a word of information, and n is called the word length
  - ◆ A unit of 8 bits is called a byte
- Modern computers have word lengths that typically range from 16 to 64 bits

#### **Memory Addresses**


- Accessing the memory to store or retrieve a single item of information, either a word or a byte, requires distinct
  - names or addresses for each item location
- It is customary to use numbers from 0 to 2 k-1 as the address space of successive locations in the memory
  - K denotes address
  - 2<sup>k</sup>-1 denotes address space of memory locations
- For example, a 24-bit address generates an address space of 2<sup>24</sup> (16,777,216) locations
- Terminology
  - ◆ 2<sup>10</sup>: 1K (kilo)
  - 2<sup>20</sup>: 1M (mega)
  - 2<sup>30</sup>: 1G (giga)
  - 240: 1T (tera)

- SY
- A 2102201 -75
- B 2202201 -75
- C 2302201-75


• A 🛮 8 bit 🗎 0000 1010

## **Memory Words**

#### Memory words



#### A signed integer




#### Four characters



ASCII character

## **Big-Endian & Little-Endian Assignments**

- Byte addresses can be assigned across words in two ways
  - Big-endian and little-endian



Little-endian assignment

#### **Memory Operation**

- Random access memories must have two basic operations
  - Write: writes a data into the specified location
  - Read: reads the data stored in the specified location
- In machine language program, the two basic operations usually are called
  - Store: write operation
  - Load: read operation
- The Load operation transfers a copy of the contents of a specific memory location to the processor. The memory contents remain unchanged
- The Store operation transfers an item of information from the processor to a specific memory location, destroying the former contents of that location

#### **Instructions**

- A computer must have instruct ions capable of performing four types of operations
  - Data transfers between the memory and the processor registers
  - Arithmetic and logic operations on data
  - Program sequencing and control
  - I / O transfers

#### Register transfer notation

- The contents of a location are denoted by placing square brackets around the name of the location
- ◆ For example, R1 € [ L O C ] means that the contents of manay location LOC are transferred into processor register R1
- As another example, R3€[R1]+[R2] means that adds the contents of registers R1 and R2, and then places their sum into register R3

#### C = A + B

- Read A
- Read B
- Add A, B
- Move B, C
- Print C

OPCODE	Operand list		
ADD	A Source operand	B Destinatio n operand	

#### **Assembly Language Notation**

#### Types of instructions

- Zero-address instruction
- One-address instruction
- Two-address instruction
- Three-address instruction

#### Zero-address instruction

- For example, store operands in a structure called a pushdown stack
- One-address instruction
  - Instruction form: Operation Destination
  - For example, Add A: add the contents of memory location A to the contents of the accumulator register and place the sum back into the accumulator
  - As another example, Load A: copies the contents of memory location A into the accumulator

#### **Assembly Language Notation**

#### Two-address instruction

- Instruction form: **Operation Source**, **Destination**
- For example, Add A, B: performs the operation B € [A]+[B].
   When the sum is calculated, the result is sent to the memory and stored in location B
- As another example, Move B, C: performs the operation C€[B], leaving the contents of location B unchanged


#### Three-address instruction

- ◆ Instruction form: Operation Source1, Source2, Destination
- ◆ For example, **Add A, B, C**: adds A and B, and the result is sent to the memory and stored in location C
- If k bits are needed to specify the memory address of each operand, the encoded form of the above instruction must contain 3k bits for addressing purposes in addition to the bits needed to denote the Add operation


#### **Instruction Execution**

#### How a program is executed


- The processor contains a register called the program counter (PC), which holds the address of the instruction to be executed next. To begin executing a program, the address of its first instruction must be placed into the PC, then the processor control circuits use the information in the PC to fetch and execute instruction, one at a time, in the order of increasing address
- Basic instruction cycle




# A Program for C=[A]+[B]



# **Straight-Line Sequencing**



# **Branching**



#### **Condition Codes**

- The processor keeps track of information about the results of various operations for use by subsequent conditional branch instructions. This is accomplished by recoding required information in individual bits, often called condition code flags
- Four commonly used flags are
  - N (negative): set to 1 if the results is negative; otherwise, cleared to 0
  - Z (zero): set to 1 if the result is 0; otherwise, cleared to 0
  - ◆ V (overflow): set to 1 if arithmetic overflow occurs; otherwise, cleared to 0
  - ◆ C (carry): set to 1 if a carry-out results from the operation; otherwise, cleared to 0
- N and Z flags caused by an arithmetic or a logic operation, V and C flags caused by an arithmetic operation

## **Addressing Modes**

- Programmers use data structures to represent the data used in computations. These include lists, linked lists, array, queues, and so on
- A high-level language enables the programmer to use constants, local and global variables, pointers, and arrays
- When translating a high-level language program into assembly language, the compiler must be able to implement these constructs using the facilities in the instruction set of the computer
- The different ways in which the location of an operand is specified in an instruction are referred to as addressing modes

# **Generic Addressing Modes**

Name	Assembler syntax	Addressing function
Immediate	#Value	Operand=Value
Register	Ri	EA=Ri
Absolute (Direct)	LOC	EA=LOC
Indirect	(Ri)	EA=[Ri]
	(LOC)	EA=[LOC]
Index	X(Ri)	EA=[Ri]+X
Base with index	(Ri, Rj)	EA=[Ri]+[Rj]
Base with index and offset	X(Ri, Rj)	EA=[Ri]+[Rj]+X
Relative	X(PC)	EA=[PC]+X
Autoincrement	(Ri)+	EA=[Ri]; Increment Ri
Autodecrement	-(Ri)	Decrement Ri; EA=[Ri]

EA: effective address Value: a signed number

#### Register, Absolute and Immediate Modes

- Register mode: the operand is the contents of a processor register; the name (address) of the register is given in the instruction
  - For example, Add Ri, Rj (adds the contents of Ri and Rj and the result is stored in Rj)
- Absolute mode: the operand is in a memory location; the address of this location is given explicitly in the instruction. (In some assembly languages, this mode is called Direct)
  - For example, Move LOC, R2 (moves the content of the memory with address LOC to the register R2)
  - The Absolute mode can represent global variables in a program. For example, a declaration such as Integer A, B;
- ➤ **Immediate mode:** the operand is given explicitly in the instruction


#### **Indirection and Pointers**


- Indirect mode: the effective address of the operand is the contents of a register or memory location whose address appears in the instruction
- Indirection is denoted by placing the name of the register or the memory address given in the instruction in parentheses
- The register or memory locati on that contains the address of an operand is called a pointer

# Two Types of Indirect Addressing


Through a general-purpose register

Through a memory location





## **Register Indirect Addressing Diagram**



## **Using Indirect Addressing in a Program**


Address	Contents		
	Move	N, R1 #NUM1, R2	)
	Move	R0	Initialization
	Clear		
LOOP	Add	(R2), R0	
	Add	#4, R2	
	Decrement	R1	
	Branch>0	LOOP	
	Move	R0, SUM	

## **Indexing and Arrays**

- ➤ **Index mode:** the effective address of the operand is generated by adding a constant—value to the contents of a register
  - ◆ The register used may be either a special register provided for this purpose, or, more commonly, it may be any one of a set of general-purpose registers in the processor. It is referred to as an index register
  - The index mode is useful in dealing with lists and arrays
  - ◆ We denote the Index mode symbolically as X(Ri), where X denotes the constant value contained in the instruction and Ri is the name of the register involved. The effective address of the operand is given by EA=X+(Ri). The contents of the index register are not changed in the process of generating the effective address


## **Indexed Addressing**

Offset is given as a constant



### **Indexed Addressing**

Offset is in the index register



## An Example for Indexed Addressing

N	
LIST LIST+4 LIST+8 LIST+12 LIST+1 6	n Student ID Test 1 Test 2
	Test 3 Student ID Test 1 Test 2
	Test 3

	Move	#LIST, R0
	Clear	R1
	Clear	R2
	Clear	R3
	Move	N, R4
LOOP	Add	4(R0), R1
	Add	8(R0), R2
	Add	12(R0), R3
	Add	#16, R0
	Decrement	R4
	-Branch>0	LOOP
	Move	R1, SUM1
	Move	R2, SUM2
	Move	R3, SUM3


## Variations of Indexed Addressing Mode

- A second register may be used to contain the offset X, in which case we can write the Index mode as (Ri,Rj)
  - The effective address is the sum of the contents of registers Ri and Rj
  - ◆ The second register is usually called the base register
  - This mode implements a two-dimensional array
- Another version of the Index mode use two registers plus a constant, which can be denoted as X(Ri,Rj)
  - The effective address is the sum of the constant X and the contents of registers Ri and Rj
  - This mode implements a three-dimensional array

#### **Additional Modes**

- Autoincrement mode: the effective address of the operand is the contents of a register specified in the instruction. After accessing the operand, the contents of this register are automatically incremented to point to the next item in a list
  - ◆ The Autoincrement mode is denoted as (Ri)+
- Autodecrement mode: the contents of a register specified in the instruction are first automatically decremented and are then used as the effective address of the operand
  - ◆ The Autodecrement mode is denoted as –(Ri)

### An Example of Autoincrement Addressing



39

## **Assembly Language**

- A complete set of symbolic names and rules for their use constitute a programming language, generally referred to as an assembly language
- Programs written in an assembly language can be automatically translated into a sequence of machine instructions by a program called an *assembler*
- When the assembler program is executed, it reads the user program, analyzes it, and then generates the desired machine language program
- The user program in its origin al alphanumeric text format is called a *source program*, and the assembled machine language program is called an *object program*

#### **Assembler Directives**

- In addition to providing a mechanism for representing instructions in a program, the assembly language allows the programmer to specify of her information needed to translate the source program into the object program
- Suppose that the name SUM is used to represent the value
  - 200. The fact may be conveyed to the assembler program through a statement such as
    - **♦ SUM EQU 200**
- This statement does not denote an instruction that will be executed when the object program is run; it will not even appear in the object program
  - Such statements, called assembler directives (or commands)

#### **Assembler**

	I
100	
100	Move N, R1
104	Move #NUM1, R2
108	Clear R0
112	0.000
116	Add (R2), R0
	Add #4, R2
120	Decrement R1
124	Branch>0 LOOP
128	Move R0, SUM
132	
	•
<b>vi</b> 200	
<b>n</b> 204	100
	•

Assembler directives	SUM	EQU	200
		ORIGIN	204
	N	DATAWORD	100
	NUM1	RESERVE	400
		ORIGIN	100
Statements that	START	MOVE	N, R1
generate R2		MOVE	#NUM1,
machine		CLR	R0
instructions	LOOP	ADD	(R2), R0
		ADD	#4, R2
		DEC	R1
		BGTZ	LOOP
		MOVE	R0, SUM
Assembler directives		RETURN	
		END	START

#### **Memory arrangement**


**Assembly language representation** 

#### **Number Notation**

- When dealing with numerical values, most assemblers allow numerical values to be specified in different ways
- For example, consider the number 93, which is represented by the 8-bit binary number 01011101. If the value is to be used as immediate operand,
  - ◆ It can be given as a decimal number , as in the instruction ADD #93, R1
  - ◆ It can be given as a binary number, as in the instruction ADD # %01011101,R1 (a binary number is identified by a prefix symbol such as percent sign)
  - ◆ It also can be given as a hexadecimal number, as in the instruction ADD #\$5D, R1 (a hexadecimal num ber is identified by a prefix symbol such as dollar sign)

#### **Basic Input/Output Operations**

Bus connection for processor, keyboard, and display



DATAIN, DATAOUT: buffer registers

SIN, SOUT: status control flags

#### Wait Loop

- In order to perform I / O transfers, we need machine instructions that can check the state of the status flags and transfer data between the processor and I / O device
- Wait loop for Read operation
  - ◆ READWAIT Branch to READWAIT if SIN=0 Input from DATAIN to R1
- Wait loop for Write operation
- ◆ WRITEWAIT Branch to WRITEWAIT if SOUT=0 Output from R1 to DATAOUT
- We assume that the initial stat e of SIN is 0 and the initial state of SOUT is 1

### Memory-Mapped I/O

- Many computers use an arrangement called memory-mapped I / O in which some memory address values are used to refer to peripheral device buffer registers, such as DATAIN and DATAOUT
- Thus no special instructions are needed to access the contents of these registers; data can be transferred between these registers and the processor using instructions that we have discussed, such as Move, Load, or Store
- Also, the status flags SIN and SOUT can be handled by including them in device status registers, one for each of the two devices

## **Read and Write Programs**

- Assume that bit b<sub>3</sub> in registers INSTATUS and OUTSTATUS corresponds to SIN and SOUT, respectively
- Read Loop
  - ◆ READWAIT Testbit #3, INSTATUS

Branch=0 READWAIT

DATAIN, R1

- ➤ Write Loop MoveByte
  - WRITEWAIT Testbit #3, OUTSTATUS


Branch=0 WRITEWAIT

MoveByte R1, DATAOUT

#### **Stacks and Queues**

- A stack is a list of data elem ents, usually words or bytes, with the accessing restriction that elements can be added or removed at one end of the list only
  - It is also called a last-in-first-out (LIFO) stack
  - A stack has two basic operations: push and pop
  - The terms push and pop are used to describe placing a new item on the stack and removing the top item from the stack, respectively.
- Another useful data structure that is similar to the stack is called a queue
  - Data are stored in and retrieved from a queue on a first-in-firstout (FIFO) basis
  - Two pointers are needed to keep track of the two ends of the queue

## A Stack of Words in the Memory



### **Push and Pop Operations**

- Assume that a byte-addressable memory with 32-bit words
- The push operation can be implemented as

```
Subtract #4, SP
Move NEWITEM, (SP)
```


The pop operation can be implemented as Move
(SP), ITEM Add
#4, SP


If the processor has the Autoincrement and Autodecrement addressing modes, then the push operation can be implemented by the single instruction

Move NEWITEM, -(SP)

And the pop operation can be implemented as Move (SP)+, ITEM

# **Examples**





Push operation

Pop operation

# **Checking for Empty and Full Errors**

- When a stack is used in a program, it is usually allocated a fixed amount of space in the memory
  - We must avoid pushing an item onto the stack when the stack has reached in its maximum si ze, i.e., the stack is full
  - On the other hand, we must avoid popping an item off the stack when the stack has reached in its minimum size, i.e., the stack is empty
- Routine for a safe pop or a safe push operation
  - Compare src, dst
  - Perform [dst]-[src]
  - Sets the condition code flags according to the result

#### **Subroutines**


In a given program, it is often necessary to perform a particular subtask many times on different data values. Such a subtask is called a *subroutine*.

Memory location	Calling program	Memory location	Subroutine SUB
200 204	: Call SUB next instruction	1000	first instruction : Retur
			n

The location where the calling program resumes execution is the location pointed by the updated PC while the Call instruction is being executed. Hence the contents of the PC must be saved by the Call instruction to enable correct return to the calling program

#### **Subroutine Linkage**


- The way in which a computer makes it possible to call and return from subroutines is referred to as its subroutine linkage method
- Subroutine linkage using a link register




### **Subroutine Nesting**


- A common programming practice, called subroutine nesting, is to have one subroutine call another
- Subroutine nesting call be carried out to any depth. Eventually, the last subroutine called completes its computations and returns to the subroutine that called it
- The return address needed for this first returns is the last one generated in the nested call sequence. That is, return addresses are generated and used in a last-in-first-out order
- Many processors do this by using a stack pointer and the stack pointer points to a stack called the processor stack

## **Example of Subroutine Nesting**





## **Example of Subroutine Nesting**




[Source: B. Parhami, UCSB]

### **Parameter Passing**


- When calling a subroutine, a program must provide to the subroutine the parameters, that is, the operands or their addresses, to be used in the computation. Later, the subroutine returns other parameters, in this case, the result of computation
- The exchange of information between a calling program and a subroutine is referre d to as parameter passing
- Parameter passing approaches
  - The parameters may be placed in registers or in memory locations, where they can be accessed by the subroutine
  - The parameters may be placed on the processor stack used for saving the return address

### **Passing Parameters with Registers**




#### **Passing Parameters with Stack**

Assume top of stack is at level 1 below.




#### **Stack Frame**




#### **Shift Instructions**

Logical shifts




Arithmetic shifts




#### **Rotate Instructions**


Rotate left without carry




Rotate left with carry




#### **Linked List**





**Inserting a new record** 

#### A List of Student Test Scores




### **Encoding of Machine Instructions**

- To be executed in a processor, an instruction must be encoded in a compact binary pattern. Su ch encoded instructions are properly referred to as machine instructions. The instructions that use symbolic names and acronyms are called assembly language instructions, which are converted into the machine instructions using assembler program
- For a given instruction, the type of operation that is to be performed and the type of oper ands used may be specified using an encoded binary pattern referred to as the OP code
- In addition to the OP code, the instruction has to specify the source and destination registers, and addressing mode, etc,

#### **Examples**

- Assume that 8 bits are allocate d for OP code, and 4 bits are needed to identify each register, and 6 bits are needed to specify an addressing mode
- $\triangleright$  The instruction Move 24(R0), R5
  - Require 16 bits to denote the OP code and the two registers
  - Require 6 bits to choose the addressing mode
  - Only 10 bits are left to give the index value
- The instruction LshiftR #2, R0
  - Require 18 bits to specify the OP code, the addressing modes, and the register
  - This limits the size of the immediate operand to what is expressible in 14 bits
- In the two examples, the instructions can be encoded in a 32-bit word.

### **Encoding Instructions into 32-bit Words**



Three-operand instruction

### **Encoding Instructions into 32-bit Words**

- But, what happens if we want to specify a memory operand using the Absolute addressing mode?
- The instruction Move R2, LOC
  - Require 18 bits to denote the OP code, the addressing modes, and the register
  - The leaves 14 bits to express the address that corresponds to LOC, which is clearly insufficient
- If we want to be able to give a complete 32-bit address in the instruction, an instruction must have two words
- If we want to handle this type of instructions: Move LOC1, LOC2
  - An instruction must have three words

#### **CISC & RISC**

- Using multiple words, we can implement quite complex instructions, closely resembling operations in highlevel programming language
- The term *complex instruction set computer* (CISC) has been used to refer to processors that use instruction sets of this type
- The restriction that an instruction must occupy only one word has led to a style of computers that have become known as *reduced instruction set computer* (RISC)