This tower is symbolic of a nation whose future is filled with limitless opportunities.

-Mr. Qingwei Kong, President of the Shanghal Tower Construction & Development Co., Ltd.

HIGH RISE STRUCTURAL SYSTEMS

where valural spices are broked.
This was a combined and multiplied statistically be been a seen to achieve positive effects to the city such as reducing the urban heat seen and other publishes out of the effects.

PRESENTED BY:

- AKSHAY REVEKAR
- DURGESH PIPPAL.

MITS GWLIOR

INTRODUCTION AND DEFINITION

High rise is defined differently by different bodies.

Emporis standards-

"A multi-story structure between 35-100 meters tall, or a building of unknown height from 12-39 floors is termed as high rise.

The International Conference on Fire Safety –

"any structure where the height can have a serious impact on evacuation"

Building code of Hyderabad, India-

A high-rise building is one with four floors or more, or one 15 meters or more in height.

Massachusetts, United States General Laws –


A high-rise is being higher than 70 feet (21 m).

Demand for High-Rise Buildings

- Scarcity of land in urban areas
- Increasing demand for business and residential space
- Economic growth
- Technological advancements
- Innovations in Structural Systems
- Desire for aesthetics in urban settings
- Concept of city skyline
- Cultural significance and prestige
- Human aspiration to build higher

GEOGRAICAL DISTRIBUTION OF HIGHRISE

Locations: The Tallest 20 in 2020



Criteria: The Tallest 20 in 2020

GEOGRAICAL DISTRIBUTION OF HIGHRISE



100	4			Skyscrapers in Regions				
# Co	ntinent		Buildings	Percent				
1 As	sia		24,302	33.16 %				
2 No	orth America		22,863	31.20 %				
3 E	ırope	_	13,114	17.89 %				
4 Sc	outh America		9,903	13.51 %				
5 00	ceania	-	2,244	3.06 %				
6 Af	rica	1	859	1.17 %				

(Tables source: Emporis Corporation April 2004)


Most Skyscrapers				
#	City	Buildings		
1.	Hong Kong	7,254		
2.	New York City	5,317		
3.	Singapore	3,489		
4.	Istanbul	2,090		
5.	São Paulo	2,043		
6.	Rio de Janeiro	1,854		
7.	Toronto	1,582		
8.	Tokyo	1,466		
9.	Buenos Aires	1,410		
10.	London	1,277		
11.	Chicago	1,024		
12.	Bangkok	706		
13.	Osaka	685		
14.	Sydney	652		
15.	Caracas	650		
16.	Milan	625		
17.	Seoul	589		
18.	Shanghai	523		
19.	Kuala Lumpur	515		
20.	Vancouver	501		
21.	Madrid	500		
22.	Curitiba	495		
23.	Mumbai	476		
24.	Honolulu	431		
25.	Los Angeles	416		



The Tallest 20 in 2020


CTBUH Projection, Second Edition, January 2009

Due to the current economic climate, some buildings on this list may have slowed construction / development pace or have been put 'on hold' recently. The current intention, however, is that all projects on the list will be completed, though that may change in the coming months / years. Only buildings that are fully in the public domain and fulfill all the criteria listed at the end of this document are included in the CTBUH Tallest 20 in 2020 – there may well be other proposed buildings that would make the list, but are for client / project confidentiality reasons not yet publicized. Also, due to the changing nature of early stage designs and client information restrictions, some height data for 'proposed' tall buildings that appears on this list is unconfirmed.




EVOLUTION OF STRUCTURAL SYSTEMS

Evolution of Structural Systems



STEEL STRUCTURAL SYSTEMS AND THE NO. OF STOREYS



TYPES OF CORE SYSTEMS

Central Core

Split Core

End Core

Atrium Core

core

atrium

atrium

core

Configuration

















Plar









Plan









Single Tenant









Single Tenant









Double Tenant









Double Tenant









Multiple Tenant









Multiple Tenant











TYPES OF TUBULAR SYSTEMS




EXAMPLES OF STEEL STRUCTURAL SYSTEMS




Shear Frame System

- Resists lateral deformation by joint rotation
- Requires high bending stiffness of columns and beams
- Rigid joints are essential for stability
- Not effective for heights over 30 stories



Braced Frame System

- Lateral forces are resisted by axial actions of bracing and columns
- Steel bracing members or filled-in bays
- More efficient than a rigid frame




Outrigger Braced Structure System

 1- or 2-story deep truss connects core to perimeter columns


 Increases the bending rigidity

 Dependent of rigid core for shear resistance




Core Structure System

- Lateral and gravity loads supported by central core
- Eliminates columns and bracing elements
- Core is inefficient because it is not deep in respect to bending
- Moment supported floors are inefficient



High-Efficiency Mega-Braced Frame System


- Very large columns and bracing
- Small number of columns
- Bracing extends over multiple floors
- Stiff transfer floors allow for internal flexiblity




BELT TRUSS SYSTEM


SHANGHAI TOWER

TRUSS






Structural Loads





- Gravity loads
- Dead loads
- Live loads
- Snow loads
- Lateral loads
- Wind loads
- Seismic loads
- Special load cases
- Impact loads





Shear wall system

- A type of rigid frame construction.
- The shear wall is in steel or concrete to provide greater lateral rigidity. It is a wall where the entire material of the wall is employed in the resistance of both horizontal and vertical loads.
- Is composed of braced panels (or shear panels) to counter the effects of lateral load acting on a structure. Wind & earthquake loads are the most common among the loads.
- For skyscrapers, as the size of the structure increases, so does the size of the supporting wall. Shear walls tend to be used only in conjunction with other support systems.











FRAMED-TUBE STRUCTURES]

The lateral resistant of the framed-tube structures is provided by very stiff moment-resistant frames that form a "tube" around the perimeter of the building.

The basic inefficiency of the frame system for reinforced concrete buildings of more than 15 stories resulted in member proportions of prohibitive size and structural material cost premium, and thus such system were economically not viable.

The frames consist of 6-12 ft (2-4m) between centers, joined by deep spandrel girders.

Gravity loading is shared between the tube and interior column or walls.

When lateral loading acts, the perimeter frame aligned in the direction of loading acts as the "webs" of the massive tube of the cantilever, and those normal to the direction of the loading act as the "flanges".

The tube form was developed originally for building of rectangular plan, and probably it's most efficient use in that shape.



