

INTRODUCTION

 Dynamic analysis of instruction usage gives a good indication of the types of operations that are performed most frequently.

 For typical programs, half the instructions deal with data movement between registers and memory.

 Therefore loading and storing data efficiently is critical to processor performance

Memory

- Memory can be view as contiguous storage
 elements that hold data. It is like a long string of
 mailboxes, where your letter (data) is stored in a box
 with a specific number on it (address).
- Width of each storage element is a byte.
- Size of memory is usually measured in megabytes (MB, 2²⁰), gigabytes (GB, 2³⁰) or even terabytes (TB, 2⁴⁰)
- ARM7TDMI has 32 bits address bus which means it can interfaced to 2³² or 4GB of memory space

Types of Memory

- ROM: Read Only Memory, memory contents are retained even without power supply.
- EEPROM : Electrically Erasable Programmable ROM
- SRAM: Static Random Access Memory, contents are lost when power is off.
- DRAM: Dynamic Random Access Memory, contents must be constantly refreshed otherwise they will be lost even when power is on.

Instruction Class

- ARM instructions can be broadly separated into 3 basic classes:
- 1. Data Movement
- Memory load/store
- Register Transfers
- 2. Data Operation
- Arithmetic
- Logical
- Register movement
- Comparison and test
- 3. Flow Control
- Branch
- Conditional execution

ARM Instructions

- Fixed length of 32 bits
- Commonly take two or three operands
- Process data held in registers
- Access memory with load and store instructions only
- Can be extended to execute conditionally by adding the appropriate suffix
- Affect the CPSR status flags by adding the 'S' suffix to the instruction

Load / Store Instructions

- The ARM is a Load / Store Architecture:
- Does not support memory to memory data processing operations
- Must move data values into registers before using them
- This might sound inefficient, but in practice isn't:
- Load data values from memory into registers
- Process data in registers using a number of data processing instructions which are not slowed down by memory access
- Store results from registers out to memory
- The ARM has three sets of instructions which interact with main memory. These are:
- Single register data transfer (LDR / STR)
- Block data transfer (LDM/STM)
- Single Data Swap (SWP)

Load and Store Instructions

- Only two basic instructions are used for data transfer between memory and processor registers.
- LDR: LoaD words from memory into a Register
- STR: STore words from a Register into memory
- Basic syntax:
- LDR/STR{<cond>}{type} <Rd>, <addressing_mode>
- where <Rd> = destination (for LDR) & source (for STR)
- cond = condition flag
- type = byte, halfword, word(default), signed & unsigned

Common Load/Store Instructions

Loads	Stores	Size and Type
LDR	STR	Word (32 bits)
LDRB	STRB	Byte (8 bits)
LDRH	STRH	Halfword (16 bits)
LDRSB		Signed Byte
LDRSH		Signed Halfword
LDM	STM	Multiple Words

Addressing Modes

ARM uses a fixed-length instruction, with the lowest 12 bits available to specify immediate address

- not sufficient to cover the full 2³² address space
- hence do not support direct addressing

ARM only provides indirect addressing modes

- 1. Register indirect addressing
- 2. PC-relative addressing

Register Indirect Addressing

- An address is available in a register
- Example:

LDR r0, [r1]


- Here, the r1content is known as the 'base address', and r1 is called the base address register.
- Can be further extended to:
- a) Pre-indexed addressing
- b) Pre-indexed with write-back addressing (uses "!")
- c) Post-indexed addressing (implicit write-back)

Load and Store Word or Byte: Base Register

 The memory location to be accessed is held in a base register

; Store contents of r0 to location pointed - STR r0, [r1] ; to by contents of r1. ; Load r2 with contents of memory location

; pointed to by contents of r1.



Destination Register for LDR

r2

Load Half Word Example

LDRH r11, [r0]

;load a halfword into r11

r0 content before/after load

0x00008000

r11 before load

0x12345678

r11 after load

Ox0000FFEE

Memory

Address

0008x0

0x8001

0x8002

0x8003

Data

0xEE

0xFF

0x90

0xA7

Signed Byte Load Example

LDRSB r11, [r0]

;load a signed byte into r11

r0 content

before/after load

0x00008000

r11 before load

0x12345678

r11 after load

OxFFFFFEE

Memory

Address

0008x0

0x8001

0x8002

0x8003

Data

0xEE

0x8C

0x90

0xA7

More Register-Indirect Examples

```
LDR r0, [r1]
```

- ; load r0with the content of the memory location
- ; pointed to in r1

```
STR r2, [r1]
```

- ; store content of r2to memory location with address
- ; pointed to in r1

```
LDRB r0, [r1]; load byte size data
```

Pre-Indexed

Pre-indexed addressing adds an offset to the base address before executing the load/store.

LDR | STR{<cond>} <Rd>, [<Rn>, <offset>]{!}

Example: LDR r0, [r1, #8]

This instruction loads r0with the content of memory location at (base address + 8).

Optional! specifies to write the effective address back into Rn after execution of instruction. Otherwise Rn retains original value.

Useful for addressing an element in a data structure. For example, access a particular register of a peripheral through the peripheral base address and its offset.

Pre-index Load Example

- The load instruction
- LDR r9, [r12, r8, LSL #2]
- will load a word from the memory address given by the base register of r12 and an offset value created from register r8, after shifting left by 2 bits.
- Effective address: ea<r12+r8*4>
- If base register r12 contain value 0x4000, offset register r8 contains 0x20, the effective address will be 0x4080

More Pre-Indexed Examples

```
LDR | STR{<cond>} <Rd>, [<Rn>, <offset>]{!}
;r3 data written to ea(r0+(r5*8)) STR
        r3, [r0, r5, LSL #3]
;r6 gets data from ea(r0+(r1/64))
        r6, [r0, r1, ASR #6]
LDR
;r0 gets data from ea(r1-8) LDR
        r0, [r1, #-8]
```

;r0 gets data from ea(r1-(r2*4))

LDR r0, [r1, -r2, LSL #2]

Pre-Indexed with Write-Back

Pre-indexed addressing with write-back automatically updates the base address before executing the load/store.

Example: LDR r0, [r1, #4]!

This instruction adds 4 to the base register r1, loads r0 with the content of memory location (now is at base address + 4), and increments r1by 4.

Increment to the base address is done <u>before</u> the execution of the load instruction.

Useful for automatic stepping through a lookup table with a starting address placed in the base address register.

EE3002 Microprocessors

Pre-Indexed Example

LDR | STR{<cond>} <Rd>, [<Rn>, <offset>]{!}

STR r0, [r1, #12]; writes 0xABCDEF to address 0x20C

		address	memory	
				r0
		0x20F	0x0	0xABCDEF
		0x20E	0xAB	
	offset	0x20D	0xCD	
	12	0x20C	0xEF	
r1		•••		
0x200	>	0x200		
		ELJUUZ I	viiciohiocessois	


STR Pre-indexed Addressing

- To store to location 0x1f4instead use
- STR r0, [r1,#-12]
- To auto-increment base pointer to 0x20cuse
- STR r0, [r1, #12]!
- If r2contains 3, access 0x20cby multiplying this by 4
- STR r0, [r1, r2, LSL #2]

Pre-Indexed Example with Writeback

LDR | STR{<cond>} <Rd>, [<Rn>, <offset>]{!}

STR r0, [r1, #12]!; writes 0xABCDEF to address; 0x20C and updates r1



Pre-Indexed Examples

LDR | STR{<cond>} <Rd>, [<Rn>, <offset>]{!}

;r5 gets 2 bytes of data from ea(r9) and is sign ;extended to fill the 32 bit r5 register LDRSH R5, [R9]

;r3 gets 1 byte of data from ea(r8+3) and is sign ;extended to fill the 32 bit r3 register LDRSB R3, [R8, #3]

;r4 gets 1 byte of data from ea(r10+193) and is sign ;extended to fill the 32 bit r4 register LDRSB R4, [R10, #0xC1]

;r4 gets 1 byte of data from ea(r10+193) and is sign ;extended to fill the 32 bit r4 register and r10 is ;updated to contain r10 <- r10+193

Post-Indexed

Post-indexed addressing automatically updates the base address after executing the load/store.

Example: STR r0, [r1], #4;

This instruction stores the content of r0 into the memory location pointed to in base address register r1, executes the store operation, and increases the base address value by 4. Increment is done <u>after</u> the execution.

Note that '!' is not needed for post-indexed addressing since the update is implicit.

Useful for storing a list of data into a table with a starting address pointed to by the base address value in r1.

Post-Indexed Examples

LDR | STR{<cond>} <Rd>, [<Rn>, <offset>]

;32 bit data in r7 written to ea(r0) and ;r0 is updated to contain r0 <- r0+24 after write STR #24

r7, [r0],

;r2 gets 32 bits of data from address beginning at ;ea(r0) and r0 is updated to contain r0 <- r0+(r4/16) LDR ASR #4

r2, [r0], r4,

;r3 gets 16 bits of data from address beginning at ;ea(r9)and r9 is updated to contain r9 <- r9+2 LDRH [r9], #2

r3,


;16 bit data written from r2 to address beginning at ;ea(r5) and r5 is updated to contain r5 <- r5+8 STRH [r5], #8

r2,

Post-Indexed Example

LDR | STR{<cond>} <Rd>, [<Rn>, <offset>]

STR r0, [r1], #12; writes 0xABCDEF to address; 0x200 and updates r1



26

STR: Post-indexed Addressing

STR r0, [r1], #12 ;writes 0x5 to address 0x200

- To auto-increment the base register to location
 0x1f4instead use:
- STR r0, [r1], #-12;r1=0x200
- If r2contains 3, auto-increment base register to
 0x20cby multiplying this by 4:
- STR r0, [r1], r2, LSL #2

Store Example Using Post Indexed

STR r3, [r8], #4; Memory write to address 0x8000

r3 content before/after store

0xFEEDBABE

r8 before store

0x00008000

r8 after store

0x00008004

Memory after Store

Address

Data

0008x0

0x8001

0x8002

0x8003

0xBE

0xBA

0xED

0xFE

More Examples

LDR	r5, [r3]	;load r5 with data from	
		;ea <r3></r3>	
STRB	r0, [r9]	;store data in r0 to	
		;ea <r9></r9>	
STR	r3, [r0, r5, LSL #3]	;store data in r3	
		;ea <r0+r5*8></r0+r5*8>	
LDR	r1, [r0, #4]!; load r1 from ea <r0+4>,</r0+4>		
		;r0<-r0+4	
STRB	r7, [r6, #-1]! ;store byte to ea <r6-1>,</r6-1>		
		;r6<-r6-1	
LDR	r3, [r9], #4	;load r3 from ea <r9>,</r9>	
		;r9<-r9+4	
STR	r2, [r5], #8	;store word to ea <r5>,</r5>	
		;r5<-r5+8	
	EE3002	Microprocessors	

Example - Memory String Copy

```
0 \times 40000000
                                       ; address to store string
SRAM BASE
           EQU
                       StrCopy, CODE
           AREA
                                       mark first instruction
           ENTRY
Main
           adr
                                       ; pointer to source string
                   rl, srcstr
           ldr
                                       ; pointer to destination string
                   r0, =SRAM BASE
strcopy
           ldrb
                     r2, [r1],
                                       ; load byte, update address
           #1 strb
                            r2,
                                       ;store byte, update address
            [r0], #1
                            cmp
                                       ; check for zero terminator
           r2, #0
                                       ;loop if terminator not reached
stop
           bne
                                       ;halt processing, loop forever
          DGBcrcopyThis is my (source) string",0
srcstr
                            ; end of file marker
          END
           stop
```

Endian


- Term arises from paper D. Cohen [1981]
- ARM supports both conventions
- Only arises with systems that have smaller-sized memory storage than wordsize
- Should storage be from "left-to-right" or "right-to-left"?
- Intel x86 uses "right-to-left", Motorola 68X (now FreeScale) uses "left-to-right"
- ARM allows for either
- Core has input pin BIGEND, when asserted, results in Big Endian

Effect Of Endianess

- The ARM can be set up to access its data in either little or big-endian format.
- Little Endian: Least significant byte of a word is stored bits 0-7 of an addressed word.
- Big Endian: Least significant byte of a word is stored bits 24-31 of an addressed word.
- This has no real relevance unless data is stored in words and then accessed in smaller sized quantities (halfwords or bytes).
- Which byte / halfword accessed will depend on endianess of the system involved.


Big And Little Endian

Take this example (0x1234ABCD) and store it into a memory array. Our memory array is just a big block of bytewide storage spaces, with sequential addresses:



Starting from address 0, the number can go into memory in 2 ways,

littleendian:




and bigendian




Big And Little Endian

Sometimes the way we draw our memory array is different (i.e. for 32bit machines, we draw memory in a different way).


We can apply our example (0x1234ABCD) to both:





Big And Little Endian

To make things more interesting, let's store a halfword (0x6789) and a byte (0xEF) right after the 32bit value:



Changing Endianness

- ; On entry : R0 holds the word to be swapped
- ;On exit : R0 holds the swapped word
- ;:R1, R2 and R3 are destroyed
- Byteswap ; first three instruction does initialisation
- MOV R2, #0xff; R2 = 0xff
- ORR R2, R2, #0xff0000 ;R2 = 0x00ff00ff
- MOV R3, R2, LSL #8; R3 = 0xff00ff00
- ; repeat the following code for each word to swap
- ;R0 = W X Y Z
- AND R1, R2, R0, ROR #24; R1 = 0 Y 0 W
- AND RO, R3, RO, ROR #08; RO = Z O X O
- \bullet ORR RO, RO, R1;RO = Z Y X W

Summary

- Load/Store Architecture
- Load/Store Instructions
- Pre-index and Post-index addressing
- Endianess