# **COMP2611**

Spring 2018, HKUST Notes by **Gerald Liu** 

COMP2611 Computer Organization

```
wliuax@connect.ust.hk
COMP2611
   Digital Logic
       Combinational Logic
       Sequential Logic
   Data Representation
       Integer
       Floating Point
       Character
   ISA
        Syntax
       Registers
       Instruction Encoding
           R-format
           I-format
           J-format
   Computer Arithmetic
       2's Complement Arithmetic
       Arithmetic Logic Unit
       Multiplication and Division
   Processor
       ALU Controls
       Controls
       Hazards
           Structural Hazards
           Data Hazards
           Control Hazards
   Memory
       Hierarchy
        Cache
```

# **Digital Logic**

Gates: AND, OR, NOT, NAND, NOR, XOR

1-bit half adder:  $S = A \oplus B$ ,  $C = A \cdot B$ 

# **Combinational Logic**

Multiplexor (Selector): 2<sup>n</sup> data inputs, n selection inputs (1-bit), 1 output

Decoder: 1 n-bit input, 2<sup>n</sup> 1-bit outputs

Canonical forms:  $D = \sum m_i = \prod M_i \rightarrow \text{simplify with Boolean Algebra or K-map (cells following Grey code)}$ 

# **Sequential Logic**

S-R latch (R,S): latch (0,0) / reset to 0 (1,0) / set to 1 (0,1) / invalid (1,1)

D latch (D, WE): latch (WE = 0) / set to D (WE = 1)

Register: a collection of D latches controlled by a common WE

D Flip-flop: output updates on clock edges (falling / rising)

# **Data Representation**

## Integer

Unsigned integer:  $[000...00_2, 111...11_2] = [0, 2^k-1]$ 

Signed integer:  $[100...00_2, 011...11_2] = [-2^{k-1}, 2^{k-1}-1]$ 

Positive to negative (in 2's complement):

• e.g.  $+6 = 0110_2$ 

• Invert bits:  $-7 = 1001_2$ 

• Add 1:  $-6 = 1010_2$ 

Zero extension: bitwise logical operations, unsigned int

Signed extension: signed int

## **Floating Point**

S	Exponent (biased)	Significand		
1	8 (single) / 11 (double)	23 (single) / 52 (double)		
0/1	Exponent + Bias = Exponent + 2 <sup>k-1</sup> -1	after an implicit 1 (hidden bit)		

Exponent Significand	0 (denormalized)	[1, 2 <sup>k</sup> -2] (normalized)	2 <sup>k</sup> -1 (special cases)	
0	0	$(-1)^S \times 1.F \times 2^{E-Bias}$	(-1) <sup>S</sup> × ∞	
<b>≠ 0</b>	(-1) <sup>S</sup> × 0.F × 2 <sup>-126</sup>	(-1) <sup>S</sup> × 1.F × 2 <sup>E-Bias</sup>	NaN	

## Character

unsigned byte (8 bits) following the ASCII standard.

## ISA

## **Syntax**

```
# Data segment
.data
h: .word 1 2 3 4  # h is an array of size 4, each element is a word (32 bit)
s: .word 5
# Program begins
.text
.globl __start
start:
      $rd, $rs, $rt # $rd = $rs + $rt
add
sub
      $rd, $rs, $rt # $rd = $rs - $rt
addi
     $rt, $rs, imm # $rt = $rs + imm
     $rd, $rs, $rt # $rd = $rs + $rt, ignoring overflow
addu
subu
      $rd, $rs, $rt # $rd = $rs - $rt, ignoring overflow
addiu $rt, $rs, imm # $rt = $rs + imm(sign-extended), ignoring overflow
mult
       $rs, $rt
                      # Hi, Lo = $rs * $rt
multu $rs, $rt
# overflow ignored, no overflow if Hi is 0 for multu or the replicated sign of Lo for mult
div
       $rs, $rt
                      # Lo = $rs / $rt; Hi = $rs % $rt
divu
       $rs, $rt
mflo
                      # $rd = Lo
       $rd
mfhi
                      # $rd = Hi
       $rd
li
       $rd, 100
                      # $rd = 100
                      # $rd = $rs
move
       $rd, $rs
       $rd, label
                     # $rd = addr(label)
la
       $rd, $rs, $rt # $rd = $rs & $rt; AND
and
or
       $rd, $rs, $rt # $rd = $rs | $rt; OR
       rd, rs, rt # rd = ~(rs | rt); NOR
nor
       rd, rs, 0 # rd = ~rs; NOT
nor
       $rd, $rs, $rt # $rd = $rs ^ $rt; XOR
xor
andi
      $rt, $rs, 100 # $rt = $rs & 100
ori
      $rt, $rs, 100 # $rt = $rs | 100
      $rd, $rt, 3 # $s1 = $s2 << 2 = $s2 * 2^2; Shift left by constant</pre>
sll
      rd, rt, 3 # $s1 = $s2 >> 2 = $s2 / 2^3; Shift right by constant
srl
sllv
      $rd, $rt, $rs # $rd = $rt << $rs</pre>
srlv
       $rd, $rt, $rs # $rd = $rt >> $rs
# Data transfer
# Big-endian: the end of a word matches a bigger address
      $rt, 100($rs) # $rt = mem[$rs+100]; load word to reg from mem
lw
      $rt, 100($rs) # Memory[$rs+100] = $rt; store word from reg to mem
SW
       $rt, 100($rs) # load byte, sign extended to 32 bits in $rt
1b
```

```
$rt, 100($rs) # load byte unsigned, zero extended to 32 bits in $rt
1bu
sb
       $rt, 100($rs) # store rightmost byte in $rt
# if-else statement
   beq $s3, $s4, If
   beq $s3, $s1, ElseIf
   j Else
If: add $s0, $s1, $s2
   j exit
ElseIf: sub $s0, $s1, $s2
   j exit
Else: add $s0, $s1, $s4
   exit:
# while loop
Loop: bne $t0, $s2, Exit # go to Exit if $t0 != $s2
   # ...
   addi $s1, $s1, 1 # $s1 = $s1 + 1
   j Loop
Exit:
# Branch comparison
      $rd, $rs, $rt # $rd gets 1 if $rs < $rt</pre>
       $rs, $0, Label # go to L if $rs != 0
# slti $rt, $rs, 10
# unsigned comparison
     $rd, $rs, $rt
sltu
sltiu $rt, $rs, imm # imm is sign-extended
# blt ('branch on less than')
# ble ('branch on less than or equal')
# bgt ('branch on greater than')
# bge ('branch on greater than or equal')
# Branch comparison with zero
bgez $s, label # if ($s >= 0)
bgtz $s, label # if ($s > 0)
blez $s, label # if ($s <= 0)
bltz $s, label # if ($s < 0)
# Nested procedures
   jal proc1 #20 # [jump] $ra = PC + 4 = 24; [and link] PC = addr(proc1) = 60
               #24
   . . .
proc1: push
              #60 # addi $sp, $sp, -4; sw $ra, 0($sp)
               #64
   jal proc2 #68 # [jump] $ra = PC + 4 = 72; [and link] PC = addr(proc2) = 80
             #72 # lw $ra, 0($sp); addi $sp, $sp, 4;
   pop
             #76 # return to #24
   jr $ra
   . . .
proc2: push #80 # addi $sp, $sp, -4; sw $ra, 0($sp)
               #84
    . . .
             #88 # lw $ra, 0($sp); addi $sp, $sp, 4;
   pop
```

# **Registers**

Name	Number	Use	Preserved on Call?
\$zero	\$0	constant 0	N/A
\$at	\$1	assembler temporary	N/A
\$v0-\$v1	\$2-\$3	function returns and expression evaluation	No
\$a0-\$a3	\$4-\$7	function arguments	No
\$t0-\$t7	\$8-\$15	temporaries	No
\$s0-\$s7	\$16-\$23	saved temporaries	Yes
\$t8-\$t9	\$24-\$25	temporaries	No
\$k0-\$k1	\$26-\$27	reserved for OS kernel	N/A
\$gp	\$28	global pointer	Yes
\$sp	\$29	stack pointer	Yes
\$fp	\$30	frame pointer	Yes
\$ra	\$31	return address	Yes

Program counter (PC): holds the address of current instruction updated after executing: PC = PC + 4 or PC = branch target address

## **Instruction Encoding**

### **R-format**

ор	rs	rt	rd	shamt	funct
6 bits	5 bits	5 bits	5 bits	5 bits	6 bits
opcode	1 <sup>st</sup> register source	2 <sup>nd</sup> register source	register destination	shift amount	function code

usage: add, sub, and, or, sll, srl

### **I-format**

ор	rs	rt	const / address
6 bits	5 bits	5 bits	16 bits
opcode	base register	register source / destination	const: [-2 <sup>15</sup> , 2 <sup>15</sup> -1] address: offset on base address

usage: andi, ..., lw, sw

Conditional branches: PC-relative addressing

• Branch Address = PC + 4 + Branch Offset × 4 (Branch Offset is described in number of **words**)

• Branching range: [-128KB, 128KB-1] = 2<sup>16</sup>B

## J-format

ор	const
6 bits	26 bits

Pseudo-direct Addressing:

• Jump Address = const concatenated with the upper 4 bits of PC

• Jump Range: 256MB = 2<sup>26</sup>B

# **Computer Arithmetic**

# 2's Complement Arithmetic

Overflow condition:

Operation	Sign of X	Sign of Y	Sign of Result
X + Y	0	0	1
X + Y	1	1	0
X - Y	0	1	1
X - Y	1	0	0

Control jumps to a predefined address (code) to handle the exception.

The interrupted address is saved to EPC (Exception Program Counter) – return to it via jr


## **Arithmetic Logic Unit**

Processor = Control Unit + ALU (arithmetic and logical operations) + Registers & Cache


### Adder:

- 1-bit half adder: C=ab,  $S=a\oplus b$
- 1-bit full adder:  $C_{out}=(a+b)C_{in}+ab$ ,  $S=a\oplus b\oplus C_{in}=(aar{b}+ar{a}b)\overline{C_{in}}+(ab+ar{a}ar{b})C_{in}$

1-bit ALU: AND, OR, Addition, and Subtraction




- Connect 32 1-bit ALU to form a 32-bit ALU
- sub: Invert (Binvert = 1), add 1 (ALU0's CarryIn = 1)
- slt : copy **Set** = Bit #31 of (\$rs \$rt), to the Bit #0 of slt 's output = **Less** of the Bit #0
- beq: \$rs \$rt == 0, all bits are 0 ⇔ NAND(Results0, 1, ..., 31) = 1
- For ALU0, Binvert and Carryln are both 0 for add , and , or , and both 1 for sub ⇒ combine



Carry-lookahead: for  $C_{out} = (a+b)C_{in} + ab$ ,

- ullet A Bit position generates a Carry iff both inputs are 1:  $G_i=a_i+b_i$
- ullet A Bit position propagates a Carry if exactly one input is 1:  $P_i=a_i\cdot b_i$

$$\begin{array}{l} \bullet \quad C_{i+1}=G_i+P_iC_i=\sum_{j=0}^i(G_i\prod_{k=j+1}^{i-j}P_k)+C_0\prod_{k=0}^iP_k\\ \\ \text{e.g. } C_4=G_3+G_2P_3+G_1P_2P_3+G_0P_1P_2P_3+C_0P_0P_1P_2P_3 \end{array}$$



# **Multiplication and Division**

(Example: 4-bit multiplication and division)

Unsigned multiplication:

```
Right(P) = Multiplier
while repetitions < 4
  if Product[0] = 1
    Left(P) = Left(P) + M
P = P >> 1
```

Signed multiplication: Booth's algorithm

```
Right(P) = Multiplier
while repetitions < 4
  if Product[0] = 1 and Product[-1] = 0
    Left(P) = Left(P) - M
  else if Product[0] = 0 and Product[-1] = 1
    Left(P) = Left(P) + M
  P = P >> 1
```

Unsigned division:

```
Right(R) = Dividend
R = R << 1

while repetitions < 4
    Left(R) = Left(R) - D
    if R[7] = 1
        Left(R) = Left(R) + D
        R = R << 1
        R[0] = 0
    else
        R = R << 1
        R[0] = 1</pre>
Left(R) = Left(R) >> 1
```


Unsigned Multiplication		Signed Multiplication			Unsigned Division			
		Multiplier			Multiplier	Divisor (D)	Remainder (R)	Remark
Multiplicand (M)	Product (P)	Remark	Multiplicand (M)	Product (P)	Remark		0000 0111 0000 1110	Initial state R = R << 1
	0000 0011	Initial state		0000 0110 0	Initial state		<u>1101</u> 1110	Left(R) = Left(R) - D
	0110 0011	Left(P) = Left(P) + M		0000 0110 0	No operation		0000 1110 0001 1100	Undo R = R << 1, R <sub>0</sub> = 0
	0011 0001	P = P >> 1		0000 0011 0	P = P >> 1		<u>1110</u> 1100	Left(R) = Left(R) - D
	1001 0001	Left(P) = Left(P) + M		1110 0011 0	Left(P) = Left(P) - M	0011	0001 1100 0011 1000	Undo R = R << 1, R <sub>0</sub> = 0
0110	0100 1000	P = P >> 1	0010	1111 0001 1	P = P >> 1		0000 1000	Left(R) = Left(R) – D
	0100 1000	No operation		1111 0001 1	No operation		0001 0001	R = R << 1, R <sub>0</sub> = 1
	0010 0100	P = P >> 1		1111 1000 1	P = P >> 1		1110 0001 0001 0001	Left(R) = Left(R) - D Undo
	0010 0100	No operation		0001 1000 1	Left(P) = Left(P) + M		0010 0010	R = R << 1, R <sub>0</sub> = 0
	0001 0010	P = P >> 1		0000 1100 0	P = P >> 1	Remainder	000 <b>1</b> 0010	Left(R) = Left(R) >>  Ouotient
							correction	•

Signed division:


- different signs on dividend and divisor: result should be negated
- remainder: same sign as the dividend

## **Processor**

## **ALU Controls**




## **Controls**



Instructions		E	X		MEM			WB	
	RegDst	ALUOp1	ALUOp2	ALUSrc	Branch	MemRead	MemWrite	RegWrite	MemToReg
R-format	1	1	0	0	0	0	0	1	0
lw	0	0	0	1	0	1	0	1	1
sw	Х	0	0	1	0	0	1	0	X
beq	Х	0	1	0	1	0	0	0	X

Signal name	Effect when deasserted	Effect when asserted
RegDst	The register destination number for the Write register comes from rt field (bits 20-16)	The register destination number for the Write register comes from <b>rd</b> field (bits 15-11)
RegWrite	None	Enable data write to the register specified by the register destination number
ALUSrc	The second ALU operand comes from the second register file output (Read data port 2).	The second ALU operand is the sign- extended, lower 16 bits of the instruction
PCSrc	The next PC picks up the output of the adder that computes PC+4	The next PC picks up the output of the adder that computes the branch target
MemRead	None	Enable read from memory. Memory contents designated by the address are put on the Read data output
MemWrite	None	Enable write to memory. Overwrite the memory contents designated by the address with the value on the Write data input
MemtoReg	Feed the Write data input of the register file with output from ALU	Feed the Write data input of the register file with output from memory

# Hazards



## **Structural Hazards**

- separate instruction and data memory/cache
- write in the 1st half (WB, MEM), read in the 2nd half (ID, IF) → read & write in one clock cycle

### **Data Hazards**

#### EX hazard


- EX/MEM.RegWrite and (EX/MEM.Rd ≠ 0) and (EX/MEM.Rd = ID/EX.Rs/Rt)
- Forward A/B = 10

### MEM hazard

- MEM/WB.RegWrite and (MEM/WB.Rd ≠ 0) and (MEM/WB.Rd = ID/EX.Rs/Rt) and (not EX hazard)
- Forward A/B = 01

#### Load-Use hazard


- ID/EX.Rt = IF/ID.Rs/Rt
- stall and insert bubble: force control values in ID/EX to 0, no update of PC and IF/ID



#### **Control Hazards**

### Branch hazards:

- can make decision: flush the ongoing subsequent instructions, branch to the correct one
- cannot make decision: forwarding and stalls
  - o forwarding from ALU: EX/MEM to ID/EX; from load: MEM/WB to ID/EX
  - o from preceding ALU or 2nd preceding load: 1 stall
  - o from preceding load: 2 stall



# **Memory**

# Hierarchy

#### **SRAM**

- Fastest
- Static: read is not destructive
- no need to periodically refresh
- transistors only

#### DRAM

- Dynamic: read is destructive
- need to recharge the capacitors periodically
- data stored in capacitors, read/write enabled in transistors

Disk: non-volatile, rotating magnetic storage

- Average Read Time
  - = seek time + rotational latency + transfer time + controller delay
  - = seek time + 0.5 / (rpm/60) + sector size / transfer rate + controller overhead
  - = 4ms + 0.5 / (15000/60) + 512B / (100MB/s) + 0.2ms = 6.2ms

Flash: non-volatile, semiconductor storage

### Cache

- hit rate = 1 miss rate
- cache hit time = time to determine hit/miss + time to access the cache
- cache miss penalty = time to bring a block from lower level to upper level >> cache hit time

### Direct-mapped

- block address = floor(memory address / bytes per block) = tag × number of blocks + index
- index = block address **mod** number of blocks = low-order m bits (if block address is 2<sup>m</sup>)
- tag = high-order bits
- memory (byte) address = tag (zero-extended) + index + data
- e.g. 8 cache frames for 8-word (2<sup>5</sup> bytes) blocks: 00 10 110 10001
- Cache Size: (e.g. 16KB of data, 8-word blocks, 32-bit address)
  - o = number of blocks × (bits of data per block + bits per tag + 1 valid bit)
  - o number of blocks = data size / bytes per block = 16KB / (32 B/block) = 29
  - o bits of data per block = 8 bit/B × 32 B/block = 256
  - bits per index = log<sub>2</sub>(number of blocks) = 9
  - bits per data =  $log_2(32 B/block \times 1 block) = 5$
  - bits per tag = bits per address bits per index bits per data = 32 9 5 = 18
  - $\circ = 2^9 \times (256 + 9 + 5 + 1) = 140800 \text{ (bits)} = 17.1875 \text{ KB}$
- Average Memory Access Latency = hit time<sub>1</sub> + miss rate<sub>1</sub> × miss penalty<sub>1</sub> = hit time<sub>1</sub> + miss rate<sub>1</sub> × (hit time<sub>2</sub> + miss rate<sub>2</sub> × miss penalty<sub>2</sub>) = hit time<sub>1</sub> + miss rate<sub>1</sub> × hit time<sub>2</sub> + miss rate<sub>1</sub> × miss rate<sub>2</sub> × miss penalty<sub>2</sub> + ...

N-Way Set associative: trade-off between hit rate and hit time

- Each block can be placed in a certain number (N) of cache locations
- Parallel lookup in one cache set

Block	Cache	Hit/miss	Cache content after access				
address	index		Set 0		Se	t 1	
0	0	miss	Mem[0]	Mem[0]			
8	0	miss	Mem[0]	Mem[8]			
0	0	hit	Mem[0]	Mem[8]			
6	0	miss	Mem[0]	Mem[6]			
8	0	miss	Mem[8]	Mem[6]			