Thomas E. Roth[®], Ruichao Ma, and Weng C. Chew [®]

The Transmon Qubit for Electromagnetics Engineers

An introduction.

ne of the most popular approaches being pursued to achieve a quantum advantage with practical hardware is the use of superconducting circuit devices. Although significant progress has been made over the previous two decades, substantial engineering efforts are required to scale these devices so they can be used to solve many problems of interest. Unfortunately, much of this exciting field is described using technical jargon and concepts from physics that are unfamiliar to a classically trained electromagnetics engineer. As a result, this work is often difficult for engineers to become engaged in.

We hope to lower the barrier to this field by providing an accessible review of one of the most prevalently used quantum bits (qubits) in superconducting circuit systems, the transmon qubit. Most of the physics of these systems can be understood intuitively with only some background in quantum mechanics. As a result, we avoid invoking quantum mechanical concepts except where it is necessary to ease the transition between details in this work and those that would be encountered in the literature. We believe this leads to a gentler introduction to this fascinating field, and we hope that more researchers from the classical electromagnetics community become engaged in this area in the future.


INTRODUCTION

Quantum computing and quantum communication are becoming increasingly active research areas, with recent advances in the field breaking into a "quantum advantage," where it has been claimed that quantum hardware has outperformed what is possible with the most powerful state-of-the-art classical hardware [1]–[3]. Although many platforms are still being pursued to implement quantum information processing, superconducting circuit architectures are one of the leading candidates [4]–[7]. These systems, also often called *circuit quantum electrodynamics* (QED)

Digital Object Identifier 10.1109/MAP.2022.3176593 Date of current version: 7 June 2022 devices, utilize the quantum dynamics of electromagnetic fields in superconducting circuits to generate and process quantum information.

Circuit QED devices are most often formed by embedding a special kind of superconducting device, known as a *Josephson junction*, into complex systems of planar microwave circuitry (also made from superconductors) [4]. At a high level, a Josephson junction is synonymous to a nonlinear inductor. By engineering Josephson junctions into various topologies, the nonlinear spectra of the resulting circuit can be used as the basis of a qubit with individually addressable quantum states. Using superconductors for the surrounding microwave circuitry also leads to close to zero dissipation. This allows the typically fragile quantum states involved to survive for long enough that planar "on-chip" realizations of the fundamental interactions of light and matter necessary to create and process quantum information can be leveraged at microwave frequencies [4]–[7].

Using these tools and the flexibility of these architectures, circuit QED designs have been implemented for a wide range of quantum technologies. Examples include analog quantum computers (see [8] for a specific example and [9] for a broader review), digital or gate-based quantum computers [1], [3], [10], [11], single photon sources [12]–[14], quantum memories [15], [16], and components of quantum communication systems [17], to name a few.



Circuit QED systems have garnered such a high degree of interest in large part because of the engineering control in the design and operation of these systems as well as the strength of light-matter coupling that can be achieved. The engineering control is due to the many types of qubits that can be designed to have desirable features using different configurations of Josephson junctions [6], [18]-[22]. Further, the operating characteristics of these qubits can be tuned in situ by electrically biasing them, allowing for a dynamic reconfiguration of the qubit that is not possible with fixed systems, like natural atoms and ions [6]. Additionally, the macroscopic scale of circuit QED qubits and the high confinement of electric and magnetic fields possible in planar transmission lines can be leveraged to achieve exceptionally strong coupling [23]. As a result, circuit QED systems have achieved some of the highest levels of light-matter coupling strengths seen in any physical system to date, providing an avenue to explore and harness untapped areas of physics [24]. Finally, many aspects of the fabrication of these systems can follow from established semiconductor fabrication techniques [6]. However, there remain many open challenges and opportunities related to the fabrication of these devices to continue to improve their performance [7].

Of the many superconducting qubits that have been designed to date, the transmon has become one of the most widely used since its creation and forms a key part of many scalable quantum information processing architectures using superconducting circuits [1], [3], [20]. An example of the typical on-chip features needed to operate a circuit QED device with four transmon qubits is shown in Figure 1. The features of this device will be discussed in more detail throughout this review.

In an effort to help the classical electromagnetics community become engaged in circuit QED research, we present a review of the essential properties of the transmon qubit. Our review is presented in a manner that should be largely accessible to individuals with a limited background in quantum mechanics. However, to achieve a deeper understanding of the quantum concepts discussed in this review, readers can also consult [25].

SUPERCONDUCTIVITY FOR CIRCUIT QED

Superconductivity plays a central role in the operation of all circuit QED systems. Fortunately, the physical effects needed in understanding circuit QED systems do not require a full microscopic theory to be used. Only a minimal knowledge of superconductivity is needed to understand the general physics of these systems. We review only the essential properties of superconductivity in this section at a very high level. A more detailed introduction to superconductivity in the context of circuit QED systems can be found in [26]–[28]. A more complete discussion of the physics of superconductivity, although not needed to understand most circuit QED systems, can be found in many common textbooks, e.g., [29].

Typically, quantum effects are only observable at microscopic levels due to the fragility of individual quantum states.

To observe quantum behavior at a macroscopic level (e.g., on the size of circuit components), a strong degree of coherence between individual microscopic systems must be achieved, with one possibility being superconductors cooled to very low temperatures [29]. At these temperatures, electrons in the material become bound to each other as Cooper pairs, which become the charge carriers of the superconductor [29]. These Cooper pairs are quasi-particles formed between two electrons with equal and opposite momenta, including the spins of the electrons. Many of the prop-

erties of superconductivity are able to occur due to the pairing of the electrons.

One particularly important result is that the Pauli exclusion principle does not apply to Cooper pairs, allowing them all to "condense" into a single quantum ground state (often referred to as a *condensate*) [29]. In addition to this, Cooper pairs are highly resilient to disturbances caused by scattering events (e.g., scattering from atomic lattices), making the overall quantum state describing the Cooper pair very stable. It is this remarkable stability that allows the quantum aspects of a superconductor to

Transmon Qubits 1 mm

FIGURE 1. An optical image of a typical device with four transmon qubits and the on-chip microwave network needed to operate the device. The arms of the transmons are $\sim 300 \, \mu m$ long and form an ~ 70 -fF capacitance to ground. The main operating frequencies of the transmons in this device are around 5 GHz, but this can be tuned in situ between approximately 4 and 6 GHz. The surrounding microwave transmission lines are used to control the transmons and monitor their quantum states through microwave spectroscopy.

Unfortunately, much of this exciting field is described using technical jargon and concepts from physics that are unfamiliar to a classically trained electromagnetics engineer.

be characterized by a small number of macroscopic quantum states [29]. As a result, tracking individual Cooper pair states is unnecessary, and a collective wave function can be used instead. Importantly, these collective wave functions have the necessary degree of coherence to make observing macroscopic quantum behavior possible. Circuit QED systems interact with these macroscopic quantum states using microwave photons and other circuitry [6].

To ensure that circuit QED systems can interact with macroscopic quantum states, the system must be cooled to an appropriately low tem-

perature. To observe basic superconducting effects, the relevant materials typically need to be cooled to $O(1\,K)$ [29]. However, circuit QED systems must operate at even lower temperatures so that thermal noise does not "swamp" the very-low-energy microwave photons used in these systems. As a result, circuit QED devices often operate at $O(10\,\mathrm{mK})$, which is achievable with modern dilution refrigerators [26], [30]. Although achievable, this impacts the cost of the system and the design of auxiliary components, such as microwave sources, circulators, and amplifiers, to name a few.

PHYSICS OF A JOSEPHSON JUNCTION

With the basic properties of superconductors understood, we can now consider more complicated systems used in qubits. Of utmost interest is a Josephson junction, which, for circuit QED systems, is typically formed by a thin insulative gap (on the order of a nanometer thick [26]) between two superconductors, although other configurations are possible [29]. Josephson junctions can be made from many materials, but, in circuit QED, Al/AlO_x/Al is typical. As we will see, this superconductor–insulator–superconductor "sandwich" exhibits a nonlinear I–V relationship, which is needed in designing most qubits.

The nonlinearity arises because the insulative gap in the junction acts as a barrier to the flow of Cooper pairs. However, as is commonly found at "thin" potential barriers, the Cooper pair wave functions between the two superconductors can overlap and allow interactions between the two regions. Due to this interaction, it is possible for Cooper pairs to coherently tunnel between the two superconducting regions without requiring an applied voltage [29]. The resulting tunneling supercurrent can be shown to have a nonlinear dependence on the junction voltage that is synonymous to that of a nonlinear inductor.

HAMILTONIAN DESCRIPTION OF A JOSEPHSON JUNCTION

Since, later, we will need to consider the quantum aspects of a Josephson junction, it is useful to consider a Hamiltonian mechanics description of this system. (For basic introductions to Hamiltonian mechanics in quantum theory, see [25], [31] and [32].) This amounts to expressing the total energy of the junction in terms of conjugate variables. These conjugate variables vary with respect to each other to ensure that the total energy of the system is conserved [25]. For the Josephson junction, the conjugate variables are often written in a dimensionless form as the Cooper pair density difference n and the Josephson phase φ . Importantly, voltage and current are not conjugate variables and, therefore, are not often used

in quantum descriptions of Josephson junctions. Initially considering the classical case, n and φ are real-valued deterministic numbers.

We will now assume that we have two isolated, finite-sized superconductors that are connected to each other by a Josephson junction. For the classical case, n is the net density of the Cooper pairs that have tunneled through the Josephson junction, and φ is the Josephson phase, which corresponds to the phase difference between the macroscopic condensate wave functions of the two superconductors [29].

The Hamiltonian of the Josephson junction can be found by considering the total energy of the junction in terms of an effective inductance and capacitance expressed in terms of n and φ . For most Josephson junctions, the effective inductance is the dominant effect. The form of the inductance can be readily inferred from the two Josephson relations, given as

$$\begin{cases} I = I_c \sin \varphi, & (1) \\ \frac{\partial \varphi}{\partial t} = \frac{2e}{\hbar} V, & (2) \end{cases}$$

where I is the supercurrent flowing through the junction, and V is the voltage across the junction [29]. Further, $I_c = 2eE_J/\hbar$ is the critical current of the junction, which is the maximum current that can nondissipatively tunnel through the junction. Finally, E_J is the Josephson energy, which measures the energy of a Cooper pair tunneling through the junction. In terms of the Josephson inductance L_J (the junction's minimum inductance), $E_J = L_J I_c^2$ follows a typical circuit theory form.

The relations given in (1) and (2) can be used to derive the form of the nonlinear Josephson inductance by noting that

$$\frac{\partial I}{\partial t} = \frac{\partial I}{\partial \varphi} \frac{\partial \varphi}{\partial t} = I_c \frac{2e}{\hbar} \cos(\varphi) V. \tag{3}$$

Rearranging this in the form of an I–V relation for an inductor shows that the tunneling physics results in an effective inductance given by $L(\varphi) = L_J/\cos\varphi$, where $L_J = \hbar/(2eI_c)$. Overall, the inductive energy needed in the Hamiltonian is typically given as $H_L = -E_I\cos\varphi$ [29].

Due to the physical arrangement of a Josephson junction, there is also a stray "parallel plate" capacitance. The energy

Circuit QED systems must operate at even lower temperatures so that thermal noise does not "swamp" the very-low-energy microwave photons used in these systems.

is found by noting that the total charge Q "stored" in the junction capacitance is 2en, where 2e is the charge of a Cooper pair. The charging energy of a single electron is $E_C = e^2/2C$, so the total capacitive energy of the junction $Q^2/2C$ can be written as $H_C = 4E_C n^2$ [29]. Depending on how the Josephson junction will be used, the stray capacitance may be negligible, so the junction can be considered to be purely a nonlinear inductor. We include the stray capacitance here since a similar term will be important in considering transmons later.

Combining the inductive and capacitive energy, the Hamiltonian for the Josephson junction is given by

$$H = H_C + H_L = 4E_C n^2 - E_I \cos \varphi.$$
 (4)

From a circuit theory viewpoint, this describes the total energy of a linear capacitor and nonlinear inductor in parallel. Since we have expressed the total energy of our system in terms of conjugate variables, we can use the principle of conservation of energy encoded in Hamilton's equations to find the equations of motion for this system. (See [25] for an example of this process.) More importantly, finding this Hamiltonian plays a key role in developing a quantum theory for this system.

Although the circuit theory viewpoint of (4) can be useful, the dynamical variables n and φ are not very intuitive for circuits. Fortunately, there is an intuitive mechanical system with the same dynamical equations as a Josephson junction, making it a useful analogy for understanding Josephson junctions (see "The Mechanical Equivalent of a Josephson Junction").

Before moving on, it is worth commenting on the relative scales of the energies for a Josephson junction, i.e., E_C and E_{I} . Since Josephson junctions used in circuit QED are physically very small, the effective capacitance of the junction is often small (in the femtofarad to low picofarad range), while the effective inductance can be in the nanohenry to low microhenry range [26]. However, by engineering the circuitry around a Josephson junction, great control over both E_C and E_I is possible. This can be done with additional Josephson junctions or with linear inductors and capacitors (either lumped or distributed elements). Using these tools, the characteristic ratio E_I/E_C can range from less than 0.1 to greater than 10⁶ depending on the device design [6]. This flexibility has been used to design many different qubits made from various combinations of Josephson junctions and auxiliary circuit elements, leading to a vast trade space for the optimization of qubits for circuit QED systems [6].

MAGNETIC FLUX-TUNABLE JOSEPHSON JUNCTION

When Josephson junctions are used to make qubits, it can be advantageous to be able to tune the operating characteristics of the overall system. One common modification

used with transmon qubits is to use two similar Josephson junctions in parallel as opposed to using a single junction [20], [30]. The two junctions then form a superconducting loop, which is often referred to as a superconducting quantum interference device (SQUID). The SQUID arrangement allows the effective Josephson energy of the overall circuit to be tuned through the application of an external magnetic flux [29]. By modifying the Josephson energy, the effective inductance of the SQUID loop can be tuned dynamically. This makes unique qubit operations possible that are not achievable with fixed qubits [6], such as natural atoms or ions. SQUIDs are very useful for this purpose, but they also have a long history of use in other areas of interest, including magnetometry for many scientific and biomedical applications, standards and metrology, and as other sensors and electronic components [34].

To see why E_J becomes tunable, we must revisit the effective inductance Hamiltonian H_L of the Josephson junction. With the second junction, this part of the Hamiltonian becomes

$$H_L = -E_I \cos \varphi_1 - E_I \cos \varphi_2, \tag{5}$$

where φ_i is the Josephson phase of the *i*th junction, and we have assumed that the Josephson energies for both junctions are identical. In reality, the Josephson energies are often made asymmetric on purpose to limit the tuning range of the SQUID. However, junction asymmetries do not change the overall conceptual result, so they are ignored here for simplicity [29].

In addition to (5), the physics of superconductors places another constraint on the relationship between φ_1 and φ_2 . In particular, because the phase of the collective wave

THE MECHANICAL EQUIVALENT OF A JOSEPHSON JUNCTION

There exists a simple mechanical analog to the Josephson junction that helps build intuition into its dynamics [S1]. In particular, it can be shown that the Hamiltonian for a pendulum of mass m attached to its center of rotation by a rigid, massless rod of length R is mathematically equivalent to (4). The comparison of these two systems is detailed in Figure S1. The Hamiltonian for the pendulum system is

$$H = \frac{1}{2mR^2}L^2 - mgR\cos\phi,\tag{S1}$$

where L is the angular momentum of the pendulum, g is the gravitational acceleration, and ϕ is the angular position of the pendulum's mass. The resting position of the mass (which is aligned with the gravitational field) is given by $\phi=0$. Comparing (4) and (S1), it is seen that the Josephson junction variables ϕ and n can be identified with ϕ and L of the pendulum, respectively.

The Hamiltonians of these systems can be used to derive the equations of motion for φ and ϕ . For the Josephson junction, we have

$$\frac{d^2\varphi}{dt^2} + 8E_C E_J \sin \varphi = 0, \tag{S2}$$

while, for the mechanical system, we have

$$\frac{d^2\phi}{dt^2} + \frac{g}{R}\sin\phi = 0. \tag{S3}$$

Recalling that E_C is inversely proportional to the junction capacitance, we can see that the junction capacitance impacts the dynamics of the Josephson phase in a similar manner to the radius of the mechanical pendulum.

The transmon corresponds to a qubit designed to force the dynamics of the Josephson junction to keep φ small. In this regime, the $\sin\varphi$ term can be expanded in its Taylor series. The transmon operates in a regime where the first two nonzero terms




FIGURE S1. Illustrations of (a) a Josephson junction and (b) a simple mechanical pendulum.

of the Taylor series can provide a reasonable approximation of the overall system's dynamics (often referred to as a *weakly anharmonic oscillator*). As is discussed in the main text, this regime is reached by lowering E_C by increasing the effective capacitance of the Josephson junction. From the view of the mechanical analog, this change is similar to making R larger while keeping g fixed.

Reference

[S1] C. P. Poole, R. Prozorov, H. A. Farach, and R. J. Creswick, *Superconductivity*, 3rd ed. New York, NY, USA: Elsevier, 2014.

function describing the superconducting condensate is single valued, it is necessary that the total phase difference around a superconducting loop be an integer multiple of 2π [29]. However, it can also be shown that an applied magnetic flux intersecting the superconducting loop will affect the total phase change of the condensate wave function around the loop. (This can be viewed in a manner similar to Faraday's law of induction or the Aharonov–Bohm effect). Overall, the result is that the Josephson phase difference around the SQUID is

$$\varphi_1 - \varphi_2 = 2\pi\ell + 2\pi\Phi/\Phi_0, \tag{6}$$

where ℓ is an integer, Φ is the total magnetic flux intersecting the loop formed by the SQUID, and $\Phi_0 = h/2e$ is the superconducting flux quantum [29].

Now, we can utilize standard trigonometric identities to rewrite (5) as

$$H_L = -2E_J \cos\left(\frac{\varphi_1 - \varphi_2}{2}\right) \cos\left(\frac{\varphi_1 + \varphi_2}{2}\right). \tag{7}$$

Defining a new Josephson phase as $\varphi = (\varphi_1 + \varphi_2)/2$ and using (6), we can simplify (7) to be

$$H_L = -E_{I\Phi}\cos\varphi,\tag{8}$$

where $E_{J\Phi} = 2E_J \cos(\pi \Phi/\Phi_0)$.

From this, we see that the effective inductance of the SQUID has the same form as that of a single Josephson junction. The main change is that the effective Josephson energy $E_{J\Phi}$ is now tunable due to an applied magnetic flux. Although this added control mechanism has many advantages, it also introduces a new way for a qubit with a SQUID to decohere due to interactions with a "noisy environment." As a result, the loop size of the SQUID is often extremely small (typically $O(10~\mu{\rm m})$ on each side of the loop), and the qubits are kept inside a shielded enclosure to minimize the sensitivity to environmental flux noise.

DEVELOPMENT OF THE TRANSMON QUBIT

One of the earliest qubits used to observe macroscopic quantum behavior in circuit QED systems was the Cooper pair box (CPB) [35], [36], which can be viewed as a predecessor to the transmon. Hence, to better understand the transmon, it is useful to consider it in the context of how it evolved from the simpler CPB qubit. This evolution is shown in terms of circuit schematics in Figure 2. We will review each of these different qubits in the coming sections.

INTRODUCTION TO THE CPB

The traditional CPB is formed by a Josephson junction that connects a superconducting "island" and "reservoir" [30]. For the CPB, the island is not directly connected to other circuitry, while the reservoir can be in contact with external circuit components (if desired). Since the superconducting

island is isolated from other circuitry, the CPB is very sensitive to the number of Cooper pairs that have tunneled through the Josephson junction (down to a single Cooper pair). Due to this sensitivity, the CPB is also called a *charge qubit* [30].

Typically, it is advantageous to be able to control the operating point of the CPB system. For instance, this can help with initializing the state of the CPB before conducting an experiment. Generally, the operating point of the CPB is set by a voltage source capacitively coupled to the superconducting island. This voltage can be tuned to induce a certain number of "background" Cooper pairs that have tunneled onto the superconducting island [30]. The basic circuit diagram of this qubit is shown in Figure 2(a). Although the circuit is changed somewhat compared to a simple Josephson junction, the resulting Hamiltonian still has a very similar form to (4). In particular, the CPB Hamiltonian is

$$H = 4E_C(n - n_g)^2 - E_I \cos \varphi, \tag{9}$$

where n_g is the offset charge due to the voltage source, and E_C must be modified to account for C_g [29], [30].

At this point, it is useful to consider the quantum description of the CPB. (For an introduction to quantum mechanical principles, see [25].) Since we have a Hamiltonian description of the system already expressed in terms of conjugate variables in (9), finding a quantum description of the system is quite simple [25]. In particular, the two conjugate variables are elevated to be noncommuting quantum operators denoted as \hat{n} and $\hat{\varphi}$, which can be viewed as being synonymous with infinite-dimensional




FIGURE 2. The circuit schematics for the evolution of a CPB to a transmon: the (a) CPB, (b) split CPB, and (c) transmon. A pure Josephson junction tunneling element is represented schematically as an "X." Often, to simplify the schematics, the small junction capacitance *C*, is absorbed into the Josephson tunneling element symbol and is represented as a box with an "X" through it, as seen in (b) and (c).

matrix operators. These operators must always satisfy the commutator $[\hat{\varphi},\hat{n}]=\hat{\varphi}\hat{n}-\hat{n}\hat{\varphi}=i$ [26]. Combined with a complex-valued quantum state function, denoted as $|\psi\rangle$ in Dirac notation, these quantum operators take on a statistical interpretation and share an uncertainty principle relationship [25]. In particular, the uncertainty principle for \hat{n} and $\hat{\varphi}$ gives that the standard deviations of the two operators must follow $\sigma_n\sigma_{\varphi}\geq 1/2$. As a result, measurements of the observables associated with these quantum operators (e.g., the number of Cooper pairs that have tunneled through the junction) cannot be measured simultaneously with arbitrary precision [25].

Now, in transitioning to a quantum description, the classical Hamiltonian for the CPB given in (9) becomes a Hamiltonian operator given by

$$\hat{H} = 4E_C(\hat{n} - n_g)^2 - E_I \cos \hat{\varphi},\tag{10}$$

where it is noted that n_g remains a classical variable that describes the offset charge induced by an applied dc voltage. This Hamiltonian can be used in the quantum state equation (a generalization of the Schrödinger equation) to determine the time evolution of a quantum state [25]. In particular, the quantum state equation is

$$\hat{H} \mid \psi \rangle = i\hbar \partial_t \mid \psi \rangle. \tag{11}$$

In the process of solving (11), it is often useful to identify the stationary states of the Hamiltonian by converting (11) into a time-independent eigenvalue problem. This is

$$\hat{H} \mid \Psi \rangle = E \mid \Psi \rangle, \tag{12}$$

where E is the energy associated with stationary state (or eigenvector) $|\Psi\rangle$.

For a typical CPB, $E_J/E_C < 1$. As a result, it becomes useful to write the qubit Hamiltonian given in (10) in terms of charge states. These are eigenstates of \hat{n} and are often denoted as $|N\rangle$. (In this notation, $|N\rangle$ can be viewed like a column vector, with $\langle N|$ being its conjugate transpose.) The eigenvalue associated with this eigenstate is N, which is always a discrete number that counts how many Cooper pairs have tunneled through the Josephson junction relative to the equilibrium state. In terms of charge states, the effective capacitance term of the CPB Hamiltonian becomes

$$4E_{C}(\hat{n}-n_{g})^{2} = 4E_{C} \sum_{N} (N-n_{g})^{2} |N\rangle\langle N|.$$
 (13)

The combination $|N\rangle\langle N|$ can be viewed as an outer product between the states $|N\rangle$ and $|N\rangle$. Hence, the operator $|N\rangle\langle N|$ can be viewed like a matrix in a more familiar linear algebra notation. Since the charge states are all orthogonal, the sum of operators $|N\rangle\langle N|$ can be viewed as "diagonalizing" this term

ESSENTIAL PROPERTIES OF A QUBIT

For a physical system to be used as a qubit, it must have two distinct quantum states that can be "isolated" from other states in the system. Further, one needs to selectively drive transitions between the two states that form the qubit without accidentally exciting other states of the physical system. For the qubits discussed in this review, a qubit is formed by the two lowest energy levels of the system. The difference in energy levels dictates what frequencies of microwave radiation can be absorbed or emitted from the qubit. As a result, it is necessary for the energy levels to be unevenly spaced for the physical system to act as a qubit.

Oftentimes, this requires the qubit to be nonlinear. The nonlinearity refers to the "restoring force" due to the potential energy term of the Hamiltonian. Physical systems with quadratic potentials have linear restoring forces and are characterized by having evenly spaced energy levels (and, thus, are a kind of quantum harmonic oscillator). Linear transmission lines and *LC* resonators have these characteristics, and, as a result, cannot be used as qubits. In contrast to this, the CPB and transmon have a cosine potential energy term that leads to a nonlinear restoring force and unevenly spaced energy levels (see Figure S2). Hence, they are candidates to be used as qubits. Many other physical systems with different potential energies can also be used as qubits [S2, Box 1]. The corresponding different energy level configurations make for a rich toolbox for manipulating quantum information.




FIGURE S2. The potential energies and corresponding energy level spacing for (a) a quadratic potential (e.g., that of a linear LC resonator) and (b) a cosine potential (e.g., that of a nonlinear resonator, like the CPB or transmon). In (b), the corresponding levels of a harmonic oscillator are included as dashed lines to highlight the anharmonicity of the cosine potential.

It is also necessary to reliably initialize the state of the qubit to a known value, often the qubit's ground state. Generally, this requires the qubit to be isolated from any environments that could provide enough energy to the qubit to spontaneously raise it to its excited state. One prevalent source of this is thermal energy, and this is the primary reason why circuit QED systems must be operated at such low temperatures.

Reference

[S2] I. Buluta, S. Ashhab, and F. Nori, "Natural and artificial atoms for quantum computation," *Rep. Prog. Phys.*, vol. 74, no. 10, p. 104,401, 2011, doi: 10.1088/0034-4885/74/10/104401.

of the Hamiltonian. Now, in terms of charge states, the effective nonlinear inductance term of the CPB Hamiltonian becomes [29], [30]

$$-E_{J}\cos\hat{\varphi} = \frac{E_{J}}{2} \sum_{N} (|N\rangle\langle N+1| + |N+1\rangle\langle N|). \tag{14}$$

Due to the orthogonality of the charge states, the operator $|N\rangle\langle N+1|$ represents the coherent transfer of a single Cooper pair from the island to the reservoir. Correspondingly, the operator $|N+1\rangle\langle N|$ has a similar interpretation, but with the Cooper pair being transferred from the reservoir to the island. Hence, this representation clearly shows the tunneling physics involved in the effective inductance of the CPB.

CPB AS A QUBIT

To determine how a CPB can be used as a qubit, it is useful to consider its operating characteristics as a function of the offset charge $n_{\rm g}$. (For a discussion of the needed properties of a qubit, see "Essential Properties of a Qubit"). As we will see shortly, it is advantageous to set $n_{\rm g}$ to either integer or half-integer values for typical qubit operations [30]. For this discussion, the primary benefits of operating at these $n_{\rm g}$ points can be best understood by considering the energy level diagram of a CPB as a function of $n_{\rm g}$. This diagram plots the energy eigenvalues E_i of (12) for different eigenvectors (or stationary states) $|\Psi_i\rangle$. The operating frequency of the CPB qubit (i.e., what frequencies of microwave radiation can be absorbed or emitted) is based on the energy difference between two adjacent energy levels.

The energy level diagram is shown for the first three energy levels of the CPB in Figure 3, where it is seen that the energy levels strongly depend on $n_{\rm g}$. Beginning with $n_{\rm g}$ having an integer value, it is seen that there is a very large separation between the ground and excited states. This large spacing makes it highly unlikely that the CPB can be spontaneously excited, making this operating point useful for quickly initializing the CPB to its ground state.

Although this operating point can establish a good ground state, it is not useful for qubit operations because the first two excited states have similar energies. This makes it difficult to prevent the system from unintentionally transitioning into and out of the second excited state once the first excited state has been populated. Hence, a different operating point is needed to perform qubit operations.

Considering the energy level diagram of Figure 3 again, it is seen that half-integer values of $n_{\rm g}$ are ideal for performing qubit operations. At these values, there is a large separation between the energy levels of the first two excited states. Further, it is seen that the energy levels exhibit a high degree of anharmonicity here. That is, the energy levels are not evenly spaced like a harmonic oscillator or linear resonator (see Figure S2 in "Essential Properties of a Qubit" for a direct comparison). As a result of these two properties, the transition between the ground and first excited state can be selectively driven with fast microwave pulses (on the order one to tens of nanoseconds [20], [37]) without requiring significant filtering of the pulse. This allows for qubit operations to be performed very quickly, which is very attractive for building a quantum computer.

The flexibility of operating a CPB can be increased further by replacing the single Josephson junction with a SQUID. This configuration is known as a *split CPB* and is shown schematically in Figure 2(b). By applying a magnetic flux, the E_J of the split CPB can be tuned dynamically. Since the energy difference between the different states seen in Figure 3 depends on E_J , the SQUID can be used to tune the operating frequency of the split CPB in situ.

A further benefit to operating at half-integer values of n_g is that the two lowest energy levels are locally flat near this operating point (i.e., the slope is approximately zero). As a result, the qubit transition frequency is less sensitive to noise in the n_g variable (often referred to as *charge fluctuations* or *charge noise*). The improved coherence of the CPB at this operating point has led to it being known as the *sweet spot* for CPBs [30]. Using these strategies, CPBs with coherence times on the nanosecond to microsecond scale were achieved [38]. Although this was sufficient to replicate various quantum phenomena observed in quantum optical systems [6], the CPB was still too sensitive to charge noise to form a part of a scalable quantum information processing system. The transmon was introduced to address this issue.

TRANSMON

The transmon qubit is best viewed as a CPB shunted by a capacitor that is large relative to the stray capacitance of the Josephson junction [20]. This kind of design modification was originally proposed in the context of superconducting flux qubits [19], and it continues to be a useful technique in qubit design. In the context of the transmon, the updated circuit schematic is shown in Figure 2(c), where C_B is the large shunting capacitance. Recalling that E_C is inversely proportional to capacitance, this results in the characteristic ratio E_J/E_C transitioning from $E_J/E_C < 1$ for a traditional CPB to $E_J/E_C \gg 1$ for a transmon.

Originally, the large shunting capacitance was made using interdigital capacitors [20]. Now, the shunting capacitance is more commonly implemented as a large "cross" shape (which is




FIGURE 3. The first three energy levels of the qubit Hamiltonian given in (10) for $E_J/E_C=1$. The energy levels are normalized by the transition energy between the first two states evaluated at half-integer values of n_q .

shown in Figure 4 and is sometimes also referred to as an *Xmon qubit*) [11]. This newer shape is typically favored because it provides better interconnectivity between the different parts of a design. Although the physical implementation of the transmon qubit is different from more traditional CPB qubits, a Hamiltonian with the same form as (10) can still be used to describe its behavior [20]. Similarly, a SQUID can be used to connect the differ-

ent superconductors that make up the transmon (see Figure 4), allowing the operating frequency of the transmon to be tuned via an applied magnetic flux.

It is instructive to see how the first few energy levels of (10) change as a function of E_J/E_C to understand the impact of adding the large shunting capacitance around the Josephson junction. This is shown for four different values of E_J/E_C in Figure 5. These demonstrate the transition from a traditional CPB in Figure 5(a) to a transmon in Figure 5(d). From Figure 5, it is seen that, as E_J/E_C is increased, the energy levels flatten out as a function of n_g while simultaneously becoming more harmonic (closer to equally spaced, like a quantum harmonic oscillator). Fortunately, the sensitivity to charge noise reduces at an exponential rate, while the anharmonicity reduces following a weak power law [20]. This leads to a qubit that is insensitive to charge noise for practical purposes but is still able to provide sufficient anharmonicity to effectively perform qubit operations with

The transmon qubit is best viewed as a CPB shunted by a capacitor that is large relative to the stray capacitance of the Josephson junction.

short-duration microwave pulses. Typically, the main operating frequencies of transmons range from a few gigahertz to 10 GHz, with anharmonicities of ~100–300 MHz

From the view of a mechanical equivalent, the transmon case is analogous to the rigid pendulum with dynamics dominated by a gravitational field [20] (see "The Mechanical Equivalent of a Josephson Junction"). This forces

the angular values of the pendulum to small values. For this operating point, the dynamics correspond to a weakly anharmonic oscillator, which leads to the energy level separation seen in Figure 5(d). The flatness of the energy levels in Figure 5(d) can be understood from the transmon Hamiltonian (10), where it is seen that $n_{\rm g}$ is multiplied by $E_{\rm C}$. Since $E_{\rm C}$ is made small for a transmon, $n_{\rm g}$ can only have a small role in the dynamics. Due to this, the voltage source seen in Figure 2(c) is no longer a useful control mechanism and so is omitted for practical designs.

As a result of the transmon's resilience to charge noise (and other manufacturing and experimental advances), the coherence times of modern transmons are able to achieve values in the range of hundreds of microseconds, representing an orders-of-magnitude improvement over the best CPB qubits [38], [40]. However, other sources of decoherence still persist, making the identification and reduction of decoherence still an important research topic [7].




FIGURE 4. Images of a frequency-tunable transmon qubit: (a) the entire transmon consisting of a large capacitance (the "+" shape) in parallel with a SQUID to the ground, (b) a zoom-in of the SQUID, and (c) a single Josephson junction.

INTERFACING TRANSMON QUBITS WITH OTHER CIRCUITRY

A completely isolated qubit cannot be controlled or measured and, therefore, is of little use. Further, to implement many kinds of quantum information processing operations, multiple qubits that are spatially separated need to interact with each other to generate entanglement. Circuit QED systems address this by coupling qubits to transmission line structures. Often, these transmission lines will be resonators that can be used as a quantum "bus" to connect different qubits to each other or as part of a measurement chain to read out the quantum states of the qubits (e.g., see Figure 1) [4]–[6]. Although this is the most common scenario, it is also possible to interface superconducting qubits with other quantum systems [41]. These hybrid quantum circuits provide exciting new capabilities and may form an essential part of future quantum technologies.

An example of the typical on-chip features needed to operate a single transmon and the corresponding approximate circuit model are shown in Figure 6. As is common in the circuit QED community, a single mode of the transmission line resonator is modeled in a lumped-element approximation as an *LC*

tank circuit in Figure 6(b) [20]. More modes of the resonator often must be considered to provide more accurate predictions of experimental results, and they can be accounted for by including additional LC tank circuits [42], [43]. Regardless, the lumped-element approximation makes it difficult to optimize the design of these systems. Hence, developing full-wave numerical modeling methods that can rigorously analyze these systems is an area of future research interest [33].

The main features to operate the transmon shown in Figure 6 are the flux bias line, the qubit drive line, and the state readout features. The flux bias line is used to apply a magnetic flux to the SQUID loop of the transmon to change its operating frequency. This can help correct for manufacturing variability and can also be a key capability in executing certain quantum-information-processing algorithms [11].

The qubit drive line is used to modify the state of the qubit by applying a microwave drive pulse with a center frequency that matches the transmon's operating frequency. If the transmon starts in its ground state, an appropriately designed microwave drive pulse can be used to raise the transmon to its excited state or to place it in some superposition of the transmon's ground and




FIGURE 5. The first three energy levels of the qubit Hamiltonian given in (10) for values of E_J/E_C , ranging from the (a) CPB regime to (d) transmon regime. The energy levels are normalized by the transition energy between the first two states evaluated at half-integer values of n_q .

excited states [5]. Further microwave drive pulses can be applied along the qubit drive line to modify the transmon's state as needed throughout the course of executing a quantum algorithm.

Finally, it is necessary to determine the state of the transmon after executing a quantum algorithm. The most common way to do this is known as a *dispersive readout*, with a simple setup to achieve this shown in Figure 6 [5]. This approach leverages the fact that the state of the transmon (e.g., if it is in its ground or excited state) modifies the resonant frequencies of the readout resonator, as shown in Figure 6(c). These changes can be monitored via microwave spectroscopy in the form of transmission measurements made between the readout ports.

All of these effects (and many more) can be studied for circuit QED systems using a generalization of the famous Jaynes—Cummings Hamiltonian, which is one of the most widely studied models in quantum optics and cavity QED [39]. This is also the starting point for many applied circuit QED studies. To help transition between this work and the modern literature, we now provide a brief introduction to how this Hamiltonian can be used for circuit QED systems.

GENERALIZED JAYNES-CUMMINGS HAMILTONIAN

To simplify the development, we focus only on describing the case of a single transmon qubit capacitively coupled to a single resonator. More qubits and resonators can be handled as simple extensions of the model discussed here.

A full development of the Hamiltonian description of this circuit is tedious and, therefore, will be omitted for brevity (for details, see [28, Appendix A]). Here, we focus on an intuitive development only. As is often possible for coupled systems, we can write the total Hamiltonian as a sum of uncoupled (or "free") Hamiltonians and an interaction Hamiltonian that accounts for the coupling. Considering this, we will have

$$\hat{H} = \hat{H}_T + \hat{H}_R + \hat{H}_I,\tag{15}$$

where $\hat{H}_T(\hat{H}_R)$ denotes the free transmon (resonator) Hamiltonian, and \hat{H}_I is the interaction Hamiltonian. The free transmon Hamiltonian has already been given in (10). However, to further simplify the analysis, the transmon Hamiltonian is typically diagonalized in terms of its eigenstates [20]. Using these eigenstates, (10) can be rewritten as

$$\sum_{j} \hbar \omega_{j} |j\rangle\langle j|, \tag{16}$$

where ω_j is the eigenvalue associated with eigenstate $|j\rangle$, and the operator $|j\rangle\langle j|$ can be viewed as part of an eigenmode decomposition of the Hermitian "matrix" \hat{H}_T .




FIGURE 6. (a) A typical single-transmon device. Microwave pulses are applied to the qubit drive line to modify the state of the transmon. The flux bias line is used to dynamically tune the operating frequency of the transmon. The state of the transmon (e.g., if it is in its ground or excited state) can be monitored via microwave transmission measurements made between the two readout ports. (b) An equivalent lumped-element circuit model of the device in (a). (c) The transmon state-dependent transmission spectra between the readout ports.

The free resonator Hamiltonian is simple to write since it is the total energy contained in the LC tank circuit elements C_r and L_r . From basic circuit theory, this will be

$$\hat{H}_r = \frac{1}{9} [L_r \hat{I}_r^2 + C_r \hat{V}_r^2], \tag{17}$$

where \hat{I}_r and \hat{V}_r are the current and voltage in the LC tank circuit, respectively. Typically, it is advantageous to express the voltage and current in terms of ladder operators that diagonalize \hat{H}_r [20]. In particular, \hat{a}^{\dagger} (\hat{a}) is known as the *creation* (annihilation) operator, and, when it operates on the quantum state of the resonator, it increases (decreases) the photon number by one [39]. Using the properties of the ladder operators, (17) can be rewritten as

$$\hat{H}_r = \hbar \omega_r \hat{a}^\dagger \hat{a},\tag{18}$$

where ω_r is the resonant frequency of the transmission line resonator, and a constant term (known as the zero point energy) has been removed since it does not affect the dynamics.

One way to approach determining \hat{H}_I is to recognize that, because it is a capacitive coupling, it will be sensible to write the interaction in terms of the voltages and charges. Now, for many circuit QED systems, the resonator voltage, as seen from the transmon, can be approximately viewed as coming from an ideal voltage source. Considering this, the interaction between the resonator and transmon can be given by

$$\hat{H}_I = 2e\beta \hat{V}_r \hat{n},\tag{19}$$

where \hat{n} is the charge operator of the transmon, and $\beta = C_g/(C_g + C_q)$ is a capacitive voltage divider that places the correct ratio of the resonator voltage on the transmon [20]. In terms of the resonator ladder operators, this becomes

$$\hat{H}_I = 2e\beta V_{\rm rms}(\hat{a} + \hat{a}^{\dagger})\hat{n},\tag{20}$$

where $V_{\rm rms} = \sqrt{\hbar \omega_r/2C_r}$. To further simplify the analysis, \hat{n} can be rewritten in terms of transmon eigenstates, and a number of standard approximations can be applied to finally arrive at an interaction Hamiltonian of [20]

$$\sum_{j} \langle g_{j} | j - 1 \rangle \langle j | \hat{a}^{\dagger} + g_{j}^{*} | j \rangle \langle j - 1 | \hat{a} \rangle, \tag{21}$$

where $g_j = 2e\beta V_{\text{rms}} \langle j - 1 | \hat{n} | j \rangle$.

Putting all of these results together, the complete system Hamiltonian of (15) becomes

$$\begin{split} \hat{H} &= \sum_{j} \hbar \omega_{j} \left| j \right\rangle \left\langle j \right| + \hbar \omega_{r} \hat{a}^{\dagger} \hat{a} \\ &+ \sum_{j} \left(g_{j} \left| j - 1 \right\rangle \left\langle j \right| \hat{a}^{\dagger} + g_{j}^{*} \left| j \right\rangle \left\langle j - 1 \right| \hat{a} \right), \end{split} \tag{22} \end{split}$$

This is a generalized form of the Jaynes-Cummings Hamiltonian, which can be used to study many practical effects related to quantum information processing [4]–[6]. In (22), the terms multiplied by g_j represent the coherent exchange of excitations between the transmon and resonator. This "swapping" of

excitations is particularly prevalent when ω_j and ω_r are nearly equal and is usually referred to as *vacuum Rabi oscillations*.

However, when $\Delta = |\omega_j - \omega_r| \gg g_j$, the transmon and resonator are said to be in the dispersive regime of circuit QED [6]. In this regime, the Hamiltonian of (22) can be approximated as

$$\hat{H} \approx \hbar (\omega_r - \chi |1\rangle \langle 1| + \chi |0\rangle \langle 0|) \hat{a}^{\dagger} \hat{a} + \frac{\hbar}{2} (\omega_1 + \chi) (|0\rangle \langle 0| - |1\rangle \langle 1|),$$
(23)

where only the two lowest transmon states have been used for clarity, and $\chi = g_1^2/|\omega_1 - \omega_r|$ [6]. One important property of (23) is that the resonator frequency depends on the state of the transmon. [This is seen in the first set of parentheses in (23).] In particular, the resonator frequency shifts to $\omega_r + \chi$ or $\omega_r - \chi$ if the transmon is in its ground or excited state, respectively. For this reason, χ is often referred to as the *dispersive shift*. This shift in the resonant frequency can be measured via microwave spectroscopy of the readout resonator. This technique is known as the *dispersive readout* because there is no energy transfer between the transmon and the resonator, and it is one of the most common ways to monitor the state of a transmon [6].

CONCLUSIONS AND OUTLOOK

Circuit QED systems have emerged as one of the most promising candidates for quantum information processing on the scale needed to achieve a quantum advantage in practical applications. Although many different qubits have been used in circuit QED systems, the transmon has become the workhorse qubit in superconducting circuit systems.

In this work, we presented a review of the essential properties of the transmon qubit in a manner that is largely accessible to members of the classical electromagnetics engineering community who have a limited background in quantum mechanics. These systems require a significant amount of classical engineering to be successful, such as designing the classical control and readout systems for the qubits and developing compact electrical components that can operate at the various cryogenic stages of a dilution refrigerator, to name a few. There is also a need for improved classical simulation tools to assist in the design process of these systems. We firmly believe that members of the classical electromagnetics engineering community can play a vital role in the advancement of this new era of electromagnetics devices, and we look forward to seeing this happen.

ACKNOWLEDGMENTS

This work was supported by NSF ECCS 169195, a start-up fund at Purdue University, and the Distinguished Professorship Grant at Purdue University.

AUTHOR INFORMATION

Thomas E. Roth (rothte@purdue.edu) is an assistant professor with the Elmore Family School of Electrical and Computer Engineering, Purdue University, West Lafayette, Indiana, 47907, USA. His research interests include multiscale and multiphysics

electromagnetic modeling, with an emphasis on quantum electromagnetic systems. He is a Member of IEEE.

Ruichao Ma (maruichao@purdue.edu) is an assistant professor with the Department of Physics and Astronomy, Purdue University, West Lafayette, Indiana, 47907, USA. His research interests include engineering synthetic quantum matter in superconducting circuits for the experimental investigation of many-body physics and quantum information sciences.

Weng C. Chew (wcchew@purdue.edu) is with the Department of Electrical and Computer Engineering, University of Illinois at Urbana-Champaign, Urbana, Illinois, 61801, USA, and is a distinguished professor with the Elmore Family School of Electrical and Computer Engineering, Purdue University, West Lafayette, Indiana, 47907, USA. His research interests include wave physics, fast algorithms for imaging, electromagnetics/computational electromagnetics from statics to optics, and the quantum theory of electromagnetics. He is a Fellow of IEEE.

REFERENCES

- [1] F. Arute *et al.*, "Quantum supremacy using a programmable superconducting processor," *Nature*, vol. 574, no. 7779, pp. 505–510, 2019, doi: 10.1038/s41586-019-1666-5.
- [2] H.-S. Zhong $et\ al.$, "Quantum computational advantage using photons," Science, vol. 370, no. 6523, pp. 1460–1463, 2020, doi: 10.1126/science.abe8770.
- [3] Y. Wu et al., "Strong quantum computational advantage using a superconducting quantum processor," *Phys. Rev. Lett.*, vol. 127, no. 18, p. 180,501, 2021, doi: 10.1103/PhysRevLett.127.180501.
- [4] A. Blais, R.-S. Huang, A. Wallraff, S. M. Girvin, and R. J. Schoelkopf, "Cavity quantum electrodynamics for superconducting electrical circuits: An architecture for quantum computation," *Phys. Rev. A*, vol. 69, no. 6, p. 062320, 2004, doi: 10.1103/PhysRevA.69.062320.
- [5] A. Blais et al., "Quantum-information processing with circuit quantum electrodynamics," Phys. Rev. A, vol. 75, no. 3, p. 032329, 2007, doi: 10.1103/ PhysRevA.75.032329.
- [6] X. Gu, A. F. Kockum, A. Miranowicz, Y.-X. Liu, and F. Nori, "Microwave photonics with superconducting quantum circuits," *Phys. Rep.*, vols. 718–719, pp. 1–102, Nov. 2017, doi: 10.1016/j.physrep.2017.10.002.
- [7] P. Krantz, M. Kjaergaard, F. Yan, T. P. Orlando, S. Gustavsson, and W. D. Oliver, "A quantum engineer's guide to superconducting qubits," *Appl. Phys. Rev.*, vol. 6, no. 2, p. 021318, 2019, doi: 10.1063/1.5089550.
- [8] R. Maet~al., "A dissipatively stabilized Mott insulator of photons," Nature, vol. 566, no. 7742, pp. 51–57, 2019, doi: 10.1038/s41586-019-0897-9.
- [9] I. M. Georgescu, S. Ashhab, and F. Nori, "Quantum simulation," Rev. Modern Phys., vol. 86, no. 1, p. 153, 2014, doi: 10.1103/RevModPhys.86.153.
- [10] A. Kandala et al., "Hardware-efficient variational quantum eigensolver for small molecules and quantum magnets," *Nature*, vol. 549, no. 7671, pp. 242–246, 2017, doi: 10.1038/nature23879.
- [11] R. Barends *et al.*, "Superconducting quantum circuits at the surface code threshold for fault tolerance," *Nature*, vol. 508, no. 7497, pp. 500–503, 2014, doi: 10.1038/nature13171.
- [12] A. A. Houck et al., "Generating single microwave photons in a circuit," Nature, vol. 449, no. 7160, pp. 328–331, 2007, doi: 10.1038/nature06126.
- [13] Y. Zhou, Z. Peng, Y. Horiuchi, O. Astafiev, and J. Tsai, "Tunable microwave single-photon source based on transmon qubit with high efficiency," *Phys. Rev. Appl.*, vol. 13, no. 3, p. 034007, 2020, doi: 10.1103/PhysRevApplied.13.034007.
- [14] C. Lang *et al.*, "Correlations, indistinguishability and entanglement in Hong–Ou–Mandel experiments at microwave frequencies," *Nature Phys.*, vol. 9, no. 6, pp. 345–348, 2013, doi: 10.1038/nphys2612.
- [15] M. Reagor et al., "Quantum memory with millisecond coherence in circuit QED," Phys. Rev. B, vol. 94, no. 1, p. 014506, 2016, doi: 10.1103/Phys RevB.94.014506.
- [16] K. Sardashti, M. C. Dartiailh, J. Yuan, S. Hart, P. Gumann, and J. Shabani, "Voltage-tunable superconducting resonators: Platform for random access quantum memory," *IEEE Trans. Quantum Eng.*, vol. 1, pp. 1–7, Jun. 2020, doi: 10.1109/TQE.2020.3034553.
- [17] N. Leung *et al.*, "Deterministic bidirectional communication and remote entanglement generation between superconducting qubits," *npj Quantum Inf.*, vol. 5, no. 1, pp. 1–5, 2019, doi: 10.1038/s41534-019-0128-0.

- [18] D. Vion et al., "Manipulating the quantum state of an electrical circuit," Science, vol. 296, no. 5569, pp. 886–889, 2002, doi: 10.1126/science.1069372.
- [19] J. You, X. Hu, S. Ashhab, and F. Nori, "Low-decoherence flux qubit," *Phys. Rev. B*, vol. 75, no. 14, p. 140,515, 2007, doi: 10.1103/PhysRevB.75.140515.
- [20] J. Koch et al., "Charge-insensitive qubit design derived from the Cooper pair box," Phys. Rev. A, vol. 76, no. 4, p. 042319, 2007, doi: 10.1103/PhysRevA.76.042319.
- [21] V. E. Manucharyan, J. Koch, L. I. Glazman, and M. H. Devoret, "Fluxonium: Single cooper-pair circuit free of charge offsets," *Science*, vol. 326, no. 5949, pp. 113–116, 2009, doi: 10.1126/science.1175552.
- [22] F. Yan et al., "The flux qubit revisited to enhance coherence and reproducibility," Nature Commun., vol. 7, no. 1, pp. 1–9, 2016, doi: 10.1038/ncomms12964.
- [23] M. Devoret, S. Girvin, and R. Schoelkopf, "Circuit-QED: How strong can the coupling between a Josephson junction atom and a transmission line resonator be?" *Annalen der Physik*, vol. 16, nos. 10–11, pp. 767–779, 2007, doi: 10.1002/andp.200710261.
- [24] A. F. Kockum, A. Miranowicz, S. De Liberato, S. Savasta, and F. Nori, "Ultrastrong coupling between light and matter," *Nature Rev. Phys.*, vol. 1, no. 1, pp. 19–40, 2019, doi: 10.1038/s42254-018-0006-2.
- [25] W. C. Chew, D. Y. Na, P. Bermel, T. E. Roth, C. J. Ryu, and E. Kudeki, "Quantum Maxwell's equations made simple: Employing scalar and vector potential formulation," *IEEE Antennas Propag. Mag.*, vol. 63, no. 1, pp. 14–26, 2021, doi: 10.1109/MAP.2020.3036098.
- [26] U. Vool and M. Devoret, "Introduction to quantum electromagnetic circuits," *Int. J. Circuit Theory Appl.*, vol. 45, no. 7, pp. 897–934, 2017, doi: 10.1002/cta.2359.
- [27] N. K. Langford, "Circuit QED Lecture notes," 2013, arXiv:1310.1897.
- [28] S. M. Girvin, "Circuit QED: Superconducting qubits coupled to microwave photons," in *Quantum Machines: Measurement and Control of Engineered Quantum Systems*, M. Devoret, B. Huard, R. Schoelkopf, and L. F. Cugliandolo, Eds. London, U.K.: Oxford Univ. Press, 2014, pp. 113–256.
- [29] M. Tinkham, Introduction to Superconductivity. New York, NY, USA: Dover, 2004.
- [30] A. F. Kockum and F. Nori, "Quantum bits with Josephson junctions," in Fundamentals and Frontiers of the Josephson Effect, F. Tafuri, Ed. New York, NY, USA: Springer-Verlag, 2019, pp. 703–741.
- [31] W. C. Chew, A. Y. Liu, C. Salazar-Lazaro, and W. E. I. Sha, "Quantum electromagnetics: A new look–Part I," *IEEE J. Multiscale Multiphys. Comput. Tech.*, vol. 1, pp. 73–84, Oct. 2016, doi: 10.1109/JMMCT.2016.2617018.
- [32] W. C. Chew, A. Y. Liu, C. Salazar-Lazaro, and W. E. I. Sha, "Quantum electromagnetics: A new look–Part II," *IEEE J. Multiscale Multiphys. Comput. Tech.*, vol. 1, pp. 85–97, Oct. 2016.
- [33] T. E. Roth and W. C. Chew, "Macroscopic circuit quantum electrodynamics: A new look toward developing full-wave numerical models," *IEEE J. Multiscale Multiphys. Comput. Tech.*, vol. 6, pp. 109–124, Apr. 2021, doi: 10.1109/JMMCT.2021.3112808.
- [34] J. Clarke and A. I. Braginski, *The SQUID Handbook Vol. 2: Applications of SQUIDs and SQUID Systems*. Weinheim, Germany: Wiley-VCH, 2006.
- [35] V. Bouchiat, D. Vion, P. Joyez, D. Esteve, and M. H. Devoret, "Quantum coherence with a single Cooper pair," *Physica Scripta*, vol. 1998, no.T76, p. 165, 1998, doi: 10.1238/Physica.Topical.076a00165.
- [36] Y. Nakamura, Y. A. Pashkin, and J. S. Tsai, "Coherent control of macroscopic quantum states in a single-Cooper-pair box," *Nature*, vol. 398, no. 6730, pp. 786–788, 1999, doi: 10.1038/19718.
- [37] F. Motzoi, J. M. Gambetta, P. Rebentrost, and F. K. Wilhelm, "Simple pulses for elimination of leakage in weakly nonlinear qubits," *Phys. Rev. Lett.*, vol. 103, no. 11, p. 110,501, 2009, doi: 10.1103/PhysRevLett.103.110501.
- [38] M. H. Devoret and R. J. Schoelkopf, "Superconducting circuits for quantum information: An outlook," Science, vol. 339, no. 6124, pp. 1169–1174, 2013, doi: 10.1126/science.1231930.
- [39] C. Gerry and P. Knight, *Introductory Quantum Optics*. Cambridge, U.K.: Cambridge Univ. Press, 2005.
- [40] A. P. M. Place *et al.*, "New material platform for superconducting transmon qubits with coherence times exceeding 0.3 milliseconds," *Nature Commun.*, vol. 12, no. 1, pp. 1–6, 2021, doi: 10.1038/s41467-021-22030-5.
- [41] Z.-L. Xiang, S. Ashhab, J. You, and F. Nori, "Hybrid quantum circuits: Superconducting circuits interacting with other quantum systems," *Rev. Modern Phys.*, vol. 85, no. 2, p. 623, 2013, doi: 10.1103/RevModPhys.85.623.
- [42] A. A. Houck et al., "Controlling the spontaneous emission of a superconducting transmon qubit," Phys. Rev. Lett., vol. 101, no. 8, p. 080502, 2008, doi: 10.1103/PhysRevLett.101.080502.
- [43] S. E. Nigg *et al.*, "Black-box superconducting circuit quantization," *Phys. Rev. Lett.*, vol. 108, no. 24, p. 240,502, 2012, doi: 10.1103/PhysRev Lett.108.240502.